

#### **COMPUTER ORGANIZATION AND DESIGN**



The Hardware/Software Interface

## Chapter 7

Multicores, Multiprocessors, and Clusters



# Multithreading

- Performing multiple threads of execution in parallel
  - Replicate registers, PC, etc.
  - Fast switching between threads
- Fine-grain multithreading
  - Switch threads after each cycle
  - Interleave instruction execution
  - If one thread stalls, others are executed
- Coarse-grain multithreading
  - Only switch on long stall (e.g., L2-cache miss)
  - Simplifies hardware, but doesn't hide short stalls (eg, data hazards)



## Simultaneous Multithreading

- In multiple-issue dynamically scheduled processor
  - Schedule instructions from multiple threads
  - Instructions from independent threads execute when function units are available
  - Within threads, dependencies handled by scheduling and register renaming
- Example: Intel Pentium-4 HT
  - Two threads: duplicated registers, shared function units and caches



## **Future of Multithreading**

- Will it survive? In what form?
- Power considerations ⇒ simplified microarchitectures
  - Simpler forms of multithreading
- Tolerating cache-miss latency
  - Thread switch may be most effective
- Multiple simple cores might share resources more effectively



#### **Instruction and Data Streams**

An alternate classification

		Data Streams	
		Single	Multiple
Instruction Streams	Single	SISD: Intel Pentium 4	SIMD: SSE instructions of x86
	Multiple	MISD: No examples today	MIMD: Intel Xeon e5345

- SPMD: Single Program Multiple Data
  - A parallel program on a MIMD computer
  - Conditional code for different processors



### SIMD

- Operate elementwise on vectors of data
  - E.g., MMX and SSE instructions in x86
    - Multiple data elements in 128-bit wide registers
- All processors execute the same instruction at the same time
  - Each with different data address, etc.
- Simplifies synchronization
- Reduced instruction control hardware
- Works best for highly data-parallel applications



## **Vector Processors**

- Highly pipelined function units
- Stream data from/to vector registers to units
  - Data collected from memory into registers
  - Results stored from registers to memory
- Example: Vector extension to MIPS
  - 32 × 64-element registers (64-bit elements)
  - Vector instructions
    - I v, sv: load/store vector
    - addv. d: add vectors of double
    - addvs. d: add scalar to each element of vector of double
- Significantly reduces instruction-fetch bandwidth



## Example: DAXPY $(Y = a \times X + Y)$

#### Conventional MIPS code

#### Vector MIPS code

```
I.d $f0, a($sp) ; load scalar a
Iv $v1, 0($s0) ; load vector x
mulvs.d $v2, $v1, $f0 ; vector-scalar multiply
Iv $v3, 0($s1) ; load vector y
addv.d $v4, $v2, $v3 ; add y to product
sv $v4, 0($s1) ; store the result
```



### Vector vs. Scalar

- Vector architectures and compilers
  - Simplify data-parallel programming
  - Explicit statement of absence of loop-carried dependences
    - Reduced checking in hardware
  - Regular access patterns benefit from interleaved and burst memory
  - Avoid control hazards by avoiding loops
- More general than ad-hoc media extensions (such as MMX, SSE)
  - Better match with compiler technology

