
# Chapter 5

Large and Fast: Exploiting Memory Hierarchy



## **Example: Larger Block Size**

- 64 blocks, 16 bytes/block
  - To what block number does address 1200 map?
- Block address = \[ 1200/16 \] = 75
- Block number = 75 modulo 64 = 11



#### **Block Size Considerations**

- Larger blocks should reduce miss rate
  - Due to spatial locality
- But in a fixed-sized cache
  - Larger blocks ⇒ fewer of them
    - More competition ⇒ increased miss rate
  - Larger blocks ⇒ pollution
- Larger miss penalty
  - Can override benefit of reduced miss rate
  - Early restart and critical-word-first can help

#### **Cache Misses**

- On cache hit, CPU proceeds normally
- On cache miss
  - Stall the CPU pipeline
  - Fetch block from next level of hierarchy
  - Instruction cache miss
    - Restart instruction fetch
  - Data cache miss
    - Complete data access

### Write-Through

- On data-write hit, could just update the block in cache
  - But then cache and memory would be inconsistent
- Write through: also update memory
- But makes writes take longer
  - e.g., if base CPI = 1, 10% of instructions are stores, write to memory takes 100 cycles
    - Effective CPI = 1 + 0.1×100 = 11
- Solution: write buffer
  - Holds data waiting to be written to memory
  - CPU continues immediately
    - Only stalls on write if write buffer is already full

#### Write-Back

- Alternative: On data-write hit, just update the block in cache
  - Keep track of whether each block is dirty
- When a dirty block is replaced
  - Write it back to memory
  - Can use a write buffer to allow replacing block to be read first

#### **Write Allocation**

- What should happen on a write miss?
- Alternatives for write-through
  - Allocate on miss: fetch the block
  - Write around: don't fetch the block
    - Since programs often write a whole block before reading it (e.g., initialization)
- For write-back
  - Usually fetch the block

### **Measuring Cache Performance**

- Components of CPU time
  - Program execution cycles
    - Includes cache hit time
  - Memory stall cycles
    - Mainly from cache misses
- With simplifying assumptions:

Memory stall cycles

### Cache Performance Example

- Given
  - I-cache miss rate = 2%
  - D-cache miss rate = 4%
  - Miss penalty = 100 cycles
  - Base CPI (ideal cache) = 2
  - Load & stores are 36% of instructions
- Miss cycles per instruction
  - I-cache: 0.02 × 100 = 2
  - D-cache: 0.36 × 0.04 × 100 = 1.44
- Actual CPI = 2 + 2 + 1.44 = 5.44
  - Ideal CPU is 5.44/2 =2.72 times faster

### **Average Access Time**

- Hit time is also important for performance
- Average memory access time (AMAT)
  - AMAT = Hit time + Miss rate × Miss penalty
- Example
  - CPU with 1ns clock, hit time = 1 cycle, miss penalty = 20 cycles, I-cache miss rate = 5%
  - $\blacksquare$  AMAT = 1 + 0.05 × 20 = 2ns
    - 2 cycles per instruction

### **Performance Summary**

- When CPU performance increased
  - Miss penalty becomes more significant
- Decreasing base CPI
  - Greater proportion of time spent on memory stalls
- Increasing clock rate
  - Memory stalls account for more CPU cycles
- Can't neglect cache behavior when evaluating system performance