

Indoor Camera — Owner's Manual

Aria Home · SKU ARIA-CAM-IN · camera · \$59

This manual covers the Indoor Camera (model ARIA-CAM-IN) only. Other Aria products have their own manuals; procedures and error codes are not interchangeable between models.

1. Specifications

Video	1080p, 130° field of view
Privacy	physical lens shutter, closes when Home mode is set
Audio	two-way talk
Power	USB-C, 5 V 1 A adapter included (6 ft cable)
Mount	magnetic base, wall or shelf

2. In the box

Indoor Camera, magnetic base, USB-C cable, power adapter.

3. Setup

1. Plug in the camera; the shutter opens and the light pulses white.
2. In the Aria app, tap Add device, Indoor Camera, and scan the QR code on the base.
3. Set Home and Away modes so the shutter closes automatically when you are home.

4. Status light

White pulse: pairing.

Solid white: connected, shutter open.

No light with shutter closed: privacy mode.

5. Power and battery

Indoor Camera: USB-C 5 V 1 A. No battery.

6. Troubleshooting

Indoor Camera — Shutter stays closed. Privacy mode is on. Tap the camera in the app and turn Privacy off, or change Home mode.

Indoor Camera — Image is dark at night. Indoor Camera uses infrared night vision up to 15 feet; remove reflective glass in front of the lens.

7. Error codes

Indoor Camera error IC-02: Shutter motor jammed — power cycle; if it persists the unit is replaced under warranty.

8. Factory reset

To factory reset the Indoor Camera: Hold the button on the underside for 10 seconds until the light pulses white.

9. Warranty and compatibility

The Indoor Camera carries a two-year standard warranty covering manufacturing defects, from the delivery date. Unwanted returns follow the Aria Home returns policy: 30 days from delivery for the Indoor Camera (most devices have a 30-day window). Damage caused by the customer is handled as a warranty repair, not a refund.

Works with: Aria app, Aria Video plan, Google Home.