

Aria Thermostat — Owner's Manual

Aria Home · SKU ARIA-THERM · thermostat · \$129

This manual covers the Aria Thermostat (model ARIA-THERM) only. Other Aria products have their own manuals; procedures and error codes are not interchangeable between models.

1. Specifications

Display	2.4-inch colour LCD, auto-dim
Sensors	temperature, humidity, proximity
HVAC support	1H/1C conventional, heat pump with O/B
Wiring	R, C, W, Y, G, O/B (C-wire required)
Temperature range	50–90 °F setpoint, accuracy ± 0.5 °F
Wi-Fi	2.4 GHz 802.11 b/g/n only

2. In the box

Thermostat, wall plate, 4 screws + anchors, wire labels, quick start card.

3. Setup

1. Switch off HVAC power at the breaker before removing your old thermostat.
2. Label each wire with the supplied stickers, then remove the old base.
3. Mount the Aria wall plate and insert wires until the tab clicks.
4. Attach the thermostat; it powers from the C-wire and shows the Aria logo.
5. In the Aria app tap Add device, choose Thermostat, and scan the QR code on the back.
6. Join a 2.4 GHz Wi-Fi network; 5 GHz networks are not supported.

4. Status light

Solid green ring: connected and idle.

Pulsing orange ring: heating.

Pulsing blue ring: cooling.

Blinking red ring: no C-wire power — check the C terminal.

Blinking white ring: pairing mode.

5. Power and battery

Aria Thermostat: 24 V AC from the C-wire; no batteries. Draws under 1 W.

6. Troubleshooting

Aria Thermostat — Screen is blank. No power on the C-wire. Check the breaker, then confirm the C terminal has a wire seated with the tab down.

Aria Thermostat — Reads 3–4 degrees warmer than the room. Proximity wake keeps the backlight on; set Display > Auto-dim to On and keep the unit out of direct sun.

Aria Thermostat — Shows Offline in the app. Hold the dial for 5 seconds until the ring blinks white to re-enter pairing, then rejoin a 2.4 GHz network.

Aria Thermostat — Cooling runs but house never reaches setpoint. Enable Compressor Protection off only if your installer confirms; otherwise check the filter and the O/B setting.

Aria Thermostat — Schedule does not run. Eco mode overrides schedules; turn Eco off from the home screen.

7. Error codes

Aria Thermostat error E1: Temperature sensor fault — restart by holding the dial 10 seconds; replace if it persists.

Aria Thermostat error E4: No C-wire detected — the thermostat will not power the display without a common wire.

Aria Thermostat error E7: Heat pump reversing valve (O/B) mismatch — swap the O/B setting in Settings > Equipment.

Aria Thermostat error E12: Firmware update interrupted — leave powered for 15 minutes; it recovers automatically.

8. Factory reset

To factory reset the Aria Thermostat: Hold the dial for 10 seconds until the ring turns red, then release. Wi-Fi and schedules are erased.

9. Warranty and compatibility

The Aria Thermostat carries a two-year standard warranty covering manufacturing defects, from the delivery date. Unwanted returns follow the Aria Home returns policy: 30 days from delivery for the Aria Thermostat (most devices have a 30-day window). Damage caused by the customer is handled as a warranty repair, not a refund.

Works with: Aria app iOS 15+/Android 10+, Google Home, Amazon Alexa, Apple Home via Aria Hub.