

Lab_Syn_2.1

You have to synthesize **regfile.v** file using **Design Compiler shell** and generate **Technology Dependent** gate level netlists in Verilog format using standard cell libraries (typical, worst, best) inside **std_cells** folder:-

- **scmetro_tsmc_cl013g_rvt_tt_1p2v_25c.db**

Steps: -

1. Copy **Lab_Syn_2.1** folder from your computer into the virtual machine inside Labs directory
 - Open a terminal inside path **/home/ICer/Labs/Lab_Syn_2.1/syn** and run **syn_script.tcl** script through design compiler shell using the following command in the terminal
 - **dc_shell -f syn_script.tcl | tee syn.log**

Required: -

- Check the synthesis log (**syn.log**) and find out the following: -
 - Removed registers
 - Merged registers
- Can you know why some registers are removed and merged?
- Can you repeat using **compile** instead of **compile_ultra**?