```
%EXTRA credit
function [ output_args ] = do_ik( x,y,z )
%IK for three link arm
clear all;
close all;
clc;
links = zeros(3,4);
A = ones(4,4,length(links(:,1)));
T = ones(4,4,length(links(:,1)));
x prime = 170;
z_prime = 475
a1 = 720;
a2 = 805
Px = x - x_prime;
Py = y;
Pz = z - z_{prime}
theta3 = a\cos d((Px^2 + Pz^2 - a1^2 - a2^2)/(2*a1*a2))
theta2 = atan2d(Pz,Px)-atan2d((a2*sind(theta3)), (a1 +
a2*cosd(theta3)))
theta1 = atan2d(Py,Px)
theta = [ theta1 theta2 theta3 ];
links(1,:) = [ 150 degtorad(90) 475 degtorad(theta(1))];
links(2,:) = [ 720 0 0 degtorad(theta(2))];
links(3,:) = [ 805 0 0 degtorad(theta(3))];
theta(4)];
% links(5,:) = [ 0 -90 0 ]
                          theta(5)];
% links(6,:) = [ 0 90 0 ]
                           theta(6)];
%get the A and T matrix
A = qetA(links)
T = getT(A)
%plot
figure(1);
title('theta3 = pi')
plotArm(T)
2
end
z_prime =
   475
a2 =
```

805

Reference to a cleared variable x.

Error in do_ik (line 18)
Px = x - x_prime;

Published with MATLAB® R2016a