

Plotting Bode plot with complex roots and zeros with hand

Nail Tosun
Electric and Electronic Engineering Department, METU

2018
March

Introduction

Given second order transfer function can be generalized following form;

$$H(s) = \frac{\omega_n^2}{s^2 + 2\xi\omega_n s + \omega_n^2}$$

where ξ is **damping ratio** and ω_n is natural frequency.

When $\xi > 1$ system response said over-damped, and it can easily separate two first order system cascaded.

Then transfer function rewritten in following form;

$$H(s) = \frac{K}{(s + \alpha)(s + \beta)}$$

Then bode plot of that transfer function is straight-forward.

-Regulate the transfer function

$$H(s) = \frac{\frac{K}{\alpha\beta}}{(1 + \frac{s}{\alpha})(1 + \frac{s}{\beta})}$$

-Find the dc-gain (gain at $\omega = 0$)

$$G_{dc} = \frac{K}{\alpha\beta}$$

Since there is no zero (no s in the numerator) in the following function also no pole at zero (no zero in the denominator), plot came with straight line before first pole hit.

-Plot the asymptotes and bode

When $\xi = 1$ we said system response critically-damped. Denominator can rewrite as $(s + \omega_n)^2$. That means now we have double pole in a particular location. Bode plot algorithm is still same just make sure know we have $40 \frac{dB}{decade}$

Complex poles and zeros

Complex poles

All points in second order term with $\xi < 1$ is we plot asymptotes like $\xi = 1$ case. With closing ξ to one (from zero), transfer function start behave;

$$H(s) = \frac{\omega_n}{(s + \omega_n)^2}$$

The can plot above function bode plot easily. So after that we just should edit a little by looking ξ , damping ratio.

$$H(s) = \frac{1}{s^2 + 2\xi s + 1}$$




Figure 1: Bode plot of $H(s)$ with different ξ

$\xi = 1$, we draw asymptotes and we did -3 dB approximation (for poles). However with $\xi < \frac{1}{\sqrt{2}}$ actual gain underline the other side of the asymptotes (positive over-shoot characteristic for poles).

Complex zeros

$$H(s) = s^2 + 2\xi s + 1$$




Figure 2: Bode plot of $H(s)$ with different ξ

Similarly, $\xi = 1$, we draw asymptotes and we did +3 dB approximation (for poles). Now the actual gain again is at other side of the asymptote (negative over-shoot characteristic for zeros)

Example

$$H(s) = 128 \frac{s^2 + 4}{(s + 32)(s^2 + 8s + 64)}$$

Behaviour at DC

System is type-0, no pole at $\omega = 0$ also no zero at $\omega = 0$ therefore straight line comes from the left side of the graph

DC gain

Normalizing the transfer function;

$$H(s) = \frac{1}{4} \frac{1 + \frac{s^2}{4}}{(1 + \frac{s}{32})(1 + \frac{s}{8} + \frac{s^2}{64})}$$
$$G_{dc} = 20\log(\frac{1}{4}) = -12 \text{ dB}$$

Second order Behaviour

Second order pole

$$s^2 + 2\xi\omega_n + \omega_n^2 = s^2 + 8s + 64$$

$$\omega_n = 8$$

$$\xi = 0.5$$

Double pole at $\omega = 8$

Second order zero

$$s^2 + 2\xi\omega_n + \omega_n^2 = s^2 + 8$$

$$\omega_n = 2$$

$$\xi = 0$$

Double zero at $\omega = 2$

Matlab plot;




Figure 3: Bode plot of $H(s)$ with different ξ

By hand;