Introduction To Robotics

Adithya Nair

August 13, 2024

Contents

Ι	Ro	botics	2
1	Unit 1		3
	1.1	Introduction	3
		Syllabus	
		Glossary	
	1.4	Degree Of Freedom	3
	1.5	Kinematic Pair	4
	1.6	Robotic Manipulator	4
	1.7	Pose of a rigid body	4
	1.8	Denavit Hartenberg Parameters	Ę

Part I Robotics

Chapter 1

Unit 1

1.1 Introduction

This course is mainly going to focus on **Manipulators**. These machines are used to manipulate positions and the state of the objects in an environment. We're going to break down their movements into Dynamics Analysis akin to the work done in Computational Mechanics.

1.2 Syllabus

- Overview Of Robotics
- Kinematics Of Simple Robotic Systems
- Dynamics And Control Of Simple Robotic Systems

1.3 Glossary

- 1. Actuator Does work upon receiving voltage
- 2. Encoder Sensor that measures raw angle data.

Software for robotics - **v-rep**, MATLAB This software involves making a CAD model, and apply a mathematical model. Unity can also be used in making such models.

1.4 Degree Of Freedom

The degree of freedom of a mechanical system is defined as the no. of independent paramets need to completely define its position in space at a given time..

The degree of freedom is defined with respect to a reference frame. If the object is free to rotate and move, it means it has 6 degrees of freedom. Localization - Finding the position and orientation of an object in 3-dimensional space.

We call a system 'fully actuated' when there are as many actuators as there are degrees of freedom.

No. of controlling inputs < No. of degrees of freedom

Underactuated systems contain lesser actuators than the number of degrees of freedom

No. of controlling inputs = No. of degrees of freedom

Redundant systems contain more actuators than the number of degrees of freedom

No. of controlling inputs > No. of degrees of freedom

1.5 Kinematic Pair

Linkages are the basic elements of all mechanisms and robots. Links are rigid body member with nodes, and joints are connection between links at nodes. Allows relative motion between links.

1.6 Robotic Manipulator

- Why study kinematics and dynamics of robotic manipulator
 - To manipulate an object in space
 - Understand the workspace and limitations of a robotic manipulator
 - Understand and estimate contact force between end-effector and object being manipulated.

1.7 Pose of a rigid body

A rigid body is completely defined in space by its position and orientation with respect to a reference.

We use the terminology 'Inertial reference frame' to mean an observer where Newton's laws of physics apply. We use the terminology 'Inertial reference frame' to mean an observer where Newton's laws of physics apply and the frame itself does not accelerate. Generally the base of the robotic manipulator is treated as the inertial reference frame

We use unit vectors $\hat{x}, \hat{y}, \hat{z}$ to describe the basis vectors. For the orientation of the rigid body, since they lie in 3d space, we must define new basis vectors to define the orientation, $\hat{x'}, \hat{y'}, \hat{z'}$

$$\hat{x'} = x_x'\hat{x} + x_y'\hat{y} + x_z'\hat{z}$$

$$\hat{y'} = y_x'\hat{x} + y_y'\hat{y} + y_z'\hat{z}$$

$$\hat{z'} = z'_x \hat{x} + z'_y \hat{y} + z'_z \hat{z}$$

1. When the frame is translationally different from the original frame.

$$\vec{AP} = \vec{BP} + \vec{AP}_{Borg}$$

Where ${}^{A}\vec{P}$ is the position vector of P with respect to A, ${}^{B}\vec{P}$ is the position vector of P with respect to B, and ${}^{A}\vec{P}_{Borg}$ is the vector of A to B.

2. When the frame is oriented differently from the original frame. Generating a rotation matrix B_AR to rotate vectors from a frame B to A. Where A and B are reference frames, with B being oriented differently than A.

$$\begin{bmatrix} \hat{X}_b \cdot \hat{X}_a & \hat{Y}_b \cdot \hat{X}_a & \hat{Z}_b \cdot \hat{X}_a \\ \hat{X}_b \cdot \hat{Y}_a & \hat{Y}_b \cdot \hat{Y}_a & \hat{Z}_b \cdot \hat{Y}_a \\ \hat{X}_b \cdot \hat{Z}_a & \hat{Y}_b \cdot \hat{Z}_a & \hat{Z}_b \cdot \hat{Z}_a \end{bmatrix}$$

We can simply the matrix into 3 column vectors, with the notation ${}^{A}X_{B}$ which means B with respect to A

$$\begin{bmatrix} A\hat{X}_B & A\hat{Y}_b & A\hat{Z}_B \end{bmatrix}$$

3. When the frame is both translationally and oriented different from the original frame

$${}^A\vec{P} = {}^A_B R^B \vec{P} + {}^A \vec{P}_{Borg}$$

To simplify the equations, we write.

$$^{A}\vec{P} = ^{A}_{B}T^{B}P$$

Where T becomes

$${}_{B}^{A}T = \begin{bmatrix} {}_{B}^{A}R_{3\times3} & {}^{A}P_{Borg} \\ 0_{1\times3}1_{1\times1} \end{bmatrix}$$

This T is the homogeneous transformation matrix.

The Rotation Matrix belongs to a category of matrices called SO(3) (Special Orthogonal Matrices)

1.8 Denavit Hartenberg Parameters

These parameters are used to assign the same co-ordinate frames while dealing with robotic manipulators to ensure that the entire scientific community are working under the same conventions.

- Number the link sequentially from 0 to n. Giving us n+1 links.
- Number the joints sequentially from 1 to n, Giving us n joints.
- Number of co-ordinate frames: n+1
- The Z_i axis is aligned with the $(i+1)^t h$ joint axis.
- X_i is defined along the common normal between the Z_i and Z_{i-1} axis. (Common normal is the line which is perpendicular to both of these axes.)
- Y_i is obtained via cross product between Z_i and X_i axis.
- The origin is placed at this point of intersection of x_i , y_i and z_i
- We define H_i (which is the point of intersection of the common normal of the next axis with the current axis.), and 4 new terms:
 - $-a_i$ Offset distance between two adjacent joint axes(The distance between O_i and H_{i-1})
 - d_i Distance between H_{i-1} and O_{i-1}
 - $-\alpha_i$ Angle between Z_i and Z_{i-1} when viewed from X_i , this is also known as the twist angle.
 - $-\theta_i$ Angle between X_i and X_{i-1} when viewed from Z_i ,

For a 3R Planar serial chain manipulator: