
AA 101 102 103 104 105 106 107 108 109 110 111 112 | 113 114 115 116 117 118 119 120 121 122 123 124
STUDIO PANEL TIE AV-1
STUDIO PANEL TIE AV-2
AA 125 126 127 128 129 130 131 132 133 134 135 136 | 137 138 139 140 141 142 143 144 145 146 147 148
STUDIO PANEL TIE AV-3
STUDIO PANEL TIE AV-4
BB 149 150 151 152 153 154 155 156 157 158 159 160 | 161 162 163 164 165 166 167 168 169 170 171 172
ISO PANEL TIE AV-5
ISO PANEL TIE AV-6
BB 173 174 175 176 177 178 179 180 | 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16
ISO PANEL TIE AV-6
STUDIO 2 TIE
A 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24
MICROPHONE LINES
A 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48
MICROPHONE LINES
A 49 50 51 52 53 54 55 56 57 58 59 60
MICROPHONE LINES
A 1 2 3 4 5 6 7 8
AUX OUTPUT
A 1L 1R 2L 2R | 1L 1R 2L 2R | 1L 1R 2L 2R 3L 3R 4L 4R | 1L 1R 2L 2R 3L 3R 4L 4R
CUE MIX 1 IN
CUE MIX 2 IN
CUE OUTPUT
REV RETURN
B 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24
MICROPHONE (LINE 'A') INPUT
B 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48
MICROPHONE (LINE 'A') INPUT
B 49 50 51 52 53 54 55 56 57 58 59 60
MICROPHONE (LINE 'A') INPUT
B 1 2 3 4 5 6 7 8
AUX LINE
B 1L 1R 2L 2R | 1L 1R 2L 2R | 1L 1R 2L 2R 3L 3R 4L 4R | 1L 1R 2L 2R 3L 3R 4L 4R
CUE MIX 3 IN
CUE MIX 4 IN
CUE AMPS
CONSOLE REV RETURN
C 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24
MULTITRACK RETURN
C 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48
MULTITRACK RETURN
C 49 50 51 52 53 54 55 56 57 58 59 60
MULTITRACK RETURN
C U U U U | V V V V
MULT
MULT
C L C R 1 2 3 4 5 6 7 8 9 10
LEFT-HAND/MASTER MIX BUS OUTPUT SENDS
C O Ø | 1 2 3 4 5 6
PHASE
GROUP FADER INPUTS
D 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24
LINE (LINE 'B') INPUT
D 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48
LINE (LINE 'B') INPUT
D 49 50 51 52 53 54 55 56 57 58 59 60
LINE (LINE 'B') INPUT
D 1 2 3 4 5 6
MIX BUS DIRECT INPUT
D L C R 1 2 3 4 5 6 7 8 9 10
LEFT-HAND/MASTER MIX BUS OUTPUT RETURNS
D O Ø | 1 2 3 4 5 6
PHASE
GROUP FADER OUTPUTS
E 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24
INSERTION SEND
E 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48
INSERTION SEND
E 49 50 51 52 53 54 55 56 57 58 59 60
INSERTION SEND
E 1 2 3 4 5 6 | L R
MIX BUS PREFADE SEND
2T PRE S
E L C R 1 2 3 4 5 6 7 8 9 10
RIGHT-HAND MIX BUS OUTPUT SENDS
F 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24
INSERTION RETURN
F 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48
INSERTION RETURN
F 49 50 51 52 53 54 55 56 57 58 59 60
INSERTION RETURN
F 1 2 3 4 5 6 | L R
MIX BUS PREFADE RETURN
2T PRE R
F L C R 1 2 3 4 5 6 7 8 9 10
RIGHT-HAND MIX BUS OUTPUT RETURNS
G 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24
MULTITRACK RETURN
G 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48
MULTITRACK RETURN
G 49 50 51 52 53 54 55 56 57 58 59 60
MULTITRACK RETURN
G 1-2 3-4 5-6 | 1 2 3 4 5 6 | L R
MONO
MIX BUS OUTPUT SEND
2T SEND
G L C R S LS RS | L C R S LS RS | L C R S LS RS | 4L 4R 5L 5R 6L LR
EXT SOURCE 1 REPRO
EXT SOURCE 2 REPRO
EXT SOURCE 3 REPRO
EXT SOURCE REPRO
H 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24
MONITOR INPUT
H 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48
MONITOR INPUT
H 49 50 51 52 53 54 55 56 57 58 59 60
MONITOR INPUT
H 1-2 3-4 5-6 | 1 2 3 4 5 6 | L R
MONO M/C
MIX BUS OUTPUT RETURN
2T RET
H L C R S LS RS | L C R S LS RS | L C R S LS RS | 4L 4R 5L 5R 6L LR
EXT SOURCE 1 RECORD
EXT SOURCE 2 RECORD
EXT SOURCE 3 RECORD
EXT SOURCE RECORD
J 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24
GROUP OUTPUT
J 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48
GROUP OUTPUT
J 49 50 51 52 53 54 55 56 57 58 59 60
GROUP OUTPUT
LT RT | 1 2
ENC RET
RTB
AUDIO DAW LINE OUT 1-8
L C R S LS RS LE RE
STEM A PLAYBACK
AUDIO DAW LINE OUT 9-16
J L C R S LS RS LE RE | L C R S LS RS LE RE | L C R S LS RS LE RE | L C R S LS RS LE RE
STEM B PLAYBACK
STEM C PLAYBACK
STEM D PLAYBACK
K 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24
MULTITRACK SEND
K 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48
MULTITRACK SEND
K 49 50 51 52 53 54 55 56 57 58 59 60
MULTITRACK SEND
LT RT | 1 2
MON I/P
RTB IN
L C R S LS RS
STEM A OUTPUT
K L C R S LS RS
STEM B OUTPUT
L C R S LS RS
STEM C OUTPUT
L C R S LS RS
STEM D OUTPUT
L 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24
GATE INPUT
L 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48
GATE INPUT
L 49 50 51 52 53 54 55 56 57 58 59 60
GATE INPUT
L C R S LS RS
LIMITER COMPRESSOR OUT
L C R S LS RS MONO | L C R S LS RS | L C R | L C R | L R | EN TB | SW TB | OSC
STD MONITOR PREFADE INS SEND
LARGE SPEAKER OUTPUT
SMALL OUTPUT
MINI OUTPUT
SLS OUT
O/P
O/P
O/P
M THIS ROW INTENTIONALLY LEFT BLANK
M THIS ROW INTENTIONALLY LEFT BLANK
M
KEY L C R S LS RS
LIMITER COMPRESSOR IN
M L C R S LS RS MONO | L C R S LS RS | L C R | L C R | L R | EN TB | SW TB | OSC
STD MONITOR PREFADE INS RET
LARGE AMP IN
SMALL AMP IN
MINI AMP IN
SLS AMP
LINE
LINE
LINE
CC IN TLA | IN 33609 | IN EL8 DIST | IN 1176 | IN 176 | IN TG-1 | IN LA2A | IN LA-3A | IN RS124 | MIC LINE COMP 6176 #1 IN | MIC LINE COMP 6176 #2 IN | IN GML 8200 | IN PE1C | IN SANS | IN API 2500 | IN PCM 42 | IN 512C | IN 550B | IN 560 | IN G COMP | IN CL1B | NEVE MOTU PT#1 BRAINSTORM SR112
LINEAR TIME CODE OUT
CC
DD OUT TLA | OUT 33609 | OUT EL8 DIST | OUT 1176 | OUT 176 | OUT TG-1 | OUT LA2A | OUT LA-3A | OUT RS124 | LINE COMP 6176 #1 OUT | LINE COMP 6176 #2 OUT | OUT GML 8200 | OUT PE1C | OUT SANS | OUT API 2500 | OUT PCM 42 | OUT 512C | OUT 550B | OUT 560 | OUT G COMP | OUT CL1B | PT#1 SR112 PT#2 PT#3 NEVE MOTU
LINEAR TIME CODE IN
DD
EE 181 AV11 | 182 MIC | MIC PODIUM
EE W W W W | X X X X | Y Y Y Y | Z Z Z Z | 61 62 63 64
MULT
MULT
MULT
MULT
RECORD DAW LINE OUT
EE
FF 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16
AUDIO DAW LINE IN
FF
61 62 63 64
RECORD DAW LINE IN
FF
GG A107 A108 A109 A110 A111 A112 A113 A114 A115 A116 A117 A118 A119 A120 A121 A122
CMR B TIELINES
GG PB1 PB2 PB3 PB4 PB9
AV-11 GUEST PANEL
GG PB11 PB12 PB13 PB14 PB15 PB16 PB17 PB18 PB19 PB20 PB21 PB22 PB23 PB24 PB25 PB26 PB27 PB28 PB29 PB30 PB31 PB32 PB33 PB34
AV-14 REAR OF RACK TIELINE
HH 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16
HEARBACK PRO CUE LINE INPUT
HH PB5 PB6 PB7 PB8 PB10
AV-11 GUEST PANEL
HH PB35 PB36 PB37 PB38 PB39 PB40 PB41 PB42 PB43 PB44 PB45 PB46 PB47 PB48 PB49 PB50 PB51 PB52 PB53 PB54 PB55 PB56 PB57 PB58
AV-14 REAR OF RACK TIELINE