AA

201 202 203 204 205 206 207 208 209 210 211 212 — STUDIO PANEL TIE AV-1
213 214 215 216 217 218 219 220 221 222 223 224 — STUDIO PANEL TIE AV-2
225 226 227 228 229 230 231 232 233 234 235 236 — STUDIO PANEL TIE AV-3
237 238 239 240 241 242 243 244 245 246 247 248 — ISO PANEL TIE AV-4

BB

249 250 251 252 253 254 — SOUNDLOCK PANEL TIE AV-5
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 — STUDIO 1 TIE

A

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 — MICROPHONE LINES
25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 — MICROPHONE LINES

B

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 — MICROPHONE (LINE 'A') INPUT
25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 — MICROPHONE (LINE 'A') INPUT

C

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 — MULTITRACK RETURN
25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 — MULTITRACK RETURN

D

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 — LINE (LINE 'B') INPUT
25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 — LINE (LINE 'B') INPUT

E

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 — INSERTION SEND
25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 — INSERTION SEND

F

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 — INSERTION RETURN
25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 — INSERTION RETURN

G

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 — MULTITRACK RETURN
25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 — MULTITRACK RETURN

H

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 — MONITOR INPUT
25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 — MONITOR INPUT

J

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 — GROUP OUTPUT
25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 — GROUP OUTPUT

K

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 — MULTITRACK SEND
25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 — MULTITRACK SEND

L

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 — GATE INPUT
1 2 3 4 5 6 — MIX BUS PREFADE SEND
L R — 2T PRE S
1 2 3 4 5 6 — MIX BUS OUTPUT SEND
L R — 2T SEND

M

25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 — GATE INPUT
1 2 3 4 5 6 — MIX BUS PREFADE RETURN
L R — 2T PRE R
1 2 3 4 5 6 — MIX BUS OUTPUT RETURN
L R — 2T RET

N

L C R 1 2 3 4 5 6 7 8 9 10 — LEFT-HAND/MASTER MIX BUS OUTPUT SENDS
1-2 3-4 5-6 — MONO
Ø Ø — PHASE
L C R 1 2 3 4 5 6 7 8 9 10 — RIGHT-HAND MIX BUS OUTPUT SENDS
1 2 3 — MIX BUS DIR IN
1 2 3 4 5 6 — GROUP FADER INPUTS

P

L C R 1 2 3 4 5 6 7 8 9 10 — LEFT-HAND/MASTER MIX BUS OUTPUT RETURNS
1-2 3-4 5-6 — MONO M/C
Ø Ø — PHASE
L C R 1 2 3 4 5 6 7 8 9 10 — RIGHT-HAND MIX BUS OUTPUT RETURNS
4 5 6 — MIX BUS DIR IN
1 2 3 4 5 6 — GROUP FADER OUTPUTS

Q

1 2 3 4 5 6 7 8 — AUX OUTPUT
1L 1R 2L 2R 3L 3R 4L 4R — REV RETURN
1 2 — RTB
Q Q Q Q — MULT
R R R R — MULT
S S S S — MULT
1L 1R 2L 2R 3L 3R 4L 4R — CUE OUTPUT
1L 1R 2L 2R — CUE MIX 1 IN
1L 1R 2L 2R — CUE MIX 2 IN

R

1 2 3 4 5 6 7 8 — AUX LINE
1L 1R 2L 2R 3L 3R 4L 4R — CONSOLE REV RETURN
1 2 — RTB IN
T T T T — MULT
U U U U — MULT
V V V V — MULT
1L 1R 2L 2R 3L 3R 4L 4R — CUE AMPS
1L 1R 2L 2R — CUE MIX 3 IN
1L 1R 2L 2R — CUE MIX 4 IN

S

L C R S LS RS LE RE — STEM A PLAYBACK
L C R S LS RS LE RE — STEM B PLAYBACK
L C R S LS RS LE RE — STEM B PLAYBACK
L C R S LS RS LE RE — STEM D PLAYBACK
L C R S LS RS MONO — STD MONITOR PREFADE INS SEND
LT RT — ENC RET
W W W — MULT
X X X X — MULT

T

L C R S LS RS — STEM A OUTPUT
L C R S LS RS — STEM B OUTPUT
L C R S LS RS — STEM C OUTPUT
L C R S LS RS — STEM D OUTPUT
L C R S LS RS MONO — STD MONITOR PREFADE INS RET
LT RT — MON I/P
Y Y Y — MULT
Z Z Z Z — MULT

U

L C R S LS RS — LARGE SPEAKER OUTPUT
L C R — SMALL OUTPUT
L C R — MINI OUTPUT
L R — SLS OUT
L C R S LS RS — LIMITER COMPRESSOR OUT
EN TB — O/P
SW TB — O/P
OSC — O/P
L C R S LS RS — EXT SOURCE 1 REPRO
L C R S LS RS — EXT SOURCE 2 REPRO
L C R S LS RS — EXT SOURCE 3 REPRO
4L 4R 5L 5R 6L LR — EXT SOURCE REPRO

V

L C R S LS RS — LARGE AMP INPUT
L C R — SMALL AMP IN
L C R — MINI AMP IN
L R — SLS AMP
KEY L C R S LS RS — LIMITER COMPRESSOR IN
EN TB — LINE
SW TB — LINE
OSC — LINE
L C R S LS RS — EXT SOURCE 1 RECORD
L C R S LS RS — EXT SOURCE 2 RECORD
L C R S LS RS — EXT SOURCE 3 RECORD
4L 4R 5L 5R 6L LR — EXT SOURCE RECORD

CC

IN TLA
IN IN 33609
IN IN EL8 DIST
IN IN 1176
IN 176
IN IN TG-1
IN IN LA2A
IN IN LA-3A
MIC LINE MILLENNIA
MIC LINE COMP 6176 #1 IN
MIC LINE COMP 6176 #2 IN
IN CL1B
IN IN GML 8200
IN IN PE1C
MIC LINE GML 2020
IN IN API 2500
IN IN PCM 42
IN IN 512C
IN IN 550B
IN IN 560
IN IN G COMP
MIC LINE 1084 #1
MIC LINE 1084 #2

DD

OUT TLA
OUT OUT 33609
OUT OUT EL8 DIST
OUT OUT 1176
OUT 176
OUT OUT TG-1
OUT OUT LA2A
OUT OUT LA-3A
DIR MASTER MILLENNIA
LINE COMP 6176 #1 OUT
LINE COMP 6176 #2 OUT
OUT CL1B
OUT OUT GML 8200
OUT PE1C
LINE GML 2020
OUT OUT API 2500
OUT OUT PCM 42
OUT OUT 512C
OUT OUT 550B
OUT OUT 560
OUT OUT G COMP
LINE 1084 #1
LINE 1084 #2

EE

PT NEVE — TC OUT
B205 B206 B207 B208 B209 B210 B211 B212 B213 B214 B215 B216 B217 B218 B219 B220 — CMR B TIELINES
PB1 PB2 PB3 PB4 PB9 — AV-31 GUEST PANEL
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 — ALTERNATE MULTITRACK RETURN

FF

PT NEVE — TC IN
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 — HEARBACK PRO CUE LINE INPUT
PB5 PB6 PB7 PB8 PB10 — AV-31 GUEST PANEL
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 — 24T TAPE SEND