A

MIC TIE LINE OUT																MIC TIE LINE OUT															
33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64

B

MIC TIE LINE OUT																MIC TIE LINE OUT															
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

C

MIC PREAMP IN																MIC PREAMP IN															
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

D

200 IN																200 IN															
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

E

200 KEY IN																200 KEY IN															
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

F

200 OUT																200 OUT															
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

H

MIC PREAMP OUT																MIC PREAMP OUT															
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

J

MULTIRACK DAW OUT																MULTIRACK DAW OUT															
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

K

SMALL CHANNEL IN																SMALL CHANNEL IN															
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

L

SMALL INSERT SEND																SMALL INSERT SEND															
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

M

SMALL INSERT RETURN																SMALL INSERT RETURN															
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

N

SMALL FADER IN																SMALL FADER IN															
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

P

LARGE CHANNEL IN																LARGE CHANNEL IN															
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

R

LARGE INSERT SEND																LARGE INSERT SEND															
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

S

LARGE INSERT RETURN																LARGE INSERT RETURN															
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

T

LARGE FADER IN																LARGE FADER IN															
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

V

EQUALIZER IN																EQUALIZER IN															
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

X

EQUALIZER OUT																EQUALIZER OUT															
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

Y

DIRECT OUT																DIRECT OUT															
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

Z

BUS OUT																BUS OUT															
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

AA

MULTITRACK DAW IN																MULTITRACK DAW IN															
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

BB

AUX SEND OUT												ACA OUT						BSTR OUT						GM ACA		GM BSTR		2 TRACK IN			
1	2	3	4	5	6	7	8	9	10	11	12	L	STA	R	L	STB	R	L	STC	R	L	STA	R	L	STB	R	L	STC	R	L	OUT	R	L	OUT	R	L	1	R	L	2	R

CC

AUX DEVICE IN						STEREO CUE AMP IN								FADER IN								GM SELECT IN								GM FDR				2T FEED				2 TRACK IN					
1	2	3	4	5	6	L	1	R	L	2	R	L	3	R	L	STA	R	L	STB	R	L	STC	R	L	STA	R	L	STB	R	L	STC	R	L	IN	R	L	IN	R	L	3	R	L	4	R

DD

MONITOR OUT									STU OUT			EXT STU IN				2 TRACK PLAYBACK																EXT MNTR OUT									
L	LG	R	L	ALT1	R	L	ALT2	R	L		R	L		R	L	1	R	L	2	R	L	3	R	L	4	R	L	5	R	L	6	R	L	7	R	L	8	R	L	1	R	L	2	R	L	3	R

EE

MONITOR AMP IN									SLS AMP IN			GM EXT IN				CONTROL ROOM MNTR IN																CR MNTR IN									
L	LG	R	L	ALT1	R	L	ALT2	R	L		R	L		R	L	1	R	L	2	R	L	3	R	L	4	R	L	5	R	L	6	R	L	7	R	L	8	R	L	1	R	L	2	R	L	3	R

FF

OSC OUT		EXT	REV TB		Ø REV		MULT				MULT				MULT				MULT				MULT				MULT			
1	2	OSC IN	MIC	OUT PRE IN	O	Ø	U	U	U	U	V	V	V	V	W	W	W	W	X	X	X	X	Y	Y	Y	Y	Y	Z	Z	Z	Z

HH

SIGNAL PROCESSOR IN																SIGNAL PROCESSOR IN															
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

JJ

SIGNAL PROCESSOR OUT																SIGNAL PROCESSOR OUT															
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

KK

PROCESSOR KEY IN								HEAR BACK IN								JOECO BLACKBOX OUT												OSC SCOPE		RTA IN	MTR IN
1	2	3	4	5	6	7	8	1	2	3	4	5	6	7	8	1	2	3	4	5	6	7	8	9	10	11	12	1	2		

LL

PROCESSOR KEY OUT								HEAR BACK IN								REV 1			REV 2			REV 3			
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	L	OUT	R	L	OUT	R	L	MAIN	R	L	ALT	R