UF-500 Clamp-on Ultrasonic Flow Meter - Operating Manual (excerpt)

The UF-500 measures the flow of clean and slightly contaminated liquids from outside the pipe, using the transit-time difference between two clamp-on transducers.

Specifications

Parameter	Value
Pipe size	DN 50 to DN 1200
Accuracy	1% of reading
Outputs	4-20 mA and Modbus RTU
Power supply	24 V DC
Transmitter enclosure	IP66

Installation

Mount the transducers on a straight pipe section with at least 10 pipe diameters upstream and 5 pipe diameters downstream. Remove paint and rust and apply coupling gel before clamping.

After installation the signal quality shown on the display must be at least 60%. Below this value the reading is not reliable.

Error codes

Code	Description	Action
U-01	Low signal quality	Re-apply coupling gel and check transducer spacing
U-04	Empty pipe	Reading forced to zero; check that the pipe runs full
U-09	Transducer mismatch	The two transducers are not a matched pair; replace both

Verification

Verify the zero point with the pipe full and the flow stopped every 24 months. No wet calibration is required.