Product manual for the Aurora kettle. Please read this guide before first use.
The warranty lasts twenty four months from the date of purchase and covers faulty parts.
Keep your receipt as proof of purchase for any warranty claim.

Returns are accepted within thirty days if the kettle is unused and in its box.
To return the kettle, contact support and ask for a prepaid return label.
Refunds are paid to the original payment method within five working days.