

# STREAMLINE TM






## EKLIPSE ARCHITECTURAL LIGHTING

2090 rue Moreau, Suite 100 Montréal, Qc, H1W 2M3 t. 514.590.0099 | f. 514.590.0098 e. sales@eklipselighting.com w. www.EklipseLighting.com


SPECIFICATIONS MAY VARY, WITHOUT ALTERING OR REDUCING PRODUCT PERFORMANCE. ALL INFORMATION ON THIS DOCUMENT ARE THE SOLE PROPERTY OF EKLIPSE. REPRODUCTION OF THIS DOCUMENT, IN WHOLE OR IN PART, WITHOUT WRITTEN PERMISSION IS ILLEGAL.// LES SPÉCIFICATIONS PEUVENT DIFFÉRÉES SANS PRÉAVIS SANS RÉDUIRE LA PERFORMANCE DU PRODUIT. LES INFORMATIONS CONTENUES DANS CE DOCUMENT SONT LA PROPRIÉTÉ DE EKLIPSE. TOUTE REPRODUCTION PARTIELLE OU TOTALE SANS L'AUTORISATION ÉCRITE EST INTERDITE.


# STREAMLINE THE LINEAR LED


### **INCLUDED IN THE BOX**



### **EXAMPLES OF HOLE POSITION AND REMOTE DRIVER SETUP**









## STREAMLINE THE LINEAR LED

### **PREPARATION**



### **SOURCE POINT DIMENSIONING**Always start from a source point when taking dimensions for drilling the installation holes.



**NEVER ACCUMULATE DIMENSIONS**Accumulating dimensions multiplies the slightest measuring mistakes.


### **HOLE DIAMETER**




Using a power tool & hole saw, drill a D1.375" (35mm) hole for the wall anchor, according to the left-end side dimensions.

USE ONLY A HOLE SAW FOR DRILLING HOLE D1.375" (D1 3/8")


#### **INSTALLATION**




STEP 1
Insert the end caps with rods at the end of the fixture.




STEP 2
If applicable (middle section), insert the joining caps with rods to the end of the fixture.




STEP 3
Position the light beam & lock the assembly by screwing the end cap / joining cap to the fixture's rod with Allen Key.



STEP 4
With the power off, wire the fixture to the wall wires using the included connectors.



STEP 5
Insert the anchor in the pre-drilled hole. Tighten the assembly with the anchor screws.



STEP 6
To adjust the fixture, slightly unscrew the end cap / join cap with the Allen Key and pivot the extrusion.