

















CHOOSE 17-24




GO 17-24




STOP 17-24




FLASH 17-24




CHOOSE 25-32




GO 25-32



STOP 25-32



CHOOSE 33-40



FUNCTION 1-8

