

Schematic diagram of water levels and power outputs for an est generation scheme time of day Schenatic diagram of water levels and power outputs for a flood generation scheme fine of day

Schenatic diagram of noter levels and power outputs D for a two-way generation scheme water level time of day Bulb Turbine

Porinemover

Porinemover

Motion in Power to Share bound

Conventor Conventor

Conditioning

Other turbines Seabed

hund

Tidal legoons (Boundel reservoisz) Starting point 1 high fide, enclowefull high fide level low fide level Tide goesdown creating hard's power generion starting posit

