# Contents


1	Bas	ic Progra													Ċ
	1.1	BasicLedI	3link .			 	. <b>.</b> .	 3							
		1.1.1 Ci	rcuit .			 		 3							
		1.1.2 Co	ode			 		 3							
			ıtput												9
	1.2	Interrupts	_												4
	1.4														
			rcuit .												4
			ode												4
		1.2.3 Ou	ıtput			 	. <b>.</b> .	 Ę							
	1.3	Interrupts	sPinCh	nange		 	. <b>.</b> .	 ٦							
		1.3.1 Ci	rcuit .			 		 F							
		1.3.2 Co	ode			 		 Ę							
			ıtput												6
	1.4	TimerCou	_												(
	1.1		$\operatorname{rcuit}$ .												(
			ode												(
			ıtput												8
	1.5	TimerCou													(
		1.5.1 Ci	rcuit .			 	. <b>.</b> .	 (							
		1.5.2 Co	ode			 	. <b>.</b> .	 ć							
		1.5.3 Ou	ıtput			 		 11							
	1.6	TimerCou	$\inf_{1}^{-1}$	FastP	WM .	 		 11							
			rcuit .												11
			ode												11
			ıtput												16
	1.7	TimerCou	_												17
	1.1														$\frac{17}{17}$
			rcuit .												
			ode												17
			ıtput												22
	1.8	TimerCou													23
		1.8.1 Ci	rcuit .			 	. <b>.</b> .	 23							
		1.8.2 Co	ode			 		 23							
		1.8.3 Ot	ıtput			 		 25							
	1.9	TimerCou													26
			rcuit .												26
			ode												26
			ıtput												29
	1 10	TimerCou													30
	1.10														
		1.10.1 Ci													30
		1.10.2 Co													30
		1.10.3 Ou	•												35
	1.11	TimerCou													36
		1.11.1 Ci	rcuit .			 	. <b>.</b> .	 36							
		1.11.2 Co	ode			 		 36							
		1.11.3 Ot													41
	1.12	TimerCou													42
	_	1.12.1 Ci													42
		1.12.1 Co													42
		_													
	1 10	1.12.3 Ot													43
	1.13	TimerCou													44
		1.13.1 Ci													44
		1.13.2 Co	ode			 		 44							

		1.13.3 Output	45
	1.14	TimerCounter2_FastPWM	46
		1.14.1 Circuit	46
		1.14.2 Code	46
		1.14.3 Output	50
	1.15	TimerCounter2_PhaseCorrectedPWM	51
		1.15.1 Circuit	51
		1.15.2 Code	51
		1.15.3 Output	56
	1 16	SPI	57
	1.10	1.16.1 Circuit	57
		1.16.2 Code	57
			58
	1 17	1.16.3 Output	58
	1.17	USARTO	
		1.17.1 Circuit	58
		1.17.2 Code	58
		1.17.3 Output	60
	1.18	TwinWireInterface	60
		1.18.1 Circuit	60
		1.18.2 Code	60
		1.18.3 Output	66
	1.19	AnalogComparator	67
		1.19.1 Circuit	67
		1.19.2 Code	67
		1.19.3 Output	68
	1.20	${ m Analog To Digital}$	68
		1.20.1 Circuit	68
		1.20.2 Code	68
		1.20.3 Output	69
2		plications	<b>70</b>
	2.1	BasicLCD	70
		2.1.1 Circuit	70
		2.1.2 Code	70
		2.1.3 Output	70
	2.2	UARTLCD	71
		2.2.1 Circuit	71
		2.2.2 Code	71
		2.2.3 Output	71
	2.3	CDILCD	70
	4.0	SPILOD	72
	2.0	SPILCD         2.3.1 Circuit	
	2.0	2.3.1 Circuit	72
	2.0	2.3.1 Circuit	72 72
		2.3.1 Circuit       Code         2.3.2 Code       Code         2.3.3 Output       Code	72 72 75
	2.4	2.3.1 Circuit	72 72 75 75
		2.3.1 Circuit	72 72 75 75 75
		2.3.1 Circuit 2.3.2 Code 2.3.3 Output I2CLCD 2.4.1 Circuit 2.4.2 Code	72 72 75 75 75 76
	2.4	2.3.1 Circuit 2.3.2 Code 2.3.3 Output I2CLCD 2.4.1 Circuit 2.4.2 Code 2.4.3 Output	72 72 75 75 75 76 77
		2.3.1 Circuit 2.3.2 Code 2.3.3 Output I2CLCD 2.4.1 Circuit 2.4.2 Code 2.4.3 Output I2CEEPROM	72 72 75 75 75 76 77 77
	2.4	2.3.1 Circuit 2.3.2 Code 2.3.3 Output I2CLCD 2.4.1 Circuit 2.4.2 Code 2.4.3 Output I2CEEPROM 2.5.1 Circuit	72 72 75 75 75 76 77 77
	2.4	2.3.1 Circuit 2.3.2 Code 2.3.3 Output I2CLCD 2.4.1 Circuit 2.4.2 Code 2.4.3 Output I2CEEPROM 2.5.1 Circuit 2.5.2 Code	72 72 75 75 75 76 77 77 77
	2.4	2.3.1 Circuit 2.3.2 Code 2.3.3 Output I2CLCD 2.4.1 Circuit 2.4.2 Code 2.4.3 Output I2CEEPROM 2.5.1 Circuit	72 72 75 75 75 76 77 77

# **Basic Programs**

## 1.1 BasicLedBlink

## 1.1.1 Circuit




## 1.1.2 Code

## 1.1.3 Output

The Output can be seen @ PC0.

## 1.2 InterruptsExternal

## 1.2.1 Circuit



#### 1.2.2 Code


```
void externalInterruptINTO()
        DDRD &= ^{(1<<2)};
        PORTD |= (1<<2);
        EICRA |= (1<<ISCO1);</pre>
        EICRA &= ~(1<<ISCOO);</pre>
        EIMSK |= (1<<INTO);</pre>
        sei();
void externalInterruptINT1()
        DDRD &= (1 << 3);
        PORTD |= (1<<3);
        EICRA |= ((1<<ISC11) | (1<<ISC10));
        EIMSK |= (1<<INT1);</pre>
        sei();
int main(void)
{
        DDRC \mid = 0X03;
        PORTC &= OXFC;
        externalInterruptINTO();
        externalInterruptINT1();
        while(1)
```

## 1.2.3 Output

The Output can be seen @ PC0 and PC1 when falling edge @ INT0 and rising edge @ INT1 occurs.

## 1.3 InterruptsPinChange

## 1.3.1 Circuit




#### 1.3.2 Code

## 1.3.3 Output

The Output can be seen @ PC0 when pin change @ PCINT20 occurs.

## 1.4 TimerCounter0\_NormalMode

## 1.4.1 Circuit



## 1.4.2 Code

```
#define F_CPU 16000000L
#include
#include

#include

void Timer0_asTimer()
{

    /* TCNTO starts from 0X00 goes upto 0XFF and restarts */
    /* No possible use case as it just goes upto 0xFF and restarts */
    // MOde of operation to Normal Mode -- WGMO[2:0] === 000
```

```
TCCROA = TCCROA & (~(1<<0) & ~(1<<1));
        TCCROB = TCCROB & ^{\sim}(1 << 3);
        TCCROA = TCCROA & ^{\sim}(1 << 7);
        TCCROA = TCCROA | (1 << 6);
        TCCROA = TCCROA & ~(1 << 5);
        TCCROA = TCCROA \mid (1 << 4);
        TIMSKO = TIMSKO | (1 << 0);
        TCCROB = TCCROB | (1<<1);</pre>
        TCCROB = TCCROB & (^{\sim}(1<<0) & ^{\sim}(1<<2));
        sei();
void Timer0_asCounter()
{
        TCCROA = TCCROA & (~(1<<0) & ~(1<<1));
        TCCROB = TCCROB & ^{\sim}(1 << 3);
        TCCROB = TCCROB \mid (1 << 2);
        TCCROB = TCCROB \mid (1 << 1);
        TCCROB = TCCROB & ~(1 << 0);
void TimerO_asDelay()
}
        TCCROA = TCCROA & (~(1<<0) & ~(1<<1));
        TCCROB = TCCROB & ^{\sim}(1 << 3);
        TCCROA = TCCROA & ~(1 << 7);
        TCCROA = TCCROA & ~(1 << 6);
```

```
TCCROB = TCCROB & ^{\sim}(1 << 0);
        TCCROB = TCCROB | (1<<1);</pre>
        TCCROB = TCCROB & ~(1 << 2);
        while((TIFRO & 0x01) == 0x00); // checking overflow flag when overflow happns
        TIFRO = TIFRO \mid 0x01;
int main(void)
        DDRD = DDRD | (1<<6) | (1<<5);
        DDRD = DDRD & ^{\sim}(1 << 4);
        DDRC |= (1<<0) | (1<<1);
        PORTC &= (1 << 0);
        while(1)
                 PORTC &= ~(1<<0);
                 Timer0_asDelay();
                 PORTC |= (1<<0);
                 Timer0_asDelay();
        }
ISR(TIMERO_OVF_vect)
        PINC |= (1<<1);
```

## 1.4.3 Output

#### $Timer0\_asTimer$

- The output can be seen @ OC0A and OC0B pins with a on time of  $128\mu$ s and off time of  $128\mu$ s ( $\frac{0xFF*8}{16000000} = 127.5\mu s$ ).
- Also, *PC1* toglles for the overflow Timer0.

#### $Timer0\_asCounter$


• The output can be seen @ Watch Window and see the  ${f TCNT0}$  register when pulsed @  ${f T0}$  pin.

## $Timer0_asDelay$

• The output can be seen PC0 pin.

## 1.5 TimerCounter0\_CTC

## 1.5.1 Circuit



#### 1.5.2 Code

```
void Timer0_asTimer()
        TCCROA = TCCROA & ~(1 << 0);
        TCCROA = TCCROA \mid (1 << 1);
        TCCROB = TCCROB & ^{\sim}(1 << 3);
        TCCROA = TCCROA & ~(1 << 7);
        TCCROA = TCCROA \mid (1 << 6);
        // COMOB[1](bit7) from TCCROA, COMOB[0](bit6) from TCCROA
TCCROA = TCCROA & ~(1<<5);
        TCCROA = TCCROA | (1 << 4);
        TIMSKO = TIMSKO | (1 << 1);
         // setting the value till the counter should reach in OCROA
        OCROA = 0x32;
        TCCROB = TCCROB | (1<<1);
        TCCROB = TCCROB & (^{\sim}(1<<0) & ^{\sim}(1<<2));
        sei();
```

```
void Timer0_asCounter()
{
        TCCROA = TCCROA & ~(1<<0);
        TCCROA = TCCROA \mid (1 << 1);
        TCCROB = TCCROB & ~(1 << 3);
        TIMSKO = TIMSKO | (1 << 1);
        OCROA = OxA;
        TCCROB = TCCROB | (1<<2);
        TCCROB = TCCROB \mid (1 << 1);
        TCCROB = TCCROB & ~(1 << 0);
        sei();
void Timer0_asDelayIn_ms(uint32_t delayInMs)
{
        TCCROA = TCCROA & ~(1 << 0);
        TCCROA = TCCROA | (1 << 1);
        TCCROB = TCCROB & ~(1 << 3);
        while(delayInMs--)
        {
                OCROA = 249;
                TCCROB = TCCROB | (1<<0);
                TCCROB = TCCROB | (1<<1);</pre>
                TCCROB = TCCROB & ~(1 << 2);
                 while((TIFRO & 0x02) == 0x00);
                TIFRO = TIFRO \mid 0x02;
        }
int main(void)
        DDRD = DDRD | (1<<6) | (1<<5);
        DDRD = DDRD & (1 << 4);
        DDRB |= (1<<0);
        DDRC |= (1<<0) | (1<<1);
        PORTC \&= (1 << 0);
```

## 1.5.3 Output

#### $Timer0_asTimer$

- The output can be seen @ OC0A and OC0B pins with a on time of  $25.5\mu$ s and off time of  $25.5\mu$ s ( $\frac{(0x32+1)*8}{16000000} = 25.5\mu$ s).
- Also, *PC1* toglles for the **TCNT0** matches **OCR0A**.

#### ${\bf Timer 0\_ as Counter}$


- The output can be seen @ Watch Window and see the **TCNT0** register when pulsed @ *T0* pin.
- Also, the *PC1* pin toggles for every 10 changes at *T0* pin.

## $Timer0\_asDelayIn\_ms$

• The output can be seen PC0 pin.

## 1.6 TimerCounter0\_FastPWM

## 1.6.1 Circuit



## 1.6.2 Code

```
// WGMO[2](bit3) from TCCROB, WGMO[1](bit1) from TCCROA, WGMO[0](bit0) from TCCROA
        TCCROA = TCCROA | (1 << 0);
        TCCROA = TCCROA | (1 << 1);
        TCCROB = TCCROB & ^{\sim}(1 << 3);
        TCCROA = TCCROA | (1<<7);
        TCCROA = TCCROA & ^{\sim}(1 << 6);
        TCCROA = TCCROA | (1 << 5);
        TCCROA = TCCROA \& ~(1 << 4);
        TIMSKO = TIMSKO | (1<<0);
        TIMSKO = TIMSKO | (1 << 1);
        TIMSKO = TIMSKO | (1 << 2);
        OCROA = 0x19; // for 10% duty clcle
        OCROB = 0xCO; // for 75% duty clcle
        TCCROB = TCCROB | (1<<0);
        TCCROB = TCCROB & ~(1 << 1);
        TCCROB = TCCROB & ~(1<<2);
        sei();
void Timer0_Inverting_TOP_at_MAX()
{
        TCCROA = TCCROA | (1 << 0);
        TCCROA = TCCROA \mid (1 << 1);
        TCCROB = TCCROB & ^{\sim}(1 << 3);
```

```
// COMOA[1](bit7) from TCCROA, COMOA[0](bit6) from TCCROA
TCCROA = TCCROA | (1<<7);</pre>
        TCCROA = TCCROA \mid (1 << 6);
        TCCROA = TCCROA | (1 << 5);
        TCCROA = TCCROA \mid (1 << 4);
        TIMSKO = TIMSKO | (1 << 0);
        TIMSKO = TIMSKO | (1 << 1);
        TIMSKO = TIMSKO | (1 << 2);
        OCROA = 0x19; // for 10% duty clcle
        OCROB = 0xCO; // for 75% duty clcle
        TCCROB = TCCROB | (1<<0);
        TCCROB = TCCROB & ~(1 << 1);
        TCCROB = TCCROB \& ~(1 << 2);
        sei();
void TimerO_NonInverting_TOP_at_OCROA()
{
        TCCROA = TCCROA \mid (1 << 0);
        TCCROA = TCCROA \mid (1 << 1);
        TCCROB = TCCROB \mid (1 << 3);
        TCCROA = TCCROA | (1 << 5);
        TCCROA = TCCROA & ~(1 << 4);
        OCROA = 0x70; // for frequency
        OCROB = 0x60; // for pwm duty cylc
        TCCROB = TCCROB \mid (1 << 0);
        TCCROB = TCCROB & ~(1 << 1);
        TCCROB = TCCROB & ^{\sim}(1 << 2);
        sei();
void Timer0_Inverting_TOP_at_OCROA()
{
```

```
TCCROA = TCCROA | (1 << 0);
    TCCROA = TCCROA | (1<<1);
    TCCROB = TCCROB \mid (1 << 3);
    TCCROA = TCCROA \mid (1 << 5);
    TCCROA = TCCROA \mid (1 << 4);
    OCROA = 0x70; // for frequency
    OCROB = 0x60; // for pwm duty cylc
    TCCROB = TCCROB \mid (1 << 0);
    TCCROB = TCCROB & ^{\sim}(1 << 1);
    TCCROB = TCCROB & ^{\sim}(1 << 2);
    sei();
void Timer0_0C0A_Square()
    TCCROA = TCCROA | (1 << 0);
    TCCROA = TCCROA | (1 << 1);
    TCCROB = TCCROB \mid (1 << 3);
    TCCROA = TCCROA & ^{\sim}(1 << 7);
    TCCROA = TCCROA | (1 << 6);
    OCROA = 0x70; // for frequency
    TCCROB = TCCROB | (1<<0);
    TCCROB = TCCROB & ^{\sim}(1 << 1);
    TCCROB = TCCROB & ^{\sim}(1 << 2);
    sei();
void Timer0_FastPWMGeneration(uint32_t on_time_us, uint32_t off_time_us)
{
        uint32_t total_time = on_time_us + off_time_us;
        TCCROA = TCCROA \mid (1 << 0);
        TCCROA = TCCROA \mid (1 << 1);
        TCCROB = TCCROB \mid (1 << 3);
        TCCROA = TCCROA | (1 << 5);
        TCCROA = TCCROA & ~(1 << 4);
        if(total_time <=3)</pre>
        {
                 OCROA = 0;
```

```
TCCROB = TCCROB & ~(1 << 0);
                 TCCROB = TCCROB & ^{\sim}(1 << 1);
                 TCCROB = TCCROB & ~(1 << 2);
        else if((3 < total_time) && (total_time <= 16))</pre>
                 OCROA = ((total_time * 16) >> 0) - 1;
                 OCROB = ((on_time_us * 16) >> 0) - 1;
                 TCCROB = TCCROB | (1<<0);
                 TCCROB = TCCROB & ~(1<<1);
                 TCCROB = TCCROB & ^{\sim}(1 << 2);
        else if((16 < total_time) && (total_time <= 128))</pre>
                 OCROA = ((total_time * 16) >> 3) - 1;
                 OCROB = ((on_time_us * 16) >> 3) - 1;
                 TCCROB = TCCROB & ^{\sim}(1<<0);
                TCCROB = TCCROB | (1<<1);
                TCCROB = TCCROB & ~(1 << 2);
        else if((128 < total_time) && (total_time <= 1024))</pre>
                 OCROA = ((total_time * 16) >> 6) - 1;
                 OCROB = ((on_time_us * 16) >> 6) - 1;
                 TCCROB = TCCROB | (1<<0);
                 TCCROB = TCCROB | (1<<1);
                 TCCROB = TCCROB & ^{\sim}(1 << 2);
        else if((1024 < total_time) && (total_time <= 4096))</pre>
                 OCROA = ((total_time * 16) >> 8) - 1;
                 OCROB = ((on_time_us * 16) >> 8) - 1;
                TCCROB = TCCROB & ^{\sim}(1<<0);
                 TCCROB = TCCROB \& ~(1 << 1);
                 TCCROB = TCCROB | (1<<2);</pre>
        else if(total_time > 4096)
void PWMGeneration(double duty_cycle_percent,uint32_t frequency)
```

```
double total_time_us = (1000000.0/freqeuncy);
    double on_time_us = (duty_cycle_percent/100.0) * total_time_us;
    if (on_time_us<1.0)
    {
            on_time_us = 1;
    }
      // max time = Ams -- min frequency = 250 Hz
      // min time = Aus -- max frequency = 250000 = 250khz
      TimerO_FastPWMGeneration(on_time_us, total_time_us - on_time_us);
}
int main(void)
{
      DDRD = DDRD | (1<<6) | (1<<5);
      // TimerO_NonInverting_TUP_at_MAX();
      // TimerO_Inverting_TUP_at_OCROA();
      // TimerO_ConInverting_TUP_at_OCROA();
      // TimerO_Source();
      PWMGeneration(12, 1000);
      while(1)
      {
        }
      ISR(TIMERO_OVF_vect)
      {
        }
      ISR(TIMERO_COMPA_vect)
      {
        }
      ISR(TIMERO_COMPB_vect)
      {
        }
      ISR(TIMERO_COMPB_vect)
      {
        }
    }
}</pre>
```

## 1.6.3 Output

#### Timer0\_NonInverting\_TOP\_at\_MAX

- The output can be seen @ OCOA with a frequency of 62.74 kHz( $\frac{0xFF*1}{16000000} = 15.9\mu s$ ) and duty cycle of 10% ( $\frac{10}{100} * 0xFF = 0x19$ ).
- The output can be seen @ OCOB with a frequency of 62.74 kHz( $\frac{0xFF*1}{16000000} = 15.9\mu s$ ) and duty cycle of 75% ( $\frac{75}{100} = 0xC0$ ).

#### $Timer0\_Inverting\_TOP\_at\_MAX$

- The output can be seen @ OC0A with a frequency of 62.74 kHz( $\frac{0xFF*1}{16000000} = 15.9\mu s$ ) and duty cycle of (100 10)% ( $\frac{10}{100} * 0xFF = 0x19$ ).
- The output can be seen @ OC0B with a frequency of 62.74 kHz( $\frac{0xFF*1}{16000000} = 15.9\mu s$ ) and duty cycle of (100 75)% ( $\frac{75}{100} = 0xC0$ ).

## $Timer0\_NonInverting\_TOP\_at\_OCR0A$

• The output can be seen @ *OC0B* with a frequency of 142.857 kHz( $\frac{0x70*1}{16000000} = 7\mu s$ ) and duty cycle of 85% ( $\frac{85}{100} = 0x60$ ).

## $Timer0\_Inverting\_TOP\_at\_OCR0A$

• The output can be seen @ OC0B with a frequency of  $142.857 \text{ kHz} (\frac{0x70*1}{16000000} = 7\mu s)$  and duty cycle of (100 - 85)%  $(\frac{85}{100} = 0x60)$ .

#### Timer0\_OC0A\_Square


• The output can be seen @ OC0A with a frequency of 142.857 kHz( $\frac{0x70*1}{16000000} = 7\mu s$ ).

#### **PWMGeneration**

• The output can be seen @ OCOB.

## 1.7 TimerCounter0\_PhaseCorrectedPWM

#### 1.7.1 Circuit



## 1.7.2 Code

```
void Timer0_NonInverting_TOP_at_MAX()
        TCCROA = TCCROA | (1 << 0);
        TCCROA = TCCROA & ~(1 << 1);
        TCCROB = TCCROB & ^{\sim}(1 << 3);
        TCCROA = TCCROA | (1 << 7);
```

```
TCCROA = TCCROA & ~(1<<6);
        // which is reflected in PD65
// COMOB[1](bit5) from TCCROA, COMOB[0](bit4) from TCCROA
TCCROA = TCCROA | (1<<5);</pre>
        TCCROA = TCCROA & ~(1 << 4);
        TIMSKO = TIMSKO | (1 << 0);
        DCROA = 0x19; // for 10% duty clcle
        OCROB = 0xCO; // for 75% duty clcle
        TCCROB = TCCROB | (1<<0);
        TCCROB = TCCROB & ~(1 << 1);
        TCCROB = TCCROB & ^{\sim}(1 << 2);
        sei();
void Timer0_Inverting_TOP_at_MAX()
{
        TCCROA = TCCROA | (1 << 0);
        TCCROA = TCCROA & ~(1 << 1);
        TCCROB = TCCROB & ~(1 << 3);
        TCCROA = TCCROA | (1 << 7);
        TCCROA = TCCROA & ~(1 << 6);
        TCCROA = TCCROA | (1 << 5);
        TCCROA = TCCROA & ~(1 << 4);
        TIMSKO = TIMSKO | (1 << 0);
        OCROB to any value below max(0xFFF)
        OCROA = 0x19; // for 10% duty clcle
        OCROB = 0xC0; // for 75\% duty clcle
```

```
TCCROB = TCCROB \mid (1 << 0);
        TCCROB = TCCROB & ~(1 << 1);
        TCCROB = TCCROB & ~(1<<2);
        sei();
void Timer0_NonInverting_TOP_at_OCROA()
{
        TCCROA = TCCROA \mid (1 << 0);
        TCCROA = TCCROA & ~(1 << 1);
        TCCROB = TCCROB \mid (1 << 3);
        TCCROA = TCCROA | (1 << 5);
        TCCROA = TCCROA & ~(1 << 4);
        OCROA = 0x70; // for frequency
        OCROB = 0x60; // for pwm duty cylc
        TCCROB = TCCROB \mid (1 << 0);
        TCCROB = TCCROB \& ~(1 << 1);
        TCCROB = TCCROB & ^{\sim}(1 << 2);
        sei();
void Timer0_Inverting_TOP_at_OCROA()
{
        \overline{\text{TCCROA}} = \overline{\text{TCCROA}} \mid (1 << 0);
        TCCROA = TCCROA & ~(1 << 1);
        TCCROB = TCCROB \mid (1 << 3);
        TCCROA = TCCROA \mid (1 << 5);
        TCCROA = TCCROA \mid (1 << 4);
        OCROA = 0x70; // for frequency
        OCROB = 0x60; // for pwm duty cylc
        TCCROB = TCCROB | (1<<0);
        TCCROB = TCCROB & ~(1 << 1);
        TCCROB = TCCROB \& ~(1 << 2);
        sei();
void TimerO_OCOA_Square()
```

```
TCCROA = TCCROA | (1 << 0);
        TCCROA = TCCROA \& ~(1 << 1);
        \underline{\text{TCCROB}} = \underline{\text{TCCROB}} \mid (1 << 3);
        TCCROA = TCCROA & ~(1 << 7);
        TCCROA = TCCROA | (1 << 6);
        OCROA = 0x70; // for frequency
        TCCROB = TCCROB | (1<<0);
        TCCROB = TCCROB & ~(1 << 1);
        TCCROB = TCCROB & ^{\sim}(1 << 2);
        sei();
void TimerO_PhaseCorrectedPWMGeneration(uint32_t On_time_us, uint32_t Off_time_us)
{
        uint32_t total_time = (On_time_us>>1) + (Off_time_us>>1);
        uint32_t on_time_us = On_time_us >> 1;
        TCCROA = TCCROA \mid (1 << 0);
        TCCROA = TCCROA & ~(1 << 1);
        TCCROB = TCCROB | (1<<3);</pre>
        TCCROA = TCCROA | (1 << 5);
        TCCROA = TCCROA & ~(1 << 4);
         if(total_time <=3)</pre>
        {
                 OCROA = 0;
                 TCCROB = TCCROB & ^{\sim}(1 << 0);
                 TCCROB = TCCROB & ~(1 << 1);
                 TCCROB = TCCROB \& ~(1 << 2);
        else if((3 < total_time) && (total_time <= 16))</pre>
                 OCROA = ((total_time * 16) >> 0) - 1;
                 OCROB = ((on_time_us * 16) >> 0) - 1;
                 TCCROB = TCCROB | (1<<0);
                  TCCROB = TCCROB & ^{\sim}(1 << 1);
                 TCCROB = TCCROB & ^{\sim}(1<<2);
        else if((16 < total_time) && (total_time <= 128))</pre>
```

```
OCROA = ((total_time * 16) >> 3) - 1;
                OCROB = ((on_time_us * 16) >> 3) - 1;
                TCCROB = TCCROB & ~(1<<0);
                TCCROB = TCCROB \mid (1 << 1);
                TCCROB = TCCROB & ~(1 << 2);
        else if((128 < total_time) && (total_time <= 1024))</pre>
                OCROA = ((total_time * 16) >> 6) - 1;
                OCROB = ((on_time_us * 16) >> 6) - 1;
                TCCROB = TCCROB | (1<<0);
                TCCROB = TCCROB | (1<<1);</pre>
                TCCROB = TCCROB & ^{\sim}(1 << 2);
        else if((1024 < total_time) && (total_time <= 4096))</pre>
                OCROA = ((total_time * 16) >> 8) - 1;
                OCROB = ((on_time_us * 16) >> 8) - 1;
                TCCROB = TCCROB & ~(1 << 0);
                TCCROB = TCCROB & ^{\sim}(1 << 1);
                TCCROB = TCCROB | (1<<2);</pre>
        else if(total_time > 4096)
void PWMGeneration(double duty_cycle_percent,uint32_t frequency)
        double total_time_us = (1000000.0/frequency);
        double on_time_us = (duty_cycle_percent/100.0) * total_time_us;
        if (on_time_us<1.0)</pre>
        {
                on_time_us = 1;
                                         }
        TimerO_PhaseCorrectedPWMGeneration(on_time_us, total_time_us - on_time_us);
int main(void)
        DDRD = DDRD | (1<<6) | (1<<5);
   Timer0_OCOA_Square();
   while(1)
   {
   }
```

```
| SR(TIMERO_OVF_vect)
| SR(TIMERO_COMPA_vect)
| SR(TIMERO_COMPB_vect)
|
```

## 1.7.3 Output

## $Timer0\_NonInverting\_TOP\_at\_MAX$

- The output can be seen @ OC0A with a frequency of  $31.372 \text{ kHz}(\frac{510*1}{16000000} = 31.8\mu s)$  and duty cycle of 10%  $(\frac{10}{100}*0xFF = 0x19)$ .
- The output can be seen @ OC0B with a frequency of  $31.372 \text{ kHz}(\frac{510*1}{16000000} = 31.8\mu s)$  and duty cycle of 75% ( $\frac{75}{100}*0xFF = 0xC0$ ).

## $Timer0\_Inverting\_TOP\_at\_MAX$

- The output can be seen @ OC0A with a frequency of  $31.372 \text{ kHz}(\frac{510*1}{16000000} = 31.8\mu s)$  and duty cycle of (100 10)%  $(\frac{10}{100} * 0xFF = 0x19)$ .
- The output can be seen @ OC0B with a frequency of  $31.372 \text{ kHz} (\frac{510*1}{16000000} = 31.8 \mu s)$  and duty cycle of (100 75)%  $(\frac{75}{100} * 0xFF = 0xC0)$ .

#### $Timer0\_NonInverting\_TOP\_at\_OCR0A$

• The output can be seen @ OC0B with a frequency of 71.42 kHz( $\frac{(2*0x70)*1}{16000000} = 14\mu s$ ) and duty cycle of 85% ( $\frac{85}{100} * 0x70 = 0x60$ ).

## $Timer0\_Inverting\_TOP\_at\_OCR0A$

• The output can be seen @ OC0B with a frequency of 71.42 kHz( $\frac{(2*0x70)*1}{16000000} = 14\mu s$ ) and duty cycle of (100 - 85)% ( $\frac{85}{100}*0x70 = 0x60$ ).

## ${\bf Timer 0\_OC0A\_Square}$


• The output can be seen @ OC0A with a frequency of 71.42 kHz( $\frac{(2*0x70)*1}{16000000} = 14\mu s$ ).

## **PWMGeneration**

• The output can be seen @ OCOB.

## 1.8 TimerCounter1\_NormalMode

## 1.8.1 Circuit



#### 1.8.2 Code

```
void Timer1_asTimer()
          TCCR1A = TCCR1A & ^{\sim}(1 << WGM10);
         TCCR1A = TCCR1A & ~(1<<WGM11);
TCCR1B = TCCR1B & ~(1<<WGM12);
          TCCR1B = TCCR1B & ^{\sim}(1 << WGM13);
          // COM1A[1](bit7) from TCCR1A, COM1A[0](bit6) from TCCR1A
TCCR1A = TCCR1A & ~(1<<COM1A1);</pre>
          TCCR1A = TCCR1A | (1<<COM1A0);</pre>
          TCCR1A = TCCR1A & ~(1 << COM1B1);
          TCCR1A = TCCR1A | (1<<COM1B0);</pre>
          TIMSK1 = TIMSK1 | (1<<TOV1);</pre>
          TCCR1B = TCCR1B | (1<<CS10);
          TCCR1B = TCCR1B & ^{\sim}(1 << CS11);
          TCCR1B = TCCR1B & ^{\sim}(1 << CS12);
          sei();
```

```
void Timer1_asCounter()
{
        TCCR1A = TCCR1A & ~(1 << WGM10);
        TCCR1A = TCCR1A & ~(1 << WGM11);
        TCCR1B = TCCR1B & ^{\sim}(1 << WGM12);
        TCCR1B = TCCR1B & ^{\sim}(1 << WGM13);
        TCCR1B = TCCR1B & ~(1 << CS10);
        TCCR1B = TCCR1B | (1<<CS11);</pre>
        TCCR1B = TCCR1B \mid (1 << CS12);
void Timer1_asInputCapture()
{
        TCCR1A = TCCR1A & ^{\sim}(1 << WGM10);
        TCCR1A = TCCR1A & ~(1 << WGM11);
        TCCR1B = TCCR1B \& ~(1 << WGM12);
        TCCR1B = TCCR1B \& ~(1 << WGM13);
        TCCR1B |= (1<<ICES1);
        TIMSK1 = TIMSK1 | (1<<ICIE1);</pre>
        TCCR1B = TCCR1B | (1<<CS10);</pre>
        TCCR1B = TCCR1B & ~(1<<CS11);
        TCCR1B = TCCR1B & ^{\sim}(1 << CS12);
        sei();
}
void Timer1_asDelay()
{
        TCCR1A = TCCR1A & ~(1 << WGM10);
        TCCR1A = TCCR1A & ~(1 << WGM11);
        TCCR1B = TCCR1B & ^{\sim}(1 << WGM12);
        TCCR1B = TCCR1B & ^{\sim}(1 << WGM13);
        TCCR1A = TCCR1A & ~(1 << COM1A1);
        TCCR1A = TCCR1A & ~(1<<COM1AO);
```

```
TCCR1B = TCCR1B | (1<<CS10);</pre>
        TCCR1B = TCCR1B | (1<<CS11);
        TCCR1B = TCCR1B & ~(1 << CS12);
        while((TIFR1 & 0x01) == 0x00); // checking overflow flag when overflow happns
        TIFR1 = TIFR1 \mid 0x01;
volatile uint16_t capVal=0;
int main(void)
{
    DDRB = DDRB | (1<<1) | (1<<2);
        DDRD = DDRD & (1 << 5);
        DDRC |= (1<<0) | (1<<1);
        PORTC &= ~(1<<0);
        Timer1_asInputCapture();
    while(1)
}
ISR(TIMER1_OVF_vect)
        PINC |= (1 << 1);
ISR(TIMER1_CAPT_vect)
        if((TIFR1 & (1<<ICF1)) != 0)</pre>
                 capVal = ICR1L;
                 capVal = (ICR1H<<8) | (capVal & 0xFF);</pre>
        }
```

## 1.8.3 Output

#### $Timer1\_asTimer$

- The output can be seen @ OC1A and OC1B pins with a on time of 4.096 ms and off time of 4.096 ms ( $\frac{0xFFFFF*1}{16000000} = 4.096ms$ ).
- Also, *PC1* toggles for the overflow Timer1.

#### $Timer1\_asCounter$

• The output can be seen @ Watch Window and see the TCNT1 register when pulsed @ T1 pin.

#### Timer1\_asDelay


• The output can be seen PC0 pin.

#### Timer1\_asInputCapture

• The output can be seen @ Watch Window and see the ICR1 register when pulsed @ ICP1 pin.

## 1.9 TimerCounter1\_CTC

## 1.9.1 Circuit



#### 1.9.2 Code

```
#include
#includ
```

```
TIMSK1 = TIMSK1 | (1<<OCIE1A);</pre>
        OCR1A = 0x4861;
        TCCR1B = TCCR1B | (1<<CS10);</pre>
        TCCR1B = TCCR1B & ^{\sim}(1 << CS11);
        TCCR1B = TCCR1B & ^{\sim}(1 << CS12);
        sei();
void Timer1_asCounter()
        TCCR1A = TCCR1A & ~(1 << WGM10);
        TCCR1A = TCCR1A \& ~(1 << WGM11);
        TCCR1B = TCCR1B | (1<<WGM12);</pre>
        TCCR1B = TCCR1B \& ~(1 << WGM13);
        TCCR1A = TCCR1A | (1<<COM1AO);
        TCCR1A = TCCR1A & ~(1 << COM1A1);
        OCR1A = Ox000a;
        TIMSK1 = TIMSK1 | (1<<OCIE1A);</pre>
        TCCR1B = TCCR1B & ~(1 << CS10);
        TCCR1B = TCCR1B \mid (1 << CS11);
        TCCR1B = TCCR1B | (1<<CS12);</pre>
        sei();
void Timer1_asDelayIn_us(uint32_t delay_in_us)
{
```

```
TCCR1A = TCCR1A & ~(1 << WGM10);
TCCR1A = TCCR1A & ~(1 << WGM11);
TCCR1B = TCCR1B | (1<<WGM12);</pre>
TCCR1B = TCCR1B & ^{\sim}(1 << WGM13);
TCCR1A = TCCR1A & ~(1<<COM1A1);
TCCR1A = TCCR1A & ~(1<<COM1AO);</pre>
if(delay_in_us <=3)</pre>
{
         OCR1A = 0;
         TCCR1B = TCCR1B & ^{\sim}(1 << CS10);
         TCCR1B = TCCR1B \& ~(1 << CS11);
         TCCR1B = TCCR1B & ^{\sim}(1 << CS12);
else if((3 < delay_in_us) && (delay_in_us <= 4000))</pre>
         OCR1A = ((delay_in_us * 16) >> 0) - 1;
        TCCR1B = TCCR1B \mid (1 << CS10);
         TCCR1B = TCCR1B \& ~(1 << CS11);
         TCCR1B = TCCR1B & ~(1 << CS12);
else if((4000 < delay_in_us) && (delay_in_us <= 32000))</pre>
         OCR1A = ((delay_in_us * 16) >> 3) - 1;
         TCCR1B = TCCR1B & ^{\sim}(1 << CS10);
         TCCR1B = TCCR1B \mid (1 << CS11);
         TCCR1B = TCCR1B \& ~(1 << CS12);
else if((32000 < delay_in_us) && (delay_in_us <= 260000))
         OCR1A = ((delay_in_us * 16) >> 6) - 1;
         TCCR1B = TCCR1B | (1<<CS10);</pre>
        TCCR1B = TCCR1B | (1<<CS11);</pre>
         TCCR1B = TCCR1B \& ~(1 << CS12);
}
```

```
else if((260000 < delay_in_us) && (delay_in_us <= 1000000))</pre>
                 OCR1A = ((delay_in_us * 16) >> 8) - 1;
                TCCR1B = TCCR1B & ~(1 << CS10);
                 TCCR1B = TCCR1B & ~(1<<CS11);
                 TCCR1B = TCCR1B | (1<<CS12);</pre>
        else if(delay_in_us > 1000000)
                Timer1_asDelayIn_us(delay_in_us - 1000000);
                 OCR1A = ((10000000 * 16) >> 8) - 1;
                TCCR1B = TCCR1B \& ~(1 << CS10);
                 TCCR1B = TCCR1B \& ~(1 << CS11);
                 TCCR1B = TCCR1B | (1<<CS12);</pre>
        while((TIFR1 & 0x02) == 0x00);
        TIFR1 = TIFR1 \mid 0x02;
int main(void)
{
    DDRB = DDRB | (1<<1) | (1<<2);
        DDRD = DDRD & (1 << 5);
        DDRC |= (1<<0) | (1<<1);
        PORTC &= ~(1<<0);
    while(1)
    {
                 PINC \mid = (1 << 0);
                Timer1_asDelayIn_us(400);
ISR(TIMER1_COMPA_vect)
        PINC |= (1 << 1);
```

## 1.9.3 Output

## $Timer1\_asTimer$

- The output can be seen @ OC1A and OC1B pins with a on time of 1.15ms and off time of 1.15 ms  $(\frac{(0x4861+1)*1}{16000000} = 1.15ms)$ .
- Also, *PC1* toglles for the **TCNT1** matches **OCR1A**.

## Timer1\_asCounter

• The output can be seen @ Watch Window and see the TCNT1 register when pulsed @ T1 pin.


• Also, the PC1 pin toggles for every 10 changes at T1 pin.

#### $Timer1_asDelayIn_us$

• The output can be seen PC0 pin.

## 1.10 TimerCounter1\_FastPWM

#### 1.10.1 Circuit



#### 1.10.2 Code

```
void Timer1_NonInverting_TOP_at_MAX()
        TCCR1A = TCCR1A \mid (1 << WGM10);
        TCCR1A = TCCR1A \mid (1 << WGM11);
        TCCR1B = TCCR1B | (1<<WGM12);</pre>
        TCCR1B = TCCR1B & ^{\sim}(1 << WGM13);
    // here we set COMOA[1:0] as 10 for non-inverting
        TCCR1A = TCCR1A | (1<<COM1A1);</pre>
        TCCR1A = TCCR1A & ~(1 << COM1AO);
        TCCR1A = TCCR1A | (1<<COM1B1);
        TCCR1A = TCCR1A & ~(1 << COM1B0);
        TIMSK1 = TIMSK1 | (1<<TOIE1);</pre>
        TIMSK1 = TIMSK1 | (1<<OCIE1A);</pre>
        TIMSK1 = TIMSK1 | (1<<0CIE1B);</pre>
```

```
OCR1A = 102; // for 10% duty clcle
        OCR1B = 767; // for 75% duty clcle
        TCCR1B = TCCR1B | (1<<CS10);</pre>
        TCCR1B = TCCR1B & ^{\sim}(1 << CS11);
        TCCR1B = TCCR1B & ^{\sim}(1 << CS12);
        sei();
void Timer1_Inverting_TOP_at_MAX()
        TCCR1A = TCCR1A | (1<<WGM10);
        TCCR1A = TCCR1A | (1<<WGM11);</pre>
        TCCR1B = TCCR1B | (1<<WGM12);</pre>
        TCCR1B = TCCR1B \& ~(1 << WGM13);
        // COM1A[1](bit7) from TCCR1A, COM1A[0](bit6) from TCCR1A
TCCR1A = TCCR1A | (1<<COM1A1);</pre>
        TCCR1A = TCCR1A | (1<<COM1A0);</pre>
        TCCR1A = TCCR1A | (1<<COM1B1);</pre>
        TCCR1A = TCCR1A | (1<<COM1B0);</pre>
        TIMSK1 = TIMSK1 | (1<<TOIE1);</pre>
        TIMSK1 = TIMSK1 | (1<<0CIE1A);</pre>
        TIMSK1 = TIMSK1 | (1<<0CIE1B);</pre>
        OCR1A = 102; // for 10% duty clcle
        OCR1B = 767; // for 75% duty clcle
        TCCR1B = TCCR1B | (1<<CS10);
        TCCR1B = TCCR1B & ~(1 << CS11);
        TCCR1B = TCCR1B & ^{\sim}(1 << CS12);
        sei();
void Timer1_NonInverting_TOP_at_OCR1A()
```

```
TCCR1A = TCCR1A | (1<<WGM10);</pre>
        TCCR1A = TCCR1A | (1<<WGM11);</pre>
        TCCR1B = TCCR1B | (1<<WGM12);</pre>
        TCCR1B = TCCR1B | (1<<WGM13);
        TCCR1A = TCCR1A & ~(1<<COM1BO);
        TCCR1A = TCCR1A | (1<<COM1B1);
        OCR1A = 0x7869; // for frequency
        OCR1B = 0x1A20; // for pwm duty cylc
        TIMSK1 |= (1<<TOV1);
        TIMSK1 = (1 << 0CF1B);
        TCCR1B = TCCR1B \mid (1 << CS10);
        TCCR1B = TCCR1B & ^{\sim}(1 << CS11);
        TCCR1B = TCCR1B \& ~(1 << CS12);
        sei();
void Timer1_Inverting_TOP_at_OCR1A()
{
        TCCR1A = TCCR1A | (1<<WGM10);
        TCCR1A = TCCR1A | (1<<WGM11);</pre>
        TCCR1B = TCCR1B | (1<<WGM12);</pre>
        TCCR1B = TCCR1B | (1<<WGM13);</pre>
        TCCR1A = TCCR1A | (1<<COM1B0);
        TCCR1A = TCCR1A | (1<<COM1B1);</pre>
        OCR1A = 0x7869; // for frequency
        OCR1B = 0x1A20; // for pwm duty cylc
        TIMSK1 |= (1<<TOV1);
        TIMSK1 |= (1<<0CF1B);
```

```
TCCR1B = TCCR1B | (1<<CS10);</pre>
        TCCR1B = TCCR1B \& ~(1 << CS11);
        TCCR1B = TCCR1B \& ~(1 << CS12);
        sei();
void Timer1_0C1A_Square()
{
        TCCR1A = TCCR1A | (1<<WGM10);</pre>
        TCCR1A = TCCR1A | (1<<WGM11);</pre>
        TCCR1B = TCCR1B | (1<<WGM12);</pre>
        TCCR1B = TCCR1B | (1<<WGM13);</pre>
    TCCR1A = TCCR1A & ~(1<<5);
    TCCR1A = TCCR1A \mid (1 << 4);
    OCR1A = 0x7869; // for frequency
        TCCR1B = TCCR1B | (1<<CS10);</pre>
        TCCR1B = TCCR1B \& ~(1 << CS11);
        TCCR1B = TCCR1B \& ~(1 << CS12);
    sei();
void Timer1_FastPWMGeneration(uint32_t on_time_us, uint32_t off_time_us)
{
        uint32_t total_time = on_time_us + off_time_us;
        TCCR1A = TCCR1A | (1<<WGM10);</pre>
        TCCR1A = TCCR1A | (1<<WGM11);</pre>
        TCCR1B = TCCR1B | (1<<WGM12);</pre>
        TCCR1B = TCCR1B | (1<<WGM13);</pre>
        TCCR1A = TCCR1A | (1<<COM1B0);</pre>
        TCCR1A = TCCR1A | (1<<COM1B1);
        if(total_time <4)</pre>
        {
```

```
OCR1A = 0;
        OCR1B = 0;
        TCCR1B = TCCR1B & ~(1<<0);
        TCCR1B = TCCR1B & ~(1<<1);
        TCCR1B = TCCR1B & ^{\sim}(1 << 2);
else if((3 < total_time) && (total_time <= 4000))</pre>
        OCR1A = ((total_time * 16) >> 0) - 1;
        OCR1B = ((on_time_us * 16) >> 0) - 1;
        TCCR1B = TCCR1B \mid (1 << 0);
        TCCR1B = TCCR1B & ~(1<<1);
        TCCR1B = TCCR1B & ~(1<<2);
else if((4000 < total_time) && (total_time <= 32000))</pre>
        OCR1A = ((total_time * 16) >> 3) - 1;
        OCR1B = ((on_time_us * 16) >> 3) - 1;
        TCCR1B = TCCR1B & ~(1<<0);
        TCCR1B = TCCR1B | (1<<1);
        TCCR1B = TCCR1B \& ~(1 << 2);
else if((32000 < total_time) && (total_time <= 260000))</pre>
        OCR1A = ((total_time * 16) >> 6) - 1;
        OCR1B = ((on_time_us * 16) >> 6) - 1;
        TCCR1B = TCCR1B \mid (1 << 0);
        TCCR1B = TCCR1B \mid (1 << 1);
        TCCR1B = TCCR1B \& ~(1 << 2);
else if((260000 < total_time) && (total_time <= 1000000))</pre>
        OCR1A = ((total_time * 16) >> 8) - 1;
        OCR1B = ((on_time_us * 16) >> 8) - 1;
        TCCR1B = TCCR1B & ~(1<<0);
        TCCR1B = TCCR1B & ~(1<<1);
        TCCR1B = TCCR1B \mid (1 << 2);
else if(total_time > 1000000)
```

```
void PWMGeneration(double duty_cycle_percent,uint32_t frequency)
        double total_time_us = (10000000.0/frequency);
        double on_time_us = (duty_cycle_percent/100.0) * total_time_us;
        if (on_time_us<1.0)</pre>
        {
                on_time_us = 1;
        }
        Timer1_FastPWMGeneration(on_time_us, total_time_us - on_time_us);
int main(void)
        DDRB = DDRB | (1<<1) | (1<<2);
    Timer1_NonInverting_TOP_at_OCR1A();
    while(1)
ISR(TIMER1_OVF_vect)
ISR(TIMER1_COMPA_vect)
ISR(TIMER1_COMPB_vect)
```

## 1.10.3 Output

#### $Timer1\_NonInverting\_TOP\_at\_MAX$

- The output can be seen @ OC1A with a frequency of 15.640 kHz( $\frac{0x03FF*1}{16000000} = 64ms$ ) and duty cycle of 10% ( $\frac{10}{100}*0x3FF = 0x66$ ).
- The output can be seen @ OC1B with a frequency of 15.640 kHz( $\frac{0x03FF*1}{16000000} = 64ms$ ) and duty cycle of 75% ( $\frac{75}{100} * 0x3FF = 0x2FF$ ).

## $Timer1\_Inverting\_TOP\_at\_MAX$

- The output can be seen @ OC1A with a frequency of 15.640 kHz( $\frac{0x03FF*1}{16000000} = 64ms$ ) and duty cycle of (100 10)% ( $\frac{10}{100} * 0x3FF = 0x66$ ).
- The output can be seen @ OC1B with a frequency of 15.640 kHz( $\frac{0x03FF*1}{16000000} = 64ms$ ) and duty cycle of (100 75)% ( $\frac{75}{100}*0x3FF = 0x2FF$ ).

## $Timer1\_NonInverting\_TOP\_at\_OCR1A$

• The output can be seen @ OC1B with a frequency of  $0.5208 \text{ kHz}(\frac{0x7869*1}{16000000} = 1.92ms)$  and duty cycle of 21% ( $\frac{21}{100} = 0x1A20$ ).

#### Timer1\_Inverting\_TOP\_at\_OCR1A

• The output can be seen @ OC1B with a frequency of  $0.5208 \text{ kHz} (\frac{0x7869*1}{16000000} = 1.92ms)$  and duty cycle of (100 - 21)%  $(\frac{21}{100} = 0x1A20)$ .

## $Timer1\_OC1A\_Square$


• The output can be seen @ OC1A with a frequency of  $0.5208 \text{ kHz} (\frac{0x70*1}{16000000} = 1.92ms)$ .

#### **PWMGeneration**

• The output can be seen @ *OC1B*.

## 1.11 TimerCounter1\_PhaseCorrectedPWM

#### 1.11.1 Circuit



#### 1.11.2 Code

```
TIMSK1 = TIMSK1 | (1<<0CIE1A);</pre>
        TIMSK1 = TIMSK1 | (1<<0CIE1B);</pre>
        OCR1A = 102; // for 10% duty clcle
        OCR1B = 767; // for 75% duty clcle
        TCCR1B = TCCR1B \mid (1 << CS10);
        TCCR1B = TCCR1B & ~(1 << CS11);
        TCCR1B = TCCR1B \& ~(1 << CS12);
        sei();
void Timer1_Inverting_TOP_at_MAX()
{
        TCCR1A = TCCR1A | (1<<WGM10);</pre>
        TCCR1A = TCCR1A | (1<<WGM11);</pre>
        TCCR1B = TCCR1B & ^{\sim}(1 << WGM12);
        TCCR1B = TCCR1B & ^{\sim}(1 << WGM13);
        TCCR1A = TCCR1A | (1<<COM1A1);
        TCCR1A = TCCR1A | (1<<COM1AO);
        TCCR1A = TCCR1A | (1<<COM1B1);</pre>
        TCCR1A = TCCR1A | (1<<COM1B0);
        TIMSK1 = TIMSK1 | (1<<TOIE1);</pre>
        TIMSK1 = TIMSK1 | (1<<OCIE1A);</pre>
        TIMSK1 = TIMSK1 | (1 << OCIE1B);
        OCR1A = 102; // for 10% duty clcle
        OCR1B = 767; // for 75% duty clcle
        TCCR1B = TCCR1B | (1<<CS10);</pre>
```

```
TCCR1B = TCCR1B \& ~(1 << CS11);
        TCCR1B = TCCR1B & ^{\sim}(1 << CS12);
        sei();
void Timer1_NonInverting_TOP_at_OCR1A(){
        TCCR1A = TCCR1A \mid (1 << WGM10);
        TCCR1A = TCCR1A | (1<<WGM11);</pre>
        TCCR1B = TCCR1B & ~(1 << WGM12);
        TCCR1B = TCCR1B | (1<<WGM13);</pre>
        TCCR1A = TCCR1A \mid (1 << 5);
        TCCR1A = TCCR1A \& ~(1 << 4);
        OCR1A = 0x7869; // for frequency
        OCR1B = Ox1A2O; // for pwm duty cylc
        TCCR1B = TCCR1B \mid (1 << CS10);
        TCCR1B = TCCR1B & ~(1 << CS11);
        TCCR1B = TCCR1B & ^{\sim}(1 << CS12);
        sei();
void Timer1_Inverting_TOP_at_OCR1A()
{
        TCCR1A = TCCR1A | (1<<WGM10);
        TCCR1A = TCCR1A | (1<<WGM11);</pre>
        TCCR1B = TCCR1B & ~(1 << WGM12);
        TCCR1B = TCCR1B | (1<<WGM13);</pre>
```

```
// COM1B[1](bit5) from TCCR1A, COMOB[0](bit4) from TCCR1A
TCCR1A = TCCR1A | (1<<5);</pre>
        TCCR1A = TCCR1A | (1 << 4);
        OCR1A = 0x7869; // for frequency
        OCR1B = 0x1A20; // for pwm duty cylc
        TCCR1B = TCCR1B \mid (1 << CS10);
        TCCR1B = TCCR1B & ~(1 << CS11);
        TCCR1B = TCCR1B \& ~(1 << CS12);
        sei();
void Timer1_PhaseCorrectedPWMGeneration(uint32_t On_time_us, uint32_t Off_time_us)
{
        uint32_t total_time = (On_time_us>>1) + (Off_time_us>>1);
        uint32_t on_time_us = On_time_us >> 1;
        TCCR1A = TCCR1A | (1<<WGM10);</pre>
        TCCR1A = TCCR1A | (1<<WGM11);</pre>
        TCCR1B = TCCR1B \& ~(1 << WGM12);
        TCCR1B = TCCR1B \mid (1 << WGM13);
        TCCR1A = TCCR1A | (1<<COM1B0);</pre>
        TCCR1A = TCCR1A | (1<<COM1B1);</pre>
        if(total_time <4)</pre>
        {
                 OCR1A = 0;
                 OCR1B = 0;
                 TCCR1B = TCCR1B & ~(1<<0);
                 TCCR1B = TCCR1B & ~(1<<1);
                 TCCR1B = TCCR1B & ~(1<<2);
        else if((3 < total_time) && (total_time <= 4000))</pre>
                 OCR1A = ((total_time * 16) >> 0) - 1;
                 OCR1B = ((on_time_us * 16) >> 0) - 1;
```

```
TCCR1B = TCCR1B \mid (1 << 0);
                TCCR1B = TCCR1B & ~(1<<1);
                TCCR1B = TCCR1B & ^{\sim}(1 << 2);
        else if((4000 < total_time) && (total_time <= 32000))</pre>
                OCR1A = ((total_time * 16) >> 3) - 1;
                OCR1B = ((on_time_us * 16) >> 3) - 1;
                TCCR1B = TCCR1B & ^{\sim}(1 << 0);
                TCCR1B = TCCR1B | (1<<1);
                TCCR1B = TCCR1B & ~(1<<2);
        else if((32000 < total_time) && (total_time <= 260000))</pre>
                OCR1A = ((total_time * 16) >> 6) - 1;
                OCR1B = ((on_time_us * 16) >> 6) - 1;
                TCCR1B = TCCR1B | (1<<0);
                TCCR1B = TCCR1B \mid (1 << 1);
                TCCR1B = TCCR1B & ~(1<<2);
        else if((260000 < total_time) && (total_time <= 1000000))</pre>
                OCR1A = ((total_time * 16) >> 8) - 1;
                OCR1B = ((on_time_us * 16) >> 8) - 1;
                TCCR1B = TCCR1B & ~(1<<0);
                TCCR1B = TCCR1B & ~(1<<1);
                TCCR1B = TCCR1B \mid (1 << 2);
        else if(total_time > 1000000)
void PWMGeneration(double duty_cycle_percent, uint32_t frequency)
{
        double total_time_us = (1000000.0/frequency);
        double on_time_us = (duty_cycle_percent/100.0) * total_time_us;
        if (on_time_us<1.0)</pre>
        {
                on_time_us = 1;
        }
        Timer1_PhaseCorrectedPWMGeneration(on_time_us, total_time_us - on_time_us);
int main(void)
        DDRB = DDRB | (1<<1) | (1<<2);
```

```
// Timer1_NonInverting_TOP_at_MAX();
// Timer1_Inverting_TOP_at_OCR1A();
// Timer1_Inverting_TOP_at_OCR1A();
// PNWGeneration(12, 1000);
while(1)
{
}
ISR(TIMER1_OVF_vect)
{
}
ISR(TIMER1_COMPA_vect)
{
}
ISR(TIMER1_COMPB_vect)
{
}
```

## 1.11.3 Output

### $Timer1\_NonInverting\_TOP\_at\_MAX$

- The output can be seen @ OC1A with a frequency of 7.812 kHz( $\frac{(2*0x03FF)*1}{16000000} = 128ms$ ) and duty cycle of 10% ( $\frac{10}{100}*0x3FF = 0x66$ ).
- The output can be seen @ OC1B with a frequency of 7.812 kHz( $\frac{(2*0x03FF)*1}{16000000} = 128ms$ ) and duty cycle of 75% ( $\frac{75}{100}*0x3FF = 0x2FF$ ).

#### $Timer0\_Inverting\_TOP\_at\_MAX$

- The output can be seen @ OC1A with a frequency of 7.812 kHz( $\frac{(2*0x03FF)*1}{16000000} = 128ms$ ) and duty cycle of (100 10)% ( $\frac{10}{100}*0x3FF = 0x66$ ).
- The output can be seen @ OC1B with a frequency of 7.812 kHz( $\frac{(2*0x03FF)*1}{16000000} = 128ms$ ) and duty cycle of (100 75)% ( $\frac{75}{100}*0x3FF = 0x2FF$ ).

## $Timer1\_NonInverting\_TOP\_at\_OCR1A$

• The output can be seen @ OC1B with a frequency of  $0.2604 \text{ kHz}(\frac{(2*0x7869)*1}{16000000} = 3.84ms)$  and duty cycle of 21% ( $\frac{21}{100} = 0x1A20$ ).

## $Timer1\_Inverting\_TOP\_at\_OCR1A$

• The output can be seen @ OC1B with a frequency of 0.2604 kHz( $\frac{(2*0x7869)*1}{16000000} = 3.84ms$ ) and duty cycle of (100 - 21)% ( $\frac{21}{100} = 0x1A20$ ).

## $Timer1\_OC1A\_Square$


• The output can be seen @ OC1A with a frequency of  $0.2604 \text{ kHz} (\frac{(2*0x7869)*1}{16000000} = 3.84ms)$ .

#### **PWMGeneration**

• The output can be seen @ OC1B.

## 1.12 TimerCounter2\_NormalMode

## 1.12.1 Circuit



#### 1.12.2 Code

```
void Timer2_asTimer()
{
        TCCR2A = TCCR2A & (~(1<<0) & ~(1<<1));
        TCCR2B = TCCR2B \& ~(1 << 3);
        TCCR2A = TCCR2A \& ~(1 << 7);
        TCCR2A = TCCR2A \mid (1 << 6);
        TCCR2A = TCCR2A \& ~(1 << 5);
        TCCR2A = TCCR2A \mid (1 << 4);
        TIMSK2 = TIMSK2 | (1 << 0);
        TCCR2B = TCCR2B \mid (1 << 1);
        TCCR2B = TCCR2B & (~(1<<0) & ~(1<<2));
        sei();
}
void Timer2_asDelay()
{
```

```
TCCR2A = TCCR2A & (~(1<<0) & ~(1<<1));
        TCCR2B = TCCR2B & ~(1<<3);
        TCCR2A = TCCR2A \& ~(1 << 7);
        TCCR2A = TCCR2A \& ~(1 << 6);
        TCCR2B = TCCR2B & ~(1<<0);
        TCCR2B = TCCR2B \mid (1 << 1);
        TCCR2B = TCCR2B \& ~(1 << 2);
        while((TIFR2 & 0x01) == 0x00); // checking overflow flag when overflow happns
        TIFR2 = TIFR2 \mid 0x01;
int main(void)
{
    DDRD = DDRD \mid (1 << 3);
    DDRB = DDRB | (1 << 3);
        DDRC |= (1<<0) | (1<<1);
        PORTC &= ~(1<<0);
    while(1)
                PORTC &= ~(1<<0);
                Timer2_asDelay();
                 PORTC |= (1 << 0);
                 Timer2_asDelay();
ISR(TIMER2_OVF_vect)
                PINC |= (1 << 1);
```

## 1.12.3 Output

## $Timer2\_asTimer$


- The output can be seen @ OC2A and OC2B pins with a on time of  $128\mu s$  and off time of  $128\mu s$  ( $\frac{0xFF*8}{16000000} = 127.5\mu s$ ).
- Also, *PC1* toglles for the overflow Timer2.

## $Timer2\_asDelay$

• The output can be seen PC0 pin.

## 1.13 TimerCounter2\_CTC

### 1.13.1 Circuit



#### 1.13.2 Code

```
void Timer2_asTimer()
{
         TCCR2A = TCCR2A \& ~(1 << 0);
         TCCR2A = TCCR2A \mid (1 << 1);
         TCCR2B = TCCR2B & ~(1<<3);
         TCCR2A = TCCR2A \& ~(1 << 7);
         TCCR2A = TCCR2A \mid (1 << 6);
         TCCR2A = TCCR2A \& ~(1 << 5);
         \underline{\text{TCCR2A}} = \underline{\text{TCCR2A}} \mid (\underline{1 << 4});
         TIMSK2 = TIMSK2 | (1 << 1);
         OCR2A = 0x32;
         TCCR2B = TCCR2B \mid (1 << 1);
         TCCR2B = TCCR2B & (~(1<<0) & ~(1<<2));
         sei();
void Timer2_asDelayIn_ms(uint32_t delayInMs)
```

```
TCCR2A = TCCR2A & ~(1<<0);
        TCCR2A = TCCR2A \mid (1 << 1);
        TCCR2B = TCCR2B \& ~(1 << 3);
         while(delayInMs--)
         {
                  OCR2A = 249;
                  TCCR2B = TCCR2B \mid (1 << 0);
                  TCCR2B = TCCR2B \mid (1 << 1);
                  \texttt{TCCR2B} = \texttt{TCCR2B} \& ~(1 << 2);
                  while((TIFR2 & 0x02) == 0x00);
                  TIFR2 = TIFR2 \mid 0x02;
int main(void)
    DDRD = DDRD \mid (1 << 3);
    DDRB = DDRB | (1 << 3);
        DDRC |= (1 << 0);
        PORTC &= ~(1<<0);
    while(1)
                  PORTC &= ~(1<<0);
                  Timer2_asDelayIn_ms(10);
                 PORTC |= (1<<0);
                 Timer2_asDelayIn_ms(10);
}
ISR(TIMER2_COMPA_vect)
{
        PINC |= (1 << 1);
```

#### 1.13.3 Output

## ${\bf Timer 2\_ as Timer}$


- The output can be seen @ OC2A and OC2B pins with a on time of  $25.5\mu$ s and off time of  $25.5\mu$ s ( $\frac{(0x32+1)*8}{16000000} = 25.5\mu$ s).
- Also, *PC1* toglles for the **TCNT2** matches **OCR2A**.

#### $Timer2\_asDelayIn\_ms$

• The output can be seen PC0 pin.

## 1.14 TimerCounter2\_FastPWM

### 1.14.1 Circuit



#### 1.14.2 Code

```
void Timer2_NonInverting_TOP_at_MAX()
         TCCR2A = TCCR2A \mid (1 << 0);
         TCCR2A = TCCR2A \mid (1 << 1);
         TCCR2B = TCCR2B \& ~(1 << 3);
         TCCR2A = TCCR2A \mid (1 << 7);
         TCCR2A = TCCR2A \& ~(1 << 6);
         TCCR2A = TCCR2A \mid (1 << 5);
         TCCR2A = TCCR2A \& ~(1 << 4);
         TIMSK2 = TIMSK2 | (1 << 0);
         TIMSK2 = TIMSK2 | (1 << 1);
         TIMSK2 = TIMSK2 | (1 << 2);
         // Next we set values for OCR2A and OCR2B
/* Since, TCNT2 goes till max(OxFF), we can choose
         OCR2A = 0x19; // for 10% duty clcle
         OCR2B = 0xC0; // for 75% duty clcle
```

```
TCCR2B = TCCR2B \mid (1 << 0);
        TCCR2B = TCCR2B & ~(1<<1);
        TCCR2B = TCCR2B & ~(1 << 2);
        sei();
void Timer2_Inverting_TOP_at_MAX()
{
        TCCR2A = TCCR2A \mid (1 << 0);
        TCCR2A = TCCR2A \mid (1 << 1);
        TCCR2B = TCCR2B & ~(1<<3);
        TCCR2A = TCCR2A \mid (1 << 7);
        TCCR2A = TCCR2A \mid (1 << 6);
        TCCR2A = TCCR2A \mid (1 << 5);
        TCCR2A = TCCR2A \mid (1 << 4);
        TIMSK2 = TIMSK2 | (1 << 0);
        TIMSK2 = TIMSK2 | (1 << 1);
        TIMSK2 = TIMSK2 | (1 << 2);
        OCR2A = 0x19; // for 10% duty clcle
        OCR2B = OxCO; // for 75% duty clcle
        TCCR2B = TCCR2B \mid (1 << 0);
        TCCR2B = TCCR2B & ~(1<<1);
        TCCR2B = TCCR2B \& ~(1 << 2);
        sei();
void Timer2_NonInverting_TOP_at_OCR2A()
{
        TCCR2A = TCCR2A \mid (1 << 0);
        TCCR2A = TCCR2A \mid (1 << 1);
        TCCR2B = TCCR2B \mid (1 << 3);
        TCCR2A = TCCR2A \mid (1 << 5);
        TCCR2A = TCCR2A \& ~(1 << 4);
        OCR2A = 0x70; // for frequency
        OCR2B = 0x60; // for pwm duty cylc
```

```
TCCR2B = TCCR2B \mid (1 << 0);
        TCCR2B = TCCR2B \& ~(1 << 1);
        TCCR2B = TCCR2B \& ~(1<<2);
        sei();
void Timer2_Inverting_TOP_at_OCR2A()
{
        TCCR2A = TCCR2A \mid (1 << 0);
        TCCR2A = TCCR2A \mid (1 << 1);
        TCCR2B = TCCR2B \mid (1 << 3);
        TCCR2A = TCCR2A \mid (1 << 5);
        TCCR2A = TCCR2A \mid (1 << 4);
        OCR2A = Ox70; // for frequency
        OCR2B = 0x60; // for pwm duty cylc
        TCCR2B = TCCR2B \mid (1 << 0);
        TCCR2B = TCCR2B \& ~(1 << 1);
        TCCR2B = TCCR2B & ~(1<<2);
        sei();
void Timer2_OC2A_Square()
{
        TCCR2A = TCCR2A \mid (1 << 0);
        TCCR2A = TCCR2A \mid (1 << 1);
        TCCR2B = TCCR2B \mid (1 << 3);
        TCCR2A = TCCR2A \& ~(1 << 7);
        TCCR2A = TCCR2A \mid (1 << 6);
        OCR2A = 0x70; // for frequency
        TCCR2B = TCCR2B \mid (1 << 0);
        TCCR2B = TCCR2B & ~(1<<1);
        TCCR2B = TCCR2B \& ~(1<<2);
        sei();
void Timer2_FastPWMGeneration(uint32_t on_time_us, uint32_t off_time_us)
```

```
uint32_t total_time = on_time_us + off_time_us;
// MOde of operation to fast_pwm_top_max Mode -- WGM2[2:0] === 111
// WGM2[2](bit3) from TCCR2B, WGM2[1](bit1) from TCCR2A, WGM2[0](bit0) from TCCR2A
TCCR2A = TCCR2A \mid (1 << 0);
TCCR2A = TCCR2A \mid (1 << 1);
TCCR2B = TCCR2B \mid (1 << 3);
TCCR2A = TCCR2A \mid (1 << 5);
TCCR2A = TCCR2A \& ~(1 << 4);
if(total_time <=3)</pre>
         TCCR2B = TCCR2B \& ~(1<<0);
         TCCR2B = TCCR2B & ~(1 << 1);
        TCCR2B = TCCR2B \& ~(1 << 2);
else if((3 < total_time) && (total_time <= 16))</pre>
         OCR2A = ((total_time * 16) >> 0) - 1;
         OCR2B = ((on_time_us * 16) >> 0) - 1;
         TCCR2B = TCCR2B | (1<<0);
         TCCR2B = TCCR2B & ~(1<<1);
        TCCR2B = TCCR2B \& ~(1<<2);
else if((16 < total_time) && (total_time <= 128))</pre>
         OCR2A = ((total_time * 16) >> 3) - 1;
         OCR2B = ((on_time_us * 16) >> 3) - 1;
         TCCR2B = TCCR2B & ~(1<<0);
         TCCR2B = TCCR2B \mid (1 << 1);
        TCCR2B = TCCR2B \& ~(1 << 2);
else if((128 < total_time) && (total_time <= 1024))</pre>
         OCR2A = ((total_time * 16) >> 6) - 1;
         OCR2B = ((on_time_us * 16) >> 6) - 1;
         TCCR2B = TCCR2B \mid (1 << 0);
         TCCR2B = TCCR2B \mid (1 << 1);
         TCCR2B = TCCR2B & ~(1<<2);
else if((1024 < total_time) && (total_time <= 4096))</pre>
         OCR2A = ((total_time * 16) >> 8) - 1;
         OCR2B = ((on_time_us * 16) >> 8) - 1;
```

```
TCCR2B = TCCR2B & ~(1<<0);
                TCCR2B = TCCR2B \& ~(1 << 1);
                TCCR2B = TCCR2B \mid (1 << 2);
         lse if(total_time > 4096)
void PWMGeneration(double duty_cycle_percent,uint32_t frequency)
        double total_time_us = (1000000.0/frequency);
        double on_time_us = (duty_cycle_percent/100.0) * total_time_us;
        if (on_time_us<1.0)</pre>
                 on_time_us = 1;
        Timer2_FastPWMGeneration(on_time_us, total_time_us - on_time_us);
int main(void)
{
        DDRD = DDRD \mid (1 << 3);
        DDRB = DDRB | (1 << 3);
    PWMGeneration(12, 1000);
    while(1)
ISR(TIMER2_OVF_vect)
ISR(TIMER2_COMPA_vect)
ISR(TIMER2_COMPB_vect)
```

#### 1.14.3 Output

### $Timer2\_NonInverting\_TOP\_at\_MAX$

- The output can be seen @ OC2A with a frequency of 62.74 kHz( $\frac{0xFF*1}{16000000} = 15.9\mu s$ ) and duty cycle of 10% ( $\frac{10}{100} * 0xFF = 0x19$ ).
- The output can be seen @ OC2B with a frequency of 62.74 kHz( $\frac{0xFF*1}{16000000} = 15.9\mu s$ ) and duty cycle of 75% ( $\frac{75}{100} = 0xC0$ ).

## ${\bf Timer2\_Inverting\_TOP\_at\_MAX}$

• The output can be seen @ OC2A with a frequency of 62.74 kHz( $\frac{0xFF*1}{16000000} = 15.9\mu s$ ) and duty cycle of (100 - 10)% ( $\frac{10}{100} * 0xFF = 0x19$ ).

• The output can be seen @ OC2B with a frequency of 62.74 kHz( $\frac{0xFF*1}{16000000} = 15.9\mu s$ ) and duty cycle of (100 - 75)% ( $\frac{75}{100} = 0xC0$ ).

#### $Timer2\_NonInverting\_TOP\_at\_OCR2A$

• The output can be seen @ OC2B with a frequency of  $142.857 \text{ kHz} (\frac{0x70*1}{16000000} = 7\mu s)$  and duty cycle of 85% ( $\frac{85}{100} = 0x60$ ).

#### Timer2\_Inverting\_TOP\_at\_OCR2A

• The output can be seen @ *OC2B* with a frequency of 142.857 kHz( $\frac{0x70*1}{16000000} = 7\mu s$ ) and duty cycle of (100 - 85)% ( $\frac{85}{100} = 0x60$ ).

## $Timer2\_OC2A\_Square$


• The output can be seen @ OC2A with a frequency of 142.857 kHz( $\frac{0x70*1}{16000000} = 7\mu s$ ).

#### **PWMGeneration**

• The output can be seen @ O20B.

## 1.15 TimerCounter2\_PhaseCorrectedPWM

#### 1.15.1 Circuit



2

#### 1.15.2 Code

```
TCCR2A = TCCR2A \mid (1 << 5);
        TCCR2A = TCCR2A \& ~(1 << 4);
        TIMSK2 = TIMSK2 | (1 << 0);
        OCR2A = 0x19; // for 10% duty clcle
        OCR2B = 0xC0; // for 75% duty clcle
        TCCR2B = TCCR2B \mid (1 << 0);
        TCCR2B = TCCR2B & ~(1<<1);
        TCCR2B = TCCR2B & ~(1<<2);
        sei();
void Timer2_Inverting_TOP_at_MAX()
{
        TCCR2A = TCCR2A \mid (1 << 0);
        TCCR2A = TCCR2A \& ~(1 << 1);
        TCCR2B = TCCR2B & ~(1<<3);
        TCCR2A = TCCR2A \mid (1 << 7);
        TCCR2A = TCCR2A \mid (1 << 6);
        TCCR2A = TCCR2A \mid (1 << 5);
        TCCR2A = TCCR2A \mid (1 << 4);
        TIMSK2 = TIMSK2 | (1 << 0);
        // Next we set values for OCR2A and OCR2B
        and OCR2B to any value below max(0xFFF)
        OCR2A = 0x19; // for 10% duty clcle
        OCR2B = 0xC0; // for 75% duty clcle
```

```
TCCR2B = TCCR2B \mid (1 << 0);
        TCCR2B = TCCR2B & ~(1<<1);
        TCCR2B = TCCR2B & ~(1<<2);
        sei();
void Timer2_NonInverting_TOP_at_OCR2A()
{
        TCCR2A = TCCR2A \mid (1 << 0);
        TCCR2A = TCCR2A \& ~(1 << 1);
        TCCR2B = TCCR2B \mid (1 << 3);
        // COM2B[1](bit5) from TCCR2A, COM2B[0](bit4) from TCCR2A
TCCR2A = TCCR2A | (1<<5);</pre>
        TCCR2A = TCCR2A \& ~(1 << 4);
        OCR2A = 0x70; // for frequency
        OCR2B = 0x60; // for pwm duty cylc
        TCCR2B = TCCR2B \mid (1 << 0);
        TCCR2B = TCCR2B \& ~(1 << 1);
        TCCR2B = TCCR2B \& ~(1<<2);
        sei();
void Timer2_Inverting_TOP_at_OCR2A()
{
        TCCR2A = TCCR2A \mid (1 << 0);
        TCCR2A = TCCR2A \& ~(1 << 1);
        TCCR2B = TCCR2B \mid (1 << 3);
        TCCR2A = TCCR2A \mid (1 << 5);
        TCCR2A = TCCR2A \mid (1 << 4);
        OCR2A = 0x70; // for frequency
        OCR2B = 0x60; // for pwm duty cylc
        TCCR2B = TCCR2B \mid (1 << 0);
        TCCR2B = TCCR2B & ~(1<<1);
        TCCR2B = TCCR2B & ~(1<<2);
        sei();
void Timer2_OC2A_Square()
```

```
TCCR2A = TCCR2A \mid (1 << 0);
        TCCR2A = TCCR2A \& ~(1 << 1);
        TCCR2B = TCCR2B \mid (1 << 3);
        TCCR2A = TCCR2A \& ~(1 << 7);
        TCCR2A = TCCR2A \mid (1 << 6);
        // Next we set values for OCR2A and OCR2B
        OCR2A = 0x70; // for frequency
        TCCR2B = TCCR2B \mid (1 << 0);
        TCCR2B = TCCR2B & ~(1<<1);
        TCCR2B = TCCR2B & ~(1<<2);
        sei();
void Timer2_PhaseCorrectedPWMGeneration(uint32_t On_time_us, uint32_t Off_time_us)
        uint32_t total_time = (On_time_us>>1) + (Off_time_us>>1);
        uint32_t on_time_us = On_time_us >> 1;
        TCCR2A = TCCR2A \mid (1 << 0);
        TCCR2A = TCCR2A \& ~(1 << 1);
        TCCR2B = TCCR2B \mid (1 << 3);
        TCCR2A = TCCR2A \mid (1 << 5);
        TCCR2A = TCCR2A \& ~(1 << 4);
        if(total_time <=3)</pre>
        {
                OCR2A = 0;
                TCCR2B = TCCR2B & ~(1<<0);
                TCCR2B = TCCR2B \& ~(1 << 1);
                TCCR2B = TCCR2B & ~(1<<2);
        else if((3 < total_time) && (total_time <= 16))</pre>
                OCR2A = ((total_time * 16) >> 0) - 1;
                OCR2B = ((on_time_us * 16) >> 0) - 1;
                 TCCR2B = TCCR2B \mid (1 << 0);
                 TCCR2B = TCCR2B & ~(1 << 1);
                TCCR2B = TCCR2B & ~(1<<2);
        else if((16 < total_time) && (total_time <= 128))</pre>
                OCR2A = ((total_time * 16) >> 3) - 1;
```

```
OCR2B = ((on_time_us * 16) >> 3) - 1;
                TCCR2B = TCCR2B \& ~(1<<0);
                TCCR2B = TCCR2B \mid (1 << 1);
                TCCR2B = TCCR2B & ~(1<<2);
        else if((128 < total_time) && (total_time <= 1024))</pre>
                 OCR2A = ((total_time * 16) >> 6) - 1;
                OCR2B = ((on_time_us * 16) >> 6) - 1;
                TCCR2B = TCCR2B \mid (1 << 0);
                 TCCR2B = TCCR2B \mid (1 << 1);
                TCCR2B = TCCR2B \& ~(1 << 2);
        else if((1024 < total_time) && (total_time <= 4096))</pre>
                OCR2A = ((total_time * 16) >> 8) - 1;
                OCR2B = ((on_time_us * 16) >> 8) - 1;
                TCCR2B = TCCR2B \& ~(1<<0);
                TCCR2B = TCCR2B \& ~(1 << 1);
                TCCR2B = TCCR2B \mid (1 << 2);
                         }
        else if(total_time > 4096)
void PWMGeneration(double duty_cycle_percent, uint32_t frequency)
{
        double total_time_us = (1000000.0/frequency);
        double on_time_us = (duty_cycle_percent/100.0) * total_time_us;
        if (on_time_us<1.0)</pre>
                on_time_us = 1;
        Timer2_PhaseCorrectedPWMGeneration(on_time_us, total_time_us - on_time_us);
int main(void)
}
        DDRD = DDRD \mid (1 << 3);
        DDRB = DDRB | (1 << 3);
        Timer2_Inverting_TOP_at_MAX();
    while(1)
    {
```

```
}
}
ISR(TIMER2_OVF_vect)
{
}
ISR(TIMER2_COMPA_vect)
{
}
ISR(TIMER2_COMPB_vect)
{
}
```

## 1.15.3 Output

### $Timer2\_NonInverting\_TOP\_at\_MAX$

- The output can be seen @ OC2A with a frequency of  $31.372 \text{ kHz}(\frac{510*1}{16000000} = 31.8\mu s)$  and duty cycle of 10% ( $\frac{10}{100}*0xFF = 0x19$ ).
- The output can be seen @ OC2B with a frequency of  $31.372 \text{ kHz}(\frac{510*1}{16000000} = 31.8\mu s)$  and duty cycle of 75% ( $\frac{75}{100}*0xFF = 0xC0$ ).

## $Timer2\_Inverting\_TOP\_at\_MAX$

- The output can be seen @ OC2A with a frequency of  $31.372 \text{ kHz}(\frac{510*1}{16000000} = 31.8\mu s)$  and duty cycle of (100 10)%  $(\frac{10}{100} * 0xFF = 0x19)$ .
- The output can be seen @ OC2B with a frequency of  $31.372 \text{ kHz} (\frac{510*1}{16000000} = 31.8 \mu s)$  and duty cycle of (100 75)%  $(\frac{75}{100} * 0xFF = 0xC0)$ .

## $Timer0\_NonInverting\_TOP\_at\_OCR2A$

• The output can be seen @ *OC2B* with a frequency of 71.42 kHz( $\frac{(2*0x70)*1}{160000000} = 14\mu s$ ) and duty cycle of 85% ( $\frac{85}{100}$  \* 0x70 = 0x60).

### $Timer2\_Inverting\_TOP\_at\_OCR2A$

• The output can be seen @ OC2B with a frequency of 71.42 kHz( $\frac{(2*0x70)*1}{16000000} = 14\mu s$ ) and duty cycle of (100 - 85)% ( $\frac{85}{100}*0x70 = 0x60$ ).

#### Timer2\_OC2A\_Square


• The output can be seen @ OC2TiA with a frequency of 71.42 kHz( $\frac{(2*0x70)*1}{16000000} = 14\mu s$ ).

#### **PWMGeneration**

• The output can be seen @ OC2B.

## 1.16 SPI

### 1.16.1 Circuit



## 1.16.2 Code

```
void SPI_Init()
{
    DDRB |= (1<<DDB2) | (1<<DDB3) | (1<<DDB5);
    DDRB &= ~(1<<DDB4);
    PORTB &= ~(1<<PORTB3) & ~(1<<PORTB5);
    PORTB |= (1<<PORTB2);</pre>
    SPCR &= ~(1<<DORD);
    SPCR \mid = (1 << MSTR);
    SPCR &= ~(1<<CPOL);</pre>
    SPCR &= ^{(1 << CPHA)};
    SPSR &= ^{\sim}(1 << SPI2X);
    SPCR &= ^{\sim}(1 << SPR1);
    SPCR &= ~(1<<SPRO);
    SPCR &= ~(1<<SPIE);
    SPCR \mid = (1 << SPE);
uint8_t SPITransferReceive(uint8_t data_)
{
    SPDR = data_;
    while((SPSR & (1<<SPIF)) == 0 ) {};</pre>
    return SPDR;
int main(void)
```


```
{
    SPI_Init();
    PORTB &= ~(1<<PORTB2);
    SPITransferReceive('A');
    while(1)
    {
    }
}</pre>
```

## 1.16.3 Output

The Output can be seen @ the SPI debugger.

## 1.17 USART0

### 1.17.1 Circuit



## 1.17.2 Code


```
UCSROC |= (1<<UCSZ00);</pre>
    UCSROC &= ~(1<<UPMO1);
    UCSROC &= ^{(1 << \text{UPMOO})};
    UCSROC \&= ~(1 << USBSO);
    UCSROB &= ^{\sim}(1<<7);
    UCSROB &= ~(1<<6);
    UCSROB &= ^{\sim}(1 << 5);
    UCSROB |= (1<<TXENO);</pre>
    UCSROB |= (1<<RXENO);</pre>
void USARTOsendChar(uint8_t data_)
        while((UCSROA & (1<<UDREO)) == 0x00){};
        UDR0 = data_;
void USARTOsendString(uint8_t *c_data_)
        while(*c_data_ != '\0')
        {
                USARTOsendChar(*c_data_++);
uint8_t USARTOreceiveChar()
{
        while((UCSROA & (1<<RXCO)) == 0x00){};
        return UDRO;
void USARTOreceiverStringUntil(uint8_t *rec_buff,uint8_t deliminator)
        uint16_t i=0;
        uint8_t curr_char = USARTOreceiveChar();
        while(curr_char != deliminator)
                rec_buff[i] = curr_char;
                 curr_char = USARTOreceiveChar();
                 i++;
        rec_buff[i] = '\0';
int main(void)
{
        uint8_t rec_buff[1024];
        USARTOinit();
    USARTOsendString((uint8_t *)"This is working\n\r");
    while(1)
    {
        USARTOreceiverStringUntil(rec_buff, '\n');
        _delay_ms(100);
```

## 1.17.3 Output

The Output can be seen @ the Virtual Terminal.

## 1.18 TwinWireInterface

### 1.18.1 Circuit



### 1.18.2 Code

Master Code

```
uint8_t status = 0;
void I2C_Master_Init()
{
        TWBR = 72;
        TWSR &= ^{\sim}(1 << TWPSO);
        TWSR &= ^{\sim}(1 << TWPS1);
uint8_t I2C_Master_Status()
{
        return TWSR & OXF8;
uint8_t I2C_Master_START()
{
        TWCR \mid = (1 << TWEN);
        TWCR |= (1<<TWSTA);
        TWCR \mid = (1 << TWINT);
         while((TWCR & (1 << TWINT)) == 0 \times 00);
         status = I2C_Master_Status();
         if(status == 0x08)
```

```
return 0;
uint8_t I2C_Master_STOP()
{
        TWCR &= ^{\sim}(1 << TWSTA);
        TWCR |= (1<<TWSTO);
        TWCR \mid = (1 << TWINT);
        TWCR &= ^{\sim}(1 << TWSTO);
        TWCR &= ^{\sim}(1 << TWEN);
        return 0;
uint8_t I2C_Master_Mode(uint8_t slave_address, uint8_t transmiter0_receiver1)
{
        TWDR = (slave_address<<1) | transmiter0_receiver1;</pre>
        TWCR \mid = (1 << TWINT);
        while((TWCR & (1<<TWINT )) == 0x00);
        status = I2C_Master_Status();
        uint8_t status_val_checker = (transmiter0_receiver1==0) ? 0x18 : 0x40;
        if(status == status_val_checker)
        }
        {
        }
uint8_t I2C_Master_DataTransmitByte(uint8_t data_)
        TWDR = data_;
        TWCR \mid = (1 << TWINT);
        while((TWCR & (1<<TWINT )) == 0x00);
        status = I2C_Master_Status();
        if(status == 0x28)
        {
```

```
else if(status == 0x30)
        {
        }
void I2C_Master_DataTransmitString(uint8_t *cdata)
        while(*cdata != '\0')
        {
                status = I2C_Master_DataTransmitByte(*cdata++) ;
                if(status == 0)
                {
                }
                else if(status == 1)
                {
                }
        }
uint8_t I2C_Master_DataReceiveByte()
{
        uint8_t value_ = 0;
        TWCR \mid = (1 << TWINT);
        while((TWCR & (1<<TWINT )) == 0x00)
                value_ = TWDR;
        }
        status = I2C_Master_Status();
        if(status == 0x58)
                return value_;
        }
        {
void I2C_Master_DataReceiveString(uint8_t *recData,uint8_t NUMBYTE)
```

```
uint8_t i=0;
        recData[NUMBYTE] = '\0';
        while(i < NUMBYTE)</pre>
                TWCR \mid = (1 << TWEA);
                if(i==(NUMBYTE-1))
                {
                         TWCR &= ^{\sim}(1 << TWEA);
                }
                status = I2C_Master_DataReceiveByte();
                if(status==0xFF)
                         recData[i] = status;
                i++;
        }
int main(void)
{
        I2C_Master_Init();
        DDRC |= (1<<0) | (1<<1) | (1<<2);
        PORTC |= (1<<0) | (1<<1) | (1<<2);
        I2C_Master_START();
        I2C_Master_Mode(SLAVE_ADDRESS, 0);
        I2C_Master_DataTransmitString((uint8_t *)"K");
        I2C_Master_STOP();
        I2C_Master_START();
        I2C_Master_Mode(SLAVE_ADDRESS, 0);
        I2C_Master_DataTransmitString((uint8_t *)"Narendiran");
        I2C_Master_STOP();
       PINC |= (1<<2);
   while(1)
```

#### Slave Code

```
TWAR = (my_address<<1) & 0xFE;</pre>
        TWCR \mid = (1 << TWEN);
        TWCR &= ^{\sim}(1 << TWSTA);
        TWCR &= ^{(1 << TWSTO)};
uint8_t I2C_Status()
{
        return TWSR & OXF8;
}
uint8_t I2C_SlaveMode( uint8_t transmiter0_receiver1)
{
        TWCR = (1 < TWEA);
        while((TWCR & (1 << TWINT)) == 0x00);
        status = I2C_Status();
        uint8_t status_val_checker = (transmiter0_receiver1==0) ? 0xA8 : 0x60;
        if(status == status_val_checker)
        {
        }
        {
        }
uint8_t I2C_Slave_DataTransmitByte(uint8_t data_)
{
        TWDR = data_;
        TWCR \mid = (1 << TWINT);
        while((TWCR & (1<<TWINT )) == 0x00);
        status = I2C_Status();
        if(status == 0xB8)
        {
        else if(status == 0xC8)
        {
                return 2;
        }
void I2C_Slave_DataTransmitString(char *cdata)
```

```
uint8_t i = 0;
        while(cdata[i] != '\0')
                status = I2C_Slave_DataTransmitByte(cdata[i]) ;
                i++;
                if(status == 0)
                {
                }
                else if(status == 1)
                }
                {
                         return;
                }
        }
}
uint8_t I2C_Slave_DataReceiveByte()
{
        uint8_t value_ = 0;
        TWCR \mid = (1 << TWINT);
        while((TWCR & (1<<TWINT )) == 0x00)
        {
                value_ = TWDR;
        status = I2C_Status();
        if(status == 0x80)
        {
                return value_;
        }
        else if(status == 0x88)
        {
                return value_;
                return 0xFF;
        }
void I2C_Slave_DataReceiveString(uint8_t *recData,uint8_t NUMBYTE)
{
        uint8_t i=0;
        recData[NUMBYTE] = '\0';
        while(NUMBYTE > 0)
        {
                NUMBYTE = NUMBYTE - 1;
                TWCR \mid = (1 << TWEA);
                if(NUMBYTE==0)
```


```
TWCR &= ^{\sim}(1 << TWEA);
                }
                status = I2C_Slave_DataReceiveByte();
                if(status==0xFF)
                         recData[i] = status;
                i++;
int main(void)
        DDRC |= (1<<0) | (1<<1) | (1<<2);
        PORTC |= (1<<0) | (1<<1) | (1<<2);
        I2C_SlaveInit(SLAVE_ADDRESS);
        I2C_SlaveMode(1);
        uint8_t recData[11];
        I2C_Slave_DataReceiveString(recData, 1);
        TWCR &= ^{\sim}(1 << TWEN);
        if(recData[0] == 'K')
                PINC |= (1 << 0);
        I2C_SlaveInit(SLAVE_ADDRESS);
        I2C_SlaveMode(1);
        I2C_Slave_DataReceiveString(recData, 5);
        TWCR &= ^{\sim}(1 << TWEN);
        if(strcmp((char *)recData, (char *)"Naren")==0)
                PINC |= (1<<1);
    while(1)
    {
```

## 1.18.3 Output

The Output can be seen @ the I2C debugger.

# 1.19 AnalogComparator

### 1.19.1 Circuit



### 1.19.2 Code


```
void AnalogCompartorInit()
{
        ADCSRB &= ~(1<<ACME);
        ACSR &= ~(1<<ACBG);
        ACSR &= ~(1<<ACIS1);
        ACSR &= ~(1<<ACISO);
        ACSR \mid = (1 << ACIE);
        ACSR &= ~(1<<ACD);
        sei();
int main(void)
        DDRD &= ~(1<<6);
        DDRD &= ~(1<<7);
        DDRC |= (1<<0);
    while(1)
ISR(ANALOG_COMP_vect)
    PINC |= (1<<0);
```

## 1.19.3 Output

The Output can be seen @ *PC0* by changing the voltages.

# 1.20 AnalogToDigital

### 1.20.1 Circuit



### 1.20.2 Code

```
uint16_t ADC_SingleConversion(uint8_t channel_no)
{
         DDRC &= ~(1<<channel_no);</pre>
         ADMUX &= ^{(1 << REFSO)};
         ADMUX &= ^{\sim}(1 << REFS1);
         ADMUX &= ^{(1 << ADLAR)};
         ADMUX = (ADMUX & OXFO) | channel_no;
         ADCSRA &= ~(1<<ADATE);
         ADCSRA &= ~(1<<ADIE);
         ADCSRA |= (1<<ADPS2) | (1<<ADPS1);
         ADCSRA &= ~(1<<ADPSO);
// ENABLING adc
         ADCSRA \mid = (1 << ADEN);
         ADCSRA |= (1<<ADSC);
         while((ADCSRA & (1<<ADSC)))</pre>
```

```
return ADC;
volatile uint16_t free_running_value=0;
void ADC_FreeRunningInit(uint8_t channel_no)
{
        DDRC &= ~(1<<channel_no);</pre>
        ADMUX &= ~(1<<REFSO);
        ADMUX &= ^{\sim}(1 << \text{REFS1});
        ADMUX &= ^{\sim}(1 << ADLAR);
        ADMUX = (ADMUX & OXFO) | channel_no;
        ADCSRB &= ^{\sim}(1 << ADTS2);
        ADCSRB &= ~(1<<ADTS1);
        ADCSRB &= ~(1<<ADTSO);
        ADCSRA |= (1<<ADATE);
        ADCSRA |= (1<<ADIE);
        ADCSRA |= (1<<ADPS2) | (1<<ADPS1);
        ADCSRA &= ^{\sim}(1 << ADPSO);
        ADCSRA |= (1<<ADEN);
        ADCSRA |= (1<<ADSC);
        sei();
int main(void)
{
        ADC_FreeRunningInit(5);
    while(1)
    }
ISR(ADC_vect)
        free_running_value = ADC;
```


#### 1.20.3 Output

The Output can be seen @ watch windows by seeing the ADC register by changing the voltages.

# **Applications**

# 2.1 BasicLCD

## 2.1.1 Circuit




## 2.1.2 Code

## 2.1.3 Output

The Output can be seen @ the LCD display.

## 2.2 UARTLCD

## 2.2.1 Circuit




## 2.2.2 Code

# **2.2.3** Output

The Output can be seen @ the LCD display.

## 2.3 SPILCD

## 2.3.1 Circuit



## 2.3.2 Code

```
void SPILCD_init_pins()
          DDRB |= (1<<RST) | (1<<DC) | (1<<SS) | (1<<SIN) | (1<<SCK);
          PORTB |= (1<<RST); // initially let's reset</pre>
         PORTB &= ~(1<<DC); // initially command mode
PORTB |= (1<<SS); // initially disable chip
PORTB &= ~(1<<SIN); // initially SIN is O
          PORTB &= ~(1<<SCK); // initially SCK is O
void SPILCD_shiftOut( uint8_t val)
          uint8_t i;
          for (i = 0; i<8; i++)</pre>
                     if ((val & (1<<(7-i))) == 0)</pre>
                               PORTB &= ~(1<<SIN);
```

```
else
                {
                         PORTB |= (1<<SIN);
                PORTB |= (1<<SCK);
                PORTB &= ^{\sim}(1 << SCK);
        }
void SPILCD_reset_procedure()
{
        PORTB |= (1<<RST); // initially let's reset</pre>
        chip_disable;
        PORTB &= ~(1<<RST); // remove reset
        _delay_ms(100);
        PORTB |= (1<<RST); // initially let's reset</pre>
void SPILCD_send_cmd(uint8_t cmd_)
        cmd_mode;
        chip_enable;
        SPILCD_shiftOut(cmd_);
        chip_disable;
void SPILCD_send_data(uint8_t data_)
}
        data_mode;
        chip_enable;
        SPILCD_shiftOut(data_);
        chip_disable;
void SPILCD_init()
        SPILCD_init_pins();
        SPILCD_reset_procedure();
        SPILCD_send_cmd(0x21);
        SPILCD_send_cmd(0xc0);
        SPILCD_send_cmd(0x13);
```

```
SPILCD\_send\_cmd(0x07);
       SPILCD_send_cmd(0x20);
       SPILCD_send_cmd(0x0C);
       SPILCD_send_cmd(0xAA);
       SPILCD_send_cmd(0x40);
       SPILCD_send_data(0b10101010);
void SPILCD_pixel(uint8_t blank, uint8_t column)
       SPILCD_send_cmd(0x80 + column);
       SPILCD_send_cmd(0x40 + blank);
void SPILCD_demo()
       SPILCD_pixel(0,0);
       SPILCD_send_data(0b11111111);
       SPILCD_pixel(0,2);
```


```
SPILCD_send_data(0b11111111);
        SPILCD_pixel(0,4);
        SPILCD_send_data(0b11110000);
        SPILCD_pixel(0,6);
        SPILCD_send_data(0b00001111);
        SPILCD_pixel(0,8);
        SPILCD_send_data(0b11001100);
        SPILCD_pixel(0,10);
        SPILCD_send_data(0b10010010);
        for (uint8_t i=0; i<84; i++)</pre>
                SPILCD_pixel(2,0+i);
                SPILCD_send_data(0b00000001);
        for (uint8_t i=0;i<6;i++)</pre>
                SPILCD_pixel(0+i,12);
                SPILCD_send_data(0b11111111);
        uint8_t heartine[]={ 0x18, 0x3c, 0x7c, 0x3c, 0x18};
        for(uint8_t i=0;i<5;i++)</pre>
                SPILCD_pixel(3,42+i);
                SPILCD_send_data(heartine[i]);
int main(void)
{
        SPILCD_init();
        SPILCD_demo();
   while(1)
```

## **2.3.3** Output

The Output can be seen @ the LCD display.

## 2.4 I2CLCD

### 2.4.1 Circuit



#### 2.4.2 Code

```
void I2CLCD_send_cmd(uint8_t cmd_)
       I2C_Master_START();
         _delay_ms(10);
        I2C_Master_Mode(SLAVE_ADDRESS, 0);
        _delay_ms(10);
        I2C_Master_DataTransmitByte(0x00);
        _delay_ms(10);
        I2C_Master_DataTransmitByte(cmd_);
         _delay_ms(10);
        I2C_Master_STOP();
   _delay_ms(10);
void I2CLCD_send_data(uint8_t data_)
       I2C_Master_START();
        _delay_ms(10);
        I2C_Master_Mode(SLAVE_ADDRESS, 0);
        _delay_ms(10);
        I2C_Master_DataTransmitByte(0x40);
        _delay_ms(10);
       I2C_Master_DataTransmitByte(data_);
         _delay_ms(10);
       I2C_Master_STOP();
   _delay_ms(10);
void I2CLCD_init()
        I2C_Master_Init();
        I2CLCD_send_cmd(0x38);
        I2CLCD_send_cmd(0x06); // cursoR left moment and display not shift
        I2CLCD_send_cmd(0x0E); // dsiply on cursor on blink on
        I2CLCD_send_data(0x80); // BGIGIND OF libne
int main(void)
{
       I2CLCD_init();
       I2CLCD_send_data('a');
       I2CLCD_send_data('v');
   while(1)
```


```
//TODO:: Please write your application code
}
```

## 2.4.3 Output

The Output can be seen @ the LCD display.

### 2.5 I2CEEPROM

## 2.5.1 Circuit



#### 2.5.2 Code

```
uint8_t string_count=0;
        I2C_Master_START();
        I2C_Master_Mode(SLAVE_ADDRESS | block_address ,0);
       I2C_Master_DataTransmitByte(word_address);
       while(*my_str != '\0')
                string_count++;
                if (string_count==17)
                {
                        string_count = 0;
                        I2C_Master_STOP();
                        I2C_Master_START();
                        I2C_Master_Mode(SLAVE_ADDRESS | block_address ,0);
                        I2C_Master_DataTransmitByte(word_address + 16);
                I2C_Master_DataTransmitByte(*my_str++);
       I2C_Master_STOP();
uint8_t EEPROM_readByte(uint8_t block_address, uint8_t word_address)
{
        I2C_Master_START();
       I2C_Master_Mode(SLAVE_ADDRESS | block_address,0);
       I2C_Master_DataTransmitByte(word_address);
        I2C_Master_STOP();
       I2C_Master_START();
       I2C_Master_Mode(SLAVE_ADDRESS | block_address,1);
       uint8_t value_ = I2C_Master_DataReceiveByte();
        I2C_Master_STOP();
        return value_;
void EEPROM_read_string(uint8_t *redval,uint8_t lenght_,uint8_t block_address, uint8_t word_address)
       uint8_t i;
        for (i=0;i<lenght_;i++)</pre>
                 redval[i] = EEPROM_readByte(block_address, word_address + i);
       redval[i] = ' \ 0';
```

```
int main(void)
       UARTLCD_init();
       I2C_Master_Init();
       EEPROM_writeByte('A', 0, 0);
       UARTLCD_set_cursor(1,1);
       _delay_ms(10);
       char a=EEPROM_readByte(0,0);
       UARTLCD_send_data(a);
       EEPROM_writeString((uint8_t *)"abcdefghijklmnopqrstuvwxyz",0,0);
        _delay_ms(10);
       UARTLCD_set_cursor(2,1);
       uint8_t redval[50];
       EEPROM_read_string(redval, 18,0,0);
       UARTLCD_send_string((char *)redval);
       while(1)
       {
       }
```

## 2.5.3 Output

The Output can be seen @ the LCD display and EEPROM memory.

# **APPENDIX**

# Basic Setup

- The programs are compiled using *CompileAndProgram* script.
- The proteus setup is as follows:
  - CLKDIV8 Unprogrammed
  - CKOUT Unprogrammed
  - RSTDISB Unprogrammed
  - WDTON Unprogrammed
  - BOOTRST Unprogrammed
  - CKSEL Fuses (0110) External Full-swing Crystall
  - Boot Loader Size 00
  - SUT Fuses 10
  - Clock frequency 160000000

