


THE MECHANICAL ASPECTS OF ROBOTICS

http://students.iitk.ac.in/roboclub



DC Motors


- These are simple motors used for simple purpose.
- Apply +12V (generally) and they start rotating. Apply -12V and they rotate in the opposite direction!
- Speed can be reduced by reducing the voltage supplied, however that's not an efficient way of doing things.
- Torque and speed are inter-related. A
 10rpm motor has relatively high
 torque. Generally a 100rpm 300rpm
 motor is used as the wheels of a robot



Servo Motors

- They are used for specific purposes (for instance, in grippers, etc.)
- They have a restricted rotation of 180° or 360°. The least rotation angle possible is 1°.
- They are driven through microcontrollers. Power comes separately from a battery (12V, generally).
- Arduino has one line command for driving a servo. Using an Atmega PWM needs to be generated to drive a servo.
- Speed can be reduced by sending the commands at a delay. This doesn't reduce the efficiency of the motor.






Stepper Motors

- Stepper motors, unlike ordinary DC motors, are brushless and can divide a full 360° into a large number of steps, for example 200.
- Unlike servo motors, their rotation is not restricted.
- Stepper motors have got a different mechanism for rotation. The four electromagnets are activated successively and this causes the disc to rotate. Each activation results in a small rotation, called a step, generally of 1.8°.
- Again, speed can be varied by applying a delay in the control signal send to the





Encoder Motors

- High quality DC motors, with a feedback mechanism.
- The encoders can be optical or magnetic.
- They measure the rotation of the DC motor and give a feedback of the amount of rotation done, so that the rotation can be controlled.
- Finds use in situations similar to where stepper motors are used.





Circuitry (Driving the motors)

- The microcontrollers like Atmega16 and Arduino have a current rating of 5-10 mA.
- The normal DC motor's current ratings start from 150 mA and above.
- So the motor cannot be directly attached to the Atmega, hence a motor-driver is used.
- Generally, L298, L293 are used to drive simple DC motors. The servo motors already have a power cable and a different control cable which can directly be connected to the microcontrollers. L298, UART can drive the stepper motors.
- More about the circuitry will be covered in the further lectures...

The mechanical model


- Different mechanical models are made depending on the task needed to be achieved through the robot.
- This is where the innovation lies!
- While designing a mechanical model we need to think about the task, the time, the feasibility; we need to think in different dimensions.
- We shall discuss some methods of motion transference through gears and other utilities. However, implementing them is difficulty because while implementing we can face various difficulties of giving support, ensuring less friction, proper synchronization, etc. Also, arranging particular type of gears is difficult.

Rotation to linear motion

We many-a-times need some linear motion in our robots.

In the forthcoming slides I have listed some of the mechanisms that I have used. You may come up with your own!

2. Rack and Pinion



4. Conveyer Belt

This is a simple way to achieve linear motion. It doesn't have much complicacies and could be easily implemented. I used it in my robot.



Other mechanisms

Scissor mechanism



Spring mechanism

Some other useful things





Ball Bearings.

- Support for minimizing friction.
- Generally not needed, as friction is not much

Omni wheels.

 Special types of wheels is motion is desired in both x and y directions.



Castor wheels.

 Provides a one point support minimizing friction.

Thank You!

Prashant Jalan, B-306/5, 8960402355
Abhishek Attal, 273/2, 8009961678
Saket Kanodia, A326/10, 8765696051
https://www.facebook.com/groups/roboclub.iitk/http://students.iitk.ac.in/roboclub/