Method Statement

Product: Protecta FR Acrylic **Packing:** 310 ml Cartridge

Application: For Cable, cable bunch, metallic and non metallic

Pipe penetrations Through wall or Floor

Image

Description

Surface Preperation:

Ensure the faces of the aperture opening are free of dust and any other contaminants. The faces may be moistened for better adhesion.

Pipe Wrap:

For penetrants like non metallic pipes, protecta pipe wrap needs to be installed. The number of turns required depends on the diameter of the pipe.

Rockwool:

Insert the rockwool tightly into the gap between the penetrant and the cutout.



Sealant Depth:

Measure and adjust the rockwool as per the depth required for sealant installation as per certifications

Image

Description



Sealant Application:

Apply Protecta FR Acrylic sealant into the gap with an applicator gun. Put in sufficient quantity for tooling it into place.

Tooling:

Tool the sealant with the help of a spatula or any suitable tool by applying sufficient pressure that will push the sealant into the gap leaving no blank space. Clean up any excess sealant.

Repeat all the steps on other side of the wall.

Final Product