

[← Go Back](#)

Hardware

UNO R4 WiFi

Tutorials

[Arduino UNO R4 WiFi ADC Resolution](#)[Arduino UNO R4 WiFi CAN Bus](#)[Arduino UNO R4 WiFi User Manual](#)

Arduino UNO R4 WiFi Arduino Cloud Setup Guide

[Arduino UNO R4 WiFi Digital-to-Analog Converter \(DAC\)](#)[Debugging the Arduino UNO R4 WiFi](#)[Arduino UNO R4 WiFi EEPROM](#)[UNO R4 WiFi Custom Firmware Upload to ESP32 \(Advanced\)](#)[Using the Arduino UNO R4 WiFi LED Matrix](#)[Arduino UNO R4 WiFi OPAMP](#)[Arduino UNO R4 WiFi Qwiic Connector](#)[Getting Started with UNO R4 WiFi](#)[Arduino UNO R4 WiFi Real-Time Clock](#)[UNO R4 WiFi Stack Trace Debug Runtime Errors](#)[UNO R4 Capacitive-Touch Tutorial](#)[Arduino UNO R4 WiFi USB HID](#)

Home / Hardware / UNO R4 WiFi / [Arduino UNO R4 WiFi Arduino Cloud Setup Guide](#)

Arduino UNO R4 WiFi Arduino Cloud Setup Guide

A step-by-step guide on how to set up the UNO R4 WiFi with the Arduino Cloud.

Author · Hannes Siebeneicher · Last revision · 10/07/2025

The Arduino UNO R4 WiFi comes with a built-in ESP32-S3 module that enables Wi-Fi® functionality. This also means you can use it with the Arduino Cloud!

This article shows you how to set up your board and connect it to the Cloud allowing you to upload code over the air, create dashboards to monitor your data and control your Arduino board remotely.

Software & Hardware Needed

[Arduino UNO R4 WiFi](#)
[Arduino Cloud](#)

Setup and Process

 If you are new to the Arduino Cloud before check out [Getting Started With the Arduino Cloud](#).

To use the Arduino Cloud you will need to register and set up a **free**

ON THIS PAGE

Software & Hardware Needed


Setup and Process +

Summary

[Help](#)


Configure Your Board

After you have set up your account you can connect your board to your pc. Inside the Cloud Things overview click on **Create**.




Create new Thing

This will take you to the setup menu for creating your Thing. Here you can set up your device, configure your network connection and add Cloud variables. You can learn more about Cloud variables in [Getting Started With the Arduino Cloud](#). First, under associate device, click on **Select Device**.




Select Device

Then click on **Set Up New Device**.




Set Up New Device

You can now choose between three different options depending on what type of board you are using. In this case, using the UNO R4 WiFi continue by clicking on **Arduino board**.




Select Arduino

If this is your first time using the Arduino Cloud you will be asked to download the **Arduino Create Agent**. The Create Agent is a piece of software that is necessary for your Arduino board to communicate with your browser. Download and install it by clicking on download and following the installation process.



Arduino Create Agent

When the installation is finished you will see a short loading screen and once your board has been found continue by pressing **configure**.




Configure Device

Choose a name for your board and chose the network you want to connect to. Pick and add your Wi-Fi® credentials.



Network Configuration

After completing the steps in the popup you should be greeted by a prompt telling you that you can now use the board with the Arduino Cloud.



Finish set up

Network Configuration

Summary

You have now successfully set up your UNO R4 WiFi to work with the Arduino Cloud. To get started with your first IoT project, check out our [Getting Started With the Arduino Cloud](#) guide.

Suggest changes

The content on docs.arduino.cc is facilitated through a public [GitHub repository](#). If you see anything wrong, you can edit this page [here](#).

Need support?

[Help Center](#)
[Ask the Arduino Forum](#)
[Discover Arduino Discord](#)

License

The Arduino documentation is licensed under the [Creative Commons Attribution-Share Alike 4.0](#) license.

