

[← Go Back](#)

Hardware

Nano ESP32



Tutorials

[Arduino Nano ESP32 User Manual](#)[Arduino Nano ESP32 IoT Cloud Setup Guide](#)[Debugging with the Nano ESP32](#)[Device to Device Communication with ESP-NOW](#)[Getting Started with Nano ESP32](#)[Nano ESP32 Selecting Pin Configuration](#)[SPIFFS Partition on Nano ESP32](#)

[Home](#) / [Hardware](#) / [Nano ESP32](#) / [Getting Started with Nano ESP32](#)

Getting Started with Nano ESP32

A step-by-step guide to install the board package needed for the Nano ESP32.

Author · [Karl Söderby](#) · Last revision · 10/24/2024

To use the [Arduino Nano ESP32](#) board, you will need to install the Nano ESP32 board package, which is part of the [Arduino ESP32 Core](#).

To install it, you will need the Arduino IDE, which you can download from the [Arduino Software page](#). In this guide, we will use the latest version of the IDE 2.

Note: The Nano ESP32 utilizes the Arduino ESP32 Boards core based on the 2.x branch of the arduino-esp32 core, leveraging ESP-IDF version v5.1.4. Please be aware that functions and features may differ between versions, so ensure you reference the correct documentation for this setup.

ON THIS PAGE

Software & Hardware Needed

[Download & Install IDE](#)[Install Board Package](#)[Compile & Upload Sketches](#)[Summary](#)

Software & Hardware Needed

[Arduino Nano ESP32](#)[Help](#)


You can also use the



Arduino Cloud Editor which comes with all Arduino boards pre-installed.

Download & Install IDE


- 1 First, we need to download the Arduino IDE, which can be done from the [Arduino Software page](#).
- 2 Install the Arduino IDE on your local machine.
- 3 Open the Arduino IDE.




The Arduino IDE.

Install Board Package

To install the board package, open the "Board Manager" from the menu to the left. Search for Nano ESP32 and install the latest version (or the version you want to use).



Install Nano ESP32



Nano ESP32 examples.

Summary

In this tutorial, we have installed the Nano ESP32 board package, using the Arduino IDE.

For any issues regarding the Arduino ESP32 board package, please refer to the [arduino-esp32 Core](#).

Suggest changes	Need support?	License
The content on docs.arduino.cc is facilitated through a public GitHub repository. If you see anything wrong, you can edit this page here .	Help Center Ask the Arduino Forum Discover Arduino Discord	The Arduino documentation is licensed under the Creative Commons Attribution-Share Alike 4.0 license.

Was this article helpful?



