

[← Go Back](#)

Hardware

[Due](#)

<

[Home](#) / [Hardware](#) / [Due](#) / [Arduino Due Keyboard Controller](#)

ON THIS PAGE

[Keyboard Controller](#)[Hardware Required](#)[Code](#)

Arduino Due Keyboard Controller

This example demonstrates the use of the KeyboardController library.

Author • [Arduino](#) Last revision • 03/15/2023

Keyboard Controller

The Arduino Due has the ability to act as a USB host for peripherals such as a keyboard connected to the SerialUSB port. This example demonstrates the use of the KeyboardController library.

Hardware Required

[Arduino Due](#) Board

USB keyboard (note that keyboards that connect through an internal USB hub, like Apple keyboards, will not work)

Arduino IDE ([online](#) or [offline](#)).

[USBHost library](#)

Code

[Help](#)

```
1  /*
2
3  Keyboard Controller
4
5  Shows the output of
6
7  controller of an Ar
8
9  created 8 Oct 2012
10
11  by Cristian Maglie
12
13  */
14
15  // Require keyboard
16  #include <KeyboardCc
17
18  // Initialize USB Co
19
20  USBHost usb;
21
22  // Attach keyboard c
23
24  KeyboardController k
25
26  // This function int
27  void keyPressed() {
28
```

Suggest changes Need support?

The content on docs.arduino.cc is facilitated through a public GitHub repository. If you see anything wrong, you can edit this page [here](#).

[Help Center](#)
[Ask the Arduino Forum](#)
[Discover Arduino](#)
[Discord](#)

License

The Arduino documentation is licensed under the [Creative Commons Attribution-Share Alike 4.0](#) license.

Was this article helpful?

