

← Go Back

Hardware

Due ▾

Tutorials

Extended SPI Library Usage
with the Arduino Due

Due Motor Shield
Example

Arduino Due Keyboard
Controller

Mouse Controller

Due Multiple Blinks
Example

Simple Waveform
Generator with Arduino
Due

Keyboard Controller

Upgrading Firmware of the
Arduino Due Programming
Port 16U2



Home / Hardware / Due / **Due
Motor Shield Example**

Due Motor Shield Example

This example shows how to drive a DC motor in forward and backward directions, using the Arduino Due and Motor Shield.

Author · Arduino Last
revision · 03/15/2023

ON THIS PAGE

Hardware Required

Circuit

Code


Hardware Required

- Arduino Due
- Arduino Motor Shield
- DC motor
- Wall wart power supply

Circuit

To build the circuit you need to mount the Arduino Motor Shield on top of the Arduino Due. Then you have to connect the two wires that comes out of the DC motor to the screw drivers terminals of the Motor Shield channel A. Last thing connect your wall wart power supply adapter to the DC connector of the Arduino Due. You must choose it respecting the voltage requirements of your DC motor. With the fan that we used in this example we provided 12V to the board.

Then plug your Arduino board into your computer, start the Arduino IDE 1.5, and enter the code below.



Connect the DC motor.

Arduino Due, Motor Shield and fan connected together.

```
1  const int
2  PWM_A   = 3,
3  DIR_A   = 12,
4  BRAKE_A = 9,
5  SNS_A   = A0;
6
7
8  void setup() {
9    // Configure the A
10   pinMode(BRAKE_A, OU
11   pinMode(DIR_A, OUTP
12
13   // Open Serial comm
14   Serial.begin(9600);
15   Serial.println("Mot
16 }
17
18 void loop() {
19
20 // Set the outputs to
21
22   digitalWrite(BRAKE_
23   digitalWrite(DIR_A,
24
25   analogWrite(PWM_A,
26
27   delay(5000);
28   Serial.print("curre
```

Suggest changes Need support?

The content on docs.arduino.cc is facilitated through a public GitHub repository. If you see anything wrong, you can edit this page [here](#).

[Help Center](#)
[Ask the Arduino Forum](#)
[Discover Arduino](#)
[Discord](#)

License

The Arduino documentation is licensed under the [Creative Commons Attribution-Share Alike 4.0](#) license.

Was this article helpful?

