Playable Fashion: Abstract Electronic Toys Hacking the Doorbell Kaho Abe and Ramsey Nasser



Carefully open the doorbell with a philips screwdriver.



Remove cover to reveal the circuit board.



