SPARE PARTS LIST AIRTRONIC S2 COMMERCIAL AIRTRONIC M2 COMMERCIAL / AIRTRONIC M2 RECREATIONAL



This spare parts list is valid for the following engine-independent water heaters:

Air heaters for diesel fuel	Order No.	Order No. incl. EasyStart Pro
Airtronic S2, D2L, 12 V	25.2721.05.0000	25.2753.05.0000
Airtronic S2, D2L, 24 V	25.2726.05.0000	25.2754.05.0000
Airtronic M2, D4L, 12 V	25.2720.05.0000	25.2755.05.0000
Airtronic M2, D4L, 24 V	25.2729.05.0000	25.2756.05.0000
Airtronic M2, D4R, 12 V	25.2746.05.0000	25.2757.05.0000
Air heaters for petrol Order No.		Order No. incl. EasyStart Pro
Airtronic M2, B4L, 12 V	20.1987.05.0000	20.2032.05.0000





Chapter	Chapter title	J	Page
	Chapter contents		
1	Information		
	1.1 General information		3
	1.2 Reference Documents		3
	1.3 Determining the quantity required for the order		3
2	Heater		
	2.1 Spare parts diagram		4
	2.2 Spare parts list		5
3	Electrics, fuel, hot air and combustion air system		
	3.1 Spare parts diagram		6
	3.2 Spare parts list		7



1 Information

1.1 General information

This document is to be used when ordering spare parts for the heaters listed on the title page, to the exclusion of all liability claims.

Depending on the version or revision status of the heater, differences may occur compared to this documentation. Please check this before ordering the spare parts and take any possible differences into account.

1.2 Reference Documents

Technical description

Describes the function and proper installation and contains all information necessary for safe operation of the heater.

Repair instructions

Contains the necessary information for troubleshooting and for repair of the heater.

Installation recommendation

Describes vehicle-specific installation situations.

Installation Instructions Plus

Supplementary information on heaters and control units.

1.3 Determining the quantity required for the order

The information in the "quantity per unit" and "quantity per SU" (sales unit) columns is used to determine the quantity of a spare part required and the SU (sales units) to be ordered.

Quantity per unit

The number in this column indicates how many of the spare part concerned are installed in the whole unit.

Quantity per SU

The number in this column indicates how many of the spare part concerned are contained in one SU (sales unit).


Order No. (SU)

The order number refers to an SU.



2 Heater

Spare parts diagram 2.1






2.2 Spare parts list

					For	uni	t									
	Quantity	Quantity			4 L, 12 V - 20.1987.05	4 L, 12 V - 20.2032.05	2 L, 12 V - 25.2721.05	2 L, 12 V - 25.2753.05	2 L, 24 V - 25.2726.05	2 L, 24 V - 25.2754.05	4 L, 12 V - 25.2720.05	4 L, 12 V - 25.2755.05	4 L, 24 V - 25.2729.05	4 L, 24 V - 25.2756.05		4 R, 12 V - 25.2757.05
	per unit	per SU	Designation	Order No. (SU)	В	В	Ω	٥	0			O		D	0	D
2	1	1	Heat exchanger incl. seal	25.2720.99.0601 25.2721.99.0601 20.1987.99.0601	•	•	•	•	•	•		•		•	•	•
3	1	1	Combustion chamber incl. screws, <u>Item 6</u>	25.2720.99.1000 25.2721.99.1000 20.1987.99.1000	•	•	•	•		•	•	•	•	•	•	•
4	1	1	Combustion chamber seal	25.2113.06.0001 25.2069.06.0001	•	•		•	•	•	•	•	•	•	•	•
5	1	1	Grommet	25.2720.06.0002	•	•	•	•	•	•	•	•	•	•	•	•
6	4	100	Cheese-head screw M 5 x 12 Torx	Item 3	•	•	•	•	•	•	•	•	•	•	•	•
7	1	1	Blower 12 V incl. screws, ltem 8 Blower 24 V incl. screws, ltem 8	25.2720.99.1500 25.2721.99.1500 25.2746.99.1500 25.2726.99.1500	•	•	•	•	•	•	•	•			•	•
				25.2729.99.1500									•	•		
8	3	100	Cheese-head screw M 4 x 10 Torx	Item 7	•	•	•	•	•	•	•	•	•	•	•	•
9	1	1	Seal, blower	25.2720.01.0003 25.2721.01.0003	•	•	•	•	•	•	•	•	•	•	•	•
10	1	1	Cable harness heater	25.2720.99.0103	•	•	•	•	•	•	•	•	•	•	•	•
11	1	1	Control box 12 V Control box 24 V	20.1987.99.5000 25.2721.99.5000 25.2720.99.5000 25.2746.99.5000 25.2726.99.5000 25.2729.99.5000	•	•	•	•	•	•	•	•	•	•	•	•
12	3	100	Cheese-head screw M 4 x 16 Torx	25.2281.01.0031	•	•	•	•	•	•	•	•	•	•	•	•
13	1	1	Jacket shell, top	25.2113.01.0001 25.2069.01.0600	•	•	•	•	•	•	•	•	•	•	•	•
14	1	1	Grommet	25.2069.01.0001	•	•	•	•	•	•	•	•	•	•	•	•
15	1	1	Jacket shell, bottom	25.2113.01.0100 25.2069.01.0100	•	•	•	•	•	•	•	•	•	•	•	•
16	1	1	Seal, flange	25.2069.01.0002	•	•	•	•	•	•	•	•	•	•	•	•
17	1	1	Sensor, flame monitoring, overheating incl. connector	25.2720.99.4000	•	•	•	•	•	•	•	•	•	•	•	•
18	1	1	Glow plug with socket spanner, 12 V Glow plug with socket spanner, 24 V	25.2720.99.0106 25.2729.99.0106	•	•	•	•	•	•	•	•	•	•	•	•



3 Electrics, fuel, hot air and combustion air system

3.1 Spare parts diagram





3.2 Spare parts list

Countries Coun						For	unit	į									
Ouantity Ouantity						V - 20.1987.05	V - 20.2032.05	V - 25.2721.05	V – 25.	- 25.	1		V – 25.	V - 25.	V – 25.	V – 25.	
Item No. per wint Per Su		Quantity	Ouantity			-, 12	., 12	-, 12	-, 12	-, 24	-, 24	-, 12	-, 12	-, 24			3, 12
1 1	Item No.	-	-	Designation	Order No. (SU)										4	4	4
2			•				•	•									\Box
3 1 1 Bracket diagnostic connector, combi-clip 22.1000.51.4900 •	not ill.				22.4553.01.0000					•	•			•	•		
1	2	1	1	Control unit EasyStart Pro (optional)	22.1000.35.2200	•	•	•	•	•	•	•	•	•	•	•	•
The state of the	3	1	1	Bracket diagnostic connector, combi-clip	22.1000.51.4900	•	•	•	•	•	•	•	•	•	•	•	•
State Stat	4	1	1	Fuel remover	360.75.400	•	•	•	•	•	•	•	•	•	•	•	•
8 1 1 Flexible pipe 0 25 mm 360,00.006 • • • • • • • • • • • • • • • • • • •	7	1	1		360.61.274	•	٠		•	•	•	•	•	•	•	•	•
10	8	1	1		360.00.006	•	•	•	•	•	•	•	•	•	•	•	•
11	10	1	1			•	•	•	•	•	•	•	•	•	•	•	•
13						•	•	•	•	•	•	•	•	•	•	•	•
14				<u> </u>		•	•	•	•	•	•	•	•	•	•	•	•
1	10	•	•			•		•		•	•	•	•	•	•	•	
1	14	1	1	Air outlet, straight, rotatable Ø 60 mm	22.1000.01.0044			•	•	•	•						
1					22.1000.01.0052	•	•					•	•	•	•	•	•
16 1 1 Connection socket	15	1	1	Air outlet, angled, rotatable Ø 60 mm	22.1000.01.0056			•	•	•	•						
18				Ø 75 mm, Ø 90 mm	22.1000.01.0060	•	•					•	•	•	•	•	•
18	16	1	1					•	•	•	•						
18 1 1 Grille Ø 60 mm 25.1688.80.0600 volume • • • • • • • • • • • • • • • • • • •												•	•	•	•	•	
1						•	•					•	•	•	•	•	
19 1 1 Hood	18	1	1					•	•	•	•						
0 90 mm 22.1000.01.0019 0 0 0 0 0 0 0 0 0	10	1	1														H
0	19	'				•	•	Ĭ				•	•	•	•	•	
Ø 90 mm 10.2114.37.0000 •						•	•	•	•	•	•	•	•	•	•	•	•
Ø 75 mm 10.2114.34.0000 •	20	1	1	Flexible pipe Ø 60 mm	10.2114.31.0000			•	•	•	•						П
21 1 1 Exhaust silencer 25.1864.81.0100 • • • • • • • • • • • • • • • • • • •						•	•					•	•	•	•	•	•
22 1 1 Cable harness heater 25.2720.80.1100 •				Ø 75 mm	10.2114.34.0000	•	•	•	•	•	•	•	•	•	•	•	•
23 1 1 Bracket exhaust silencer, Z shape 20.1533.88.0007 •	21	1	1	Exhaust silencer	25.1864.81.0100	•	•	•	•	•	•	•	•	•	•	•	•
not ill. Bracket exhaust silencer, L shape 20.1348.03.0004 •	22	1	1	Cable harness heater	25.2720.80.1100	•	•	•	•			•	•			•	•
24 3 10 Pipe clip 22.1000.51.4400 • • • • • • • • • • • • • • • • • • •		1	1	· · · · · · · · · · · · · · · · · · ·		•	•	•	•	•	•	•	•	•	•	•	•
25 1 1 Exhaust pipe with end sleeve, flexible di = 24 mm, L = 300 mm 26 2 100 Grommet 20.1280.09.0103 • • • • • • • • • • • • • • • • • • •	not ill.					•	•	•	•	•	•	•	•	•	•	•	•
di = 24 mm, L = 300 mm 26 2 100 Grommet 20.1280.09.0103 • • • • • • • • • • • • 27 1 End sleeve, combustion air 25.1729.89.0002 • • • • • • • • • • • • • •	24	3	10	Pipe clip	22.1000.51.4400	•	•	•	•	•	•	•	•	•	•	•	•
27 1 1 End sleeve, combustion air 25.1729.89.0002 • • • • • • • • • • •	25	1	1	• •	20.1731.80.0400	•	•	•	•	•	•	•	•	•	•	•	•
	26	2	100	Grommet	20.1280.09.0103	•	•	•	•	•	•	•	•	•	•	•	•
28 1 10 Hose clip Ø 20 – 32 mm 10.2067.02.0032 • • • • • • • • • • •	27	1	1	End sleeve, combustion air	25.1729.89.0002	•	•	•	•	•	•	•	•	•	•	•	•
	28	1	10	Hose clip Ø 20 – 32 mm	10.2067.02.0032	•	•	•	•	•	•	•	•	•	•	•	•



						For	unit	t									
						12 V - 20.1987.05	12 V - 20.2032.05	12 V - 25.2721.05	12 V - 25.2753.05	24 V - 25.2726.05	24 V - 25.2754.05	12 V - 25.2720.05	12 V - 25.2755.05	24 V - 25.2729.05	24 V - 25.2756.05	, 12 V - 25.2746.05	, 12 V – 25.2757.05
	Quantity	Quantity				4 L,	4 L,	2 L,	2 L,	2 L,	2 L,	4 L,	4 L,	4 L,	4 L,	4 R	4 B
Item No.	per unit	per SU	Designation		Order No. (SU)	8	B	0	0	0		۵	0	٥	ò	ā	à
29	8	100	Hose clip	Ø 9 mm	10.2068.00.9098	•	•	•	•	•	•	•	•	•	•	•	•
30	1	1	Hose	3.5 x 3 mm	360.75.300	•	•	•	•	•	•	•	•	•	•	•	•
31	1	1	Fuse bracket		22.1000.31.0602	•	•	•	•	•	•	•	•	•	•	•	•
32	1	1	Connector metering pump		206.31.294	•	•	•	•	•	•	·	•	•	•	•	•













