
Honeywell

APM
Parameters Pocket Guide
AP09-641
09/08

CONTENTS

Introduction	2
Description of Parameter Definitions	2
Point Types	4
Algorithms	5
Parameters Per Point Type	6
Parameters Per Algorithm Type	28
Parameter Definitions	67

Introduction

This guide contains definitions of the parameters for TPN Release 681 used in the Advanced Process Manager (APM) and Network Interface Module (NIM). This guide is a condensed version of the *PM Family Parameter Reference Dictionary*.

Description of Parameter Definitions

The parameter definitions in this guide are listed alphabetically by parameter name. Each parameter Definition contains the parameter name, description, data type, access lock, default, and range.

Parameter

The **Parameter** column contains the short name (up to 8 characters) of the parameters. The parameter names are listed in alphabetical order.

Description

The **Description** column contains the long name of the parameter.

Type

Abbreviations in the **Type** column have the following meaning:

A = ASCII	I = Integer	S = String
BR = Blind Record	L = Logical	SDE = Self Def. Enumeration
e: = enumeration	P = Parameter Identifier	T = Time
E = Entity.Parameter	R = Real	U = Universal Entity.Parameter

Lock

Entries in the **Lock** column define who or what can change the parameter's value or option.

The following chart shows who/what can change the parameter's value for each access lock. Access level defines who or what is requesting a parameter value or option change.

Access Level							
Lock	Oper	Supr	Engr	Cont	APMMCc	Prog	PB
Oper	*	*	*	*	*	*	*
Supr		*	*	*	*	*	*
Eng or Eg			*	*	*	*	*
OnProc	*	*	*				
Supr/Eng		*	*				
EgOnly			*				
Prog				*	*	*	*
Eng/PB			*				*
PB						*	
View							

Note:

Cont = Continuous_Control (from a Module on the LCN)
Eng/PB = Engineer or Point Builder
EgOnly = Engineer Only
Engr or Eg = Engineer
OnProc = On Process
Oper = Operator
PB = Point Builder

APMMCc = PMM_Continuous_Control (from PMM)
Prog = CL/PM Sequence Program
Supr = Supervisor
Supr/Eng = Supervisor or Engineer
Special = see full PRD
View = Read Only

(Default) and Range
The default value and range for the parameter are listed in this column. The default value is the value assigned by the system when the user does not make an entry for the respective parameter. The default value is enclosed by parentheses (). The range of the value is listed to the right of the parentheses. See Full PRD means the explanation is lengthy; refer to the same parameter in the APM Parameter Reference Dictionary.

Point Types			
Abbreviation	Definition	Abbreviation	Definition
AnalogIn, AI	Analog Input	LLMUX	Low Level Multiplexer*
AnalogOut, AO	Analog Output	Logic	Logic
Array	Array	NIM	Network Interface Module
Box	APM Box	Numeric	Box Numeric
DevCtl	Device Control	PI	Pulse Input*
DigComp	Digital Composite	ProcMod	Process Module
DigIn, DI	Digital Input	RegCtl	Regulatory Control
DigOut, DO	Digital Output	RegPV	Regulatory PV
Flag	Box Flag	SDI	Serial Device Interface
IOP	Input/Output	SI	Serial Interface
	Processor	STI	Smart Field Transmitter*
		Timer	Box Timer
		UCN	Universal Control Network

*These are subsets of the Analog Input type

Algorithms

Abbreviation	Definition
AutoMan	Auto Manual Ctl Algo
CaLcuLtr	Calculator PV Algo
DataAcq	Data Acquisition PV Algo
FlowComp	Flow Compensation PV Algo
GenLin	General Linearity PV Algo
HiLoAvg	High-Low Average PV Algo
IncrSum	Incremental Summer Ctl Algo
MidOf3	Middle Of Three PV Algo
MulDiv	Multiply/Divide Ctl Algo
ORSel	Override Selector Ctl Algo
Pid	Proportional, Integral, and Derivative Ctl Algo
PidErfb	PID With External Reset Feedback Ctl Algo
PidFf	PID With Feedforward Ctl Algo
PidPosPr	PID With Position Proportional
PosProp	Position Proportional Ctl Algo
RampSoak	Ramp Soak Ctl Algo
RatioCtl	Ratio Control Ctl Algo
Summer	Summer PV Algo
Summer	Summer Ctl Algo
Switch	Switch Ctl Algo
TotaLizr	Totalizer PV Algo
VdtLdLag	Variable Deadtime With Lead Lag PV Algo

Parameters Per Point Type

Analog Input

The parameters of the Analog Input Data point are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	DECONF	PNTTYPE	PVHIFL	PVTV (F)
\$AUXUNIT (F)	DLYTIME (F)	PRIMMOD (F)	PVHIPR (F)	PVTVP (F)
\$CDETAIL	EUDESC	PTDESC	PVHITP (F)	RJTEMP
\$DLBADAL (F)	HIGHAL (F)	PTEXECST	PVLLFL	S1
\$HHSELECT (F)	HIGHALPR (F)	PTINAL	PVLLPR	SECVAR
\$HSELECT (F)	INPTDIR	PV	PVLLTP (F)	SENSRTYP
\$LSELECT (F)	KEYWORD	PVALDB (F)	PVLOFL	SERIALNO
\$LOSELECT (F)	LASTPV	PVALDBEU (F)	PVLOPR (F)	SFSTS
\$OLDEVDS	LOCUTOFF	PVAUTO	PVLOTP (F)	SLOTNUM
\$REALARM (F)	LRL	PVAUTOST	PVP	SLWSRCID
\$RINSELECT (F)	LRV	PVCALC	PVRAW	STATE
\$RPSSELECT (F)	MODNUM	PVCHAR	PVRAWHI	STI_EU
ALENBST (F)	NAME	PVCLAMP	PVRAWLO	STISWVER
ASSOCDSP	NODENUM	PVEUHI	PVROCNFL	STITAG
AVDELTHS	NODETYP	PVEULO	PVROCNPR (F)	TCRNGOPT
AVSTS	NTWKNUM	PVEXEUHI	PVROCNTP (F)	TF
BADPVFL (F)	OTDENBLE	PVEXEULO	PVROCPFL	TIMEBASE
BADPVPR (F)	OVERVAL (F)	PVEXHIFL	PVROCPPR (F)	UNIT
C1, C2	PIUOTDCF	PVEXLOFL	PVROCPTP (F)	URL
CJTACT	PNTFORM	PVFORMAT	PVSOURCE (F)	URV
COMMAND	PNTMODTY	PVHIFL	PVSRCOPT (F)	
CONTCUT (F)	PNTMODTY	PVHHPR (F)	PVSTS	
DAMPING	PNTSTATE	PVHHTP (F)	PVTEMP	

Analog Output

The parameters of the Analog Output Data point are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$CDETAIL	NODETYP	OPTDIR
\$MODESEL (F)	NTWKNUM	OUTIND
\$OLDEVDS	OP	PNTFORM
ASSOCDSP	OPCHAR	PNTMODTY
CASREQ (F)	OPFINAL	PNTMODTY
EUDESC	OPIN0	PNTSTATE
KEYWORD	OPIN1	PNTTYPE
LOCALMAN	OPIN2	PRIMMOD (F)
MODATTR (F)	OPIN3	PTDESC
MODE (F)	OPIN4	PTEXECST
MODEAPPL (F)	OPIN5	RCASOPT
MODEPERM (F)	OPOUT0	REDTAG (F)
MODNUM	OPOUT1	RINITREQ (F)
NAME	OPOUT2	SLOTNUM
NMODATTR (F)	OPOUT3	STDBYMAN
NMODE (F)	OPOUT4	UNIT
NODENUM	OPOUT5	

Array

The parameters of the Array Data point are listed below in alphabetical order.
This point is only available in the Full form.

\$CDETAIL	NODENUM	UNIT
AB_DATA1	NODETYP	USERID
AB_DATA2	NSTRING	
AB_DATA3	NTIME	
AB_DATA4	NTWKNUM	
ASSOCDSP	OVERLAP	
AUXDATA1	PNTFORM	
AUXDATA2	PNTNODY	
AUXDATA3	PNTTYPE	
AUXDATA4	PRIMMOD (F)	
BADPVFL (F)	PTDESC	
DEVADDR	SCANPRI	
ERRCODE	SLOTNUM	
EXTDATA	SPLOCK	
FL	STR8	
FLDESC	STR16	
FLSTIX	STR32	
FTANUM	STR64	
INITREQ	STRDESC	
IOPNUM	STRLEN	
KEYWORD	STRSTIX	
NFLAG	STSMMSG	
NN	TIME	
NNDESC	TIMEDESC	
NNUMERIC	TIMESECS	
NNSTIX	TIMESTIX	

APM Box

The parameters of the Advanced Process Manager Box Data Point are listed below in alphabetical order.

BADPVTXT	IOMCARD	LSPPXORN	NODETYP	SCANRATE
CHPINOPR	IOMCHAER	LSUCNORN	NODFSTAT	SCANPER
CRIOLORN	IOMCHASL	MDMHWREV	NPMSLOT	SECOND
CRUCNORN	IOMCHBER	MINUTE	NPVSLOT	SEQPRGSZ
CRPPXORN	IOMCHBSL	MONTH	NSTRING	SEQPROC
CTLOPT	IOMCMD	MOVPTXT	NTIME	STR8
CTLPATCH	IOMCOMER	NARRSLOT	NTIMER	SUMSLTSZ
CYCLETIM	IOMFILE	NCTLSLOT	PKGOPT	SWTCHACT
DATE	IOMOPER	NDCSLOT	PMMCHAER	TMCMD
DAY	IOMREALT	NDEVSLOT	PMMCHASL	TMPV
DB_VALID	IOMRECHN	NFASTCTL	PMMCHBER	TMSP
EUNDESC	IOMSEVER	NFASTDC	PMMCHBSL	TMRV
FL	IOMSTS	NFASTDEV	PMMCMD	TMSP
FTA1TYPE	IOMTYPE	NFASTLOG	PMMCOMER	TMSO
FTA2TYPE	IONTOKEN	NFASTPV	PMMCTLST	TMST
HOURL	IOP	NFLAG	PMMFLPOS	TMTB
IOLASTS	IOPNUM	NLOGSLOT	PMMOPER	UTSDRIFT
IOLBSTS	IOPSTR1	NN	PMMRECCH	USTSNODE
IOLCHAER	IOPSTR2	NNUMERIC	PMMSEVER	UTSTBCRV
IOLCHASL	IORECCHN	NODEASSN	PMMSFSTS	UTSTIME
IOLCHBER	IOSTKNDR	NODECMD	PMMSTS	UTSTIMST
IOLCHBSL	IOSSTS	NODECONF	POSITION	WEEKDAY
IOLCHERT IOLCMD	IOTKNSTL	NODENUM	RJTEMP	YEAR
IOLPERSW	LSIOLORN	NODESTS	SAFOPCMD	

Box Flag

The parameters of the Box Flag Data Point are listed below in alphabetical order. (F) indicates that the Parameter is applicable when the PNTFORM = Full; an * indicates that the parameter is applicable to Flag slots 1-128.

\$AUXUNIT (F)	HIGHAL (F)*	PTDESC (F)
\$CDETAIL	KEYWORD	PV
\$OFSELECT (F)	NAME	PVFL
\$REALARM (F)	NODENUM	S0BOXCLR
ALENBST (F)*	NTWKNUM	S1BOXCLR
ALPRIOR*	NODETYPE	SLOTNUM
ASSOCDSP	OFFNRMPR (F)	STATE0
BOXCLR	PNTNODTY	STATE1
CONTCUT (F)*	PNTTYPE	STATETXT
EIPPCODE (F)*	PNTFORM	UNIT
EUDESC	PRIMMOD (F)*	

Box Numeric

The parameters of the Box Numeric Data Point are listed below in alphabetical order.

\$CDETAIL	NODENUM	PTDESC
\$HISELCT (F)	NODETYP	PV
\$LOSELCT (F)	NTWKNUM	PVFORMAT
ASSOCDSP	PNTFORM	SLOTNUM
EUDESC	PNTNODTY	UNIT
KEYWORD	PNTTYPE	
NAME	PRIMMOD (F)	

Box Timer

The parameters of the Box Timer Data Point are listed below in alphabetical order.

\$CDETAIL	PRIMMOD (F)
ASSOCDSP	PTDESC
COMMAND	PV
EUDESC	RV
KEYWORD	SLOTNUM
NAME	SO
NODENUM	SP
NODETYP	STATE
NTWKNUM	TIMEBASE
PERIOD	TIMEOUTFL
PNTNODTY	UNIT
PNTTYPE	

Device Control

The parameters of the Device Control Data Point are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full

\$AUXUNIT (F)		D2	(#Inputs=2)
\$CDETAIL		D2D1_00	(#Inputs=2)
\$MODESEL	(#Outputs>0)	D2D1_01	(#Inputs=2)
\$REALARM (F)		D2D1_10	(#Inputs=2)
ACCELTIM (F)		D2D1_11	(#Inputs=2)
ALENBST (F)		D3	
ASSOCDSP		D4	
BADPVFL		D5	
BADPVPR (F)		DB_VALID	
BADPVTXT		DEADBAND	
BADSVFL	(#Inputs>0)	DEADTIME	
BADSVPR (F)		DISRC	(#Inputs>0)
BOXCLR		DODSTN	(#Outputs>0)
BYPASS		EIPPCODE (F)	
CMDDISFL		EUDESC	
CMDDISPR (F)		EVOPT (F)	(#Inputs>0)
CMDFALFL		FBTIME (F)	
CMDFALTM		FL 1-12	
CONTCUT (F)		HIGHAL	
D1	(#Inputs>0)	HIGHALPR	
D1_0	(#Inputs=1)	HISVPEAK	
D1_1	(#Inputs=1)		(Continued)

Device Control (Continued)

The parameters of the Device Control Data Point are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full

I0	(#Outputs>0)	MASKTIM	
I1	(#Outputs>0)	MAXTIM0H	
I2	(#Outputs>0)	MAXTIM1H	
INITMAN		MAXTIM2H	
INITREQ		MAXTRAN0	
KEYWORD		MAXTRAN1	
L		MAXTRAN2	
LIBADOPT		MODATTR	(#Outputs>0)
LIDESC		MODE	(#Outputs>0)
LISRC 1-12		MODEAPPL	(#Outputs>0)
LMREV		MODEPERM	(#Outputs>0)
LMSRC		MODNUM	
LOCALMAN	(#Outputs>0)	MOMSTATE	(#Outputs>0)
LODSTN 1-2		MOVVPVFL	(#Inputs>0)
LOENBL 1-2		MOVVPVXT	
LOGICSRC		NAME	
LOSRC 1-2		NI0	(#Outputs>0)
MAINDAT		NI1	(#Outputs>0)
MAINTOPT		NI2	(#Outputs>0)
MANMODFL		NMODATTR	(#Outputs>0)

(Continued)

Device Control (Continued)

Continuation of the parameters of the Device Control Data Point is listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

NMODE	(#Outputs>0)	OP	(#Outputs>0)
NN		OPCMD	(#Outputs>0)
NNINSET 1-10		OPFINAL	(#Outputs>0)
NODENUM		OPRATRFL	(#Outputs>0)
NODETYP		OROPT	(#Outputs>0)
NODINTPS		OVRCTIM	
NODOPTS		OVRDCONF	
NOLINPTS		OVRDDDESC	
NOLOPTS		OVRDI0FL	
NOPGATE		OVRD1FL	
NOSGATE		OVRD2FL	
NOSIOVRD		OVRDALOP	
NOSTATES		OVRDALPR (F)	
NOTRANS0		OVRDSIFL	
NOTRANS1		P0	(#Outputs>0)
NOTRANS2		P1	(#Outputs>0)
NSIO	(#Outputs>0)	P2	(#Outputs>0)
NTWKNUM		PAUSETIM	
OFFNRMFL		PERIOD	
OFFNRMPR (F)		PGALGID 1 - 4	

(Continued)

Device Control (Continued)

Continuation of the parameters of the Device Control Data Point is listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

PGDSTN 1 - 4		PVFL	(#Inputs>0)
PGPLSWTH 1 - 4		PVNORMAL (F)	
PGSO 1 - 4		PVNORMFL	
PIALGID 1 - 12		PVSOURCE (F)	(#Inputs>0)
PIDEADB1 - 12		PVSRCOPT (F)	(#Inputs>0)
PINN 1 - 12		PVSTATES 0 - 4	(#Inputs>0)
PISO 1 - 12		PVTXTOPT	
PISRC 1 - 12		REDTAG (F)	(#Outputs>0)
PNTFORM		RESETFL	
PNTMODTY		S0BOXCLR	
PNTNODTY		S1BOXCLR	
PNTSTATE		S2BOXCLR	
PNTTYPE		SEALOPT	
PRIMMOD (F)		SECVAR	
PTDESC		SGALGID 1 - 2	
PTEXECST (F)		SGDSTN 1 - 2	
PTINAL		SGPLSWTH 1 - 2	
PULSEWTH	(#Outputs>0)	SGSO 1 - 2	
PV	(#Inputs>0)	SI0	
PVAUTO	(#Inputs>0)	SI0ALOPT	

(Continued)

Device Control (Continued)

Continuation of the parameters of the Device Control Data Point is listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

SI0ALPR (F)	STATE2	SVHHTPP
SIALGID 1 – 12	STATTIM0	SVHIFL
SISO 1 -12	STATTIM1	SVHIPR (F)
SLOTNUM	STATTIM2	SVHITP
SO 0 - 2	STATETXT0-3	SVHITPP
SOCMD (#Outputs>0)	STCHGOPT	SVP
ST0_OP1 (#Outputs>0)	STSMMSG	SVPEAK
ST0_OP2 (#Outputs>=2)	SVALDB	SVSRC
ST0_OP3 (#Outputs>=3)	SVALDBEU	SVTV
ST1_OP1 (#Outputs>0)	SVDESC	SVTVP
ST1_OP2 (#Outputs>=2)	SVEUDISC	TRANTIM0
ST1_OP3 (#Outputs>=3)	SVEUHI	TRANTIM1
ST2_OP1 (#Outputs>0)	SVEULO	TRANTIM2
ST2_OP2 (#Outputs>=2)	SVHHFL	UNCMDFL
ST2_OP3 (#Outputs>=3)	SVHHPR (F)	UNIT
STATE0	SVHHTP	USERID
STATE1		

Digital Composite

The parameters of the Digital Composite Data Point are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$AUXUNIT (F)		D2D1_00	(#Inputs=2)
\$CDETAIL		D2D1_01	(#Inputs=2)
\$MODESEL	(#Outputs>0)	D2D1_10	(#Inputs=2)
\$OFSELECT (F)		D2D1_11	(#Inputs=2)
\$REALARM (F)		DISRC1 - 2	(#Inputs>0)
ALENBST (F)		DODSTN1 - 3	(#Outputs>0)
ALPRIOR		EIPPCODE (F)	
ASSOCDSP		EUDESC	
BADCTLPR		EVTOPT (F)	(#Inputs>0)
BADPVFL (F)	(#Inputs>0)	FBTIME (F)	
BADPVPR (F)		HIGHAL (F)	
BADPVTXT		HIGHALPR	
BOXCLR		I0	(#Outputs>0)
BYPASS	(#Outputs>0)	I1	(#Outputs>0)
CMDDISFL		I2	(#Outputs>0)
CMDDISPR (F)		I0DESC	
CMDFALFL		I1DESC	
CMDFALTM		I2DESC	
CONTCUT (F)		INITMAN	
D1	(#Inputs>0)	INITREQ	
D1_0	(#Inputs=1)	KEYWORD	
D1_1	(#Inputs=1)		
D2	(#Inputs=2)		

(Continued)

Digital Composite (Continued)

Continuation of the parameters of the Digital Composite Data Point is listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

LOCALMAN	(#Outputs>0)	NMODATTR	(#Outputs>0)
LOGICSRC		NMODE	(#Outputs>0)
MAINDAT		NODETYP	
MAINTOPT		NODINTPS	
MAXTIM0H		NODOPTS	
MAXTIM1H		NNOSIOVRD	
MAXTIM2H		NOSTATES	
MAXTRAN0		NOTRANS0	
MAXTRAN1		NOTRANS1	
MAXTRAN2		NOTRANS2	
MODATTR	(#Outputs>0)	NSIO	(#Outputs>0)
MODE	(#Outputs>0)	NTWKNUM	
MODEAPPL	(#Outputs>0)	OFFNRMFL	
MODEPERM	(#Outputs>0)	OFFNRMPR(F)	
MODNUM		OP	(#Outputs>0)
MOMSTATE	(#Outputs>0)	OPCMD	(#Outputs>0)
MOVVPVFL	(#Inputs>0)	OPFINAL	(#Outputs>0)
MOVVPVXT		OPRATRFL	(#Outputs>0)
NAME		OPSTTEXT	
NIO		OROPT	(#Outputs>0)
N11		OVRDALOP	(Continued)
N12			
NODENUM			

Digital Composite (Continued)

Continuation of the parameters of the Digital Composite Data Point is listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

OVRDALPR (F)		PTINAL	
OVRDCONF		PULSEWITH	(#Outputs>0)
OVRDESC		PV	(#Inputs>0)
OVRDI0FL		PVAUTO	(#Inputs>0)
OVRDI1FL		PVFL0 - 2	(#Inputs>0)
OVRDI2FL		PVNORMAL (F)	
OVRDSIFL		PVSOURCE (F)	(#Inputs>0)
P0	(#Outputs>0)	PVSRCOPT (F)	(#Inputs>0)
P1	(#Outputs>0)	PVSTATES0 - 4	(#Inputs>0)
P2	(#Outputs>0)	PVTXTOPT	
PAUSETIM		REDTAG (F)	(#Outputs>0)
PERIOD		RESETFL	
PNTFORM		S0BOXCLR	
PNTMODTY		S1BOXCLR	
PNTNODTY		S2BOXCLR	
PNTSTATE		SEALOPT	
PNTTYPE		SIO	
PRIMMOD (F)		SIOALOPT	
PTDESC		SIOALPR	
PTEXCST		SLOTNUM	

(Continued)

Digital Composite (Continued)

Continuation of the parameters of the Digital Composite Data Point is listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

SO	(#Outputs>0)	STATIM0
SOCMD	(#Outputs>0)	STATIM1
ST0_OP1	(#Outputs>0)	STATIM2
ST0_OP2	(#Outputs>=2)	STCHGOPT
ST0_OP3	(#Outputs>=3)	STSMMSG
ST1_OP1	(#Outputs>0)	TRANTIM1
ST1_OP2	(#Outputs>=2)	TRANTIM2
ST1_OP3	(#Outputs>=3)	UNCMDFL
ST2_OP1	(#Outputs>0)	UNIT
ST2_OP2	(#Outputs>=2)	USERID
ST2_OP3	(#Outputs>=3)	
STATE0		
STATE1		
STATE2		
STATETXT0 - 4		

Digital Input

The parameters of the Digital Input Data Point are listed below in alphabetical order. (L), (S), or (A)—parameter applies only when DITYPE = Latched, Status, or Accum. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$AUXUNIT (F)	CONTCUT (S) (F)	OFFNRMMPR (S) (F)	PVRAW
\$CDETAIL	COUNTDWN (A)	OLDAV (A)	PVSOURCE (L) (F)
\$DLYOPT	DEBOUNCE (L) (S) (A)	OVERFLOW (A)	PVSRCOPT (S) (L) (F)
\$OFSELECT (F)	DITYPE (F)	OVERVAL (A) (F)	RESETFL (A)
\$PMDLYTM	DLYTIME (S) (F)	PNTFORM	RESETVAL (A)
\$REALARM (F)	EIPPCODE (S) (L) (F)	PNTMODTY	S0BOXCLR (S) (L)
ALENBST (S) (F)	EUDESC	PNTMODTY	S1BOXCLR (S) (L)
ALMOPT (S) (F)	EVTOPT (L) (F)	PNTSTATE	SLOTNUM
ALPRIOR	HIGHAL (S)	PNTTYPE	STARTFL (A)
ASSOCDSP	INPTDIR (F)	PRIMMOD (S) (F)	STATE (A)
AV (A)	KEYWORD	PTDESC	STATE0 (S) (L)
AVTV (A)	MODNUM	PTEXECST	STATE1 (S) (L)
AVTVFL (A)	NAME	PV (S) (L)	STATETXT (S) (L)
BADPVFL (F)	NODENUM	PVAUTO (S) (L)	STOPFL (A)
BADPVPR	NODETYP	PVFL (S) (L)	UNIT
BOXCLR (L)	NTWKNUM	PVNORMAL (S) (F)	
COMMAND (A)	OFFNRMFL (S)	PVNORMFL (S)	

Digital Output

The parameters of the Digital Output Data Point are listed below in alphabetical order. (S) or (P) parameter applies only when DOTYPE = Status or Pulse Width Modulated (PWM). This point type is available only in the component form.

\$CDETAIL	NODENUM	PNTFORM	S1BOXCLR (S)
ASSOCDSP	NODETYP	PNTMODTY	SLOTNUM
DOTYPE	NTWKNUM	PNTNODTY	SO (S)
EUDESC	OFFPULSE (S)	PNTSTATE	STATE0 (S)
INITREQ	ONPULSE (S)	PNTTYPE	STATE1 (S)
KEYWORD	OP (P)	PTDESC	STDBYMAN
MODNUM	OPTDIR (P)	PTEXECST	UNIT
NAME	PERIOD (P)	S0BOXCLR (S)	

Input/Output Processor

The parameters of the Input/Output Processor Point are listed below in alphabetical order.

CALIBALL	IOMSTS	STDBYSTS
CALIBRJ	IONTOKEN	SWTCHACT
FAILOPT	IOPSTR1	WARMSTRT
FTAPRES	IOPSTR2	
FREQ6050	IORECCHN	
IOMACTYP	LINEPERD	
IOMFWREV	MAXSLOTS	
IOMHWREV	NODETYP	
IOMLHFST	PIUOTDCF	
IOMOPER	RJRAW	
IOMTYPE	SLOT0SF	

Logic

The parameters of the Logic Data Point (otherwise referred to as the Logic Slot) are listed below in alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$AUXUNIT (F)	DLYTIME 1-24	NTWKNUM	STMSG
\$CDETAIL	EIPPCODE (F)	PERIOD	UNIT
\$REALARM (F)	FL1-12	PNTFORM	USERID
ALENBST	GENDESC 1-12 (F)	PNTMODTY	
ASSOCDSP	HIGHAL	PNTNODTY	
C1DESC	HIGHALPR	PNTSTATE	
C2DESC	L1-12	PNTTYPE	
C3DESC	LIBADOPT	PRIMMOD (F)	
C4DESC	LISRC 1-12	PRMDESC 1 -12 (F)	
C1FL	LODSTN 1-12	PTDESC	
C2FL	LOENBL 1-12	PTEXECST	
C3FL	LOGALGID 1-16	PTINAL	
C4FL	LOGMIX	R1 1-24	
C1PR	LOSRC 1-12	R2 1-24	
C2PR	MODNUM	S1 1-24	
C3PR	NAME	S1REV 1-24	
C4PR	NN1-8	S2 1-24	
C1SRC	NODENUM	S2REV 1-24	
C2SRC	NODESC (F)	S3 1-24	
C3SRC	NODETYP	S3REV 1-24	
C4SRC	NOLINPTS	S4 1-24	
CONTCUT	NOLOGBLK	SLOTNUM	
DEADBAND 1-24	NOLOPTS	SO 1-24	

Process Module

The parameters of the Process Module Data Point are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$CDETAIL	OVERSTEP	SEQSLTSZ
ABHEMSD	PERIOD	SLOTNUM
ABHHOLD	PHASE	SNAME 1-2
ABHRSTR	PHASEAL	SPLOCK
ABHSHDN	PHASETIM	SSTEP 1-2
ACP (F)	PHREMTIM	SSTMT 1-2
ALPRIOR (F)	PNTFORM	STATMENT
ANAME 1-3	PNTTYPE	STEP
ASSOCDSP	PRIMMOD (F)	STR8 1-16
ASTEP 1-3	PROCMOD	STR16 1-8
ASTMT 1-3	PTDESC	STR32 1-4
CNTLLOCK	RESTART	STR64 1-2
FL 1-27	RSTROPT	STRLEN
MSGPEND	RUNSTATE	STSMMSG
NAME (F)	SEQERR	SUSPSTAT
NN 1-80	SEQEXEC	SUSPTIM
NODENUM	SEQMODE	TIME 1-4
NODETYP	SEQNAME	UNIT
OVERPHAS	SEQOBSZ	USERID
OVERSTAT	SEQPR (F)	

Some of the parameters in the listing above are arrays that are not defined in this publication.

UCN Network

The parameters of the UCN Network Data Point are listed below in alphabetical order.

CHPINHWY
CLPZMXC
CLPZMXP
HWYCTLST
LOADSCOP
MSGTXT 0-15
NIMADDR
NIMREV
NIMVERS
NMSGTXT
TIMESYNC
UPGRADE

UCN Node Data Point

The parameters of the UCN Node Data Point are listed below in alphabetical order.

\$UCNLSB 1-50
CABLESTS
CLPZMXC
CLPZMXP
LOADSCOP
MDMHWREV
MODNUM
NMSGTXT
NODESTAT
NODESTS
NODETYP
TIMESYNC
UCNRECHN
UPGRADE
UTSDRIFT
UTSNODE
UTSTBCRV
UTSTIME
UTSTIMST

Parameters Per Algorithm Type

Auto Manual

The parameters of the Auto Manual algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$AUXUNIT (F)	CONTCUT (F)	KEYWORD
\$CDETAIL	CTLALGID	LOCALMAN
\$DLBADAL (F)	CTLEQN	MANMODFL
\$MODESEL	CTRLINIT	MODATTR
\$REALARM (F)	CV	MODE
ALENBST (F)	CVEUHI	MODEAPPL
ARWNET	CVEULO	MODEPERM
ARWOP	DLYTIME (F)	MODNUM
ASSOCDSP	ESWAUTO	NAME
AUTOMODFL	ESWCAS	NMODATTR
B	ESWENBST	NMODE
B0	ESWMAN	NOCINPTS
BADCTLFL	EUDESC	
BADCTLPR (F)	EXTSWOPT	(Continued)
CASREQ	HIGHAL (F)	
CIDSTN	HIGHALPR (F)	
CISRC	INITMAN	
CODSTN	K	

Auto Manual (Continued)

NOCOPTS	PTORST
NODENUM	RARWSTS
NODETYP	RATEL
NTWKNUM	RCASOPT
OP	RCASSHED
OPALDB (F)	REDTAG (F)
OPEU	RINITREQ
OPHAFL (F)	RINITVAL
OPHIFL	SAFEOP
OPHILM	SHEDMODE
OPHIPR (F)	SHEDTIME
OPHITP (F)	SHUTDOWN
OPLAFL (F)	SLOTNUM
OPLOFL	STDBYMAN
OPLOLM	STSMMSG
OPLOPR (F)	UNIT
OPLOTP (F)	USERID
OPMCHLM	X1
OPRATRFL	X2
OPROCLM	XEUHI
OUTIND	XEULO
OVERVAL (F)	
PERIOD	
PNTFORM	
PNTMODTY	
PNTNODTY	
PNTSTATE	
PNTTYPE	
PRIMMOD (F)	
PTDESC (F)	
PTEXECST	
PTINAL	

Calculator

The parameters of the Calculator PV algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	LASTPV	PNTNODTY
\$AUXUNIT (F)	MODNUM	PNTSTATE
\$CDETAIL	N	PNTTYPE
\$DLBADAL (F)	NAME	PRIMMOD (F)
\$HISELCT (F)	NODENUM	PTDESC (F)
\$HHSELCT (F)	NODETYP	PTEXECST
\$LOSELCT (F)	NOPINPTS	PTINAL
\$LSELCT (F)	NTWKNUM	
\$REALARM (F)	OVERVAL (F)	
\$RNSLCT (F)	P1	(Continued)
\$RPSLCT (F)	P1STS	
ALENBST (F)	P2	
ASSOCDSP	P2STS	
BADPVFL (F)	P3	
BADPVPR (F)	P3STS	
C1	P4	
C2	P4STS	
C3	P5	
C4	P5STS	
CALCEXP	P6	
CONTCUT (F)	P6STS	
DLYTIME (F)	PERIOD	
EUDESC (F)	PIDSTN	
HIGHAL (F)	PISRC	
HIGHALPR (F)	PNTFORM	
KEYWORD	PNTMODTY	

Calculator (Continued)

PV
PVALDB (F)
PVALDBEU (F)
PVALGID
PVAUTO
PVAUTOST
PVCALC
PVCLAMP
PVEUHI
PVEULO
PVEUEUHI
PVEUEULO
PVEXHIFL
PVEXLOFL
PVFORMAT
PVHHFL

PVHHPR (F)
PVHHTP (F)
PVHIFL
PVHIPR (F)
PVHITP (F)
PVINIT
PVLLFL
PVLLPR (F)
PVLLTP (F)
PVLOFL
PVLOPR (F)
PVLOTP (F)
PVP
PVROCNFL
PVROCNPR (F)
PVROCNTF (F)

PVROCPVFL
PVROCPPR (F)
PVROCTP (F)
PVSGCTP (F)
PVSOURCE (F)
PVSRCOPT (F)
PVSTS
PVTV (F)
PVTVP (F)
SCHSTS
SLOTNUM
STSMMSG
TF
UNIT
USERID

Data Acquisition

The parameters of the Data Acquisition PV algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	NAME	PVALGID	PVLOPR (F)
\$AUXUNIT (F)	NODENUM	PVAUTO	PVLOTP (F)
\$CDETAIL	NODETYP	PVAUTOST	PVP
\$DLBADAL (F)	NORINPTS	PVCALC	PVROCNFL
\$HISELCT (F)	NTWKNUM	PVCLAMP	PVROCNPR (F)
\$HHESELCT (F)	OVERVAL (F)	PVEUHI	PVROCNTP (F)
\$LOSELCT (F)	P1	PVEULO	PVROCPVFL
\$LLESELCT (F)	P1STS	PVEXEUHI	PVROCPPPR (F)
\$REALARM (F)	PERIOD	PVEXEULO	PVROVPTP (F)
\$RNESELCT (F)	PIDSTN	PVEXHIFL	PVSGCHTP (F)
\$RPSELCT (F)	PISRC	PVEXLOFL	PVSOURCE (F)
ALENBST (F)	PNTFORM	PVFORMAT	PVSRCOPT (F)
ASSOCDSP	PNTMODTY	PVHHFL	PVSTS
BADPVFL	PNTNODTY	PVHHPR (F)	PVTV (F)
BADPVPR (F)	PNTSTATE	PVHHTP (F)	PVTVP (F)
CONCUT (F)	PNTTYPE	PVHIFL	SLOTNUM
DLYTIME (F)	PRIMMOD (F)	PVHIPR (F)	STSMMSG
EUDESC	PTDESC (F)	PVHITP (F)	TF
HIGHAL (F)	PTEXECST	PVINIT	UNIT
HIGHALPR (F)	PTINAL	PVLLFL	USERID
KEYWORD (F)	PV	PVLLPR (F)	
LASTPV	PVALDB (F)	PVLLTP (F)	
MODNUM	PVALDBEU (F)	PVLOFL	

Flow Compensation

The parameters of the Flow Compensation PV algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	EUDESC (F)	PNTNODTY
\$AUXUNIT (F)	F	PNTSTATE
\$CDETAIL	FSTS	PNTTYPE
\$DLBADAL (F)	G	PRIMMOD (F)
\$HISELECT (F)	GSTS	PSTS
\$HHSELECT (F)	HIGHAL (F)	PTDESC
\$LOSELECT (F)	HIGHALPR (F)	PTEXECST
\$LLSELECT (F)	KEYWORD	PTINAL
\$REALARM (F)	LASTPV	PV
\$RNSELECT (F)	MODNUM	PVALDB (F)
\$RPSELECT (F)	NAME	PVALDBEU (F)
ALENBST (F)	NODENUM	PVALGID
ASSOCDSP	NODETYP	PVAUTO
BADPVFL	NOPINPTS	PVAUTOST
BADPVPR (F)	NTWKNUM	PVCALC
C	OVERVAL (F)	PVCHAR
C1	P	PVCLAMP
C2	PERIOD	PVEQN
COMPHLM	P0	
COMPLLM	PIDSTN	
COMPTerm	PISRC	
CONTCUT (F)	PNTFORM	
DLYTIME (F)	PNTMODTY	

(Continued)

Flow Compensation (Continued)

PVEUHI	PVLOFL	QSTS
PVEULO	PVLOPR (F)	RG
PVEXEUHI	PVLOTP (F)	RP
PVEXEULO	PVP	RQ
PVEXHIFL	PVROCNFL	RT
PVEXLOFL	PVROCNPR (F)	RX
PVFORMAT	PVROCNTP (F)	SLOTNUM
PVHHFL	PVROCPFL	STSMMSG
PVHHPR (F)	PVROCPPR (F)	T
PVHHTP (F)	PVROCPTP (F)	T0
PVHIFL	PVSGCHTP (F)	TF
PVHIIPR (F)	PVSOURCE (F)	TSTS
PVHITP	PVSRCOPT (F)	UNIT
PVINIT	PVSTS	USERID
PVLLFL	PVTV (F)	X
PVLLPR (F)	PVTVP (F)	XSTS
PVLLTP (F)	Q	

General Linearization

The parameters of the General Linearization PV algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	IN3	OUT5
\$AUXUNIT (F)	IN4	OUT6
\$CDETAIL	IN5	OUT7
\$DLBADAL (F)	IN6	OUT8
\$HISELECT (F)	IN7	OUT9
\$HHSELECT (F)	IN8	OUT10
\$LOSELECT (F)	IN9	OUT11
\$LSELECT (F)	IN10	OUT12
\$REALARM (F)	IN11	OVERVAL (F)
\$RSELECT (F)	IN12	P1
\$RPSELECT (F)	KEYWORD	P1STS
ALENBST (F)	LASTPV	PERIOD
ASSOCDSP	MODNUM	PIDSTN
BADPVFL (F)	NAME	PISRC
BADVPR (F)	NODENUM	PNTFORM
CONTCUT (F)	NODETYP	PNTMODTY
DLYTIME (F)	NOPINPTS	PNTMODTY
EUDESC	NTWKNUM	PNTSTATE
HIGHAL (F)	OUT0	
HIGHALPR (F)	OUT1	
IN0	OUT2	
IN1	OUT3	
IN2	OUT4	

(Continued)

General Linearization (Continued)

PNTTYPE	PVEXLOFL	PVROCNTP (F)
PRIMMOD (F)	PVFORMAT	PVROCPFL
PTDESC (F)	PVHHFL	PVROCPPR (F)
PTEXECST	PVHHPR (F)	PVROCPTP (F)
PTINAL	PVHHTP (F)	PVSGCHTP (F)
PV	PVHIFL	PVSOURCE (F)
PVAUTO	PVHIPR (F)	PVSRCOPT (F)
PVALDB (F)	PVHITP (F)	PVSTS
PVALDBEU (F)	PVINIT	PVTVP (F)
PVALGID	PVLLFL	PVTVP (F)
PVAUTOST	PVLLPR (F)	SEGTOT
PVCALC	PVLLTP (F)	SLOTNUM
PVCLAMP	PVLOFL	STSMMSG
PVEUHI	PVLOPR (F)	TF
PVEULO	PVLOTP (F)	UNIT
PVEXEUHI	PVP	USERID
PVEXEULO	PVROCNFL	
PVEXHIFL	PVROCNPR (F)	

High-Low Average

The parameters of the High-Low Average PV algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	NMIN	PTEXECST
\$AUXUNIT (F)	NODENUM	PTINAL
\$CDETAIL	NODETYP	PV
\$DLBADAL (F)	NOPINPTS	PVALDB (F)
\$HISELECT (F)	NTWKNUM	PVALDBEU (F)
\$HHSELECT (F)	OVERVAL (F)	PVALGID
\$LOSELECT (F)	P1	PVAUTO
\$LLSELECT (F)	P1STS	PVAUTOST
\$REALARM (F)	P2	PVCALC
\$RNSELECT (F)	P2STS	PVCLAMP
\$RPSELECT (F)	P3	PVEQN
ALENBST (F)	P3STS	PVEUHI
ASSOCDSP	P4	PVEULO
BADPVFL (F)	P4STS	PVEXEUHI
BADPVPR (F)	P5	PVEXEULO
CONTCUT (F)	P5STS	PVEXHIFL
DLYTIME (F)	P6	PVEXLOFL
EUDESC	P6STS	PVFORMAT
FORCE	PERIOD	PVHHFL
FRCPERM	PIDSTN	
FSELIN	PISRC	(Continued)
HIGHAL (F)	PNTFORM	
HIGHALPR (F)	PNTMODTY	
KEYWORD	PNTNODTY	
LASTPV	PNTSTATE	
MODNUM	PNTTYPE	
N	PRIMMOD (F)	
NAME	PTDESC (F)	

High-Low Average (Continued)

PVHHPR (F)
PVHHTP (F)
PVHIFL
PVHIPR (F)
PVHITP (F)
PVINIT
PVLLFL
PVLLPR (F)
PVLLTP (F)
PVLOFL
PVLOPR (F)

PVLOTP (F)
PVP
PVROCNFL
PVROCNPR (F)
PVROCNTP (F)
PVROCPFL
PVROCPPR (F)
PVROCPTP (F)
PVSGCHTP (F)
PVSOURCE (F)
PVSRCOPT (F)

PVSTS
PVTVP (F)
PVTVP (F)
SELINP
SLOTNUM
STSMMSG
TF
UNIT
USERID

Incremental Summer

The parameters of the Incremental Summer control algorithm are listed below in alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$AUXUNIT (F)	CTRLINIT	KEYWORD
\$CDETAIL	CV	LOCALMAN
\$MODESEL	CVEUHI	M
\$REALARM (F)	CVEULO	MANMODFL
ALENBST (F)	DELCV	MODATTR
ARWNET	ESWAUTO	MODE
ARWOP	ESWCAS	MODEAPPL
ASSOCDSP	ESWENBST	MODEPERM
AUTMODFL	ESWMAN	MODNUM
BADCTLFL	EUDESC	NAME
BADCTLPR (F)	EXTSWOPT	NMODATTR
BCAMODFL	HIGHAL (F)	NMODE
CASREQ	HIGHALPR (F)	NOCINPTS
CIDSTN	INITMAN	
CISRC	K1	
CODSTN	K2	
CONTCUT (F)	K3	
CTLALGID	K4	

(Continued)

Incremental Summer (Continued)

NOCOPTS
NODENUM
NODETYP
NTWKNUM
OP
OPALDB (F)
OPEU
OPHAFL (F)
OPHIFL
OPHILM
OPHIPR (F)
OPHITP (F)
OPLAFL (F)
OPLOFL
OPLOLM
OPLOPR (F)
OPLOTP (F)
OPMCHLM

OPRATRFL
OPROCLM
OVERVAL (F)
PERIOD
PNTFORM
PNTMODTY
PNTNODTY
PNTSTATE
PNTTYPE
PRIMMOD (F)
PTDESC
PTEXECST
PTINAL
PTORST
RARWSTS
RCASOPT
RCASSHED
REDTAG (F)

RINITREQ
RINITVAL
SAFEOP
SHEDMODE
SHEDTIME
SHUTDOWN
SLOTNUM
STDBYMAN
STSMMSG
UNIT
USERID
X1
X2
X3
X4
XEUHI
XEULO

Middle-Of-3

The parameters of the Middle-Of-3 PV algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	NODENUM	PVALDB (F)	PVLLTP (F)
\$AUXUNIT (F)	NODETYP	PVALDBEU (F)	PVLOFL
\$CDETAIL	NOPINPTS	PVALGID	PVLOPR (F)
\$DLBADAL (F)	NTWKNUM	PVAUTO	PVLOTP (F)
\$HISELECT (F)	OVERVAL (F)	PVAUTOST	PVP
\$HHSELECT (F)	P1	PVCALC	PVROCNEFL
\$LOSELECT (F)	P1STS	PVCLAMP	PVROCNP (F)
\$LSELECT (F)	P2	PVEQN	PVROCNT (F)
\$REALARM (F)	P2STS	PVEUHI	PVROCPFL
\$RSELECT (F)	P3	PVEULO	PVROCPPR (F)
\$RPSELECT (F)	P3STS	PVEXEUHI	PVROCTP (F)
ALENBST (F)	PERIOD	PVEXEULO	PVSGCHTP (F)
ASSOCDSP	PIDSTN	PVEXHIFL	PVSOURCE (F)
BADPVFL (F)	PISRC	PVEXLOFL	PVSRCOPT (F)
BADPVPR (F)	PNTFORM	PVFORMAT	PVSTS
CONTCUT (F)	PNTMODTY	PVHHFL	PVTV (F)
DLYTIME (F)	PNTNODTY	PVHHPR (F)	PVTV (F)
EUDESC (F)	PNTSTATE	PVHHTP (F)	SELINP
HIGHAL (F)	PNTTYPE	PVHIFL	SLOTNUM
HIGHALPR (F)	PRIMMOD (F)	PVHIPR (F)	STSMMSG
KEYWORD	PTDESC	PVHITP (F)	TF
LASTPV	PTEXECST	PVINIT	UNIT
MODNUM	PTINAL	PVLLFL	USERID
NAME	PV	PVLLPR (F)	

Override Selector

The parameters of the Override Selector control algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$AUXUNIT (F)	CISRC	LOCALMAN
\$CDETAIL	CODSTN	M
\$DLBADAL (F)	CONTCUT (F)	MANMODFL
\$MODESEL	CTALGID	MODATTR
\$REALARM (F)	CTLEQN	MODE
ALENBST (F)	CTRLINIT	MODEAPPL
ARWNET	CV	MODEPERM
ARWOP	CVEUHI	MODNUM
ASSOCDSP	CVEULO	NAME
AUTMODFL	DLYTIME (F)	NMODATTR
BADCTLFL	ESWALTO	NMODE
BADCTLOP	ESWCAS	NOCINPTS
BADCTLPR (F)	ESWENBST	
BYPASS	ESWMAN	
BYPASSX1	EUDESC	
BYPASSX2	EXTSWOPT	
BYPASSX3	HIGHAL (F)	(Continued)
BYPASSX4	HIGHALPR (F)	
CASREQ	INITMAN	
CIDSTN	KEYWORD	

Override Selector (Continued)

NOCOPTS	OPROCLM	RINITREQ
NODENUM	OROFFSET	RINITVAL
NODETYP	OROPT	SAFEOP
NTWKNUM	OVERVAL (F)	SELXINP
OP	PERIOD	SHEDMODE
OPALDB (F)	PNTFORM	SHEDTIME
OPEU	PNTMODTY	SHUTDOWN
OPHAFL (F)	PNTNODTY	SLOTNUM
OPHIFL	PNTSTATE	STDBYMAN
OPHILM	PNTTYPE	STSMMSG
OPHIPR (F)	PRIMMOD (F)	UNIT
OPHITP (F)	PTDESC (F)	USERID
OPLAFL (F)	PTEXECST	X1
OPLOFL	PTINAL	X2
OPLOLM	PTORST	X3
OPLOPR (F)	RARWSTS	X4
OPLOTP (F)	RCASOPT	XEUHI
OPMCHLM	RCASSHED	XEULO
OPRATRFL	REDTAG (F)	

Pid

The parameters of the Pid control algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	ARWOP	CVEUHI	K	NMODATTR
\$AUXUNIT (F)	ASPPROC (F)	CVEULO	KEXT	NMODE
\$CDETAIL	ASSOCDSP	DELCV	KEYWORD	NOCINPTS
\$DHSELECT (F)	AUTMODFL	DEV	KGAP	NOCOPTS
\$DLBADAL (F)	BADCTFL	DEVHIFL	KLIN	NODENUM
\$DLSELECT (F)	BADCTLOP	DEVHIPR (F)	KNL	NODETYP
\$HISELCT (F)	BADPVFL	DEVHITP (F)	LASTPV	NTWKNUM
\$HHSELECT (F)	BADPVPR (F)	DEVLOFL	LMSRC	OP
\$LOSELCT (F)	BIAS	DEVLOPR (F)	LOCALMAN	OPALDB (F)
\$LSELECT (F)	BSHILM	DEVLOTP (F)	MANMODFL	OPCMD
\$MODESEL	BSLOLM	DLYTIME (F)	MANOPCMD	OPEU
\$REALARM (F)	CASREQ	ESWAUTO	MANOPTIME	OPHAFL (F)
\$RNSLCT (F)	CIDSTN	ESWCAS	MAXPULSE	OPHIFL
\$RPSLCT (F)	CISRC	ESWENBST	MODATTR	OPHILM
ADVDEVFL	CODSTN	ESWMAN	MODE	OPHIPR (F)
ADVDEVPR (F)	CONTCUT (F)	EUDESC	MODEAPPL	OPHISRC
ADVDEVTP (F)	CTLACTN	EXTSWOPT	MODEPERM	OPHITP (F)
ADVSP (F)	CTLALGID	GAINOPT	MODNUM	(Continued)
ADVSP (F)	CTLEQN	GAPHI	NAME	
ALENBST (F)	CTRLINIT	HIGHALPR (F)	NLFM	
ARWNET	CV	INITMAN	NLGAIN	

Pid (Continued)

OPLAFL (F)	PVALDBEU (F)	PVROCPFL	SHEDTIME
OPLOFL	PVAUTO	PVROCPPR (F)	SHUTDOWN
OPLOLM	PVAUTOST	PVROGCTP (F)	SLOTNUM
OPLOPR (F)	PVEUHI	PVSGCHTP (F)	SP
OPLOSRC	PVEULO	PVSOURCE (F)	SPEUHI
OPMCHLM	PVFORMAT	PVSRCOPT (F)	SPEULO
OPRATRFL	PVHHFL	PVSTS	SPFORMAT
OPROCLM	PVHHPR (F)	PVTRACK	SPHIFL
OVERVAL (F)	PVHHTP (F)	RAMPTIME	SPHILM
PERIOD	PVHIFL	RARWSTS	SPLOFL
PIDFORM	PVHIPR (F)	RATIO	SPLOLM
PNTFORM	PVHITP (F)	RBOPT	SPOPT
PNTMODTY	PVLLFL	RCASOPT	SPP
PNTNODTY	PVLLPR (F)	RCASSHED	SPTV
PNTSTATE	PVLLTP (F)	REDTAG (F)	SPTVP
PNTTYPE	PVLOFL	RINITREQ	STDBYMAN
PTDESC	PVLOTP (F)	RINITVAL	STSMG
PTEXECST	PVLOPR (F)	RTHILM	T1
PTINAL	PVP	RTLQLM	T2
PTORST	PVROCNFL	SAFEOP	TVPROC
PV	PVROCNPR (F)	SAFOPCMD	UNIT
PVALDB (F)	PVROCNTN (F)	SHEDMODE	USERID

Pid With External Reset Feedback

The parameters of the Pid With External Reset Feedback control algorithm are listed below in Alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	BADCTLFL	DEVLOPR (F)	MODATTR
\$AUXUNIT (F)	BADCTLOP	DEVLOTP (F)	MODE
\$CDETAIL	BADPVFL	DLYTIME (F)	MODEAPPL
\$DHSELECT (F)	BADPVPR (F)	ESWAUTO	MODEPERM
\$DLBADAL (F)	BIAS	ESWCAS	MODNUM
\$DLSELECT (F)	BSHILM	ESWENBST	NAME
\$HSELECT (F)	BSLOLM	ESWMAN	NLFM
\$HHSELECT (F)	CASREQ	EUDESC (F)	NLGAIN
\$LOSELECT (F)	CIDSTN	EXTSWOPT	NMODATTR
\$LLSELECT (F)	CISRC	GAINOPT	NMODE
\$MODESEL	CODSTN	GAPHI	NOCINPTS
\$REALARM (F)	CONTCUT (F)	GAPLO	NOCOPTS
\$RNSLECT (F)	CTLACTN	HIGHAL (F)	NODENUM
\$RPSELECT (F)	CTLALGID	HIGHALPR (F)	NODETYP
ADVDEVFL	CTLEQN	INITMAN	NTWKNUM
ADVDEVPR (F)	CTRLINIT	K	OP
ADVDEVTP	CV	K1	OPALDB (F)
ADVSP (F)	CVEUHI	KEXT	OPEU
ADVSPPP (F)	CVEULO	KEYWORD	OPHAFL (F)
ALENBST (F)	DELCV	KGAP	OPHIFL
ARWNET	DEV	KLIN	(Continued)
ARWOP	DEVHIFL	KNL	
ASPPROC (F)	DEVHIPR (F)	LASTPV	
ASSOCDSP	DEVHITP (F)	LOCALMAN	
AUTMODFL	DEVLOFL	MANMODFL	

Pid With External Reset Feedback (Continued)

OPHILM	PVALDB (F)	PVROCPPR (F)	SLOTNUM
OPHIPR (F)	PVALDBEU (F)	PVROCPTP (F)	SP
OPHITP (F)	PVAUTO	PVSGCHTP (F)	SPEUHI
OPLAFL (F)	PVAUTOST	PVSOURCE (F)	SPEULO
OPLOFL	PVEUHI	PVSRCOPT (F)	SPFORMAT
OPLOLM	PVEULO	PVSTS	SPHIFL
OPLOPR (F)	PVFORMAT	PVTRACK	SPHILM
OPLOTP (F)	PVHHFL	RAMPTIME	SPLOFL
OPMCHLM	PVHHPR (F)	RARWSTS	SPLOLM
OPRATRFL	PVHHTP (F)	RATIO	SPOPT
OPROCLM	PVHIFL	RBOPT	SPP
OVERVAL (F)	PVHIPR (F)	RCASOPT	SPTV
PERIOD	PVHITP (F)	RCASSHED	SPTVP
PIDFORM	PVLLFL	REDTAG (F)	STDBYMAN
PNTFORM	PVLLPR (F)	RFB	STSMMSG
PNTMODTY	PVLLTP (F)	RINITREQ	T1
PNTMODTY	PVLOFL	RINITVAL	T2
PNTSTATE	PVLOTP (F)	RTHILM	TRFB
PNTTYPE	PVLOPR (F)	RTLOLM	TVPROC
PTDESC	PVP	S1	UNIT
PTEXECST	PVROCNFL	SAFEOP	USERID
PTINAL	PVROCNPR (F)	SHEDMODE	
PTORST	PVROCNTF (F)	SHEDTIME	
PV	PVROCPFL	SHUTDOWN	

Pid With Feed Forward

The parameters of the Pid With Feed Forward control algorithm are listed below in alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	AUTMODFL	DEVHIPR (F)	KGAP
\$AUXUNIT (F)	BADCTLFL	DEVHITP (F)	KLIN
\$CDETAIL	BADCTLPL	DEVLOFL	KNL
\$DHSELECT (F)	BADPVFL	DEVLOPR (F)	LASTPV
\$DLBADAL (F)	BADPVPR (F)	DEVLOTP (F)	LOCALMAN
\$DLSELECT (F)	BFF	DLYTIME (F)	MANMODFL
\$HSELECT (F)	BIAS	ESWAUTO	MODATTR
\$HHSELECT (F)	BSHILM	ESWCAS	MODE
\$LOSELECT (F)	BSLOLM	ESWENBST	MODEAPPL
\$LLSELECT (F)	CASREQ	ESWMAN	MODEPERM
\$MODESEL	CIDSTN	EUDESC	MODNUM
\$REALARM (F)	CISRC	EXTSWOPT	NAME
\$RNSLECT (F)	CODSTN	FF	NLFM
\$RPSELECT (F)	CONTCUT (F)	FFOPT	NLGAIN
ADVDEVFL	CTLACTN	GAINOPT	NMODATTR
ADVDEVPR (F)	CTLALGID	GAPHI	NMODE
ADVDEVTP	CTLEQN	GAPLO	NOCINPTS
ADVSP (F)	CTRLINIT	HIGHAL (F)	NOCOPTS
ADVSP (F)	CV	HIGHALPR (F)	NODENUM
ALENBST (F)	CVEUHI	INITMAN	NODETYP
ARWNET	CVEULO	K	(Continued)
ARWOP	DELCV	KEXT	
ASPPROC (F)	DEV	KEYWORD	
ASSOCDSP	DEVHIFL	KFF	

Pid With Feed Forward (Continued)

NTWKNUM	PNTTYPE	PVLOPR (F)	SAFEOP
OP	PTDESC	PVP	SHEDMODE
OPALDB (F)	PTEXECST	PVROCNFL	SHEDTIME
OPEU	PTINAL	PVROCNPR (F)	SHUTDOWN
OPHAFL (F)	PTORST	PVROCNTP (F)	SLOTNUM
OPHIFL	PV	PVROCPFL	SP
OPHILM	PVALDB (F)	PVROCPPR (F)	SPEUHI
OPHIPR (F)	PVALDBEU (F)	PVROCPPT (F)	SPEULO
OPHITP (F)	PVAUTO	PVSGCHTP (F)	SPFORMAT
OPLAFL (F)	PVAUTOST	PVSOURCE (F)	SPHIFL
OPLOFL	PVEUHI	PVSRCOPT (F)	SPHILM
OPLOLM	PVEULO	PVSTS	SPLOFL
OPLOPR (F)	PVFORMAT	PVTRACK	SPLOLM
OPLOTP (F)	PVHHFL	RAMPTIME	SPOPT
OPMCHLM	PVHHPR (F)	RARWSTS	SPP
OPRATRFL	PVHHTP (F)	RATIO	SPTV
OPROCLM	PVHIFL	RBOPT	SPTVP
OVERVAL (F)	PVHIPR (F)	RCASOPT	STDBYMAN
PERIOD	PVHITP (F)	RCASSHD	STSMG
PIDFORM	PVLLFL	REDTAG (F)	T1
PNTFORM	PVLLPR (F)	RINITREQ	T2
PNTMODTY	PVLLTP (F)	RINITVAL	TVPROC
PNTMODTY	PVLOFL	RTHILM	UNIT
PNTSTATE	PVLOTP (F)	RTLOLM	USERID

Pid With Position Proportional

The parameters of the Position Proportional control algorithm are listed below in alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	BADCTLFL	DEVLOFL	LOCALMAN
\$AUXUNIT (F)	BADCTLFP	DEVLOPR (F)	LOWERTIM
\$CDETAIL	BADPVFL	DEVLOTP (F)	LOWRDSTN
\$DHSELECT (F)	BADPVPR	DLYTIME (F)	LOWRRATE
\$DLBADAL (F)	BADPVR (F)	ESWAUTO	MANMODFL
\$DLSELECT (F)	BCAMODFL	ESWCAS	MANOPCMD
\$HISELCT (F)	BIAS	ESWENBST	MANOPTIM
\$HHSELECT (F)	BSHILM	ESWMAN	MAXPULSE
\$LOSELCT (F)	BSLOLM	EUDESC	MINPULSE
\$LSELECT (F)	CASREQ	EXTSWOPT	MODATTR
\$MODESEL	CIDSTN	GAINOPT	MODE
\$REALARM (F)	CISRC	GAPHI	MODEAPPL
\$RSELECT (F)	CODSTN	GAPLO	MODEPERM
\$RPSELECT (F)	CONTCUT (F)	HIGHAL (F)	MODNUM
ADVDEVFL	CTLALGID	HIGHALPR (F)1	NAME
ADVDEVPR (F)	CTLQON	INITMAN	NLFM
ADVDEVTP (F)	CTRLINIT	K	NLGAIN
ADVSP (F)	CYCLETIM	K1	NMODATTR
ADVSP (F)	DEADBAND	KEXT	NMODE
ALENBST (F)	DEADTIME	KEYWORD	NOCINPTS
ARWNET	DELCV	KGAP	NOCOPTS
ARWOP	DEV	KLIN	NODENUM
ASPPROC (F)	DEVHIFL	KNL	(Continued)
ASSOCDSP	DEVHPR (F)	LASTPV	
AUTMODFL	DEVHITP (F)	LMSRC	

PID With Position Proportional (Continued)

NODETYP	PVLLFL	RTLOLM
NTWKNUM	PVLLPR (F)	SAFEOPCMD
OPCMD	PVLLTP (F)	SHEDMODE
OPHIFL	PVLOFL	SHEDTIME
OPHISRC	PVLOPR (F)	SHUTDOWN
OPLOFL	PVLOTP (F)	SLOTNUM
OPLOSRC	PVP	SP
OVERVAL (F)	PVROCNFL	SPEUHI
PERIOD	PVROCNPR (F)	SPUELO
PNTFORM	PVROCNTP (F)	SPHIFL
PNTMODTY	PVROCPFL	SPHILM
PNTNODTY	PVROCPPR (F)	SPLOFL
PNTSTATE	PVROCPTP (F)	SPLOLM
PNTTYPE	PVSGCHTP (F)	SPOPT
PRIMMOD (F)	PVSOURCE (F)	SPP
PTDESC (F)	PVSRCOPT (F)	SPTV
PTEXECST	PVSTS	SPTVP
PTINAL	PVTRACK	STDBYMAN
PTORST	RAISDSTN	STSMMSG
PV	RAISETIM	T1
PVALDB (F)	RAISRATE	T2
PVALDBEU (F)	RAMPTIME	TVPROC
PVAUTO	RARWSTS	UNIT
PVAUTOST	RATIO	USERID
PVEUHI	RBOPT	
PVEULO	RCASOPT	
PVFORMAT	RCASSHED	
PVHHFL	REDTAG (F)	
PVHHPR (F)	RINITREQ	
PVHHTP (F)	RINITVAL	
PVHIFL	RP	
PVHIIPR (F)	RT	
PVHITP (F)	RTHILM	

Position Proportional

The parameters of the Position Proportional control algorithm are listed below in Alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	AUTMODFL	ESWCAS	MODEPERM
\$AUXUNIT (F)	BADCTLFL	ESWENBST	MODNUM
\$CDETAIL	BADCTLOP	ESWMAN	NAME
\$DHSELECT (F)	BADPVFL	EUDESC	NMODATTR
\$DLBADAL (F)	BADPVR (F)	EXTSWOPT	NMODE
\$DLSELECT (F)	CASREQ	HIGHAL (F)	NOCINPTS
\$HISELCT (F)	CIDSTN	HIGHALPR (F)1	NOCOPTS
\$HHSELECT (F)	CISRC	INITMAN	NODENUM
\$LOSELCT (F)	CODSTN	KEYWORD	NOTETYP
\$LSELECT (F)	CONTCUT (F)	LASTPV	NTWKNUM
\$MODESEL	CTLALGID	LMSRC	OPCMD
\$REALARM (F)	CTRLINIT	LOCALMAN	OPHIFL
\$RNSELECT (F)	CYCLETIM	LOWERTIM	OPHISRC
\$RPSELECT (F)	DEADBAND	LOWRDSTN	OPLOFL
ADVDEVFL	DEADTIME	LOWRRATE	OPLOSRC
ADVDEVPR (F)	DEV	LTHMILM	OVERVAL (F)
ADVDEVTP (F)	DEVHIFL	MANMODFL	PERIOD
ADVSP (F)	DEVHIPR (F)	MANOPCMD	(Continued)
ADVSP (F)	DEVHITP (F)	MANOPTIM	
ALENBST (F)	DEVLOFL	MAXPULSE	
ARWNET	DEVLOPR (F)	MINPULSE	
ARWOP	DEVLOTP (F)	MODATTR	
ASPPROC (F)	DLYTIME (F)	MODE	
ASSOCDSP	ESWAUTO	MODEAPPL	

Position Proportional (Continued)

PNTFORM	PVROCNPR (F)	SPLOFL
PNTMODTY	PVROCNTP (F)	SPLOLM
PNTNODTY	PVROCPFL	SPOPT
PNTSTATE	PVROCPPL (F)	SPP
PNTTYPE	PVROCTPT (F)	SPTV
PRIMMOD (F)	PVSGCHTP (F)	SPTVP
PTDESC	PVSOURCE (F)	STDBYMAN
PTXECST	PVSRCOPT (F)	STSMMSG
PTINAL	PVSTS	TVPROC
PTORST	RAISDSTN	UNIT
PV	RAISSETIM	USERID
PVALDB (F)	RAISRATE	
PVALDBEU (F)	RAMPTIME	
PVAUTO	RARWSTS	
PVAUTOST	RCASOPT	
PVEUHI	RCASSHED	
PVEULO	REDTAG (F)	
PVFORMAT	RINITREQ	
PVHHFL	RINITVAL	
PVHHPR (F)	RP	
PVHHTP (F)	RT	
PVHITP (F)	SAFOPCMD	
PVHIFL	SHEDMODE	
PVHIPR (F)	SHEDTIME	
PVLLFL	SHUTDOWN	
PVLLPR (F)	SLOTNUM	
PVLLTP (F)	SP	
PVLOFL	SPEUHI	
PVLOPR (F)	SPEULO	
PVLOTP (F)	SPFORMAT	
PVP	SPHIFL	
PVROCNFL	SPHILM	

Ramp Soak

The parameters of the Ramp Soak control algorithm are listed below in alphabetical Order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	CTRLINIT	LASTPV	OPLOLM
\$AUXUNIT (F)	CURSEGID	LOCALMAN	OPMCHLM
\$CDETAIL	CV	MANMODFL	OPRATRFL
\$DHSELECT (F)	CVEUHI	MODATTR	OPROCLM
\$DLSELECT (F)	CVEULO	MODE	OVERVAL (F)
\$MODESEL	CYCLOPT	MODEAPPL	PERIOD
\$REALARM (F)	DEV	MODEPERM	PNTFORM
ADVDEVFL	DEVHIPR (F)	MODNUM	(Continued)
ADVDEVPR (F)	DEVHIFL	MXRMPDEV	
ADVDEVTP (F)	DEVHITP (F)	MXSOKDEV	
ADVSP (F)	DEVLOFL	NAME	
ADVSP (F)	DEVLOPR (F)	NMODATTR	
ALENBST (F)	DEVLOTP (F)	NMODE	
ARWNET	DLYTIME (F)	NOCINPTS	
ARWOP	ESW AUTO	NOCOPTS	
ASPPROC (F)	ESWCAS	NODENUM	
ASSOCDSP	ESWENBST	NODETYP	
AUTMODFL	ESWMAN	NORSSEQ	
BADCTLFL	EUDESC (F)	NTWKNUM	
CASREQ	EXTSWOPT	NXTSOAKV	
CIDSTN	HIGHAL (F)	OP	
CISRC	HIGHALPR (F)	OPEU	
CODSTN	HOLD CMD	OPHIFL	
CONTCUT (F)	INITMAN	OPHILM	
CTLALGID	KEYWORD	OPLOFL	

Ramp Soak (Continued)

PNTMODTY	REMSOAKT	SOAKV3
PNTNODTY	RINITREQ	SOAKV4
PNTSTATE	RINITVAL	SOAKV5
PNTTYPE	S1	SOAKV6
PRIMMOD	S1BGNTIM	SOAKV7
PTDESC	S1ENDTIM	SOAKV8
PTEXECST	S1SEGID	SOAKV9
PTINAL	S2	SOAKV10
PTORST	S2BGNTIM	SOAKV11
PV	S2ENDTIM	SOAKV12
PVEUHI	S2SEGID	SP
PVEULO	SAFEOP	SPEUHI
PVFORMAT	SCHSTS	SPEULO
PVP	SEGTYPE	SPFORMAT
PVSTS	SHUTDOWN	SPHIFL
RAMPTIME	SLOTNUM	SPHILM
RARVSTS	SOAKT1	SPLOFL
RATE1	SOAKT2	SPLOLM
RATE2	SOAKT3	SPOPT
RATE3	SOAKT4	SPP
RATE4	SOAKT5	SPTV
RATE5	SOAKT6	SPTVP
RATE6	SOAKT7	STDBYMAN
RATE7	SOAKT8	STSMMSG
RATE8	SOAKT9	TVPROC
RATE9	SOAKT10	UNIT
RATE10	SOAKT11	USERID
RATE11	SOAKT12	
RATE12	SOAKV1	
REDTAG (F)	SOAKV2	

Ratio Control

The parameters of the Ratio Control control algorithm are listed below in Alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	ASPPROC (F)	DEVLOFL	MODEPERM
\$AUXUNIT (F)	ASSOCDSP	DEVLOPR (F)	MODNUM
\$CDETAIL	AUTMODFL	DEVLOTP (F)	NAME
\$DHSELECT (F)	B1	DLYTIME (F)	NMODATTR
\$DLBADAL (F)	B2	ESWAUTO	NMODE
\$DLSELECT (F)	BADCTLFL	ESWCAS	NOCINPTS
\$HISELCT (F)	BADPVFL	ESWENBST	NOCOPTS
\$HISELCT (F)	BADPVPR (F)	ESWMAN	NODENUM
\$LOSELCT (F)	CASREQ	EUDESC (F)	NODETYP
\$LSELECT (F)	CIDSTN	EXTSWOPT	NTWKNUM
\$MODESEL	CISRC	HIGHAL (F)	OP
\$REALARM (F)	CODSTN	HIGHALPR (F)	OPALDB (F)
\$RNSLCT (F)	CONTCUT (F)	INITMAN	OPEU
\$RPSELCT (F)	CTLALGID	K1	OPHAFL (F)
ADVDEVFL	CTRLINIT	K2	OPHIFL
ADVDEVPR (F)	CV	KEYWORD	OPHILM
ADVDEVTP (F)	CVEUHI	LASTPV	OPHIPR (F)
ADVSP (F)	CVEULO	LOCALMAN	(Continued)
ADVSP (F)	DEV	MANMODFL	
ALENBST (F)	DEVHIFL	MODATTR	
ARWNET	DEVHIPR	MODE	
ARWOP	DEVHITP (F)	MODEAPPL	

Ratio Control (Continued)

OPHITP (F)	PVHIFL	SP
OPLAFL (F)	PVHIPR (F)	SPEUHI
OPLOFL	PVHITP (F)	SPEULO
OPLOLM	PVLLFL	SPFORMAT
OPLOPR (F)	PVLLPR (F)	SPHIFL
OPLOTP (F)	PVLLTP (F)	SPHILM
OPMCHLM	PVLOFL	SPLOFL
OPRATRL	PVLOPR (F)	SPLOLM
OPROCLM	PVLOTP (F)	SPOPT
OVERVAL (F)	PVP	SPP
PERIOD	PVROCNFL	SPTV
PNTFORM	PVROCNPR (F)	SPTVP
PNTMODTY	PVROCNTP (F)	STDBYMAN
PNTNODTY	PVROCPFL	STSMMSG
PNTSTATE	PVROCPPR (F)	TVPROC
PNTTYPE	PVROCPTP (F)	UNIT
PRIMMOD (F)	PVSGCHTP (F)	USERID
PTDESC	PVSOURCE (F)	X2
PTEXECST	PVSRCOPT (F)	
PTINAL	PVSTS	
PTORST	RAMPTIME	
PV	RARWSTS	
PVALDB (F)	RCASOPT	
PVALDBEU (F)	RCASSHED	
PVAUTO	REDTAG (F)	
PVAUTOST	RINITREQ	
PVEULO	RINITVAL	
PVEUHI	SAFEOP	
PVFORMAT	SHEDMODE	
PVHHFL	SHEDTIME	
PVHHPR (F)	SHUTDOWN	
PVHHTP (F)	SLOTNUM	

Summer

The parameters of the Summer PV algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	C3	OVERVAL (F)	PNTSTATE
\$AUXUNIT (F)	C4	P1	PNTTYPE
\$CDETAIL	C5	P1STS	PRIMMOD (F)
\$DLBADAL (F)	C6	P2	PTDESC
\$HISELCT (F)	CONTCUT	P2STS	PTEXECST
\$HHSELCT (F)	D	P3	PTINAL
\$LOSELCT (F)	DLYTIME (F)	P3STS	PV
\$LSELCT (F)	EUDESC	P4	PVALDB (F)
\$MODESEL	HIGHAL (F)	P4STS	PVALDBEU (F)
\$REALARM (F)	HIGHALPR (F)	P5	PVALGID
\$RNSLCT (F)	KEYWORD	P5STS	PVAUTO
\$RPSLCT (F)	LASTPV	P6	PVAUTOST
ALENBST (F)	N	P6STS	(Continued)
ASSOCDSP	MODNUM	PERIOD	
BADPVFL	NAME	PIDSTN	
BADPVPR (F)	NODENUM	PISRC	
C	NODETYP	PNTFORM	
C1	NOPINPTS	PNTMODTY	
C2	NTWKNUM	PNTNODTY	

Summer (Continued)

PVCALC	PVSRCOPT (F)
PVCLAMP	PVSTS
PVEQN	PVTV (F)
PVEULO	PVTVP (F)
PVEUHI	SCHSTS
PVEXEUHI	SLOTNUM
PVEXEULO	STSMG
PVEXHIFL	TF
PVEXLOFL	UNIT
PVFORMAT	USERID
PVHHFL	
PVHHPR (F)	
PVHHTP (F)	
PVHIFL	
PVHIPR (F)	
PVHTP (F)	
PVINIT	
PVLLFL	
PVLLPR (F)	
PVLLTP (F)	
PVLOFL	
PVLOPR (F)	
PVLOTP (F)	
PVP	
PVROCFL	
PVROCNPR (F)	
PVROCNTP (F)	
PVROCPFL	
PVROCPPR (F)	
PVROCPTP (F)	
PVSGCHTP (F)	
PVSOURCE (F)	

Switch

The parameters of the Switch control algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$AUXUNIT (F)	CV	MODNUM
\$CDETAIL	CVEUHI	NAME
\$DLBADAL (F)	CVEULO	NMODATTR
\$MODESEL	DLYTIME (F)	NMODE
\$REALARM (F)	ESWAUTO	NOCINPTS
ALENBST (F)	ESWCAS	NOCOPTS
ARWNET	ESWENBST	NODENUM
ARWOP	ESWMAN	NODETYP
ASSOCDSP	EUDESC	NTWKNUM
AUTMODFL	EXTSWOPT	OP
BADCTL	HIGHAL (F)	OPALDB (F)
BADCTLOP	HIGHALPR (F)	OPEU
BADCTLPR (F)	INITMAN	OPHAFL
CASREQ	KEYWORD	OPHIFL
CIDSTN	LOCALMAN	OPHILM
CISRC	M	OPHIPR (F)
CODSTN	MANMODFL	OPHITP (F)
CONTCUT (F)	MODATTR	(Continued)
CTLALGID	MODE	
CTLEQN	MODEAPPL	
CTRLINIT	MODEPERM	

Switch (Continued)

OPLAFL (F)	SHEDMODE
OPLOFL	SHEDTIME
OPLOLM	SHUTDOWN
OPLOPR (F)	SLOTNUM
OPLOTP (F)	STDBYNUM
OPMCHLM	STDBYMAN
OPRATRL	STMSG
OPROCLM	TRACKING
OVERVAL (F)	UNIT
PERIOD	USERID
PNTFORM	X1
PNTMODTY	X2
PNTNODTY	X3
PNTSTATE	X4
PNTTYPE	XEUHI
PRIMMOD (F)	XEULO
PTDESC	
PTEXECST	
PTINAL	
PTORST	
RARWSTS	
RCASOPT	
RCASHED	
REDTAG	
RINITREQ	
RINITVAL	
S1	
S2	
S3	
S4	
SAFEOP	
SELXINP	

Totalizer

The parameters of the Totalizer PV algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	COMMAND	PISRC
\$AUXUNIT (F)	CONTCUT (F)	PNTFORM
\$CDETAIL	CUTOFFLM	PNTMODTY
\$DLBADAL (F)	DLYTIME (F)	PNTNODTY
\$HISELCT (F)	EUDESC	PNTSTATE
\$HHSELCT (F)	HIGHAL (F)	PNTTYPE
\$LOSELCT (F)	HIGHALPR (F)	PRIMMOD (F)
\$LSELCT (F)	KEYWORD	PTDESC
\$REALARM (F)	LASTPV	PTEXCST
\$RNSSELCT (F)	MODNUM	PTINAL
\$RPSSELCT (F)	NAME	PV
ACCTYPE	NODENUM	PVALDB (F)
ALENBST (F)	NODETYP	PVALDBEU
ASSOCDSP	NOPINPTS	PVALGID
AVDEV1FL	NTWKNUM	PVAUTO
AVDEV1TP	OLDAV	PVAUTOST
AVDEV2FL	OVERVAL (F)	PVCALC
AVDEV2TP	P1	PVCLAMP
AVTV	P1STS	PVEQN
AVTVFL	P2	PVEUHI
BADPVFL	P2STS	(Continued)
BADPVPR (F)	PERIOD	
C	PIDSTN	

Totalizer (Continued)

PVEULO	SLOTNUM
PVEXEUHI	STARTFL
PVEXEULO	STATE
PVEXHIFL	STOPFL
PVEXLOFL	STMSG
PVFORMAT	TF
PVHHFL	TIMEBASE
PVHHPR (F)	UNIT
PVHHTP (F)	USERID
PVHIFL	
PVHIPR (F)	
PVHITP (F)	
PVINIT	
PVLLFL	
PVLLPR (F)	
PVLLTP (F)	
PVLOFL	
PVLOPR (F)	
PVLOTP (F)	
PVP	
PVROCNFL	
PVROCNPR (F)	
PVROCNTP (F)	
PVROCPFL	
PVROCPPR (F)	
PVROCPTP (F)	
PVSGCHTP (F)	
PVSOURCE (F)	
PVSRCOPT (F)	
PVSTS	
PVTV (F)	
PVTV (F)	
RESETFL	

Variable Dead Time With Lead/Lag

The parameters of the Variable Dead Time With Lead/Lag PV algorithm are listed below in Alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	DLYTIME (F)	PNTNODY
\$AUXUNIT (F)	EUDESC	PNTSTATE
\$CDETAIL	HIGHAL (F)	PNTTYPE
\$DLBADAL (F)	HIGHALPR (F)	PRIMMOD (F)
\$HISELCT (F)	KEYWORD	PTDESC (F)
\$HHSELCT (F)	LASTPV	PTEXECST
\$LOSELCT (F)	MODNUM	PTINAL
\$LSELCT (F)	NAME	PV
\$REALARM (F)	NLOC	PVALDB (F)
\$RNSLCT (F)	NODENUM	PVALDBEU (F)
\$RPSLCT (F)	NODETYP	PVALGID
ALENBST (F)	NOPINPTS	PVAUTO
ASSOCDSP	NTWKNUM	PVAUTOST
BADPVFL (F)	OVERVAL (F)	PVCALC
BADPVPR (F)	P1	PVCLAMP
C	P1STS	PVEQN
C1	P2	PVEUHI
C2	P2STS	PVEULO
CONTCUT (F)	PERIOD	PVEXEUHI
CUTOFFLM	PIDSTN	(Continued)
D	PISRC	
D1	PNTFORM	
D2	PNTMODTY	

Variable Dead Time With Lead/Lag (Continued)

PVXEULO	PVLLTP (F)	PVSRCOPT (F)
PVEXHIFL	PVLOFL	PVSTS
PVEXLOFL	PVLOPR (F)	PVTVP (F)
PVFORMAT	PVLOTP (F)	PVTVP (F)
PVHHFL	PVP	SLOTNUM
PVHHPR (F)	PVROCNFL	STSMMSG
PVHHTP (F)	PVROCNPR (F)	TD
PVHIFL	PVROCNTP (F)	TF
PVHIPR (F)	PVROCPFL	TLD
PVHITP (F)	PVROCPPR (F)	TLG1
PVINIT	PVROCPTP (F)	TLG2
PVLLFL	PVSGCHTP (F)	UNIT
PVLLPR (F)	PVSOURCE (F)	USERID

Parameter	Description	Type	Lock	(Default) and Range
\$ADD	Add last parameter indicator	L	PB	(On); On Off
\$ALDLOPT	Alarm Delay Option (R620 & later)	e:	Eng	(None); OffDlyLo, OffDlyHi, OffDlyEm, OnDlyLo, OnDlyHi, OnDlyEm
\$CDETAIL	Custom Schematic Name (R620 & later)	S	Eng	(8 space characters); Any 8 character string valid for a schematic name
\$DBVALID	APM Database Valid	e:	Eng	(DBInvalid); DB_Valid, DBInvalid
\$DLBADAL	Delay for BADPV and BADCTL (R681 and later)	e:	Eng	(NONE); None, Offdelay
\$DHSELECT	Deviation High Selective Cutout (R681 & later)	e:	Eng	(Cutout); Cutout, Allow
\$DLSELECT	Deviation Low Selective Cutout (R681 & later)	e:	Eng	(Cutout); Cutout, Allow
\$DLYOPT	Digital Input Alarm Delay Option (R660 & later)	e:	Eng	(None); PmOffDly, NmOffDly, NmOnDly If you migrate to R660, the default is PmOffDly
\$HHSELECT	PV High High Selective Cutout (R681 & later)	e:	Eng	(Cutout); Cutout, Allow
\$HISELECT	PV High Selective Cutout (R681 & later)	e:	Eng	(Cutout); Cutout, Allow
\$IOMPADD(n)	IOP Address (n = 1 – 168)	I	View	(); 0, 129-255
\$LLSELECT	PV Low Low Selective Cutout (R681 & later)	e:	Eng	(Cutout); Cutout, Allow
\$LOSELECT	PV Low Selective Cutout (R681 & later)	e:	Eng	(Cutout); Cutout, Allow

Parameter	Description	Type	Lock	(Default) and Range
\$MODESEL	Mode Selection List (R630 and later) Refer PM Family Parameter Reference Dictionary for more information.	L	Eng	All the modes and mode attributes applicable for a point type that can be changed from a display.
\$OLDEVDS	Open-Line Detect Event Disable (AnalogIn) (R640 and later)	e:	Eng	(Enable); Enable, Disable (for the LLAI / LLMUX AI points having sensor type of Thermocouple or RTD). (NoOTDetc); for all other AI points.
	Open-Line Detect Event Disable (AnalogOut) (R640 and later)	e:	Eng	(Enable); Enable, Disable
\$OFSELECT	Off Normal Selective Cutout (R681 & later)	e:	Eng	(Cutout); Cutout, Allow
\$PMDLYTM	Value of IOP DLYTIME parameter for Digital Input points that have been configured as STATUS points (R660 and later)	I	View	(5); 0 - 60 Seconds
\$REALARM	Re-arming Interval (R660 and later)	I	Eng	(0) No alarm; 0 through 9999 minutes (if configured, value ranges from one minute to approximately 167 hours)
\$RNSELECT	PV Negative Rate of Change Selective Cutout (R681 & later)	e:	Eng	(Cutout); Cutout, Allow
\$RPSELECT	PV Positive Rate of Change Selective Cutout (R681 & later)	e:	Eng	(Cutout); Cutout, Allow

Parameter	Description	Type	Lock	(Default) and Range
\$UCNLSBn	Local UCN Communications Statistics (n = 1 - 50)	R	View	N/A
AB_DATA1	A-B PLC Family type: 2.0, 3.0, or 5.0	R	Eng	(NaN); N/A
AB_DATA2	A-B PLC File number; NaN for PLC-2	R	Eng	(NaN); 0 – 999, NaN
AB_DATA3	A-B PLC-3 Section ID, or PLC-2 or 5 data type	R	Eng	(NaN); 0 - 9, NaN
AB_DATA4	256 – Report by exception	R	Eng	(NaN); 0 –255, 256
ABHEMSD	Abnormal Handler Emergency Shutdown Enable Flag	L	View	(Off); On – Off
ABHHOLD	Abnormal Handler Hold Enable Flag	L	View	(Off); On – Off
ABHRSTR	Abnormal Handler Restart Enable Flag	L	View	(Off); On – Off
ABHSHDN	Abnormal Handler Shutdown Enable Flag	L	View	(Off); On – Off
ACCELTIM	Acceleration Time	T	View	(0); 0 – 4000 days
ACCTYPE	Accumulator Operation Mode	e:	Eng/ PB	(Analog); Pulse, Analog
ACP	Advanced Control Data Point	E	PB	(Null); A-Z, 0-9,
ACTPRIM(n)	Acting Primary I/O Module (n = 1 - 40)	e:	View	(); IOM A, IOM B
ADVDEVFL	Advisory Deviation Alarm Flag	L	View	(Off); On – Off
ADVDEVPR	Advisory Deviation Alarm Priority	e:	Eng	(NoAction - R670); Low, Emergency, High, Journal, NoAction, Printer, JnlPrint
ADVDEVTP	Advisory Deviation Alarm Trip Point	R	Supr	(NaN); ≥ 0.0, NaN
ADVSP	Advisory Setpoint in Engineering Units	R	Supr	(N/A); SPLOLM – SPHILM
ADVSPPP	Advisory Setpoint in Percent	R	View	(N/A); N/A
ALENBST	Alarm Enable Status	e:	Oper	(Enable); Enable, Disable, Inhibit

Parameter	Description	Type	Lock	(Default) and Range
ALMOPT	Alarming Option (DigComp) Alarming Option (DigIn)	e: e:	Eng/ PB Eng/ PB	(None); Offnorml, Cmddis, None (None); Offnorml, None
ALPRIOR	Alarm Priority	e:	Eng	(Low); Low, Emergncy, High, Journal, NoAction, Printer, JnlPrint
ANAME(n)	Abnormal Sequence Name (n = 1 - 3)	S	View	Spaces; N/A
AOCALIB(n)	AO Calibration in Prog. Flag (n = 1 - 168)	L	Eng/ PB	(); Off, - On
ARWNET	Windup Status of the Input	e:	View	(Normal); Normal, Hi, Lo, HiLo
ARWOP	Windup Status of the Output	e:	View	(Normal); Normal, Hi, Lo, HiLo
ASSOCDSP	Associated Display	S	Eng	(Blank); N/A
ASPPROC	Advisory SP Processor State	e:	Supr	(Disable); Disable, Enable
ASTEPI(n)	Abnormal Step Name (n = 1 - 3)	S	View	(Blank); N/A
ASTMT(n)	Abnormal Statement Number (n = 1 - 3)	I	View	(Blank); 0 – 255
AUTMODFL	Automatic Mode Flag	L	View	(N/A); Off – On
AUXDATA1	Modbus Keep Alive address	R	Eng	(NaN); 1 – 9999, NaN
AUXDATA2	Modbus Retry interval, NaN = 1.5 sec.	R	Eng	(NaN); .25 - 5 Sec., NaN
AUXDATA3	Modbus Protocol.Modem control (0 = off).	R	Eng	(NaN); 232.0, 232.1, 485.0
AUXDATA4	Modbus Baud Rate.Parity (0 = none). baud/odd parity	R	Eng	(NaN); 1200, 2400, 4800, 9600, 19,200. Decimal = .0, .1, or .2
AV	Accumulated Value in Engineering Units	I	Oper	(0); 0 – 32767

Parameter	Description	Type	Lock	(Default) and Range
AVDELTHS	The Last Half-Second's AV	I	View	(0); ≥ 0
AVDEV1FL	Accumulated Value – 1st Deviation Flag	L	View	(N/A); Off – On
AVDEV2FL	Accumulated Value – 1st Deviation Trip Point	R	Supr	(NaN); ≥ 0.0 , NaN
AVDEV1TP	Accumulated Value – 2nd Deviation Flag	L	View	(N/A); Off – On
AVDEV2TP	Accumulated Value – 2nd Dev. Trip Point	R	Supr/ PB	(NaN); ≥ 0.0 , NaN
AVGTF	Avg. Statistics Single Lag Filter Time Constant	R	View	(1.00 minutes); N/A
AVSTS	Value Status of AV	e:	View	(Bad); Bad, Normal
AVTV	Accumulator Target Value (DigIn)	I	Oper	(0); 0 – 32767
	Accumulator Target Value (Totalizr)	R	Oper/ PB	(NaN); N/A, NaN
AVTVFL	Accumulated Value Target Reached Flag	L	View	(N/A); Off – On
B	Overall Bias	R	Oper/ PB	(0.0); N/A
B0	Last Operator Entered Output Bias	R	View	(0.0); N/A
B1	Output Bias Constant	R	Supr/ PB	(0.0); N/A
B2	Bias for Input X2	R	Supr/ PB	(0.0); N/A
BADCTLFL	Bad Control Alarm Flag	L	View	(Off); Off – On
BADCTLOP	Bad Control Option	e:	Eng	(No_Shed); No_Shed, ShedHold, ShedLow, ShedHigh, ShedSafe
BADCTLPR	Bad Control Alarm Priority	e:	Eng	(NoAction - R670); Low, Emergency, High, Journal, NoAction, Printer, JnlPrint

Parameter	Description	Type	Lock	(Default) and Range
BADOCFL	Bad Output Connection Flag Alarm	L	View	(Off); On – Off
BADOCnFL	Bad Output Connection Flag n. (n = 1 - 4)	L	View	(Off); On – Off
BADOCPR	Bad Output Conn. Alarm Priority	e:	Eng	(NoAction - R670); Low, Emergency, High, Journal, NoAction, Printer, JnlPrint
BADOCOPT	Bad Output Conn. Alarm Option	L	Eng/ PB	(Off); On – Off
BADPVFL	Bad PV Alarm Flag	L	View	(Off); Off – On
	SI Database Status Flag (Array)	L	View	(special); Off – On
BADPVPR	Bad PV Alarm Priority	e:	Eng	(NoAction - R670); Low, Emergency, High, Journal, NoAction, Printer, JnlPrint
BADPVTXT	Bad PV Text Descriptor	S	PB	(BAD); A-Z, 0-9, _
BADSVFL	Bad SV Alarm Flag	L	View	(Off); Off, On
BADSVPR	Bad SV Alarm Priority	e:	Eng	(NoAction - R670); Low, Emergency, High, Journal, NoAction, Printer, JnlPrint
BFF	Feed Forward Input Bias	R	Supr	(0.); N/A
BHALMF(n)	Alarm Flags (n = 1 - 7)	S	View	(); 0 0-FF
BIAS	Bias	R	Oper/ PB	(0.0); BSLOLM – BSHILM
BNDRESET	Bounds Statistics Reset Flag	L	Oper	(Off); Off/On
BNDRSTIM	Last Bounds Statistics Reset Time	T	View	(APM Startup Time); N/A

Parameter	Description	Type	Lock	(Default) and Range
BOXCLR(n)	Box Color for Digital Displays (DigComp)	e:	Eng/ PB	(Green – Upper Box Default, State 1); (Red – Lower Box Default, State 2); (Yellow – Middle Box Default, State 0); Red, Green, White, Black, Cyan, Yellow, Blue, Magenta
	Box Color for Digital Displays (DigIn, Flag)	e:	Eng/ PB	(Green – Upper Box Default, State 1); (Yellow – Lower Box Default, State 0); Red, Green, White, Black, Cyan, Yellow, Blue, Magenta
BSHILM	Bias High Limit	R	Supr	(50.0); $\geq$ BSLOLM, NaN
BSLOLM	Bias Low Limit	R	Supr	(-50.0); $\leq$ BSHILM, NaN
BYPASS	Interlock Bypass Override Input Bypass Enable	L	Oper	(Off); Off – On
BYPASSX1-4	Bypass ORSel's X1 - X4 Input	L	Oper	(BYPASSX1 = Off); Off-On (BYPASSX2-X4 = On);
C	Scaling Factor	R	Supr	(1.0); Anything except NaN
C1-C2	Correction Constant (FlowComp)	R	Supr	(1.0); C1 $\geq$ 0.1, C2 $\geq$ 0.1
	Scaling Constant for Input P1-P2 (VdtLdLag)	R	Supr	(1.0); $\geq$ 0.0
	Scaling Constants Used to Calculate PVCALC (PI)	R	Supr	(1.0); C1 $\geq$ 0, C2 $>$ 0
C1-C4	Intermediate Results of Calculations (CalCuLtr)	R	Supr	(N/A); N/A
C1-C6	Scaling Constants 1-6 (Summer)	R	Supr	(1.0); N/A
CnDESC	Custom Alarm Descriptors, (n = 1- 4)	S	Eng	(Blank); 8-char string
CnFL	Custom Alarm Flag, (n = 1- 4)	L	Prog	(Off); Off, On

Parameter	Description	Type	Lock	(Default) and Range
CnPR	Custom Alarm Priorities, (n = 1- 4)	e:	Eng	(NoAction - R670); Low, Emergency, High, Journal, NoAction, Printer, JnlPrint
CnSRC	Custom Alarm Source, (n = 1- 4)	e:	PB	(None); None, L1 - L12, SO1 - SO24, FL1 - FL24,
CABLESTS	Overall Cable Status for UCN Node	I	View	(N/A); 0, 1, 2 or 3
CALCEXP	Calculator Expression	S	Eng/ PB	(Blank); N/A
CALIBALL(n)	Full Calibration Enable Flag (n = 1 - 168)	L	Eng/ PB	(Off); Off – On
CALIBRJ(n)	Reference Junction Calibration Enable Flag (n = 1 - 168)	L	Eng/Pb	(Off); Off – On
CASREQ	Remote Cascade Request	e:	Prog	(NotReq); NotReq, Request
CHPINHWY	Automatic Checkpoint Inhibit	e:	Supr	(Enable); Enable, Inhibit
CHPINOPR	Automatic Checkpoint Inhibit Operation	e:	Supr	(Enable); Enable, Inhibit
CIDSTN(n)	Control Input Connection Destination (n = 1 - 40)	P	PB	(Varies by Algo Type, Equation); N/A
CISRC(n)	Control Input Connection Source (n = 1 - 40)	E	PB	(Null.Null); "TagName.Parameter"
CJTACTION	Internal cold Junction Temperature	L	View	(Off); On, Off
CLPZMXC	Overall Cable Status for UCN Cable A	L	Eng	(N/A); Off – On
CLPZMXP	Overall Cable Status for UCN Cable B	L	View	(N/A); Off – On
CMDDISFL	Command Disagree Alarm Flag	L	Special	(Off); Off – On
CMDDISPR	Command Disagree Alarm Priority	e:	Eng	(NoAction - R670); Low, Emergency, High, Journal, NoAction, Printer, JnlPrint

Parameter	Description	Type	Lock	(Default) and Range
CMDFALFL	Command Fail Alarm Flag	L	View	(Off); Off – On
CMDFALTM	Command Fail Timeout	I	Special	(0); 0 - 999 seconds
CMDHWREV	APMM Com. Daughter Card Revision	S	View	(); 00 – FF
CNTLLOCK	Control Lock	e:	Eng	(Operator); Operator, Supervis, Engineer, Program
CODSTN(n)	Control Output Connection Destination (n = 1 - 4)	E	PB	(Null.Null); "TagName.Parameter" or "IMTmmSss.Parameter"
COMCFAVG	Avg. APM Comm. CPU Free %	R	View	(NaN); 0 – 100
COMCFMAX	Max. APM Comm. CPU Free %	R	View	0 – 100
COMCFMIN	Min. APM Comm. CPU Free %	R	View	0 – 100
COMMAND	Accumulator Commands (DigIn, Totalizr) Timer Commands (Timer) STI Point/Database Transfer; STI Calibration	e: e: e:	Oper Oper Oper	(None); None, Start, Stop, Reset (None); None, Start, Stop, Reset, RestStrt (None); None, DnLoadDb, UpLoadDb, Set_LRV, Set_URV, Cor_LRV, Cor_URV, Cor_Inpt, RstCor
COMPHILM	Compensation Term High Limit	R	Supr	(1.25); COMPLOLM - 10.0, NaN
COMPLOLM	Compensation Term Low Limit	R	Supr	(0.8); 0.0 - COMPHILM, NaN
COMPTERM	Compensation Term	R	View	(1.0); COMPLOLM – COMPHILM
CONTCUT	Contact Cutout	L	Prog	(Off); Off – On
COUNTDWN	Accumulator Count Down Flag	L	Eng/ PB	(Off); Off – On
CPMSGSEC	Number of Checkpoint Messages	R	View	(0); N/A
CRIOLORN	Current Hour I/O LinkFetch/Store Overrun Counter	I	View	(0); ≥ 0
CRPPXORN(n)	Current Hr Pt. Processing Overrun Counter (n = 0 - 8)	I	View	(0); ≥ 0

Parameter	Description	Type	Lock	(Default) and Range
CRUCNORN	Current Hour UCN Fetch/Store Overrun Counter	I	View	(0); ≥ 0
CTLACTN	Control Action	e:	Eng/ PB	(Reverse); Direct, Reverse
CTLALGID	Control Algorithm Identifier	e:	PB	(Null); Null, Pid, PidErb, PidFF, RatioCtl, IncrSum, Switch, PosProp, AutoMan, RampSoak, ORSel
CTLCFAVG	Avg. APM Ctl. Processor Free %	R	View	(NaN); 0 – 100
CTLCFMAX	Max. APM Ctl. Processor Free %	R	View	(NaN); 0 – 100
CTLCFMIN	Min. APM Ctl. Processor Free %	R	View	(NaN); 0 – 100
CTLEQN	Control Equation Type (AutoMan, ORSel, Switch)	e:	PB	(EqA); EqA, EqB
	Control Equation Type (Pid algos)	e:	PB	(EqA); EqA, EqB, EqC, EqD
CTLOPT	APMM Control Processor Option	L	PB	(On); Off – On
CTRLINIT	Control Initialization Request Flag	L	Prog	(Off); Off- On
CURPINAMn	Current Personality Image Filename	S	View	(N/A); N/A
CURSEGID	Current Segment ID	e:	Oper	(Ramp1); Ramp1/Soak1 to Ramp12/Soak12
CUTOFFLM	Zero-Flow/Belt-Speed Cut-Off Limit	R	Supr	(0.0); ≥ 0.0 , NaN
CV	Calculated Variable	R	Prog	(NaN); N/A
CVEUHI	CV's High Limit in Engineering Units	R	Eng	(100.0); $\geq$ CVEULO
CVEULO	CV's Low Limit in Engineering Units	R	Eng	(0.0); $\geq$ CVEUHI
CYCLOPT	Ramp Soak Cycle Option	e:	Oper	(Cyclic); Single, Cyclic

Parameter	Description	Type	Lock	(Default) and Range
CYCLETIM	PosProp Output Cycle Time in Seconds	R	Supr	(10.0); 0.25 - 1000.0 Seconds
D	Overall Bias	R	Supr	(0.0); N/A
D1	Fixed Deadtime in Minutes (VdtLdLag)	R	Supr	(0.0); 0.0 - 400.0 Minutes
D1_0	Digital Input 1 Equal to a PV State of 0 (DigComp)	e:	View	(PVState0); PVState0, PVState1
D1_1	Digital Input 1 Equal to a PV State of 1 (DigComp)	E:	Eng/ PB	(PVState0); PVState0, PVState1 (Off); Off – On
D1, D2	Status of Digital Inputs 1 & 2 (DigComp)	L	View	(0.0); ≥ 0.0
D2	Bias for Input D2 (VdtLdLag)	R	Supr	(MovPV); MovPV, PVState0,
D2D1_00	D2_D1 Zero_Zero PV State	E:	Eng/ PB	PVState1, PVState2, BadPV (PVState0); PVState0, MovPV,
D2D1_01	D2D1 Zero_One PV State	E:	Eng/ PB	PVState1, PVState2, BadPV (PVState1); PVState1, MovPV
D2D1_10	D2D1 One_Zero PV State	E:	Eng/ PB	PVState0, PVState2, BadPV (BadPV); BadPV, PVState0,
D2D1_11	D2D1 One_One PV State	E:	Eng/ PB	PVState1, PVState2, MovPV (Off); Off – On
D3 – D5	Status of Digital Inputs 1 & 2 (DigComp)	L	View	(0.0); 0.0 – 102.3, NaN
DAMPING	First Order PV Filtering Option for the Smart Transmitter	R	Supr/ View	(N/A); N/A
DATE	Current Date/Time	T	View	(N/A); 1 – 31
DAY	Current Day	T	View	(Invalid); Valid, Invalid
DB_VALID(n)	Database Valid, (n = 1 - 40)	E:	Engr	(1.0); ≥0.0
DEADBAND	Deadband Value (Logic) (n = 1 - 24)	R	Supr	(5.0%); 0.0 - 100.0%

Parameter	Description	Type	Lock	(Default) and Range
	Deadband in % of Full Scale (PosProp)	R	Supr	(0.0); 0.0 - 60.0 Seconds
DEADTIME	Deadtime Value for Raise Pulse	R	Supr	(10 ms) ; 0 - 50 ms
DEBOUNCE	Contact Debounce Time in Milliseconds	I	Eng/ PB	(Pv_Sv_Db); Pv, Pv_Sv,
DECONF	Digitally Enhanced Configuration Mode	E:	Eng/ View	Pv_Db, Pv_Sv_Db
DEL CV	Delta CV in Eng Units (IncrSum) Delta CV in Percent (Pid)	R R	View View	(N/A); N/A (N/A); N/A
DEV	Deviation	R	View	(N/A); N/A
DEVADDR	Serial Link Device Address	R	PB	(NaN); N/A
DEVHIFL	Deviation High Alarm Flag	L	View	(Off); Off – On
DEVHIPR	Deviation High Alarm Priority	e:	Eng	(NoAction - R670); Low, Emergency, High, Journal, NoAction, Printer, JnlPrint
DEVHITP	Deviation High Alarm Trip Point	R	Supr	(NaN); ≥0.0, NaN
DEVLOFL	Deviation Low Alarm Flag	L	View	(Off); Off – On
DEVLOPR	Deviation Low Alarm Priority	e:	Eng	(NoAction - R670); JnlPrint, Printer, Emergency, High, Low, Journal, NoAction
DEVLOTP	Deviation Low Alarm Trip Point	R	Supr	(NaN); ≥0.0, NaN
DHTIMMAXn	Maximum time to Complete a Data Handler Request; n = 1 - 5	R	View	(0); N/A
DISP_SIM	Simulation Indicator Display Switch	L	Prog	(N/A) Off – On
DISRC(n)	DigComp Input-Connection Source (n = 1 - 2)	U	PB	(Null.Null); "TagName.Parameter" or "!MTmmSss.Parameter" or "\$NMhhBxx.Parameter"

Parameter	Description	Type	Lock	(Default) and Range
DITYPE	Digital Input Type	e:	PB	(Status); Status, Latched, Accum
DLYTIME	Alarm Delay in Seconds (DigIn)	I	Supr	(5); 0 - 60 Seconds
	Alarm Delay in Seconds for Logic Blocks (Logic)	R	Supr	(1); 1 - 8000 Seconds
	Alarm Delay in Seconds (AI, RegCtl, RegPV) (R620 and later)	e:	Eng	(0); 0 - 9999 Seconds
DODSTN(n)	DigComp Output Connection Destination (n = 1 - 3)	U	PB	(Null.Null); "TagName.Parameter" or "MTmmSss.Parameter" or "\$NMhhBxx.Parameter"
DOTYPE	Digital Output Type	e:	PB	(Status); PWM, Status
DSA	Device Soft Address	I	View	(N/A); 1-40, 129-168
EIPPCODE	Event-Initiated Point Identifier	E	Eng	(Null); A-Z, 0-9, _
ERRCODE	Serial Interface/Serial Link Communication Error Code	S	View	Spaces; N/A
ESWAUTO	External Switching Flag for Auto Mode	L	Prog	(Off); Off - On
ESWCAS	External Switching Flag for Cascade Mode	L	Prog	(Off); Off - On
ESWENBST	External Mode Switching Enable State	e:	Oper	(Disable); Disable, Enable
ESWMAN	External Switching Flag for Manual Mode	L	Prog	(Off); Off - On
EUDESC	Engineering Units Descriptor	S	PB	(Blank); A-Z 0-9 space ! % & ' () * + - / : ; > < = ? _ , . \$
EUNDESCn	IOP Generic Descriptor, n = 1 - 168	S	View	Blanks; 1-40 (pri); 129-168 (sec)
EVRCINPG	NIM Event Recovery in Progress Flag	L	View	(N/A); Off, On
EVTOPT	Event Reporting Option (DigComp)	e:	PB	(None); None, Eip
	Event Reporting Option (DevCtl, DigIn)	e:	PB	(None); None, Eip, Soe, Eip_Soe

Parameter	Description	Type	Lock	(Default) and Range
EXTDATA	External Data Option	e:	PB	(None);None,IO_FL,IO_NN,IO_STR,UCN_FL,UCN_NN,UCN_STR
EXTSWOPT	External Mode Switching Option	e:	Eng/PB	(None); None, Ems, Emp
F	Flow Input (uncompensated)	R	View	(NaN); N/A
FAILCODE	I/O Processor Hard Fail Status	e:	View	(N/A); See APM PRD
FAILOPT(n)	Failure Option for Outputs (n = 1 - 168)	e:	Eng/PB	(Unpower); Unpower, Hold
FBTIME	Feedback Time	I	Eng/PB	(1000); 0-1000 Seconds
FF	Feed Forward Algorithm Input	R	View	(N/A); N/A
FFOPT	Feed Forward Type	e:	Eng/PB	(Multiply); Multiply, Add
FL(n)	Box Flags FL(1) - FL(16,384)	L	Oper	(Off); Off – On
	Logic Slot Flags FL(1) - FL(12)	L	Special	(FL2 = On, rest = Off); Off – On
	Array Point Flags FL(i)	L	Special	(N/A); $1 \leq i \leq NFLAG$
	Process Module Flags FL(1) - FL(127)	L	Special	(Off); Off-On
FLDESC	FL Array Descriptor	S	PB	(spaces); N/A
FLSTIX	Flag Array Start Index	R	PB	(0); 0 - 99,000 or 0 - 16,384
FORCE	Forced Input Request Flag	L	Oper	(Off); Off - On
FRCPERM	Forced Input Permissive	L	Eng/PB	(Off); Off - On
FREQ6050	Frequency 60/50 Hz for LLMUX or STT	e:	Eng/PB	(60Hz); 0 - 60 Hz, 1 - 50 Hz
FRQUTAVG	Average UCN Fetch Request Trip Time	R	View	(NAN); N/A
FRQUTMAX	Maximum UCN Fetch Request Trip Time	R	View	(NAN); N/A
FRSPTAVG	Average UCN Fetch Response Trip Time	R	View	(NAN); N/A
FRSPTMAX	Max. UCN Fetch Response Trip Time	R	View	(NAN); N/A
FSELIN	Force Selected Input	e:	Oper/ PB	(SelectP1); SelectP1 - SelectP6,

Parameter	Description	Type	Lock	(Default) and Range
FSTS	Flow Input Value Status	e:	View	(Bad); Bad, Normal, Uncertn
FTAnTYPE	Type of FTA Connected to LLMUX; n=1 - 2	e:	View	(None); None, TC, RTD
FTACONN	FTA Connection to I/O Module This File	e:	View	(Conn_A); Conn_A, Conn_B
FTANUM	SI IOP FTA number	I	PB	(1); 1 – 10
FTAPRES(n)	IOP FTA Present Flag; n = 1 - 168	L	View	(); Off - On
G	Specific Gravity Input	R	View	(1.0); N/A
GAINOPT	Gain (K) Option	e:	Eng/PB	(Lin); Lin, Gap, NonLin, Ext
GAPHI	Gap High Limit	R	Supr	(0.0); ≥ 0.0
GAPLO	Gap Low Limit	R	Supr	(0.0); ≥ 0.0
GENDESC(n)	Generic Descriptor (n = 1 - 12)	S	PB	(Blanks); A-Z 0-9 Space ! % & ' () * + - : ; > < = ? _ , . \$
GENDESC(n)	Generic Descriptor (n = 1 - 40 or 129 - 168)	S	View	(Blanks); 1 - 40 = Acting Primary, 129 - 168 = Acting Secondary
GSTS	Gravity Input Value Status	e:	View	(Normal); Normal, Uncertn, Bad
HIGHAL	Highest Alarm Detected (AnalIn, PI, RegCtl, RegPV)	e:	View	(NoAlarm); NoAlarm, AdvDev, DevHi, DevLo, PV RocN, PV RocP, PVHi, PVHH, PVLo, PVLL, BadCtl, BadPV, BOC
	Highest Alarm Detected (DigComp, DigIn, DevCtl, Flag, Logic)	e:	View	(NoAlarm); NoAlarm, OffNorm, UnCEvt, CmdDis BadPV, C1ALM - C4ALM, Chngofst, Cmdfail, SVHI, SVHH, BadSV, OVRDI2, OVRDI1, OVRDI0, OVRDSI0, BadCtl
HIGHALPR	Highest Level Alarm's Priority	e:	View	(NoAction); NoAction, Journal, Printer, JnlPrint, Low, High, Emergency

Parameter	Description	Type	Lock	(Default) and Range
HISVPEAK	Highest Peak SECVAR Value	R	View	(0); ≥ 0
HOLDCMD	Hold Command Flag	L	Prog	(Off); Off – On
HWYCTLST	UCN Network Functional State	e:	Supr	(Basic); Basic, Full
I0 - I2	Override Interlocks for Output States 0-2	L	Eng	(Off); On – Off
I0CONF	Override Interlock 0 Alarm Conf. flag	L	Oper	(Off); N/A
InDESC	I0 - I2 Alarm Descriptor; (n = 0 - 2)	S	Eng	(Blank); 8 Character String
I1CONF	Override Interlock 1 Alarm Conf. flag	L	Oper	(Off); N/A
I2CONF	Override Interlock 2 Alarm Conf. Flag	L	Oper	(Off); N/A
IN0 - IN12	Input Coordinates 0-12	R	Supr	(NaN); > Previous INn but < Next INn. IN0 < IN1 < IN2, < IN12
INITMAN	Initialization Manual Flags	L	View	(On); Off – On
INITREQ	Initialization Request Flag (Array)	L	View	(Off); Off – On
	Initialization Request Flags (AO, DO)	L	View	(On); Off – On
INITREQ(i)	Initialization Request Flags (DigComp, DevCtl) (i = 0 - 2)	L	View	(On); Off – On
	Initialization Request Flags (RegCtl) (i = 1 - 4)	L	View	(Off); Off – On
INITVAL	Initialization Value	R	View	(N/A); N/A
INPTDIR	Input Direction	e:	Eng/PB	(Direct); Direct, Reverse
IOLASTS	I/O Link Cable A Status	L	View	(Off); Off – On
IOLBSTS	I/O Link Cable B Status	L	View	(Off); Off – On

Parameter	Description	Type	Lock	(Default) and Range
IOLCHAER	I/O Link Channel A Error Count	l	View	(0); ≥ 0
IOLCHASL	I/O Link Channel A Silence Count	l	View	(0); ≥ 0
IOLCHBER	I/O Link Channel B Error Count	l	View	(0); ≥ 0
IOLCHBSL	I/O Link Channel B Silence Count	l	View	(0); ≥ 0
IOLCHERT	I/O Link Channel Error Threshold	l	EgOnly	(10); ≥ 0
IOLCMD	I/O Link Command	e:	EgOnly	(None); None, SelChnA, SelChnB, EnbPerSw, DisPerSw, RstoLCom
IOLPERSW	I/O Link Periodic Cable Swap	e:	View	(N/A); Enable, Disable
IOMACTYP(n)	IOP Actual Type	e:	View	(None); None, LLAI, HCAI, DI, DO, AO, APMM, LLMUX, STIM, PI
IOMCARD(n)	I/O Module Card Position for the Acting Primary/Secondary n = 1-40 for Acting Primaries; n = 129-168 for Act. Secondaries	l	View	(N/A); 1- 15
IOMCARDA(n)	I/O Module A Card Position (n = 1 – 40)	l	PtBld	(0); 0 – 15
IOMCARDB(n)	I/O Module B Card Position (n = 1 - 40)	l	PtBld	(0); 0 – 15
IOMCMD	IOP Module Command	e:	Oper	(None); None, Run, Idle, Swap
IOMCOMER(n)	IOP Communication Error Status; (n = 1- 168)	e:	View	(N/A); See APM PRD
IOMFILE(n)	I/O Module File Position for the Acting Primary/Sec. (n = 1 - 40, 129 - 168)	l	View	(0); 0 – 8
IOMFILEA(n)	I/O Module File A Position for the Acting Primary/Secondary (n = 1 - 40)	l	PtBld	(0); 0 – 8

Parameter	Description	Type	Lock	(Default) and Range
IOMFILEB(n)	I/O Module File B Position for the Acting Primary/Secondary (n = 1 - 40)	I	PtBId	(0); 0 – 8
IOMFWREV(n)	IOP Card Firmware Revision Status 1-168	A	View	(N/A); X.Y (X=Range, Y=Revision)
IOMHWREV(n)	IOP Card Hardware Revision Status 1-168	A	View	(N/A); Hexadecimal "00" to "FF"
IOMLHFST(n)	IOP Card Last Hard Fail Status	e:	View	(N/A); Unknown, PowerDwn, AdCIncmp, AdOutOvf, AdOutUdf, BadDcLtc, Dmt_Tmot, MLtOutFI, BadDaRng, MstrTmot, InvPrgEx, EpromErr, RamCntEr, RamAdrEr, DpaError, DsaError, RxBufOfL, IOLJaber, BadPgJmp, AdCCalEr,
IOMUN	IOP Card Number	I	PB	(N/A); 1 – 40
IOMOPER(n)	IOP in Operation (n = 1 -168)	e:	View	(N/A); Primary, Secondary
IOMREALT	Actual IOP Type	e:	View	(None); None, LLAI, HLAi, DI, DO, AO, LLMUX, STIM, PI
IOMRECHN(n)	IOP Receive Channel	e:	View	(N/A); ChannelA, ChannelB
IOMSEVER(n)	Error Severity Based on IOP State (n = 1 -40; 129 - 168)	e:	View	(N/A); OK, Fail, Warning, Inform
IOMSTS(n)	IOP Status (n = 1 - 40; 129 - 168)	e:	View	(N/A); CommErr, ConfigMis, Idle, IdleSF, NonExist, NoResp, NotConfig, OK, PowerOn, SoftFail, UnAvail, Confgerr
IOMTYPE(n)	IOP Type (IOP) (n = 1 - 168)	e:	View	(None); None, HLAi, LLAI, AO, DI, DO, SI; LLMUX STIM, PI; AO16; DO32; DISOE

Parameter	Description	Type	Lock	(Default) and Range
IOMTYPE	IOP Type (APM Box)	e:	PB	(NotConfig); NotConfig, HLAI, LLAI, AO, DI, DO, LLMUX STIM, PI
IOPDESC(n)	IOP Description; (n = 1 - 40)	S	View	(Spaces); 8 characters
IOPNUM	Serial Intf. IOP Module Number	I	PB	(N/A); 1 – 127
IOPSTR1(n)	IOP String For FTA #1 (n = 1-40)	S	View	(Spaces); N/A
IOPSTR2(n)	IOP String For FTA #2 (n = 1-40)	S	View	(Spaces); N/A
IOREDOPT	I/O Module Redundancy Option	e:	PB	(Nonredun); Redun, Nonredun
IOSTKNDR	IO Data Scan Period in seconds	I	View	(N/A); 0 – 32767
K	IOP Token Drop Count	R	Supr	(1.0); N/A
	Gain Constant for X2 Input (AutoMan)	R	Sup	(1.0); 0.0 - 240.0
	Overall Gain in % Per % (Pid) Gain Constant (PosProp)	R	Supr	(1.0); 0.0 - 10.0
K1	External Reset Feedback Gain (PidErfb)	R	Supr	(0.0); 0.0 - 1.0
	External Reset Feedback Gain (PIDPosPr)	R	Supr	(1.0); 0.0 - 1.0
K1-K2	K1=Ratio Scale Factor; K2= Gain for X2 Input (RatioCtl)	R	Supr	(1.0); ≥0
K1-K4	Gain Constant for X1-X4 Inputs (IncrSum)	R	Supr	(1.0); ≥ 0.0
KEXT	External Gain Modifier	R	Prog	(1.0); 0.0 - 240.0
KEYWORD	Keyword Descriptor	S	PB	(Blank); A-Z, 0-9,
KFF	Gain for Feed Forward Input	R	Supr	(1.0); ≥ 0.0 to ≤ 1.0
KGAP	Gap Gain Factor	R	Supr	(1.0); 0.0 - 1.0
KLIN	Linear Gain Factor	R	PB	(1.0); 0.0 - 240.0
KNL	Non-linear Gain Factor	R	View	(N/A); N/A
L(n)	Value of the External Input (n = 1 – 12)	L	View	(N/A); Real

Parameter	Description	Type	Lock	(Default) and Range
LASTPV	Last PV Value	R	View	(NaN); N/A
LCNRECHN	LCN Channel That NIM is Listening to	E:	View	(ChannelA); ChannelA, ChannelB
LIBADOPT	Logic Bad Input Handling Option	E:	PB	(Hold); Off, On, Hold
LIBRYNUM	NIM Library Number	I	PB	(N/A); 1 – 3
LIBRYTXT(n)	NIM Library Text, (n = 1 - 1000)	S	PB	(N/A); N/A
LIDESC(n)	Input Descriptor (n = 1 - 12)	S	Eng	(Blank); 8 Characters
LINEPERD(n)	Line Period in Microseconds (n = 1 - 168)	R	View	(N/A); 15616 - 21759 μ seconds
LISRC(n)	Logic Input Connection Source (n = 1 - 12)	U	PB	(Null.Null); "TagName.Parameter" or "!MTmmSss.Parameter" or "\$NMhhBxx.Parameter"
LMREV	Local Manual Polarity	e:	Eng/PB	(Direct); Direct, Reverse
LMSRC	Local Manual Source	U	PB	(Null.Nul); See TPS PRD
LOADSCOP	Load Scope	e:	PB	(NIMOnly); NimOnly, NimAndPm
LOADSTAT	Load Status	e:	View	(); Not Loaded, Loaded, Loading, Unlding
LOCALMAN	Local Manual Flag (AO, RegCtl) Local Manual Flag (DigComp, DevCtl)	L L	View Prog	(Off); Off – On (Off); Off – On
LOCUTOFF	Low Signal Cut Off for Flow Inputs	R	Eng/PB	(NaN); PVEULO - PVEUHI, > NaN
LODSTN(n)	Logic Output-Connection Destination Logic (n = 1 - 12) DevCtl (n = 1 - 2)	R	PB	(Null.Null); "TagName.Parameter" or "!MTmmSss.Parameter", or "\$NMhhBxx.Parameter"

Parameter	Description	Type	Lock	(Default) and Range
LOENBL(n)	Logic Output Enable, (Logic) (n = 1 - 12)	e:	PB	(FL2); FL1 - FL12, SO1 - SO16, L1 -L12
	Logic Output Enable, (DevCtl) (n = 1 - 2)	e:	PB	(FL2); See TPS PRD
LOGALGID(n)	Logic Block Algorithm Identifier (n = 1 - 24)	e:	PB	(Null); OR, NOT, NAND, NOR, XOR, AND, SWITCH, CheckBad, Pulse, Delay, OnDly, OffDly, QOR2, QOR3, EQ, NE, GT, GE, LT, LE, MinPulse, MaxPulse, WatchDog, FlipFlop, ChDetect, Null
LOGICSRC	Logic Source	E	PB	(Null); A-Z, 0-9,
LOGMIX	Logic Mix	e:	PB	12 24 4, 12 16 8, 12 8 12
LOSRC(n)	Output - Connection Source Logic (n = 1 - 12)	e:	Eng/PB	(FL1); L1 - L12, FL1 - FL12,
	DevCtl (n = 1 - 2)	e:	PB	NN1 - NN8, SO1 - SO24
LOWERTIM	Lower Output Pulse Time (Secs)	R	View	See TPS PRD
LOWRDSTN	Lower OP Pulse Destination	U	PB	(N/A); N/A
LOWRRATE	Lower OP Stroke Rate in %/Sec	R	Supr	(Null); ONPULSE, OFFPULSE
LRL	Lower Range Limit (STI)	R	View	(100.0); >0.0% / Second
LRV	Lower Range Value (STI)	R	Supr/	(NaN); Na, NaN
			View	(NaN); Na, NaN

Parameter	Description	Type	Lock	(Default) and Range
LSEQNUMR	Last Sequence Number	I	Eng	(0);
LSIOLORN(n)	Last Hour's I/O Link Fetch/Store Overruns (n = 1 - 4)	I	View	(0); ≥ 0
LSPPXORN(n)	Last Hour's Point Processing Fetch/Store Overruns (n = 1 - 8)	I	View	(0); ≥ 0
LSUCNORN	Last Hour's UCN Access Overruns	I	View	(0); ≥ 0
M	Number of Inputs	I	PB	(2); 2 – 4
MAINDAT	Maintenance Reset Statistics Date	T	Eng	(Time of pt. build) Time Stamp
MAINTOPT	Maintenance Option	L	PB	(Off); Off – On
MANMODEFL	Manual Mode Flag	L	View	(Off); Off – On
MANOPCMD	Manual Output Pulse Command	e:	Oper	(None); Raise_1, Lower_1, None, Raise_10, Lower_10
MANOPTIM	Manual Output Pulse Time	R	Eng/PB	(1.0); 0.0 - 60.0 Seconds
MASKTIM	Masktime	I	Supr	(0.0); 0 - 1000 sec.
MAXPULSE	Maximum Pulse Time Limit	R	Supr	(60.0); MINPULSE to 60.0 Seconds, NaN
MAXSLOTS	Maximum Available Slots	R	View	(0); 0 – 127
MAXTIM0H	Maximum time Allowed in state 0	R	Supr	(0); N/A
MAXTIM1H	Maximum time Allowed in state 1	R	Supr	(0); N/A
MAXTIM2H	Maximum time Allowed in state 2	R	Supr	(0); N/A
MAXTRAN0-2	Max. number transitions into each state	T	Supr	(0.0); no limit

Parameter	Description	Type	Lock	(Default) and Range
MINPULSE	Minimum Pulse Time Limit	R	PB	(0.0); 0.0 Seconds to MAXPULSE, NaN
MINUTE	Current Minute	I	View	(N/A); 0 – 59
MODATTR	Mode Attribute	e:	Oper	(Operator); Operator, Program, Normal, None
MODE	Mode (AnalgOut)	e:	Oper	(Man); Man, Cas, Normal
	Mode (DigComp, DevCtl)	e:	Oper	(Man); Man, Normal
	Mode (RegCtl)	e:	Oper	(Man); Man, Cas, Auto, Bcas Normal
MODEAPPL	Mode Applicability	L	View	(Man=On; Auto, Cas, & Bcas = Off, Static for DevCtl & DigComp); N/A
MODEPERM	Mode Permissive(DevCtl, DigComp, RegCtl)	e:	Eng	(Permit); Permit, NotPerm
	Mode Permissive(Analg Out)	e:	Eng/PB	(Permit); Permit, NotPerm
MODNUM	IOP Card Number	I	PB	(N/A); 0 – 40
MOMSTATE	Momentary Output States	e:	Eng/PB	(None); Mom_0, Mom_1, Mom_2, Mom_1_2, None
MONTH	Current Month	I	View	(N/A); 1 – 12
MOVPFVL	Moving PV Flag	L	View	(Off); Off – On
MOVPTXT	Moving PV Text Descriptor	S	PB	(MOVING); A-Z, 0-9, _
MSGPEND	Sequence Message Pending	L	View	(none); N/A
MSGTXT(n)	Status Message Text (n = 0 - 15)	S	PB	(Blank); 0-15
MXRMPDEV	Maximum Ramp Deviation Value	R	Supr	(NaN); ≥ 0.0, NaN
MXSOKDEV	Maximum Soak Deviation Value	R	Supr	(NaN); ≥ 0.0, NaN
N	Number of Inputs (CalcuLtr)	I	PB	(1); 1 – 6
	Number of Inputs (HiloAvg & Summer)	I	PB	(2); 2 – 6
NAME	Tag Name	S	PB	(N/A); A-Z, 0-9, _
NARRSLOT	Number of Array Points in an APM	I	PB	(0); 0 – 256

Parameter	Description	Type	Lock	(Default) and Range
NCTLSLOT	Number of Regulatory Control Points	I	PB	(0); 0 – 160
NDCSLOT	Number of Digital Composite Points	I	PB	(0); 0 – 512
NDEVSLOT	Number of DevCtl. Points Configured	I	PB	(0); 0 – 160
NEIPRQU	No. of Event Initiated Processing Requests	R	View	(0); N/A
NFASTCTL	Number of Fast Reg Control Slots	I	PB	(0); 0 – 40 but $\leq$ NCTLSLOT
NFASTDC	Number of Fast Digital Composite Slots	I	PB	(0); 0 – 400 but $\leq$ NDCSLOT
NFASTDEV	Number of Fast DevCtl Points	I	PB	(0); 0 – 40 but $\leq$ NDEVSLOT
NFASTLOG	Number of Fast Logic Slots	I	PB	(0); 0 – 40 but $\leq$ NLOGSLOT
NFASTPV	Number of Fast Regulatory PV Slots	I	PB	(0); 0 – 40 but $\leq$ NPVSLOT
NFLAG	Number of Flags (Box) Number of Flags (Array)	I I	View/ PB	(16,384); 16,384 (0); 0 – 512 if EXTDATA = IO_FL, else 0 – 1023 if EXTDATA $\neq$ IO_FL
NIO - 2	Inverted Interlocks Value	L	Eng	(On); On, Off
NIMREV	Revision Number of the NIM personality	I	View	(0); N/A
NIMVERS	Version Number of the NIM personality	I	View	(0); N/A
NLFM	Nonlinearity Form	I	Supr	(1); 0 or 1
NLGAIN	Nonlinear Gain	R	Supr	(0.0); 0.0 – 240.0
NLOC	Number of Locations in Delay Table	I	Eng	(30); 2 – 30
NLOGSLOT	Number of Logic Points	I	PB	(0); 0 – 80
NMIN	Minimum Number of Good Inputs	I	PB	(1); 1 to Number Specified in N
NMODATTR	Normal Mode Attribute	e:	Engr	(None); None, Operator, Program, Normal
NMODE	Normal Mode (AnalogOut)	e:	Engr/ PB	(None); None, Man, Cas

Parameter	Description	Type	Lock	(Default) and Range
	Normal Mode (DigComp, DevCtl) Normal Mode (RegCtl)	e: e:	View/ Engr	(Man); Man (None); Man, Auto, Bcas, Cas, None
NMSGTXT	Number of Message Text Items	I	PB	(0); 0 – 15
NN(n)	Numeric Value (ProcModl) (n = 1 - 80) Numeric Value (Box) (n = 1 - 16,384) Numeric Value (Logic Point) (n = 1 - 8) Numeric Value (DevCtl Point) (n = 1 - 8) Numeric Value (Array Point) (n = i)	R R R R R	Special Oper Supr Supr Special	(NaN); N/A (NaN); N/A (NaN); N/A (NaN); N/A (N/A); $1 \leq i \leq \text{NNUMERIC}$
NNDESC	NN Array Descriptor	S	PB	(Spaces); N/A
NNINSET(n)	Numeric 1 - 10, n = 1 – 10	I	Supr	(0); 32767
NNSTIX	Numeric Array Start Index	R	PB	(0); 0 - 99,999 if EXTDATA = IO_NN, else 0 - value of NNUMERIC
NNUMERIC	Number of Numerics in APM Box Number of Numerics in Array Point NN Array	I I	PB PB	(0); 0 - 16,384 (0); 0 - 16 (EXTDATA = IO_NN), else 0 - 240 if EXTDATA $\neq$ IO_NN
NOCINPTS	Number of Control Input Connections	I	PB	(Special); 0 – 4
NOCOPTS	Number of Control Output Connections	I	PB	(1); 0 – 4
NODEASSN	Node Assignment	e:	PB	(ThisNIM); ThisNIM, RemotNIM,
NODECMD	Node Command	e:	Eng	(None); None, Run, Idle, Warmstrt, Coldstrt, Pause, and Resume
NODECONF	Node Configuration (set to manual)	e:	View	(Manual); Manual, Auto
NODENUM	Node Number	I	PB	(N/A); 0, 1 – 64
NODEOPER	Node Operating Mode	e:	View	() Primary, Secndry
NODESC	Number of Generic Descriptors	I	PB	(0); 0 – 12

Parameter	Description	Type	Lock	(Default) and Range
NODESTS	Node Summary Status	e:	View	(N/A); NotConf, PowerOn, OK, Alive, Fail, OffNet, Loading, ConfigMis, Idle, IOIdL, Pf_IOIdL, Pf_Idle, PartFail, CommFail, NoSynch, Unknown, "S_" = simulation.
NODESTS	NIM Node Summary Status	e:	View	(N/A); Offnet, OK
NODESTAT	Node Status (NIM)	e:	View	(N/A); Offnet, OK
	Node Status (APM)	e:	View	(N/A); Offnet, ConfigMis, OK
NODETYP	UCN Node Type (NIM)	e:	PB	(N/A); NIM,
	UCN Node Type (APM Box)	e:	PB	(APM); APM
	UCN Node Type (APM Points)	e:	PB	(APM); APM
NODFSTAT	UCN Node's Functional Status	e:	Supr	(Basic); Basic, Full
NODINPTS	Number of Digital Input Connections	I	PB	(1); 0, 1, 2
NODOPTS	Number of Digital Output Connections	I	PB	(1); 0, 1, 2, 3
NOLINPTS	Number of Logic Inputs	I	View	(Logic = 12, DevCtl = 0); 0 – 12
NOLOGBLK	Number of Logic Blocks	I	View	(N/A); 0 – 24
NOLOPTS	Number of Logic Output Connections	I	View	(N/A); Logic = 0 - 12, DevCtl = 0 – 2
NOPGATE	Number of Primary Gates	I	PB	(0); 0 – 4
NOPINPTS	Number of PV Input Connections	I	View	(Special); 0 – 6
NORQUAVG	Avg. Number Nodes to which UCN Requests are made	R	View	(0) N/A
NORQUMAX	Max. Number Nodes to which UCN Requests are made	R	View	(0) N/A
NORSPAVG	Avg. Number Nodes to which UCN Responses are made	R	View	(0) N/A

Parameter	Description	Type	Lock	(Default) and Range
NORSPMAX	Max. Number Nodes to which UCN Responses are made	R	View	(0) N/A
NORSSEQ	Number of Ramp/Soak Pairs in the Sequence	I	Eng/PB	(2); 2 – 12
NOSGATE	Number of Secondary Gates	I	PB	(0); 0 – 2
NOTRAAVG	Avg. Number of Nodes to which UCN Transactions are made	R	View	(0); N/A
NOTRAMAX	Max. Number of Nodes to which UCN Transactions are made	R	View	(0); N/A
NOSIOVRD	Number of Safety Interlock Overrides	R	View	(0); 0 - No Limit
NOSTATES	Number of Digital States	I	PB	(2); 2 & 3
NOTRANS(n)	Accumulated Transitions (n = 0 - 2)	R	View	(0); 0 - no limit
NPARAVG	Avg. Number of UCN Parameter Access per Second	R	View	(0); N/A
NPARMAX	Max. Number of UCN Parameter Access per Second	R	View	(0); N/A
NPMSLOT	Number of Process Module Points	I	PB	(0); 0 – 160
NPRQUAVG(n)	Avg. Number of UCN Parameter Requests per Second (n = 0 - 64)	R	View	(0); N/A
NPRQUMAX(n)	Max. Number of UCN Parameter Requests per Second (n = 0 - 64)	R	View	(0); N/A
NPRSPAVG(n)	Avg. Number of UCN Parameter Responses per Second (n = 0 - 64)	R	View	(0); N/A
NPRSPMAX(n)	Max. Number of UCN Parameter Responses per Second (n = 0 - 64)	R	View	(0); N/A
NPVSLLOT	Number of Regulatory PV Slots	I	PB	(0); 0 – 80

Parameter	Description	Type	Lock	(Default) and Range
NPVTEXT	No. of entries in the NIM PV Text Library	I	View	(0); N/A
NSCANITM	Number of Scan Items in APM Scan Table	I	View	(0); 0 – 50
NSIO	Inverted Interlocks Value	L	Engr	(On); On, Off
NSTRING	Number of Strings in APM Box Point Number of Strings in Array Point String Array	I I	PB PB	(0); 0 - 16,384 (0); 0 - 8 if EXTDAT=IO_STR, else 0 - 240 if EXTDATA ≠ IO_STR
NTIME	Number of Times in APM Box Point No. of Times in Array Point Time Array	I I	PB PB	(0); 0 – 4096 (0); 0 – 240
NTIMER	Number of Box Timer Points	I	View	(0); 0 – 64
NTRAAVG	Avg. Number of UCN Transactions	R	View	(0); N/A
NTRAMAX	Max. Number of UCN Transactions	R	View	(0); N/A
NTRQUAVG(n)	Avg. No. of UCN Transaction Requests	R	View	(0); N/A. (n = 0 - 64)
NTRQUMAX(n)	Max. No. of UCN Transaction Requests	R	View	(0); N/A. (n = 0 - 64)
NTRSPAVG(n)	Avg. No. of UCN Transaction Responses	R	View	(0); N/A. (n = 0 - 64)
NTRSPMAX(n)	Max. No. of UCN Transaction Responses	R	View	(0); N/A. (n = 0 - 64)
NTWKNUM	Network Number	I	PB	(N/A); 1 – 20
NXTSOAKV	Next Soak Value	R	View	(N/A); ≥0.0
OFFNRMFL	Off-Normal Alarm Flag	L	View	(Off); Off – On
OFFNRMPR	Off-Normal Alarm Priority	e:	Eng	(NoAction - R670); Emergency, High, Low, JnlPrint, Printer, Journal, NoAction
OFFPULSE	Off-Pulse Command	R	Oper	(N/A); 0.0 - 60.0 seconds
OLDAV	Old Accumulated Value (DigIn)	I	View	(N/A); ≥0
	Old Accumulated Value (Totalizr)	R	View	(N/A); ≥ 0.0

Parameter	Description	Type	Lock	(Default) and Range
ONPULSE	On Pulse Command	R	Oper	(N/A); 0.0 - 60.0 Seconds
OP	Output in Percent (AnalogOut & RegCtl)	R	Oper	(-6.9% F/scale); -6.9 to 106.9%
	Digital State Output (DigComp, DevCtl)	SDE	Oper	(STATETXT0); STATETXT0, 1 or 2 = Descriptor, STATETXT3= NONE
	Pulsed Digital Output (DigOut)	R	Prog	(0.0%); 0 to 100.0%
OPALDB	Output Alarm Dead Band (R510 & later)	R	Eng/PB	(5 Units); 0 - 25 Output Units
OPCHAR	Output Characterization Option	L	PB	(Off); Off – On
OPCMD	Output Command, (DevCtl, DigComp)	L	Prog	(Off); Off, On
	Output Command	e:	View	(N/A); Raise, Idle, Lower
OPEU	Output Value in Engineering Units	R	View	(N/A); N/A
OPFINAL	Final OP in % Sent to Control Element (Analog Output)	R	View	(-6.9%); N/A
	(DevCtl, DigComp)	SDE	Oper	(Statetxt(0); Statetxt (0, 1, 2), None
OPHAFL	Output High Alarm Flag (R510 & >)	L	View	(Off); Off – On
OPHIFL	Output High Limit Flag	L	Prog	(Off); Off – On
OPHILM	Output High Limit in Percent	R	Supr	(105%); OPLOLM - 106.9%, NaN
OPHIPR	Output High Alarm Priority (R510 & >)	e:	Eng/PB	(NoAction - R670); Emergency, High, Low, JnlPrint, Printer, Journal, NoAction
OPHISRC	Output High Flag Input Source	U	PB	(Null); See Full PRD
OPHITP	Output High Alarm Trip Point (R510 & >)	R	Supr	(NaN); NaN, OPLOTP – OPHILM
OPIN0	Input Coordinate Number 0 in Percent	R	View	(-6.9%); N/A
OPIN1-4	Input Coordinates Number 1-4 in %	R	Supr	(N/A); ≥ Prev. Coordinate but ≤ Next Coordinate
OPIN5	Input Coordinate Number 5 in %	R	View	(106.9%); N/A
OPLAFL	Output Low Alarm Flag (R510 & >)	L	View	(Off); Off – On

Parameter	Description	Type	Lock	(Default) and Range
OPLOFL	Output Low Limit Flag	L	Prog	(Off); Off – On
OPLOLM	Output Low Limit in %	R	Supr	(-5.0%); -6.9% to OPHILM, NaN
OPLOPR	Output Low Alarm Priority (R510 & >)	e:	Eng/PB	(NoAction - R670); Emergency, High, Low, JnlPrint, Printer, Journal, NoAction
OPLOSRC	Output Low Flag Input Source	U	Null	(PB); See APM PRD
OPLOTP	Output Low Alarm Trip Point (R510 & >)	R	Supr	(NaN); NaN, OPLOLM – OPHITP
OPMCHLM	Output Minimum Change Limit in %	R	Supr	(0.0); ≥0.0, NaN
OPOUT0	Output Coordinate Number 0 in %	R	View	(-6.9%); N/A
OPOUT1-4	Output Coordinates Number 1-4 in %	R	Supr	(N/A); ≥ Previous Coordinate but ≤ Next Coordinate
OPOUT5	Output Coordinate Number 5 in %	R	View	(106.9%); N/A
OPRATRFL	Operator Mode Attribute Flag	L	View	(N/A); Off – On
OPRINPUT	Last Operator Input per sequence message	R	Oper	(0.0); N/A
OPROCLM	OP Rate of Change Limit in %	R	Supr	(NaN); ≥ 0.1, NaN
OPTDIR	Direct/Reverse Action	e:	Eng/PB	(Direct); Direct, Reverse
OROFFSET	Override Offset	L	Eng/PB	(On); Off – On
OROPT	Override Option	L	Eng/PB	(Off); Off – On
OUT0-12	Output Coordinates Number 0-12	R	Supr	(NaN); Anything but NaN
OUTIND	Direct/Reverse Action (R620 & later)	e:	Eng/PB	(Direct); Direct, Reverse
OVERFLOW	Accumulation Overflow Flag	L	View	(Off); Off – On
OVERLAP	Overlapping Array Slot Number	I	View	(0); 0 - Value of NARRSLOT
OVERPHAS	Override Current Phase	e:	Special	(Blank); Forward – Backward

Parameter	Description	Type	Lock	(Default) and Range
OVERSTAT	Override Current Statement	e:	Special	(Blank); Forward – Backward
OVERSTEP	Override Current Step	e:	Special	(Blank); Forward – Backward
OVERVAL	Overview Value in Percent	I	Eng/PB	(25%); 0 - 100%
OVRCTIM	Time Over High Trip Limit	T	View	(0); 0 - 9999 days
OVRDALOP	Override Alarm Option	e:	Eng/PB	(None); None, Auto Rtn, Cnfm Rqd
OVRDALPR	Override Alarm Priority	e:	Eng	(NoAction - R670); JnlPrint, Printer, Emergency, High, Low, Journal, NoAction
OVRDCONF	Override Confirmation Flag	L	Oper	(Off); Off – On
OVRDESC	Override Alarm Descriptor	S	View	(Blank); SIO Desc, IO-I2 Desc, L1-L12 Desc
OVRDInFL	Override Alarm Flag (n = 0 - 2)	L	View	(Off); Off – On
OVRDSIFL	Safety Override Alarm Flag	L	View	(Off); Off – On
P	Pressure Input	R	View	(1.0); ≥ 0.0
P0	Zero Reference for Pressure	R	Supr	(0.0); N/A, NaN
P0 - P2	Permissive Interlocks for Output State 0, 1, and 2	L	Engr	(On); Off – On
P1 - P6	PV Inputs 1-6 (RegPV)	R	View	(NaN); N/A
PnSTS	P1-P6 Status (n = 1 - 6)	e:	View	(Bad); Bad, Uncrtm, Normal
PAUSETIM	State 0 Pause Time	I	Supr	(0); 0 – 1000
PERIOD	Period (ProcMod, Timer)	R	PB	(1.0); 1.0 Seconds
	Period (DigOut)	R	Eng/PB	(10.0); 1.0 - 120.0 Seconds
	Period(RegPV, RegCtl Logic, DigComp, DevCtl)	R	View	(0.5); 0625 - 4.0 Seconds
		R	PB	(0.25); 0625 - 4.0 Seconds
PGALGID(n)	Primary Gate Algorithm ID (n=1 - 4)	e:	PB	(NULL); NULL, AND, OR, NAND, NOR, XOR, PAND, POR, PNAND, PNOR, PXOR

Parameter	Description	Type	Lock	(Default) and Range
PGDSTN(n)	Primary Gate Destination (n=1 - 4)	e:	PB	(NONE); NONE, SIO, IO, I1, I2, P0, P1, P2, SOCMD0, SOCMD1, SOCMD2, OPCMD, SG1, SG2
PGPLSWTHn	Primary Gate Pulse Width (n =1 - 4)	I	Supr	(0); 0 - 8000 seconds
PGSO(n)	Primary Gate Status Output (n =1 - 4)	L	View	(Off); On – Off
PHASE	Phase Name	S	View	(Spaces); N/A
PHASEAL	Phase Alarm	L	View	(Off); On – Off
PHASETIM	Phase Time	I	View	(0); 0 - 9999 Minutes
PHREMTIM	Phase Time Remaining	T	View	(0); N/A
PIALGID(n)	Primary Input Gate Algorithm ID (n=1 - 12)	e:	PB	(Null); Null, Invert, GT, GE, LT, LE, EQ, NE, GT2, GE2, LT2, LE2, EQ2, NE2, IN_SET
PIDEABD(n)	Primary Input Gate Deadband (n=1 - 12)	R	Supr	(1.0); > 0
PIDFORM	PID Controller Form	e:	Eng/PB	(Interact); Interact, Ideal
PIDSTN(n)	PV Input Connection Destination (n = 1 - 6)	P	View	(Varies by Algo Type, Equation, N); 1-8 Character Valid Parameter Name
PINN1-12	Primary Input Constants Numeric	R	Supr	(0.0); <> NaN
PISO1-12	Primary Input Gate Output Value	L	View	(Off); Off, On
PISRC(n)	PV Input Connection Source (n = 1 - 6)	E	PB	(Null.Null); "TagName.Parameter"
	Primary Input Source (DevCtl) (n = 1 - 12)	e:	PB	(Null); Null, L1 - L12
PIUOTDCF	Open Thermocouple Detection Enable (STI, LLMUX)	L	Eng/View	(On); On – Off

Parameter	Description	Type	Lock	(Default) and Range
PIUOTDCF(n)	Open Thermocouple Detection Enable (LLAI) (n = 1 - 168)	L	Supr	(On); On – Off
PKGOPT	APMM Hardware Packaging Option	e:	PB	(Redun); Nonredun, Redun, Redun_2F Redun_IO, Nodefalt
PMEVOVFL	APMM Event Overflow Flag	L	View	(); Off, On
PMMCHAER	APMM's I/O Link Chnl A Error Count	I	View	(0); ≥ 0
PMMCHASL	APMM's I/O Link Chnl A Silence Count	I	View	(0); ≥ 0
PMMCHBER	APMM's I/O Link Chnl B Error Count	I	View	(0); ≥ 0
PMMCHBSL	APMM's I/O Link Chnl B Silence Count	I	View	(0); ≥ 0
PMMCMD	APMM Command	e:	OnProc	(None); None, Run, Idle, ShutDown, SwapPri, Coldstrt, SelChnA, SelChnB, Warmstrt, RsUCNLSb, RslolCom
PMMCOMER	APMM's I/O Link Communication Error Status	e:	View	(N/A); InvAlert, InvDest, InvSourc, InvChCnt, InvCmd, Checksum, No_Resp, ChTimOut, MsgOvRun, GapError, LpBckErr, NTH_0 TknRecov, RplBufOv, None
PMMCTLST	APMM Control Processor Status	L	View	(Off); Off, On
PMMIOLST	I/O Link Status	e:	View	(); Notconfg, Confgmis,OK, Idle, Softfail, Idlesf, Nonexist, Noresp, Poweron, Commerr, Unavail
PMMOPER	APMM Operation	e:	View	(N/A); NonRedun, Primary, Secondry
PMMRECCH	APMM's I/O Link Current Receive Channel	e:	View	(N/A); ChannelA, ChannelB

Parameter	Description	Type	Lock	(Default) and Range
PMMSTS	APMM Primary Status	e:	View	(N/A); Offnet, Alive, OK, Idle, IdleSF, Fail, Loading, ConfgMis, AliveSF SoftFail, Test, TestSF, S_Idle, S_Idle SF, S_OK, S_SFFail, S_Pause (S=Simulation)
PNTFORM	Point Form	e:	PB/View	(Full); Full, Componnt
PNTMODTY	Point's IOP Type	e:	View	(NotConf) HLAI, LLAI, STIM, DISOE, AO, AO_16, DI, DO, DO_32, PI, LLMUX, NotConfg, SI, APMM, SI
PNTNODTY	Point's Node Type	e:	View	(N/A); NIM, APM, NotConfg
PNTSTATE	Point's Overall State	e:	View	(N/A); OK, Failed, Idle, Uncertn
PNTTYPE	Point Type	e:	PB	(Null); AnalgIn, AnalgOut, DigCom, DigIn, DigOut, ProcModl, RegPV, RegCtl, Logic, Null, DevCtl, Timer, ProcModl
POSITION	APMM File Position	e:	View	(N/A); Left, Right, File_1, File_2, Pref, Non_Pref, None, Unknown
PR2PREFF	Peer-To-Peer Comm Efficiency %	R	View	(100); 0 – 100
PRIMMOD	Primary Module Identifier	E	Eng	(Null); A-Z, 0-9,
PRMDESC	Parameter Descriptor Assignmnt.	e:	Eng/PB	(N/A); L1-12, FL1-12, NN1-4, SO1-16
PROCMOD	Process Module Operating State	e:	Special	(Off); Off, Norm, Hold, Shdn, Emsd, Strt, Stop
PSTS	Pressure Input Value Status	e:	View	(Normal); Normal, Uncertn, Bad
PTDESC	Point Descriptor	S	PB	(Blank); A-Z 0-9 Space ! % & ' () + - / : ; > < = ? _ , . \$
PTEXCST	Point Execution State	e:	Supr	(Inactive); Inactive, Active
PROCMOD	Process Module Operating State	e:	Special	(Off); Off, Norm, Hold, Shdn, Emsd, Strt, Stop

Parameter	Description	Type	Lock	(Default) and Range
PSTS	Pressure Input Value Status	e:	View	(Normal); Normal, Uncertn, Bad
PTDESC	Point Descriptor	S	PB	(Blank); A-Z 0-9 Space ! % & ' () + - / : ; > < = ? _ . \$
PTEXCST	Point Execution State	e:	Supr	(Inactive); Inactive, Active
PTINAL	Point in Alarm Indicator	L	View	(Off); Off – On
PTORST	Point Override Status	e:	Prog	(NotCon); NotCon, Sel, NotSel
PTSTSIOL	Redundant Partner Status as seen from the IOL	e:	View	(); OffNet, ConfgMis, Idle, Idlesf, Ok, Fail, SoftFail, Powron, Alive, Alivesf, TestSF, Test, Loading, Notconfg, Nosynch, Unavail
PTSTSUCN	Redundant Partner Status as seen from the UCN	e:	View	(); Offnet, Confgms, Idle, Idlesf, Ok, Softfail, Fail, Poweron, Alive, Alivesf, Loading, Notconfg, Nosynch, Unavail
PULSEWTH	Pulse Width for Point Outputs	R	Supr	(1.0); 0.0 - 60.0 Seconds
PV	Process Variable (AnalogIn, PI) Current State (DigComp, DevCtl) Current State (DigIn) Current State (Flag) Process Variable (Numeric) Process Variable (RegCtl) Process Variable (RegPV) Current Value (Timer)	R e: e: e: R R R I	Oper Oper Oper Oper Oper View Oper View	(NaN); PVEXEUHI - PVEXEULO, NaN (BADPVTXT); PVSTATES(0)-(4) (Off); STATETXT(0) or STATETXT(1) (Blank); STATETXT(0) or STATETXT(1) (NaN); N/A (NaN); N/A (NaN); N/A (0); 0 to 32000 Seconds or Minutes
PVALDB	PV Alarm Deadband in Percent	e:	Eng/PB	(one); Half, One, Two, Three, Four, Five, EU
PVALDBEU	EU Value of Alarm Deadband	R	Eng/PB	(NaN); > 0

Parameter	Description	Type	Lock	(Default) and Range
PVALGID	PV Algorithm Identifier	e:	PB	(Null); DataAcq, FlowComp, MidOf3, HiLoAvg, Summer, VdtLdLag, Totalizr, GenLin, CalcuLtr, Null
PVAUTO	PV Auto Value (AnalogIn, PI)	R	View	(NaN); N/A
	Current PV State (DigComp, DevCtl)	e:	View	(BADPVTXT); STATETXT(0), (1), (2),
	Current PV State (DigIn)	e:	View	MOVPVTXT, BADPVTXT
	PV Value Fetched Using Control Input Connection (RegCtl)	R	View	(N/A); STATETXT(0) or STATETXT(1)
	PV Auto Value (RegPV)	R	View	(NaN); N/A
PVAUTOST	PV Auto Value (PosProp, PIDPosPr)	R	View	(NaN); N/A
	PV Auto Value Status	e:	View	(Bad); Bad, Normal, Uncertn
PVCALC	Calculated PV (AnalogIn)	R	View	(NaN); PVEXEUHI – PVEXEULO
	Calculated PV (RegPV)	R	View	(NaN); N/A, NaN
PVCHAR	PV Characterization Option	e:	PB	(Linear); Sqroot, Btherm, Etherm, Jtherm, Ktherm, Rtherm, Stherm, Ttherm, Ntherm, RPtherm, DinRtd, NickLRtd, CopprRtd, NiNiMOTC, Linear, JisRtd, Pt100DinRtd, Pt100JisRtd, Pt200Rtd, Pt500Rtd, CU10Rtd, CU25Rtd, W3W25TC, W5W26TC, RHRAD, RTD_Ohms
PVCHGDLY	PV Change Delay time in Seconds	I	Supr	(0); 0 – 60
PVCLAMP	PV Clamping Option	e:	Eng/PB	(NoClamp); Clamp, NoClamp

Parameter	Description	Type	Lock	(Default) and Range
PVEQN	PV Equation Type (FlowComp) PV Equation Type (HiLoAvg, MidOf3) PV Equation Type (Summer) PV Equation Type (Totalizr) PV Equation Type (VdtLdLag)	e: e: e: e: e:	Eng/PB Eng/PB PB Eng/PB Eng/PB	(EqA); EqA – EqE (EqA); EqA – EqC (EqA); EqA & EqB (EqA); EqA – EqF (EqA); EqA – EqD
PVEUHI	PV High Range in Engineering Units	R	Eng	(100); PVEULO - PVEXEUHI
PVEULO	PV Low Range in Engineering Units	R	Eng	(0); PVEXEULO - PVEUHI
PVEXEUHI	PV Extended Hi Range in Engineering Units	R	Eng	(102.9); ≥ PVEUHI
PVEXEULO	PV Extended Lo Range in Engineering Units	R	Eng	(-2.9); ≤ PVEULO
PVEXHIFL	PV Extended Hi Range Violation	L	View	(Off); Off – On
PVEXLOFL	PV Extended Lo Range Violation	L	View	(Off); Off – On
PVFL(n)	PV Flag (DigComp) (n = 0 - 2)	L	View	(Off); Off, On
PVFL	PV Flag (DigIn, Flag)	L	Oper	(Off); Off, On
PVFORMAT	PV Decimal Point Format	e:	Eng	(D1 = XXX.X); D0, D1 D2, D3
PVHHFL	PV High High Alarm Flag	L	View	(Off); Off – On
PVHHPR	PV High High Alarm Priority	e:	Eng	(NoAction - R670); JnlPrint, Printer, Emergncy, High, Low, Journal, NoAction
PVHHTP	PV Hi Hi Alarm Trip Point (Analog, RegPV) PV Hi Hi Alarm Trip Point (RegCtl PosProp, PIDPosPr)	R R	Supr Supr	(NaN); PVHITP - PVEXEUHI, NaN (NaN); PVHITP - PVEUHI, NaN
PVHIFL	PV High Alarm Flag	L	View	(Off); Off – On

Parameter	Description	Type	Lock	(Default) and Range
PVHIPR	PV High Alarm Priority	e:	Eng	(NoAction - R670); JnlPrint, Printer, Emergency, High, Low, Journal, NoAction
PVHITP	PV High Alarm Trip Point	R	Supr	(NaN); PVLOTP - PVHHTP, NaN
PVINIT	PV Initialization Request Flag	L	Prog	(Off); Off – On
PVLLFL	PV Low Low Alarm Flag	L	View	(Off); Off – On
PVLLPR	PV Low Low Alarm Priority	e:	Eng	(NoAction - R670); JnlPrint, Printer, Emergency, High, Low, Journal, NoAction
PVLLTP	PV Low Low Alarm Trip Point (AnalogIn, RegPV)	R	Supr	(NaN); PVXEUULO - PVLOTP, NaN
	PV Low Low Alarm Trip Point (RegCtl, PIDPosPr, PosProp)	R	Supr	(NaN); PVEULO - PVLOTP, NaN
PVLOFL	PV Low Alarm Flag	L	View	(Off); Off – On
PVLOPR	PV Low Alarm Priority	e:	Eng/PB	(NoAction - R670); JnlPrint, Printer, Emergency, Low, High, Journal, NoAction
PVLOTP	PV Low Alarm Trip Point	R	Supr	(NaN); PVLLTP - PVHITP, NaN
PVNORMAL	PV Normal State	e:	Supr	(N/A); STATETXT(0) - STATETXT(2), None (requires lock = Engr)
PVNORMFL	PV Value's Normal State Flag	L	View	(Off); Off – On
PVP	PV in Percent	R	View	(NaN); N/A
PVRAW	PV Raw Value (AnalogIn)	R	Oper	(NaN); N/A
	PV Raw Value (PI, STI)	R	View	(NaN); N/A
	Raw State of Field Contacts (DigIn)	L	View	(Off); Off-On

Parameter	Description	Type	Lock	(Default) and Range
PVRAWHI	PV Raw High Range	R	Eng/PB	(NaN); PVRAWLO to 100 (for a 0_100_mV Input), PVRAWLO to 1 [for a Slidewire Input (ratio)]
PVRAWLO	PV Raw Low Range	R	Eng/PB	(NaN); 0.0 - PVRAWHI (0 to 100 Microvolts for a 0_100_mV Input, or 0 to 1 Ratio for a Slidewire Input)
PVROCFL	PV Negative Rate-of-Change Alarm Flag	L	View	(Off); Off – On
PVROCNP	PV Negative Rate-of-Change Alarm Priority	e:	Eng	(NoAction - R670); JnlPrint, Printer, Emergency, Low, High, Journal, NoAction
PVROCNP	PV Negative Rate-of-Change Trip Point	R	Supr	(NaN); ≥ 0.0, NaN
PVROCPL	PV Positive Rate-of-Change Alarm Flag	L	View	(Off); Off – On
PVROCPR	PV Positive Rate-of-Change Alarm Priority	e:	Eng	(NoAction - R670); JnlPrint, Printer, Emergency, Low, High, Journal, NoAction
PVROCPT	PV Positive Rate-of-Change Trip Point	R	Supr	(NaN); ≥ 0.0, NaN
PVSGCHTP	PV Significant Change Alarm Trip Point	R	Supr	(NaN); ≥ 0.0, NaN
PVSOURCE	PV Source	e:	Oper	(Auto); Auto, Man, Sub,Track
PVSRCOPT	PV Source Option	e:	Eng/PB	(OnlyAuto); All, OnlyAuto
PVSTATES(n)	PV State Descriptors (n = 0 - 4)	S	View	(N/A); N/A
PVSTS	Status of PV Input Value	e:	View	(Bad); Bad, Normal, Uncertn
PVTEMP	PV Temperature Scale	e:	PB	Degrees(C); C, F, R, K
PVTRACK	PV Tracking Option	e:	Eng/PB	(NoTrack); Track, NoTrack
PVTV	PV Target Value in Engineering Units	R	Oper	(NaN); PVEXEULO - PVEXEUHI, NaN
PVTVP	PV Target Value in Percent	R	View	(NaN); ≥ 0.0, NaN
PVTXTOPT	PV Text Option	L	PB	(Off); Off, On

Parameter	Description	Type	Lock	(Default) and Range
Q	Steam Quality Factor Input	R	View	(1.0); ≥ 0.0, NaN
QSTS	Q Input Value Status	e:	View	(Normal); Normal, Uncertn, Bad
R1(n)-R2(n)	Real Input Number 1 - 2 (n = 1 - 24)	e:	PB	(L1); L1 - L12 & NN1 - NN8
RAISDSTN	Raise Output Pulse Destination	U	PB	(Null); ONPULSE – OFFPULSE
RAISTIM	Raise Output Pulse Time	R	View	(N/A); N/A, NaN
RAISRATE	Raise OP Stroke Rate in %/Sec	R	Supr	(100.0); > 0.0
RAMPTIME	Ramp Time in Minutes	R	Oper	(0.0); ≥ 0.0
RARWSTS	Remote Anti-Reset Windup Status	e:	View	(Normal); Normal, Hi, Lo, HiLo
RATE1	Rate at Which Bias Ramps Down (AutoMan)	R	Supr	(0.0); ≥ 0.0, NaN
	Rate at Which Bias Ramps Down (RatioCtl)	R	Supr	(NaN); ≥ 0.0, NaN
RATE1-12	Ramp Rates for RampSoak Segments 1-12 (RampSoak)	R	Supr	(NaN); N/A
RATIO	Ratio	R	Oper	(1.0); RTLOLM – RTHILM
RBOPT	Ratio Bias Option	e:	Eng/PB	(NoRatBi); NoRatBi, FixRatBi, AutoRat, AutoBi
RCASOPT	Remote Cascade Option (AnalgOut)	e:	Eng/PB	(None); None, Ddc
	Remote Cascade Option (RegCtl)	e:	Eng/PB	(None); None, Spc, Ddc, DdcRsp, Rsp
RCASSHED	Remote Cascade Shed	L	View	(Off); Off – On
REDTAG	Red Tag State	e:	Supr	(Off); Off – On
REMSOAKT	Remaining Soak Time	R	Oper	(0.0); 0.0 - 720.0 Minutes
RESETFL	Reset Flag (DigIn, Totalizr)	L	Prog	(Off); Off – On
	Reset Flag (DevCtl, DigComp)	L	Oper	(Off); Off – On

Parameter	Description	Type	Lock	(Default) and Range
RESETVAL	Accumulator Reset Value (Digin) Reset Value (Totalizr)	I R	Oper Oper	(0); 0 – 32767 (0.0); N/A
RESTART	Process Module Restart State	e:	View	(None); None, Failover, Warm, Cold, PTACTVN
RFB	Reset Feedback Input in %	R	View	(N/A); $\geq 0.0\%$
RG	Reference Specific Gravity	R	Supr	(1.0); N/A
RINITREQ	Remote Initialization Request (PosProp, PIDPosPr)	L	View	(On); Off – On
RINITVAL	Remote Initialization Value	R	View	(NaN); N/A, NaN
RJRAW	Reference Junction's Raw Count in μ Volts	R	View	(NaN); N/A
RJTEMP	Reference Junction's Temperature	R	View	(); N/A
RP	Minimum Pulse Ratio (PosProp)	R	Supr	(1.0); 0.01 – 100
	Reference Pressure (Flowcomp)	R	Supr	(1.0); N/A
RQ	Reference Steam Quality Factor	R	Supr	(1.0); N/A
RSPBGP\$	Ramp/Soak Percent Bar Graph Parameter	R	View	(N/A); ≥ 0
RSTROPT	Restart Option	e:	Eng	(Off); Off, Restart
RT	Dead Time Ratio (PosProp)	R	Supr	(1.0); 0.01 - 100.0
	Reference Temperature (Flowcomp)	R	Supr	(1.0); N/A
RTHILM	Ratio High Limit	R	Supr	(100); RTLOLM - 100, NaN
RTLOLM	Ratio Low Limit	R	Supr	(0.0001); 0.0001 - RTHILM, NaN
RUNSTATE	Run State	L	View	(Off); Off, On
RV	Remaining Time	I	View	(0); >0
RX	Reference Steam Compressibility	R	Supr	(1.0); anything but NaN

Parameter	Description	Type	Lock	(Default) and Range
S0BOXCLR S1BOXCLR S2BOXCLR	State Box Color	e:	View	(N/A); Red, Green, White, Black, Cyan, Yellow, Blue, Magenta
S1	Tracking Switch (PidErfb) Transmitter Status (STI)	L S	Prog View	(Off); On – Off (Blank); Blank, N/A
S1, S2	Mark 1 and Mark 2 Flags (RampSoak)	L	View	(Off); On – Off
S1(n)-S4(n)	Status Inputs 1-4 (Logic) (n = 1 - 24)	e:	PB	(L1); L1 - L12, FL1 - FL12, SO1 - SO24
	Select X1-X4 Request Flag (Switch)	L	Oper	(On); Off – On
S1BGNTIM, S2BGNTIM	Mark 1 and Mark 2 Begin Times	R	Supr	(0.0); 0 - 120 Minutes
S1ENDTIM, S2ENDTIM	Mark 1 and Mark 2 End Times	R	Supr	(0.0); 0 - 120 Minutes
S1REV(n) - S3REV(n)	S1, S2, S3 Inputs Reversed (n = 1 - 24)	L	PB	(Off); On – Off
S1SEGID, S2SEGID	Mark 1 and Mark 2 Segment Identifiers	e:	Supr	(Ramp1); Ramp1 - Ramp12,
SAFEOP	Safe Operation for Safety Shutdown	R	Engr	Soak1 - Soak12
SAFEOPCMD	Safe Operation Command	e:	Engr	(N/A); -6.9 - 106.9%, NaN
SCANPER	SI Data Scan Period	R	PB	(Idle); Idle, Raise, Lower
SCANPRI	SI Data FTA Scan Priority	e:	PB	(1.0); .25, .5, 1.0 seconds

Parameter	Description	Type	Lock	(Default) and Range
SCANRATE	Scan Rate	e:	PB	(Low); Low, High (Reg1Log1); Reg1Log1, Reg1Log2, Reg1Log4, Reg2Log2, Reg2Log4, Reg4Log4, Null
SEALOPT	Seal in Circuit Option	e:	Eng/PB	(None); None, Sealin
SECOND	Current Second	I	View	(N/A); 0 – 59
SECSYNC	Secondary Synchronization Status	e:	View	(); Synched, NoSynch
SECVAR	Secondary Variable Secondary Variable (DevCtl)	R R	View View	(NaN); N/A, NaN (0.0); Real numbers including NaN)
SEGTOT	Total Number of Segments	I	Supr	(1); 1- 12
SEGTYPE	Segment Type	e:	View	(N/A); Ramp, Soak
SELINP	Selected Input (HiLoAvg) Selected Input (MidOf3)	e: e:	View View	(SelectP1); SelectP1 - SelectP6 (SelectP1); SelectP1 - SelectP3
SELXINP	Selected X Input (ORSel) Selected X Input (Switch)	e: e:	View Oper	(SelectX1); SelectX1 - SelectX4 (SelectX1); SelectX1 - SelectX4
SENSRYTP	Sensor Type (HLAI & LLAI) Sensor Type (LLMUX) Sensor Type (STI)	e: e: e:	PB PB PB	(1_5_V); 1_5_V, 0_5_V, P4_2_V, _5_V, 0_100_MV, Thermcpl, RTD, Slidwire (0_100_mV); 0_100_mV, Thermcpl, RTD (Spt_Dp); Spt_Dp, Spt_Gp, Spt_Ap, Stt, Sfm

Parameter	Description	Type	Lock	(Default) and Range
SEQERR	Sequence Error (Continued)	I	View	(0); 0 - 255, as Follows: 0 - No Error 1-100 - Not Used Error Codes 101 - Not Used 102 - Array Index Error 103 - Illegal IMD Code 104 - Illegal Variable/Operator Code 105 - Interpreter Stack Overflow 106 - GOTO Destination Error 107 - Key Level Error 108 - Configuration Mismatch Error 109 - I/O Link Prefetch Overflow 110 - Subroutine Nesting Level Error 111 - Illegal Value Error 112 - Fail Statement 113 - (IOL - Prefetch buffer full) 114 - (IOL - Poststore buffer full) 115 - (UCN - Prefetch buffer full) 116 - (UCN - Poststore buffer full) 117-164 - Not Used 165 - Sequence Halted by Operator 166 - Sequence Jumped to an Abnormal Condition Handler That was Not Enabled

Parameter	Description	Type	Lock	(Default) and Range
SEQERR	Sequence Error (Continued)	I	View	167 – Not Used Failure Codes 168 - Timeout Condition on WAIT Statement 169 - Attempt was Made to Start a Sequence that was Not Loaded 170 - Communication Error in READ/WRITE Statement 171 - Communication Error During I/O Link Access; also generated for all Post-Store problems 172 - Range Error 173 - Attempt was Made to Write to a Point That was Not in the Proper Mode 174 - Interlock Error 175-255 - Not Used
SEQEXEC	Sequence Execution State	e:	View	(NL); NL, DLL, Loaded, Run, Pause, Error, Fail, End
SEQMODE	Sequence Execution Mode	e:	Special	(Auto); Auto, SemiAuto, SnglStep
SEQNAME	Sequence Name	S	View	(Blank); N/A
SEQOBSZ	Sequence Prog. Size	I	View	(0); >0
SEQPR	Sequence Priority	e:	Eng	(NoAction - R670); JnlPrint, Printer, Emergency, Low, High, Journal, NoAction
SEQPRGSZ	Sequence Prog. Size	I	View	(N/A); N/A
SEQPROC	Sequence Processing	e:	PB	(1_PU); 1_PU, 2_PU
SEQSLTSZ	Sequence Slot Size	I	PB	(0); ≥0

Parameter	Description	Type	Lock	(Default) and Range
SERIALNO	Serial No./PROM Number of the Smart Transmitter	S	View	(0); ≥0 (Blank); N/A
SGALGID(n)	Secondary Gate ID (n = 1 - 2)	e:	PB	(None); Null, AND, OR, NAND, NOR, XOR, PAND, POR, PNAND, PNOR, PXOR
SGDSTN(n)	Secondary Gate Destination (n = 1 - 2)	e:	PB	(None); None, SIO, IO, I1, I2, P0, P1, P2, SOCMD0-2, OPCMD
SGPLSWTH(n)	Pulse Width for Secondary Gate (n = 1 - 2)	I	Supr	(0); 0-8000
SGSO(n)	Status Output for Secondary Gates (n = 1 - 2)	L	View	(Off); Off, On
SHEDMODE	Shed Mode (RegCtl)	e:	Eng	(Man); Man, Bcas, Auto
SHEDTIME	Remote Cascade Shed Time	I	Eng/PB	(0); 0 - 1000 Seconds
SHUTDOWN	Shutdown Command Flag	L	Prog	(Off); Off – On
SIO	Safety Override Interlock Flag	L	Prog	(Off); Off – On
SIOALOPT	Safety Override Alarm	e:	Eng	(None); None, Auto, Rtn, Cnfm, Rgd
SIOALPR	Safety Override Alarm Priority	e:	Eng	(NoAction - R670); JnlPrint, Printer, Emergency, High, Low, Journal, NoAction
SIALGID(n)	Secondary Input Gate Algorithm ID (n = 1 - 12)	e:	PB	(Null); Null, Dly, Ondly, Offdly, Pulse, Maxpulse, Minpulse

Parameter	Description	Type	Lock	(Default) and Range
SIDLYTIM(n)	Secondary Input Gate Delay/Pulse Width (n = 1 - 12)	I	Supr	(0); 0-8000
SIDSTN(n)	Secondary Input Gate Destination	e:	PB	(None); SIO, I0-I2, P0-P2, SOCMD0-2, OPCMD, SG1-SG2, PG1-PG4
SIM_TXT	Simulation Indicator	S	View	(N/A); N/A
SI0CONF	Safety Override Interlock Alarm Confirmation flag	L	Oper	(Off); N/A
SISO(n)	Status Output for Secondary Input Gate (n = 1 - 12)	L	View	(Off); Off, On

Parameter	Description	Type	Lock	(Default) and Range
SLOTNUM	Slot Number	I	PB	(N/A); HLA and STI = 1 - 16 LLAI = 1 - 8 AnalogOut = 1 - 8 or 1 - 16 Array = 1 - 256 but ≤ NARSLOT Box Numeric = 1 - 2047 Box Timer = 1 - 64 but ≤ NTIMER DevCtl = 1 - 160 but ≤ NDEVSLT DigComp = 1 - 512 but ≤ NDCSLOT DigIn = 1 - 32 DigOut = 1 - 16 or 1 - 32 Logic = 1 - 80 but ≤ NLOGSLOT ProcMod = 1 - 160 but ≤ NPMSLOT Box Timer 1 – 64 (N/A); RegCIL = 1 - 160 but ≤ NCTLSLOT RegPV = 1 - 80 but ≤ NPVSLT Box Flag = 1 - 2047 LLMUX = 1 - 32 PI = 1 – 8
SLWSRCID	Slidewire Voltage Source Identifier	I	Eng/PB	(1); 1 – 16
SNAME(n)	Subroutine Name (ProcMod) (n = 1-2)	S	View	(spaces); N/A
SO	Status Output (Digout)	L	Oper	(Off); Off – On
	Status Output (Timer)	L	View	(Off); Off – On

Parameter	Description	Type	Lock	(Default) and Range
SO1 - SO24	Logic Block Status Output	L	View	(Off); On – Off
SO(I)	Status Output Array DevCtl, DigComp (I = State)	L	View	(Off); On – Off
SOAKT1-12	Soak Time for Soak Segments 1-12	R	Supr	(0.0); 0.0 - 120.0 Minutes
SOAKV1-12	Soak Value for Soak Segments 1-12	R	Supr	(NaN); N/A
SOCMD(I)	Digital Composite Output Status Command (I = State)	L	Prog	(Off); Off – On
SP	Setpoint of the PV in Engineering Units (RegCtl) Preset Time (Timer)	R I	Oper	(0.0); SPLOLM-SPHILM (0); 0 – 32000
SPEUHI	Setpoint Engineering Unit Range High	R	View	(N/A); ≥ SPEULO
SPEULO	Setpoint Engineering Unit Range Low	R	View	(N/A); ≤ SPEUHI
SPFORMAT	Setpoint Decimal Point Format	e:	View	(N/A); D0, D1, D2, D3
SPHIFL	Setpoint High Limit Violation Flag	L	View	(Off); Off – On
SPHILM	Setpoint High Limit	R	Supr	(NaN); SPLOLM - SPEUHI, NaN
SPLOCK	Setpoint Lock	e:	Eng	(Operator); Operator, Supervis, Engineer, Program
SPLOFL	Setpoint Low Limit Violation Flag	L	View	(Off); Off – On
SPLOLM	Setpoint Low Limit	R	Supr	(NaN); SPEULO - SPHILM, NaN
SPOPT	Setpoint Option	e:	Eng/PB	(None); None, TV, Asp
SPP	Setpoint In Percent	R	View	(N/A); N/A
SPTV	Setpoint Target Value in Engineering Units	R	Oper	(N/A); SPLOLM - SPHILM, NaN
SPTVP	Set Point Target Value in %	R	View	(N/A); ≥ 0.0%
SRQUTAVG	Avg. UCN Store Request Trip Time	R	View	(NaN); N/A

Parameter	Description	Type	Lock	(Default) and Range
SRQUTMAX	Max. UCN Store Request Trip Time	R	View	(NaN); N/A
SRSPТАVG	Avg. UCN Store Resp. Trip Time	R	View	(NaN); N/A
SRSPТMAX	Max. UCN Store Resp. Trip Time	R	View	(NaN); N/A
SSTEP(n)	Subroutine Step Name (n = 1 - 2)	S	View	(Blank); N/A
SSTMT(n)	Subroutine Statement Number (n = 1 - 2)	I	View	(Blank); 0 – 255
ST0_OP1 through ST2_OP3	State 0 - Output 1 Through State 2 - Output 3	L	Eng/PB	(Off); Off – On
STARTFL	Start Command Flag	L	Prog	(Off); Off – On
STATE	Timer State (Timer, DigIn, Totalizr) Current State (STI)	e: e:	View View	(Stopped); Stopped, Running (N/A); Loading, Loadcomp, Loadfail, Calib, Calcomp, Calfail, OK, DBChange
STATE0 through STATE2	Current State	S	View	(On, Off, State2); N/A
STATETXT(n)	State Descriptor 0 - 3 Text	S	PB	STATETXT(0) = Off, STATETXT(1) = On, STATETXT(2) = STATE2 text/\$Null STATETXT(3) = None
STATEMENT	Statement	I	View	(0); 1 – 255
STATTIMn	State Time (n = 0 - 2)	T	View	(0); 0 - 4000 days
STCHGOPT	State Change Option	e:	Eng/PB	(None); None, STATE0

Parameter	Description	Type	Lock	(Default) and Range
STDBYMAN	Standby Manual Flag	L	View	(Off); Off – On
STDBYSTS(n)	Standby Status Flag (n = 1 -168)	L	View	(); Off – On
STEP	Step	S	View	(Blank); N/A
STI_EU	Smart Transmitter Engineering Units	e:	Eng	(InH2O); InH2O, MMHG, PSI, KPA, MBar, Bar, G_SQCM, KG_SQCM, MPA, MMH20, INHG, Deg_C, Deg_F, Deg_K, Deg_R, MV, V, Ohms, CM_HR, Gal_HR, LIT_HR, CC_HR, CM_Min, Gal_Min, Lit_Min, CC_Min, CM_DAY, Gal_Day, KGal_Day, BRL_Day, CM_Sec, Ft_Sec, M_Sec, PRCNT, BLANK, LBS, KG, TONS, GRAMS, OZ, GAL, BRL, CUB_M, LITERS, MLITRES, FL_OZ, FEET, METERS, MM, INCHES, KG_CUM, G_CUM, LBS_CUFT, LBS_CUIN
STISWVER	Software Revision Level of the Smart Transmitter	S	View	(Blank); N/A, MPA
STITAG	Transmitter Tag Name of the Smart Transmitter	S	Eng/PB	(Spaces); A - Z and 0 –9
STOPFL	Stop Command Flag	L	Prog	(Off); Off – On
STR8(n)	Box String Variables APM Box, (n = 1 – 16384) Local String Variables (n = 1 - 16)	S S	Oper Special	(Spaces); N/A (Spaces); N/A
STR16(n)	Local String Variables (n = 1 - 8)	S	Special	(Spaces); N/A
STR32(n)	Local String Variables (n = 1 - 4)	S	Special	(Spaces); N/A

Parameter	Description	Type	Lock	(Default) and Range
STR64(n)	Local String Variables (n = 1 - 2)	S	Special	(Spaces); N/A
STR8(i)	Array Point String Variables	S	Special	(N/A); $1 \leq i \leq (\text{NSTRING})/(8/\text{STRLEN})$
STR16(i)	Array Point String Variables	S	Special	(N/A); $1 \leq i \leq (\text{NSTRING})/(16/\text{STRLEN})$
STR32(i)	Array Point String Variables	S	Special	(N/A); $1 \leq i \leq (\text{NSTRING})/(32/\text{STRLEN})$
STR64(i)	Array Point String Variables	S	Special	(N/A); $1 \leq i \leq (\text{NSTRING})/(64/\text{STRLEN})$
STRDESC	String Array Descriptor	S	PB	(Spaces; N/A)
STRLEN	Array Point String Length	I	PB	(8); 8, 16, 32, 64
STRSTIX	String Array Start Index	R	PB	(0); 0 - NSTRING or 0 - 99,999
STRTFAIL	Startup/Failover Information	S	View	(); 00 - FF (hexadecimal)
STSMMSG	Status Message	e:	Oper	(MSGTXT(0); to MSGTXT(15)
SUMSLTSZ	Total Configured Memory for Sequence Programs	I	View	(0); >0
SUSPSTAT	Suspend State	e:	View	(None); None, ConfMsg, Wait, InputMsg, Feedback
SUSPTIME	Suspension Timer	I	View	(0); >0 - 32,767
SVALDB	Secvar Alarm Deadband (DevCtl)	e:	Eng/PB	(One); Half, One, Two, Three, Four, Five, EU
SVALDB	Secvar Alarm Deadband (DevCtl)	e:	Eng/PB	(One); Half, One, Two, Three, Four, Five, EU

Parameter	Description	Type	Lock	(Default) and Range
SVALDBEU	Secvar Alarm Deadband in Eng Units	R	Eng/PB	(0); Allowable Eng. Units
SVDESC	Secvar Descriptor	S	PB	(Blank); 8 Characters
SVEUDESC	Secvar Eng. Unit Descriptor	S	PB	(Blank); 8 Characters
SVEUHI	Secvar Range High	R	Eng/PB	(NaN); <> NaN
SVEULO	Secvar Range Lo	R	Eng/PB	(NaN); <> NaN
SVHHFL	Secvar High High Alarm Flag	L	View	(Off); Off, On
SVHHPR	Secvar High High Alarm Priority	e:	Engr	(NoAction - R670); JnlPrint, Printer, Emergency, High, Low, Journal, NoAction
SVHHTP	Secvar High High Alarm Trip Point	R	Supr	(NaN); > SVHITP or NaN
SVHHTPP	Secvar High High Alarm Trip Point Percent	R	Supr	(NaN); 0 – 100
SVHIFL	Secvar High Alarm Flag	L	View	(Off); Off, On
SVHIPR	Secvar High Alarm Priority	e:	Engr	(NoAction - R670); JnlPrint, Printer, Emergency, High, Low, Journal, NoAction
SVHITP	Secvar High Alarm Trip Point	R	Supr	(NaN); 0 – 100
SVHITPP	Secvar High Alarm Trip Point Percent	R	Supr	(NaN); 0 – 100
SVP	Secvar in Percent of Eng. Range	R	View	(NaN); 0 – 100
SVPEAK	Peak Value of Secvar	R	View	(NaN); 0 – 100
SVSRC	Secvar Input Connection	U	PB	(Null); See APM PRD
SVTV	Secondary Variable Target Value	R	Oper	(NaN); SVEULO to SVEUHI
SVTV	Secondary Variable Target Value in %	R	Oper	(NaN); 0 –100

Parameter	Description	Type	Lock	(Default) and Range
SWTCHACT(n)	IOP Synchronization (n = 1 - 40)	L	View	(On); Off, On
SYNCHSTS	Primary/Secondary Database Synchronization Status	e:	View	(None); OK, Warning, Fail
T	Temperature Input	R	View	(1); ≥ 0.0
T0	Zero Reference for Temperature	R	Supr	(0.0); N/A
T1	Integral Time in Minutes	R	Supr	(0.0); 0.0 - 1440.0 Minutes
T2	Derivative Time in Minutes	R	Supr	(0.0); 0.0 - 1440.0 Minutes
TCRNGOPT	Thermocouple Range Option	e:	Eng/PB	(Normal); Normal, Extended
TD	Total Dead Time in Minutes	R	Supr	(0.0); ≥ 0.0 Minutes
TF	PV Filter Lag Time in Minutes	R	Supr	(0.0); 0.0 - 60.0 Minutes
TIME(n)	Box Time Variables (n = 1- 4095)	T	Oper	(0); N/A
	ProcMod Local Time Variables (n = 1-4)	T	Special	(0); N/A
	Array Points Time Variables TIME (i)	T	Special	(N/A); $1 < i < NTIME$
TIMEBASE	Time Base (Timer)	e:	Eng	(Seconds); Seconds, Minutes
	Time Base (Totalizr, PI)	e:	Eng/PB	(Minutes); Seconds, Minutes, Hours
TIMEDESC	Time Array Descriptor	S	PB	(Spaces); N/A,
TIMESECS(n)	Array Point Time Variables (n = 1-240)	T	Special	PB(N/A); $1 < i < NTIME$
TIMESTIX	Time Array Start Index	R	PB	(0); 0 – NTIME

Parameter	Description	Type	Lock	(Default) and Range
TIMESYNC	Timesynch Control	e:	PB	(Disable); Enable, Disable
TLD	Lead Time Constant in Minutes	R	Supr	(0.0); -1440.0 to +1440.0 Minutes
TLG1, TLG2	Lag Time Constants 1 and 2 in Minutes	R	Supr	(0.0); 0.0 - 1440.0 Minutes
TMCMD(n)	Timer Commands for Timers 1-64	e:	Oper	(N/A); None, Start, Stop, Reset, ResetStirt
TMPV(n)	Timer PV in Seconds or Minutes for Timers 1-64	I	View	(0); > 0
TMRV(n)	Timer RV – Remaining Time for Timers 1-64	I	View	(0); > 0
TMSO(n)	Timer Status Outputs for Timers 1-64	L	View	(Off); Off – On
TMSP(n)	Timer SP in Seconds/Minutes for Timers 1-64	I	Oper	(0); 0 – 32000
TMST(n)	Timer States for Timers 1-64	e:	View	(Stopped); Stopped, Running
TMTB(n)	Time Base for Timers 1-64	e:	Engr	(Seconds); Seconds, Minutes
TRACKING	Selected Input Tracking	L	Eng/PB	(Off); Off – On
TRANTIMO-2	Transition Time	T	View	(0); Time Stamp
TRATAVG	Avg. UCN Transaction Trip Time	R	View	(NaN); N/A
TRATMAX	Max. UCN Transaction Trip Time	R	View	(NaN); N/A
TRFB	Tracking Feedback Input in EU	R	View	(NaN); N/A
TSTS	Temperature Input Value Status	e:	View	(Normal); Normal, Uncertn, Bad
TVPROC	Target Value Processor State	e:	Oper	(Off); Off, Preset, Run
UCNRECHN	UCN Receive Channel	e:	View	(ChannelA); ChannelA -ChannelB

Parameter	Description	Type	Lock	(Default) and Range
UCNSCANT	Peer-to-Peer Scan Period in seconds	R	Eng/ PB	(0.5); 0.5, 1.0
UNCMDFL	Uncommanded Change Alarm Flag	L	View	(Off); Off – On
UNIT	Unit Identifier	S	PB	(N/A); A-Z, 0-9 (Max of 100 Unit Identifiers)
UPGRADE	NIM Upgrade Status	e:	Oper	(OK); OK, Upgrade
URL	Upper Range Limit	R	Eng/ View	(N/A); N/A – NaN
URV	Upper Range Value	R	Supr/ View	(NaN); N/A – NaN
USERID	User ID Reservation	S	Oper	(Dashes); 16 Characters
UTSDRIFT	UCN Node Clock Drift	I	View	(N/A)
UTSNODE	Last UCN Syncher Node	I	View	0; 0, 1 – 64
UTSTBCRV	TBC Revision	S	View	(N/A); 5 – 15
UTSTIMST	Timesynch State of UCN Node	e:	View	0; Initial, Failed, Degraded, LCN Bad, LCN OK, OK
UTSTIME	Current Time in LCN Node	T	View	(N/A); N/A
WARMSTRT	Warm start flag	L	View	(N/A); On – Off
WEEKDAY	Current Weekday	I	View	(N/A); 1 - 7 (1 = Sunday)
WITHBIASn	I/O Module Physical Bias State (n=1 - 40)	L	View	(On); On – Off

Parameter	Description	Type	Lock	(Default) and Range
X	Steam Compressibility Input (FlowComp)	R	View	(1.0); ≥ 0.0
X1	X1 Input Value to be Biased (AutoMan)	R	Prog	(NaN); ≥ 0.0 , N/A
X1 - X4	Inputs 1-4 (IncrSum, OrSel)	R	Prog	(NaN); ≥ 0.0 , NaN
X2	Bias Adjustment Input (AutoMan)	R	View	(N/A); N/A
	Input Number 2 (RatioCtl)	R	View	(N/A); N/A
X2FILT	Filtered value of the x2 input	R	View	(N/A); N/A
X2TF	X2 input filter lag time in minutes	R	Supr	(0.0); 0 - 60 minutes
XEUHI	X Input High Range in Engineering Units	R	Eng	(100.0, Equivalent to 100%); > XEULO
XEULO	X Input Low Range in Engineering Units	R	Eng	(0.0, Equivalent to 0%); < XEUHI
XSTS	X Input Value Status	e:	View	(Normal); Normal, Uncertrn, Bad
YEAR	Current Year	I	View	(N/A); 1979 - 2115