
Honeywell

HPM
Parameters Pocket Guide
HP09-641
03/2013

CONTENTS

Introduction	2
Description of Parameter Definitions	2
Point Types	4
Algorithms	5
Parameters Per Point Type	6
Parameters Per Algorithm Type	28
Parameter Definitions	73

Introduction

This guide contains definitions of the parameters for TPN Release 684 used in the High-Performance Process Manager (HPM) and Network Interface Module (NIM). This guide is a condensed version of the HPM parameters that are defined in the *PM Family Parameter Reference Dictionary*.

Description of Parameter Definitions

The parameter definitions in this guide are listed alphabetically by parameter name. Each parameter definition contains the parameter name, description, data type, access lock, default, and range.

Parameter

The **Parameter** column contains the short name (up to 8 characters) of the parameters. The parameter names are listed in alphabetical order.

Description

The **Description** column contains the long name of the parameter.

Type

Abbreviations in the **Type** column have the following meaning:

A = ASCII	I = Integer	S = String
BR = Blind Record	L = Logical	SDE = Self Def. Enumeration
e: = enumeration	P = Parameter Identifier	T = Time
E = Entity.Parameter	R = Real	U =Universal Entity.Parameter

Lock

Entries in the **Lock** column define who or what can change the parameter's value or option.

Note: With TPN R684, Enhanced Universal Control Network (EUCN) is introduced. In EUCN, the traditional coaxial cable system is no longer utilized and is replaced with a Fault Tolerant Ethernet (FTE) based communication network. Throughout the document, unless specifically mentioned, the terms HPM, NIM, and UCN are interchangeably used with the terms **EHPM**, **ENIM**, and **EUCN** respectively.

The following chart shows who/what can change the parameter's value for each access lock. Access level defines who or what is requesting a parameter value or option change.

Lock	Access Level						
	Oper	Supr	Engr	Cont	HPMMCc	Prog	PB
Oper	*	*	*	*	*	*	*
Supr		*	*	*	*	*	*
Eng or Eg			*	*	*	*	*
OnProc	*	*	*				
Supr/Eng		*	*				
EgOnly			*				
Prog				*	*	*	*
Eng/PB			*				*
PB						*	
View							

Note:

Cont = Continuous_Control (from a Module on the LCN)

Eng/PB = Engineer or Point Builder

EgOnly = Engineer Only

Engr or Eg = Engineer

OnProc = On Process

Oper = Operator

PB = Point Builder

HPMMCc = PMM_Continuous_Control (from HPMM)

Prog = CL/PM Sequence Program

Supr = Supervisor

Supr/Eng = Supervisor or Engineer

Special = see full PRD

View = Read Only

Default and Range

The default value and range for the parameter are listed in this column. The default value is the value assigned by the system when the user does not make an entry for the respective parameter. The default value is enclosed by parentheses (). The range of the value is listed to the right of the parentheses. "See XPM PRD" means the explanation is lengthy; refer to the same parameter in the *PM Family Parameter Reference Dictionary*.

Point Types			
Abbreviation	Definition	Abbreviation	Definition
AnalogIn	Analog Input	LLMUX	Low Level Multiplexer*
AnalogOut	Analog Output	Logic	Logic
Array	Array	NIM	Network Interface Module
Box	HPM Box	Numeric	Box Numeric
DevCtl	Device Control	PI	Pulse Input*
DigComp	Digital Composite	ProcMod	Process Module
DigIn	Digital Input	RegCtl	Regulatory Control
DigOut	Digital Output	RegPV	Regulatory PV
Flag	Box Flag	SDI	Serial Device Interface
IOP	Input/Output	IS	Serial Interface
	Processor	STI	Smart Field Transmitter*
		Timer	Box Timer
		UCN	Universal Control Network

*These are subsets of the Analog Input type

Algorithms

Abbreviation	Definition
AutoMan	Auto Manual Ctl Algo
CaLcuLtr	Calculator PV Algo
DataAcq	Data Acquisition PV Algo
FlowComp	Flow Compensation PV Algo
GenLin	General Linearity PV Algo
HiLoAvg	High-Low Average PV Algo
IncrSum	Incremental Summer Ctl Algo
ModOf3	Middle Of Three PV Algo
OPSelect	Output Select Ctl Algo
ORSel	Override Selector Ctl Algo
Pid	Proportional, Integral, and Derivative Ctl Algo
PidErfb	PID With External Reset Feedback Ctl Algo
PidFf	PID With Feedforward Ctl Algo
PidPosPr	PID With Position Proportional
PosProp	Position Proportional Ctl Algo
RampSoak	Ramp Soak Ctl Algo
RatioCtl	Ratio Control Ctl Algo
Summer	Summer PV Algo
Switch	Switch Ctl Algo
TotaLizr	Totalizer PV Algo
VdtLdLag	Variable Deadtime With Lead Lag PV Algo

Parameters Per Point Type

Analog Input

The parameters of the Analog Input Data point are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	INPTDIR	PVCALC	PVROCNTP (F)
\$AUXUNIT (F)	KEYWORD	PVCHAR	PVROCPFL
\$CDETAIL	LASTPV	PVCLAMP	PVROCPPR (F)
\$DLBADAL (F)	LOCUTOFF	PVEUHI	PVROCPPT (F)
\$HHSELECT (F)	LRL	PVEULO	PVSOURCE (F)
\$HISELECT (F)	LRV	PVEUEUHI	PVSRCOPT (F)
\$LSELECT (F)	MODNUM	PVEUEULO	PVSTS
\$LOSELECT (F)	NAME	PVEXHIFL	PVTEMP
\$OLDEVDS	NODENUM	PVEXLOFL	PVTV (F)
\$REALARM (F)	NODETYP	PVFORMAT	PVTVP (F)
\$RNSELECT (F)	NTWKNUM	PVHHFL	RJTEMP
\$RPSELECT (F)	OTDENBLE	PVHHPR (F)	S1
ALENBST (F)	OVERVAL (F)	PVHHTP (F)	SECVAR
ASSOCDSP	PIUOTDCF	PVHIFL	SENSRTYP
AVDELTHS	PNTFORM	PVHIPR (F)	SERIALNO
AVSTS	PNTMODTY	PVHITP (F)	SFSTS
BADPVFL (F)	PNTNODTY	PVLLFL	SLOTNUM
BADPVPR (F)	PNTSTATE	PVLLPR	SLWSRCID
C1, C2	PNTTYPE	PVLLTP (F)	STATE
CJTACT	PRIMMOD (F)	PVLOFL	STI EU
COMMAND	PTDESC	PVLOPR (F)	STISWVER
CONTCUT (F)	PTEXECST	PVLOTP (F)	STITAG
DLYTIME (F)	PTINAL	PVP	TCRNGOPT
DAMPING	PV	PVRAW	TF
DECONF	PVALDB (F)	PVRAWHI	TIMEBASE
EUDESC	PVALDBEU (F)	PVRAWLO	UNIT
HIGHAL (F)	PVAUTO	PVROCNFL	URL
HIGHALPR (F)	PVAUTOST	PVROCNPR (F)	URV

Analog Output

The parameters of the Analog Output Data point are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$CDETAIL	NODENUM	OPOUT5
\$MODESEL (F)	NODETYP	OPTDIR
\$OLDEVDS	NTWKNUM	OUTIND
\$OPTOL	OP	PNTFORM
ASSOCDSP	OPCHAR	PNTMODTY
CASREQ (F)	OPFINAL	PNTNODTY
EUDESC	OPIN0	PNTSTATE
KEYWORD	OPIN1	PNTTYPE
LOCALMAN	OPIN2	PRIMMOD (F)
MODATTR (F)	OPIN3	PTDESC
MODE (F)	OPIN4	PTEXECST
MODEAPPL (F)	OPIN5	RCASOPT
MODEPERM (F)	OPOUT0	REDTAG (F)
MODNUM	OPOUT1	RINITREQ (F)
NAME	OPOUT2	SLOTNUM
NMODATTR (F)	OPOUT3	STDBYMAN
NMODE (F)	OPOUT4	UNIT

Array

The parameters of the Array Data point are listed below in alphabetical order.
This point is only available in the Full.form.

\$CDETAIL	NNDESC	STRSTIX
AB_DATA1	NNUMERIC	STSMMSG
AB_DATA2	NNSTIX	TIME
AB_DATA3	NODENUM	TIMEDESC
AB_DATA4	NODETYP	TIMESECS
ASSOCDSP	NSTRING	TIMESTIX
AUXDATA1	NTIME	UNIT
AUXDATA2	NTWKNUM	USERID
AUXDATA3	OVERLAP	
AUXDATA4	PERIOD	
BADPVFL (F)	PNTFORM	
CNFMU	PNTNODTY	
CNFPU	PNTTYPE	
DEVADDR	PRIMMOD (F)	
ERRCODE	PTDESC	
EXTDATA	PTEXCST	
FL	SCANPRI	
FLDESC	SLOTNUM	
FLSTIX	SPLOCK	
FTANUM	STR8	
INITREQ	STR16	
IOPNUM	STR32	
KEYWORD	STR64	
NFLAG	STRDESC	
NN	STRLEN	

HPM Box

The parameters of the High-Performance Process Manager Box Data Point are listed below in alphabetical order.

\$NSFPMS	IOLCHERT	LSIOLORN	NODETYP	SAFOPCMD
BADPVTXT	IOLCMD IOLPERSW	LSPPXORN	NODFSTAT	SCANRATE
CHPINOPR	IOMCARD	LSUCNORN	NOPTS	SCANPER
CNFPUP	IOMCHAER	MDMHWREV	NPMSLOT	SECOND
CNFPUP	IOMCHASL	MINUTE	NPVSLOT	SEQPRGSZ
CRIOLORN	IOMCHBER	MONTH	NSTRING	SEQPROC
CRPPXOR	IOMCHBSL	MOVPTXT	NTIME	STR8
CRUCNOR	IOMCMD	NARRSLOT	NTIMER	SUMSLTSZ
CTLOPT	IOMCOMER	NCTLSLOT	PKGOPT	SWTCHACT
CTLPATCH	IOMFILE	NDCSLOT	PMMCHAER	TIME
CYCLETIM	IOMOPER	NDEVSLOT	PMMCHASL	TMCMD
DATE	IOMREALT	NFASTCTL	PMMCHBER	TMPV
DAY	IOMRECHN	NFASTDC	PMMCHBSL	TMSP
DB_VALID	IOMSEVER	NFASTDEV	PMMCMD	TMRV
EUNDESC	IOMSTS	NFASTLOG	PMMCOMER	TMSP
FL	IOMTYPE	NFASTPV	PMMCTLST	TMSO
FTA1TYPE	IONTOKEN	NFLAG	PMMFLPOS	TMST
FTA2TYPE	IOP	NLOGSLOT	PMMOPER	TMTB
HOUR	IOPNUM	NN	PMMRECCH	UTSDRIFT
IOLASTS	IOPSTR1	NNUMERIC	PMMSEVER	USTSNODE
IOLBSTS	IOPSTR2	NODEASSN	PMMSFSTS	UTSTBCRV
IOLCHAER	IORECCHN	NODECMD	PMMSTS	UTSTIME
IOLCHASL	IOSTKNDR	NODECONF	PNTNODTY	UTSTIMST
IOLCHBER	IOSSTS	NODENUM	POSITION	WEE KDAY
IOLCHBSL	IOTKNSTL	NODESTS	RJTEMP	YEAR

Box Flag

The parameters of the Box Flag Data Point are listed below in alphabetical order. (F) indicates that the Parameter is applicable when the PNTFORM = Full; an * indicates that the parameter is applicable to Flag slots 1-1024.

\$AUXUNIT (F)	HIGHAL (F)*	PV
\$CDETAIL	KEYWORD	PVFL
\$OFSELECT (F)	NAME	S0BOXCLR
\$REALARM (F)	NODENUM	S1BOXCLR
ALENBST (F)*	NODETYP	SLOTNUM
ALPRIOR*	NTWKNUM	STATE0
ASSOCDSP	NODETYP	STATE1
BOXCLR	OFFNRMPR (F)	STATETXT
CNFMU	PNTNODTY	UNIT
CNFPU	PNTTYPE	
CONTCUT (F)*	PNTFORM	
EIPPCODE (F)*	PRIMMOD (F)*	
EUDESC	PTDESC (F)	

Box Numeric

The parameters of the Box Numeric Data Point are listed below in alphabetical order.

\$AUXUNIT	KEYWORD	PVALDBEU
\$CDETAIL	NAME	PVFORMAT
\$HISELCT (F)	NODENUM	PVHIFL
\$LOSELCT (F)	NODETYP	PVHIPR
ALENBST	NTWKNUM	PVHITP
ASSOCDSP	PTINAL	PVLOFL
CONTCUT	PNTFORM	PVLOPR
CNFMU	PNTNODTY	PVLOTP
CNFPU	PNTTYPE	SLOTNUM
EUDESC	PRIMMOD (F)	UNIT
HIGHAL	PTDESC	
HIGHALPR	PV	

Box Timer

The parameters of the Box Timer Data Point are listed below in alphabetical order.

\$CDETAIL	PTDESC
ASSOCDSP	PV
COMMAND	RV
EUDESC	SLOTNUM
KEYWORD	SO
NAME	SP
NODENUM	STATE
NODETYP	TIMEBASE
NTWKNUM	TIMOUTFL
PERIOD	UNIT
PNTNODTY	
PNTTYPE	
PRIMMOD (F)	

Device Control

The parameters of the Device Control Data Point are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$AUXUNIT (F)		D1_0	(#Inputs=1)
\$CDETAIL		D1_1	(#Inputs=1)
\$INITOPT		D2	(#Inputs=2)
\$MODESEL	(#Outputs>0)	D2D1_00	(#Inputs=2)
\$OFSELECT (F)		D2D1_01	(#Inputs=2)
\$REALARM (F)		D2D1_10	(#Inputs=2)
ACCELTIM (F)		D2D1_11	(#Inputs=2)
ALENBST (F)		D3	
ASSOCDSP		D4	
BADPVFL		D5	
BADPVPR (F)		DB_VALID	
BADPVTXT		DEADBAND	
BADSVFL	(#Inputs>0)	DEADTIME	
BADSVPR (F)		DISRC	(#Inputs>0)
BOXCLR		DODSTN	(#Outputs>0)
BYPASS		EIPPCODE (F)	
CMDDISFL		EUDESC	
CMDDISPR (F)		EVTOPT (F)	(#Inputs>0)
CMDFALFL		FBTIME (F)	
CMDFALTM		FL 1-12	
CNFMU		HIGHAL	
CNFPU		HIGHALPR	
CONTCUT (F)		HISVPEAK	
D1	(#Inputs>0)		(Continued)

Device Control (Continued)

The parameters of the Device Control Data Point are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

IO - 2	(#Outputs>0)	MASKTIM	
IOCONF		MAXTIM0H	
I1CONF		MAXTIM1H	
I2CONF		MAXTIM2H	
INITMAN		MAXTRAN0	
INITREQ		MAXTRAN1	
KEYWORD		MAXTRAN2	
L		MODATTR	(#Outputs>0)
LIBADOPT		MODE	(#Outputs>0)
LIDESC		MODEAPPL	(#Outputs>0)
LISRC 1-12		MODEPERM	(#Outputs>0)
LMREV		MODNUM	
LMSRC		MOMSTATE	(#Outputs>0)
LOCALMAN	(#Outputs>0)	MOVVPVFL	(#Inputs>0)
LODSTN 1-2		MOVVPVXT	
LOENBL 1-2		NAME	
LOGICSRC		NI0	(#Outputs>0)
LOSRC 1-2		NI1	(#Outputs>0)
MAINDAT		NI2	(#Outputs>0)
MAINTOPT		NMODATTR	(#Outputs>0)
MANMODFL			

(Continued)

Device Control (Continued)

Continuation of the parameters of the Device Control Data Point is listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

NMODE	(#Outputs>0)	OFFNRMPL (F)	
NN		OP	(#Outputs>0)
NNINSET 1-10		OPCMD	(#Outputs>0)
NODENUM		OPFINAL	(#Outputs>0)
NODETYP		OPRATRFL	(#Outputs>0)
NODINTPS		OROPT	(#Outputs>0)
NODOPTS		OVRCTIM	
NOLINPTS		OVRDCONF	
NOLOPTS		OVRDESC	
NOPGATE		OVRDI0FL	
NOSGATE		OVRD1FL	
NOSIOVRD		OVRD2FL	
NOSTATES		OVRDALOP	
NOTRANS0		OVRDALPR (F)	
NOTRANS1		OVRDSIFL	
NOTRANS2		P0	(#Outputs>0)
NRMATRFL		P1	(#Outputs>0)
NSI0	(#Outputs>0)	P2	(#Outputs>0)
NTWKNUM		PAUSETIM	
OFFNRMFL		PERIOD	
		PGALGID 1 - 4	

(Continued)

Device Control (Continued)

Continuation of the parameters of the Device Control Data Point is listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

PGDSTN 1 - 4		PVNORMFL	
PGPLSWTH 1 - 4		PVSOURCE (F)	(#Inputs>0)
PGSO 1 - 4		PVSRCOPT (F)	(#Inputs>0)
PIALGID 1 - 12		PVSTATES 0 - 4	(#Inputs>0)
PIDEADB1 - 12		PVTXTOPT	
PINN 1 - 12		REDTAG (F)	(#Outputs>0)
PISO 1 - 12		RESETFL	
PISRC 1 - 12		S0BOXCLR	
PNTFORM		S1BOXCLR	
PNTMODTY		S2BOXCLR	
PNTNODTY		SEALOPT	
PNTSTATE		SECVAR	
PNTTYPE		SGALGID 1 - 2	
PRIMMOD (F)		SGDSTN 1 - 2	
PSDLYFL		SGPLSWTH 1 - 2	
PTDESC		SGSO 1 - 2	
PTEXECST (F)		SIO	
PTINAL		SIOALOPT	
PULSEWTH	(#Outputs>0)	SIOALPR (F)	
PV	(#Inputs>0)	SIALGID 1 - 12	
PVAUTO	(#Inputs>0)	SIDLYTIM 1 - 12	
PVFL	(#Inputs>0)	SIDSTN 1 - 12	
PVNORMAL (F)			(Continued)

Device Control (Continued)

Continuation of the parameters of the Device Control Data Point is listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

SISO 1 -12		STATTIM0	SVHHTPP
SLOTNUM		STATTIM1	SVHIFL
SO 0 - 2	(#Outputs>0)	STATTIM2	SVHIPR (F)
SOCMD	(#Outputs>0)	STATETXT0-4	SVHITP
ST0_OP1	(#Outputs>0)	STCHGOPT	SVHITPP
ST0_OP2	(#Outputs>=2)	STMSG	SVP
ST0_OP3	(#Outputs>=3)	SVALDB	SVPEAK
ST1_OP1	(#Outputs>0)	SVALDBEU	SVSRC
ST1_OP2	(#Outputs>=2)	SVDESC	SVTV
ST1_OP3	(#Outputs>=3)	SVEUDESC	SVTV
ST2_OP1	(#Outputs>0)	SVEUHI	TRANTIM0
ST2_OP2	(#Outputs>=2)	SVEULO	TRANTIM1
ST2_OP3	(#Outputs>=3)	SVHHFL	TRANTIM2
STATE0		SVHHPR (F)	UNCMDFL
STATE1		SVHHTP	UNIT
STATE2			USERID

Digital Composite

The parameters of the Digital Composite Data Point are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$AUXUNIT (F)		D2	(#Inputs=2)
\$CDETAIL		D2D1_00	(#Inputs=2)
\$INITOPT		D2D1_01	(#Inputs=2)
\$MODESEL	(#Outputs>0)	D2D1_10	(#Inputs=2)
\$OFSELECT (F)		D2D1_11	(#Inputs=2)
\$REALARM (F)		DISRC1 - 2	(#Inputs>0)
ALENBST (F)		DODSTN1 - 3	(#Outputs>0)
ALPRIOR		EIPPCODE (F)	
ASSOCDSP		EUDESC	
BADCTLPR		EVTOP (F)	(#Inputs>0)
BADPVFL (F)	(#Inputs>0)	FBTIME (F)	
BADPVPR (F)		HIGHAL (F)	
BADPVTXT		HIGHALPR	
BOXCLR		I0 - 2	(#Outputs>0)
BYPASS	(#Outputs>0)	I0CONF	
CMDDISFL		I1CONF	
CMDDISPR (F)		I2CONF	
CMDFALFL		I0DESC	
CMDFALTM		I1DESC	
CNFMU		I2DESC	
CNFPU		INITMAN	
CONTCUT (F)		INITREQ	
D1	(#Inputs>0)	KEYWORD	
D1_0	(#Inputs=1)	LOCALMAN	(#Outputs>0)
D1_1	(#Inputs=1)		(Continued)

Digital Composite (Continued)

Continuation of the parameters of the Digital Composite Data Point is listed below in alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

LOGICSRC		NODETYP	
MAINDAT		NODINTPS	
MAINTOPT		NODOPTS	
MAXTIM0H		NOSTATES	
MAXTIM1H		NOTRANS0	
MAXTIM2H		NOTRANS1	
MAXTRAN0 - 2		NOTRANS2	
MODATTR	(#Outputs>0)	NSIO	(#Outputs>0)
MODE	(#Outputs>0)	NTWKNUM	
MODEAPPL	(#Outputs>0)	OFFNRMFL	
MODEPERM	(#Outputs>0)	OFFNRMPR(F)	
MODNUM		OP	(#Outputs>0)
MOMSTATE	(#Outputs>0)	OPCMD	(#Outputs>0)
MOVVPFL	(#Inputs>0)	OPFINAL	(#Outputs>0)
MOVPTXT		OPRATRFL	(#Outputs>0)
NAME		OPSTTEXT	
NI0		OROPT	(#Outputs>0)
NI1		OVRDALOP	
NI2			
NMODATTR	(#Outputs>0)		(Continued)
NMODE	(#Outputs>0)		
NODENUM			

Digital Composite (Continued)

Continuation of the parameters of the Digital Composite Data Point is listed below in alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

OVRDALPR (F)		PTINAL	
OVRDCONF		PULSEWITH	(#Outputs>0)
OVRDESC		PV	(#Inputs>0)
OVRDIOFL		PVAUTO	(#Inputs>0)
OVRDI1FL		PVFL0 - 2	(#Inputs>0)
OVRDI2FL		PVNORMAL (F)	
OVRDSIFL		PVSOURCE (F)	(#Inputs>0)
P0	(#Outputs>0)	PVSRCOPT (F)	(#Inputs>0)
P1	(#Outputs>0)	PVSTATES0 - 4	(#Inputs>0)
P2	(#Outputs>0)	PVTXTOPT	
PAUSETIM		RETAG (F)	(#Outputs>0)
PERIOD		RESETFL	
PFDLFL		S0BOXCLR	
PNTFORM		S1BOXCLR	
PNTMODTY		S2BOXCLR	
PNTNODTY		SCHSTS	
PNTSTATE		SEALOPT	
PNTTYPE		SIO	
PRGATREL		SIOALOPT	
PRIMMOD (F)		SIOALPR	
PSDLYFL		SLOTNUM	
PTDESC			
PTEXECST			(Continued)

Digital Composite (Continued)

Continuation of the parameters of the Digital Composite Data Point is listed below in alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

SO	(#Outputs>0)	STATTIM0
SOCMD	(#Outputs>0)	STATTIM1
ST0_OP1	(#Outputs>0)	STATTIM2
ST0_OP2	(#Outputs>=2)	STCHGOPT
ST0_OP3	(#Outputs>=3)	STSMMSG
ST1_OP1	(#Outputs>0)	TRANTIM1
ST1_OP2	(#Outputs>=2)	TRANTIM2
ST1_OP3	(#Outputs>=3)	UNCMDFL
ST2_OP1	(#Outputs>0)	UNIT
ST2_OP2	(#Outputs>=2)	USERID
ST2_OP3	(#Outputs>=3)	
STATE0		
STATE1		
STATE2		
STATETXT0 - 4		

Digital Input

The parameters of the Digital Input Data Point are listed below in alphabetical order. (L), (S), or (A)—parameter applies only when DITYPE = Latched, Status, or Accum. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$AUXUNIT (F)	EUDESC	PVAUTO (S) (L)
\$CDETAIL	EVTOP (L) (F)	PVCHGDLY (S) (L) (F)
\$DLYOPT	HIGHAL (S)	PVFL (S) (L)
\$OFSELECT (F)	INPTDIR (F)	PVNORMAL (S) (F)
\$PMDLYTM	KEYWORD	PVNORMFL (S)
\$REALARM (F)	MODNUM	PVRAW
ALENBST (S) (F)	NAME	PVSOURCE (L) (F)
ALMOPT (S) (F)	NODENUM	PVSRCOPT (S) (L) (F)
ALPRIOR	NODETYP	RESETFL (A)
ASSOCDSP	NTWKNUM	RESETVAL (A)
AV (A)	OFFNRMFL (S)	S0BOXCLR (S) (L)
AVTV (A)	OFFNRMPL (S) (F)	S1BOXCLR (S) (L)
AVTVFL (A)	OLDAV (A)	SLOTNUM
BADPVFL (F)	OVERFLOW (A)	STARTFL (A)
BADPVPR	OVERVAL (A) (F)	STATE (A)
BOXCLR (L)	PNTFORM	STATE0 (S) (L)
COMMAND (A)	PNTNODTY	STATE1 (S) (L)
CONTCUT (S) (F)	PNTMODTY	STATETXT (S) (L)
COUNTDWN (A)	PNTSTATE	STOPFL (A)
DEBOUNCE (L) (S) (A)	PNTTYPE	UNIT
DITYPE (F)	PRIMMOD (S) (F)	
DLYTIME (S) (F)	PTDESC	
EIPPCODE (S) (L) (F)	PTEXECST	
	PV (S) (L)	

Digital Output

The parameters of the Digital Output Data Point are listed below in alphabetical order. (S) or (P) parameter applies only when DOTYPE = Status or Pulse Width Modulated (PWM). This point type is available only in the component form.

\$CDETAIL	NODENUM	PNTFORM	S1BOXCLR (S)
ASSOCDSP	NODETYP	PNTMODTY	SLOTNUM
DOTYPE	NTWKNUM	PNTNODTY	SO (S)
EUDESC	OFFPULSE (S)	PNTSTATE	STATE0 (S)
INITREQ	ONPULSE (S)	PNTTYPE	STATE1 (S)
KEYWORD	OP (P)	PTDESC	STDBYMAN
MODNUM	OPTDIR (P)	PTEXCST	UNIT
NAME	PERIOD (P)	S0BOXCLR (S)	

Input/Output Processor

The parameters of the Input/Output Processor Point are listed below in alphabetical order.

CALIBALL	IOMHWREV	IOPSTR2	SLOT0SF
CALIBRJ	IOMLHFST	IORECCHN	STDBYSTS
FAILOPT	IOMOPER	LINEPERD	SWTCHACT
FTAPRES	IOMTYPE	MAXSLOTS	WARMSTRT
FREQ6050	IOMSTS	NODETYP	
IOMACTYP	IONTOKEN	PIUOTDCF	
IOMFWREV	IOPSTR1	RJRAW	

Logic

The parameters of the Logic Data Point (otherwise referred to as the Logic Slot) are listed below in alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$AUXUNIT (F)	CNFPU	NODETYP	S2 1-24
\$CDETAIL	CONTCUT	NOLINPTS	S2REV 1-24
\$REALARM (F)	DEADBAND 1-24	NOLOGBLK	S3 1-24
ALENBST	DLYTIME 1-24	NOLOPTS	S3REV 1-24
ASSOCDSP	EIPPCODE (F)	NORMCYCL	S4 1-24
C1DESC	FL1-12	NTWKNUM	SCHSTS
C2DESC	GENDESC 1-12 (F)	PERIOD	SLOTNUM
C3DESC	HIGHAL	PFDYFL	SO 1-24
C4DESC	HIGHALPR	PNTFORM	STMSG
C1FL	L1-12	PNTMODTY	UNIT
C2FL	LIBADOPT	PNTNODTY	USERID
C3FL	LISRC 1-12	PNTSTATE	
C4FL	LODSTN 1-12	PNTTYPE	
C1PR	LOENBL 1-12	PRIMMOD (F)	
C2PR	LOGALGID 1-16	PRMDESC 1-12 (F)	
C3PR	LOGMIX	PTDESC	
C4PR	LOSRC 1-12	PTEXECST	
C1SRC	MODNUM	PTINAL	
C2SRC	NAME	R1 1-24	
C3SRC	NN1-8	R2 1-24	
C4SRC	NODENUM	S1 1-24	
CNFMU	NODESC (F)	S1REV 1-24	

Process Module

The parameters of the Process Module Data Point are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$CDETAIL	OVERSTAT	SEQOBSZ
ABHEMSD	OVERSTEP	SEQPR (F)
ABHHOLD	PERIOD	SEQSLTSZ
ABHRSTR	PFDLYFL	SLOTNUM
ABHSHDN	PHASE	SNAME 1-2
ACP (F)	PHASEAL	SPLOCK
ALPRIOR (F)	PHASETIM	SSTEP 1-2
ANAME 1-3	PHREMTIM	SSTMT 1-2
ASSOCDSP	PNTFORM	STATEMENT
ASTEP 1-3	PNTTYPE	STEP
ASTMT 1-3	PRIMMOD (F)	STR8 1-16
CNTLLOCK	PSDLYFL	STR16 1-8
CLBACK	PROCMOD	STR32 1-4
FL 1-27	PTDESC	STR64 1-2
MSGPEND	RESTART	STRLEN
NAME (F)	RSTROPT	STSMMSG
NN 1-80	RUNSTATE	SUSPSTAT
NODENUM	SEQERR	SUSPTIM
NODETYP	SEQEXEC	TIME 1-4
NTWKNUM	SEQMODE	UNIT
OVERPHAS	SEQNAME	USERID

Some of the parameters in the listing above are arrays that are not defined in this publication.

UCN Network

The parameters of the UCN Network Data Point are listed below in alphabetical order.

CHPINHWY
CLPZMXC
CLPZMXP
HWYCTLST
LOADSCOP
MSGTXT 0-15
NIMADDR
NIMREV
NIMVERS
NMSGTXT
TIMESYNC
UPGRADE

UCN Node Data Point

The parameters of the UCN Node Data Point are listed below in alphabetical order.

\$UCNLSB 1-50
CABLESTS
CLPZMXC
CLPZMXP
LOADSCOP
MDMHWREV
MODNUM
NMSGTXT
NODESTAT
NODESTS
NODETYP
TIMESYNC
UCNRECHN
UPGRADE
UTSDRIFT
UTSNODE
UTSTBCRV
UTSTIME
UTSTIMST

Parameters Per Algorithm Type

Auto Manual

The parameters of the Auto Manual algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$AUXUNIT (F)	BADCTLPR (F)	EXTSWOPT
\$BADOCMD	BCAMODFL	HIGHAL (F)
\$CDETAIL	CASMODFL	HIGHALPR (F)
\$DLBADAL (F)	CASREQ	INITMAN
\$HHSELECT (F)	CIDSTN	K
\$HISELECT (F)	CISRC	KEYWORD
\$LSELECT (F)	CNFMU	LOCALMAN
\$LOSELECT (F)	CNFPU	MANMODFL
\$MODESEL	CODSTN	MODATTR
\$OPTOL	CONTCUT (F)	MODE
\$REALARM (F)	CTLALGID	MODEAPPL
\$RSELECT (F)	CTLEQN	MODEPERM
\$RPSELECT (F)	CTRLINIT	MODNUM
ALENBST (F)	CV	NAME
ARWNET	CVEUHI	NMODATTR
ARWOP	CVEULO	NMODE
ASSOCDSP	DLYTIME (F)	NOCINPTS
AUTOMODFL	ESWAUTO	
B	ESWCAS	
B0	ESWENBST	(Continued)
BADCTLOP	ESWMAN	
BADCTLPR	EUDESC	

Auto Manual (Continued)

NOCOPTS	PNTNODTY	XEULO
NODENUM	PNTSTATE	
NODETYP	PNTTYPE	
NORMCYCL	PRIMMOD (F)	
NRMATRFL	PSDLYFL	
NRMMODFL	PTDESC (F)	
NTWKNUM	PTEXECST	
OP	PTINAL	
OPALDB (F)	PTORST	
OPEU	RARWSTS	
OPHAFL (F)	RATE1	
OPHIFL	RCASOPT	
OPHILM	RCASSHD	
OPHIPR (F)	REDTAG (F)	
OPHITP (F)	RINITREQ	
OPLAFL (F)	RINITVAL	
OPLOFL	SAFEOP	
OPLOLM	SCHSTS	
OPLOPR (F)	SHEDMODE	
OPLOTP (F)	SHEDTIME	
OPMCHLM	SHUTDOWN	
OPRATRFL	SLOTNUM	
OPROCLM	STDBYMAN	
OUTIND	STSMMSG	
OVERVAL (F)	UNIT	
PERIOD	USERID	
PFDLYFL	X1	
PNTFORM	X2	
PNTMODTY	XEUHI	

Calculator

The parameters of the Calculator PV algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	KEYWORD	PIDSTN
\$AUXUNIT (F)	LASTPV	PISRC
\$CDETAIL	MODNUM	PNTFORM
\$DLBADAL (F)	N	PNTMODTY
\$HHSELECT (F)	NAME	PNTNODTY
\$HISELECT (F)	NODENUM	PNTSTATE
\$LSELECT (F)	NODETYP	PNTTYPE
\$LOSELECT (F)	NOPINPTS	PRIMMOD (F)
\$REALARM (F)	NORMCYCL	PSDLYFL
\$RSELECT (F)	NTWKNUM	PTDESC (F)
\$RPSELECT (F)	OVERVAL (F)	PTEXCST
ALENBST (F)	P1	PTINAL
ASSOCDSP	P1STS	
BADPVFL (F)	P2	(Continued)
BADPVPR (F)	P2STS	
C1	P3	
C2	P3STS	
C3	P4	
C4	P4STS	
CALCEXP	P5	
CONTCUT (F)	P5STS	
DLYTIME (F)	P6	
EUDESC (F)	P6STS	
HIGHAL (F)	PERIOD	
HIGHALPR (F)	PFDLYFL	

Calculator (Continued)

PV
PVALDB (F)
PVALDBEU (F)
PVALGID
PVAUTO
PVAUTOST
PVCALC
PVCLAMP
PVEUHI
PVEULO
PVEXEUHI
PVEXEULO
PVEXHIFL
PVEXLOFL
PVFORMAT
PVHHFL

PVHHPR (F)
PVHHTP (F)
PVHIFL
PVHIPR (F)
PVHITP (F)
PVINIT
PVLLFL
PVLLPR (F)
PVLLTP (F)
PVLOFL
PVLOPR (F)
PVLOTP (F)
PVP
PVROCNFL
PVROCNPR (F)
PVROCNTP (F)

PVROCPFL
PVROCPPR (F)
PVROCPTP (F)
PVSGCHTP (F)
PVSOURCE (F)
PVSRCOPT (F)
PVSTS
PVTVP (F)
PVTVP (F)
SCHSTS
SLOTNUM
STSMMSG
TF
UNIT
USERID

Data Acquisition

The parameters of the Data Acquisition PV algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	MODNUM	PV	PVLLTP (F)
\$AUXUNIT (F)	NAME	PVALDB (F)	PVLOFL
\$CDETAIL	NODENUM	PVALDBEU (F)	PVLOPR (F)
\$DLBADAL (F)	NODETYP	PVALGID	PVLOTP (F)
\$HHSELECT (F)	NOPINPTS	PVAUTO	PVP
\$HISELCT (F)	NORMCYCL	PVAUTOST	PVROCNFL
\$LLSELECT (F)	NTWKNUM	PVCLAMP	PVROCNPR (F)
\$LOSELCT (F)	OVERVAL (F)	PVCLAMP	PVROCNTP (F)
\$REALARM (F)	P1	PVEUHI	PVROCPVFL
\$RNSLCT (F)	P1STS	PVEULO	PVROCPPR (F)
\$RPSELECT (F)	PERIOD	PVEXEUHI	PVROVPTP (F)
ALBNBST (F)	PFDLYFL	PVEXEULO	PVSGCHTP (F)
ASSOCDSP	PIDSTN	PVEXHIFL	PVSOURCE (F)
BADPVFL	PISRC	PVEXLOFL	PVSRCOPT (F)
BADPVPR (F)	PNTFORM	PVFORMAT	PVSTS
CNFMU	PNTMODTY	PVHHFL	PVTV (F)
CNFPU	PNTNODTY	PVHHPR (F)	PVTVP (F)
CONCUT (F)	PNTSTATE	PVHHTP (F)	SCHSTS
DLYTIME (F)	PNTTYPE	PVHIFL	SLOTNUM
EUDESC	PRIMMOD (F)	PVHIPR (F)	STSMMSG
HIGHAL (F)	PSDLYFL	PVHITP (F)	TF
HIGHALPR (F)	PTDESC (F)	PVINIT	UNIT
KEYWORD (F)	PTEXECST	PVLLFL	USERID
LASTPV	PTINAL	PVLLPR (F)	

Flow Compensation

The parameters of the Flow Compensation PV algorithm are listed below in alphabetical order.

(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	G	PNTNODTY
\$AUXUNIT (F)	GSTS	PNTSTATE
\$CDETAIL	HIGHAL (F)	PNTTYPE
\$DLBADAL (F)	HIGHALPR (F)	PRIMMOD (F)
\$REALARM (F)	KEYWORD	PSDYFL
ALENBST (F)	LASTPV	PSTS
ASSOCDSP	MODNUM	PTDESC
BADPVFL	NAME	PTEXCST
BADPVPR (F)	NODENUM	PTINAL
C	NODEtyp	PV
C1	NOPINPTS	PVALDB (F)
C2	NORMCYCL	PVALDBEU (F)
CNFMU	NTWKNUM	PVALGID
CMFPU	OVERVAL (F)	PVAUTO
COMPHILM	P	PVAUTOST
COMPLOLM	PERIOD	PVCALC
COMPTERM	PFDLYFL	PVCHAR
CONTCUT (F)	P0	PVCLAMP
DLYTIME (F)	PIDSTN	PVEQN
EUDESC (F)	PISRC	
F	PNTFORM	(Continued)
FSTS	PNTMODTY	

Flow Compensation (Continued)

PVEUHI	PVLOFL	QSTS
PVEULO	PVLOPR (F)	RG
PVEXEUHI	PVLOTP (F)	RP
PVEXEULO	PVP	RQ
PVEXHIFL	PVROC NFL	RT
PVEXLOFL	PVROC NPR (F)	RX
PVFORMAT	PVROC NTP (F)	SCHSTS
PVHHFL	PVROC PFL	SLOTNUM
PVHHPR (F)	PVROC PPR (F)	STSMMSG
PVHHTP (F)	PVROC PTP (F)	T
PVHIFL	PVSGCHTP (F)	T0
PVHIPR (F)	PVSOURCE (F)	TF
PVHITP	PVSRCOPT (F)	TSTS
PVINIT	PVSTS	UNIT
PVLLFL	PVTV (F)	USERID
PVLLPR (F)	PVTVP (F)	X
PVLLTP (F)	Q	XSTS

General Linearization

The parameters of the General Linearization PV algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	IN2	OUT4
\$AUXUNIT (F)	IN3	OUT5
\$CDETAIL	IN4	OUT6
\$DLBADAL (F)	IN5	OUT7
\$HHSELECT (F)	IN6	OUT8
\$HISELECT (F)	IN7	OUT9
\$LSELECT (F)	IN8	OUT10
\$LOSELECT (F)	IN9	OUT11
\$REALARM (F)	IN10	OUT12
\$RNSELECT (F)	IN11	OVERVAL (F)
\$RPSELECT (F)	IN12	P1
ALENBST (F)	KEYWORD	P1STS
ASSOCDSP	LASTPV	PERIOD
BADPVFL (F)	MODNUM	PIDSTN
BADVPR (F)	NAME	PISRC
CNFMU	NODENUM	PNTFORM
CMFPU	NODETYP	PNTMODTY
CONTCUT (F)	NOPINPTS	PNTNODTY
DLYTIME (F)	NORMCYCL	PNTSTATE
EUDESC	NTWKNUM	
HIGHAL (F)	OUT0	(Continued)
HIGHALPR (F)	OUT1	
IN0	OUT2	
IN1	OUT3	

General Linearization (Continued)

PNTTYPE	PVEXHIFL	PVROCNPR (F)
PRIMMOD (F)	PVEXLOFL	PVROCNTN (F)
PSDLYFL	PVFORMAT	PVROCPFL
PTDESC (F)	PVHHFL	PVROCPPR (F)
PTEXECST	PVHHPR (F)	PVROCPTP (F)
PTINAL	PVHHTP (F)	PVSGCHTP (F)
PV	PVHIFL	PVSOURCE (F)
PVAUTO	PVHIPR (F)	PVSRCOPT (F)
PVALDB (F)	PVHITP (F)	PVSTS
PVALDBEU (F)	PVINIT	PVTV (F)
PVALGID	PVLLFL	PVTVP (F)
PVAUTOST	PVLLPR (F)	SCHSTS
PVCALC	PVLLTP (F)	SEGTOT
PVCLAMP	PVLOFL	SLOTNUM
PVEUHI	PVLOPR (F)	STSMMSG
PVEULO	PVLOTP (F)	TF
PVEXEUHI	PVP	UNIT
PVEXEULO	PVROCNFL	USERID

High-Low Average

The parameters of the High-Low Average PV algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	FRCPERM	P5STS
\$AUXUNIT (F)	FSELIN	P6
\$CDETAIL	HIGHAL (F)	P6STS
\$DLBADAL (F)	HIGHALPR (F)	PERIOD
\$DHSELECT (F)	KEYWORD	PFDLYFL
\$HHSELECT (F)	LASTPV	PIDSTN
\$HISELECT (F)	MODNUM	PISRC
\$LLSELECT (F)	N	PNTFORM
\$LOSELECT (F)	NAME	PNTMODTY
\$REALARM (F)	NMIN	PNTNODTY
\$RNSELECT (F)	NODENUM	PNTSTATE
\$RPSELECT (F)	NODETYP	PNTTYPE
ALENBST (F)	NOPINPTS	PRIMMOD (F)
ASSOCDSP	NORMCYCL	PSDLYFL
BADPVFL (F)	NTWKNUM	PTDESC (F)
BADPVPR (F)	OVERVAL (F)	PTEXCST
CNFMU	P1	PTINAL
CNFPU	P1STS	PV
CONTCUT (F)	P2	
DLYTIME (F)	P2STS	(Continued)
DEVHIFL	P3	
DEVHIPR (F)	P3STS	
DEVHITP (F)	P4	
EUDESC	P4STS	
FORCE	P5	

High-Low Average (Continued)

PVALDB (F)	PVHHPR (F)	PVROCPFL
PVALDBEU (F)	PVHHTP (F)	PVROCPPR (F)
PVALGID	PVHIFL	PVROCPTP (F)
PVAUTO	PVHIPR (F)	PVSGCHTP (F)
PVAUTOST	PVHITP (F)	PVSOURCE (F)
PVCALC	PVINIT	PVSRCOPT (F)
PVCLAMP	PVLLFL	PVSTS
PVEQN	PVLLPR (F)	PVTVP (F)
PVEUHI	PVLLTP (F)	SCHSTS
PVEULO	PVLOFL	SELINP
PVEXEUHI	PVLOPR (F)	SLOTNUM
PVEXEULO	PVLOTP (F)	STSMMSG
PVEXHIFL	PVP	TF
PVEXLOFL	PVROCNFL	UNIT
PVFORMA	PVROCNP (F)	USERID
PVHHFL	PVROCNT (F)	

Incremental Summer

The parameters of the Incremental Summer control algorithm are listed below in alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$AUXUNIT (F)	CNFPU	K3
\$BADO CMD	CODSTN	K4
\$CDETAIL	CONTCUT (F)	KEYWORD
\$DHSELECT (F)	CTLALGID	LOCALMAN
\$MODESEL	CTRLINIT	M
\$OPTOL	CV	MANMODFL
\$REALARM (F)	CVEUHI	MODATTR
ALENBST (F)	CVEULO	MODE
ARWNET	DELCV	MODEAPPL
ARWOP	ESWAUTO	MODEPERM
ASSOCDSP	ESWCAS	MODNUM
AUTMODFL	ESWENBST	NAME
BADCTLFL	ESWMAN	NMODATTR
BADCTLPR (F)	EUDESC	NMODE
BCAMODFL	EXTSWOPT	NOCINPTS
CASMODFL	HIGHAL (F)	
CASREQ	HIGHALPR (F)	
CIDSTN	INITMAN	(Continued)
CISRC	K1	
CNFMU	K2	

Incremental Summer (Continued)

NOCOPTS	OPMCHLM	RCASSHED
NODENUM	OPRATRFL	REDTAG (F)
NODETYP	OPROCLM	RINITREQ
NORMCYCL	OVERVAL (F)	RINITVAL
NRMATRFL	PERIOD	SAFEOP
NRMMODFL	PFDLYFL	SCHSTS
NTWKNUM	PNTFORM	SHEDMODE
OP	PNTMODTY	SHEDTIME
OPALDB (F)	PNTNODTY	SHUTDOWN
OPEU	PNTSTATE	SLOTNUM
OPHAFL (F)	PNTTYPE	STDBYMAN
OPHIFL	PRGATRFL	STSMMSG
OPHILM	PRIMMOD (F)	UNIT
OPHIPR (F)	PSDLYFL	USERID
OPHITP (F)	PTDESC	X1
OPLAFL (F)	PTEXECST	X2
OPLOFL	PTINAL	X3
OPLOLM	PTORST	X4
OPLOPR (F)	RARWSTS	XEUHI
OPLOTP (F)	RCASOPT	XEULO

Middle-Of-3

The parameters of the Middle-Of-3 PV algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	DEVHPR (F)	PERIOD	PVEQN	PVP
\$AUXUNIT (F)	DEVHITP (F)	PIDSTN	PVEUHI	PVROCNFL
\$CDETAIL	EUDESC (F)	PISRC	PVEULO	PVROCNPR (F)
\$DLBADAL (F)	HIGHAL (F)	PNTFORM	PVEXEUHI	PVROCNTN (F)
\$DHSELECT (F)	HIGHALPR (F)	PNTMODTY	PVEXEULO	PVROCPFL
\$HHSELECT (F)	KEYWORD	PNTNODTY	PVEXHIFL	PVROCPPR (F)
\$HISELECT (F)	LASTPV	PNTSTATE	PVEXLOFL	PVROCPTP (F)
\$LLSELECT (F)	MODNUM	PNTTYPE	PVFORMAT	PVSGCHTP (F)
\$LOSELECT (F)	NAME	PRIMMOD (F)	PVHHFL	PVSOURCE (F)
\$REALARM (F)	NODENUM	PSDLYFL	PVHHPR (F)	PVSRCOPT (F)
\$RSELECT (F)	NODETYP	PTDESC	PVHHTP (F)	PVSTS
\$RPSELECT (F)	NOPINPTS	PTEXECST	PVHIFL	PVTV (F)
ALENBST (F)	NORMCYCL	PTINAL	PVHIPR (F)	PVTV (F)
ASSOCDSP	NTWKNUM	PV	PVHITP (F)	SELINP
BADPVFL (F)	OVERVAL (F)	PVALDB (F)	PVINIT	SLOTNUM
BADPVPR (F)	P1	PVALDBEU (F)	PVLLFL	STSMMSG
CONTCUT (F)	P1STS	PVALGID	PVLLPR (F)	TF
CNFMU	P2	PVAUTO	PVLLTP (F)	UNIT
CNFPV	P2STS	PVAUTOST	PVLOFL	USERID
DLYTIME (F)	P3	PVCALC	PVLOPR (F)	
DEVHIFL	P3STS	PVCLAMP	PVLOTP (F)	

Multiply/Divide

The parameters of the Multiply/Divide control algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$AUXUNIT (F)	CIDSTN	HIGHAL (F)
\$BADOCMD	CISRC	HIGHALPR (F)
\$CDETAIL	CNFMU	INITMAN
\$DLBADAL (F)	CNFPU	K
\$MODESEL	CODSTN	K1, K2, K3
\$REALARM (F)	CONTCUT (F)	KEYWORD
ALENBST (F)	CTALGID	LOCALMAN
ARWNET	CTLEQN	MANMODFL
ARWOP	CTRLINIT	MODATTR
ASSOCDSP	CV	MODE
AUTMODFL	CVEUHI	MODEAPPL
B	CVEULO	MODEPERM
B1, B2, B3	DLYTIME (F)	MODNUM
BADCTLFL	ESWAUTO	NAME
BADCTLOP	ESWCAS	NMODATTR
BADCTLPR (F)	ESWENBST	NMODE
BCAMODFL	ESWMAN	NOCINPTS
CASMODFL	EUDESC	
CASREQ	EXTSWOPT	(Continued)

Multiply/Divide (Continued)

NODENUM	OPLOTP (F)	RARWSTS
NODETYP	OPMCHLM	RATE1
NORMCYCL	OPRATRFL	RCASOPT
NRMATRFL	OPROCLM	REDTAG (F)
NRMMODFL	OVERVAL (F)	RINITREQ
NTWKNUM	PERIOD	RINITVAL
OP	PNTFORM	SAFEOP
OPALDB (F)	PNTMODTY	SCHSTS
OPEU	PNTNODTY	SELXINP
OPHAFL (F)	PNTSTATE	SHEDMODE
OPHIFL	PNTTYPE	SHEDTIME
OPHILM	PRGATRFL	SHUTDOWN
OPHIPR (F)	PRIMMOD (F)	SLOTNUM
OPHITP (F)	PSDLYFL	STDBYMAN
OPLAFL (F)	PTDESC (F)	STSMMSG
OPLOFL	PTEXECST	UNIT
OPLOLM	PTINAL	USERID
OPLOPR (F)	PTORST	X1, X2, X3, X4

Output Select (OPSelect)

The parameters of OPSELECT algorithm are listed below in alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$AUXUNIT (F)	\$NOPCONN	BADOC4FL	ESWENBST
\$BADOCMD	\$REALARM (F)	BADOCPR (F)	ESWMAN
\$CDETAIL	\$SELCTOP	BADOCOPT	EUDESC
\$CV1	ALENBST (F)	CASMODFL	EXTSWOPT
\$CV2	ARWNET	CIDSTN	HIGHAL (F)
\$CV3	ARWOP	CISRC	HIGHALPR (F)
\$CV4	ASSOCDSP	CODSTN(1) –	INITMAN
\$CDEF1	AUTMODFL	CODSTN(4)	INITREQ
\$CDEF2	B	CONTCUT (F)	KEYWORD
\$CDEF3	BO	CTLALGID	LOCALMAN
\$CDEF4	BADCTLFL	CTLQON	MANMODFL
\$MODESEL	BADCTLLOP	CTRLINIT	MODATTR
\$OP1	BADCTLPR (F)	CV	MODE
\$OP2	BADOCFL	CVEUHI	MODEAPPL
\$OP3	BADOC1FL	CVEULO	MODEPERM
\$OP4	BADOC2FL	ESWAUTO	MODNUM
\$OPTOL	BADOC3FL	ESWCAS	

(Continued)

Output Select (OPSelect) (Continued)

NAME	OPLAFL (F)	REDTAG (F)
NMODATTR	OPLOFL	S1
NMODE	OPLOLM	S2
NOCINPTS	OPLOPR (F)	S3
NOCOPTS	OPLOTP (F)	S4
NODENUM	OPMCHLM	SAFEOP
NODETYP	OPRATRFL	SHUTDOWN
NRMATRFL	OPROCLM	SLOTNUM
NRMMODFL	OVERVAL (F)	STDBYMAN
NTWKNUM	PERIOD	STSMSG
OP	PNTFORM	USERID
OPALDB (F)	PNTTYPE	X1
OPEU	PRGATRFL	XEUHI
OPHAFL (F)	PRIMMOD (F)	XEULO
OPHIFL	PTDESC	
OPHILM	PTEXCST	
OPHIPR (F)	PTINAL	
OPHITP (F)	RATE1	

Override Selector

The parameters of the Override Selector control algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$AUXUNIT (F)	CASMODFL	HIGHAL (F)
\$BADOCMD	CASREQ	HIGHALPR (F)
\$CDETAIL	CIDSTN	INITMAN
\$DLBADAL (F)	CISRC	KEYWORD
\$MODESEL	CNFMU	LOCALMAN
\$OPTOL	CNFPU	M
\$REALARM (F)	CODSTN	MANMODFL
ALENBST (F)	CONTCUT (F)	MODE
ARWNET	CTALGID	MODEAPPL
ARWOP	CTLEQN	MODATTR
ASSOCDSP	CTRLINIT	MODEPERM
AUTMODFL	CV	MODNUM
BADCTLFL	CVEUHI	NAME
BADCTL0P	CVEULO	NMODATTR
BADCTLPR (F)	DLYTIME (F)	NMODE
BCAMODFL	ESWAUTO	NOCINPTS
BYPASS	ESWCAS	
BYPASSX1	ESWENBST	(Continued)
BYPASSX2	ESWMAN	
BYPASSX3	EUDESC	
BYPASSX4	EXTSWOPT	

Override Selector (Continued)

NOCOPTS	OPROCLM	REDTAG (F)
NODENUM	OROFFSET	RINITREQ
NODETYP	OROPT	RINITVAL
NORMCYCL	OUTIND	SAFEOP
NRMATRFL	OVERVAL (F)	SCHSTS
NRMODFL	PERIOD	SELXINP
NTWKNUM	PFDLYFL	SHEDMODE
OP	PNTFORM	SHEDTIME
OPALDB (F)	PNTMODTY	SHUTDOWN
OPEU	PNTNODTY	SLOTNUM
OPHAFL (F)	PNTSTATE	STDBYMAN
OPHIFL	PNTTYPE	STSMMSG
OPHILM	PRGATRFL	UNIT
OPHIPR (F)	PRIMMOD (F)	USERID
OPHITP (F)	PSDLYFL	X1
OPLAFL (F)	PTDESC (F)	X2
OPLOFL	PTEXECST	X3
OPLOLM	PTINAL	X4
OPLOPR (F)	PTORST	XEUHI
OPLOTP (F)	RARWSTS	XEULO
OPMCHLM	RCASOPT	
OPRATRFL	RCASSHED	

Pid

The parameters of the Pid control algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	ADVSP (F)	CODSTN	ESWMAN	MANOPCMD
\$AUXUNIT (F)	ALENBST (F)	CONTCUT (F)	EUDESC	MANOPTIME
\$BADO CMD	ARWNET	CTLACTN	EXTSWOPT	MAXPULSE
\$CDETAIL	ARWOP	CTLALGID	GAINOPT	MODATTR
\$DHSELECT (F)	ASPPROC (F)	CTLEQN	GAPHI	MODE
\$DLBADAL (F)	ASSOCDSP	CTRLINIT	GAPLO	MODEAPP
\$DLSELECT (F)	AUTMODF	CV	HIGHAL (F)	L
\$HHSELECT (F)	L	CVEUHI	HIGHALPR (F)	MODEPERM
\$HISELCT (F)	BADCTFL	CVEULO	INITMAN	MODNUM
\$LSELECT (F)	BADCTLOP	DELCV	K	NAME
\$LOSELCT (F)	BADPVFL	DEV	KEXT	NLFM
\$MODESEL	BADPVPR (F)	DEVHIFL	KEYWORD	NLGAIN
\$OPTOL	BIAS	DEVHIPR (F)	KGAP	NMODATT
\$REALARM (F)	BSHILM	DEVHITP (F)	KLIN	R
\$RNSELECT (F)	BSLOLM	DEVLOFL	KNL	NMODE
\$RPSELECT (F)	CASMODL	DEVLOPR (F)	LASTPV	NOCINPTS
\$SPTOL	CASREQ	DEVLOTP (F)	LMSRC	NOCOPTS
ADVDEVFL	CIDSTN	DLYTIME (F)	LOCALMA	
ADVDEVPR (F)	CISRC	ESWAUTO	N	
ADVDEVTP (F)	CNFMU	ESWCAS	MANMODF	
ADVSP (F)	CNFPU	ESWENBST	L	

Pid (Continued)

NODENUM	PIDFORM	PVLLFL	RTHILM
NODETYP	PNTFORM	PVLLPR (F)	RTLOLM
NORMCYCL	PNTMODTY	PVLLTP (F)	SAFEOP
NRMATRFL	PNTNODTY	PVLOFL	SAFOPCMD
NRMODFL	PNTSTATE	PVLOTP (F)	SHEDMODE
NTWKNUM	PNTTYPE	PVLOPR (F)	SHEDTIME
OP	PRGATRFL	PVP	SHUTDOWN
OPALDB (F)	PSDLYFL	PVROCNFL	SLOTNUM
OPCMD	PTDESC	PVROCNP (F)	SP
OPEU	PTXECST	PVROCNP (F)	SPEUHI
OPHAFL (F)	PTINAL	PVROCPFL	SPEULO
OPHIFL	PTORST	PVROCPPR (F)	SPFORMAT
OPHILM	PV	PVROCPTP (F)	SPHIFL
OPHIPR (F)	PVALDB (F)	PVSGCHTP (F)	SPHILM
OPHISRC	PVALDBEU (F)	PVSOURCE (F)	SPLOFL
OPHITP (F)	PVAUTO	PVSRCOPT (F)	SPLOLM
OPLAFL (F)	PVAUTOST	PVSTS	SPOPT
OPLOFL	PVEUHI	PVTRACK	SPP
OPLOLM	PVEULO	RAMPTIME	SPTV
OPLOPR (F)	PVFORMAT	RARWSTS	SPTVP
OPLOSRC	PVHHFL	RATIO	STDBYMAN
OPMCHLM	PVHHPR (F)	RBOPT	STSMMSG
OPRATRFL	PVHHTP (F)	RCASOPT	T1, T2
OPROCLM	PVHIFL	RCASSHED	TVPROC
OVERVAL (F)	PVHIPR (F)	REDTAG (F)	UNIT
PERIOD	PVHITP (F)	RINITREQ	USERID
PFDLYFL	PVHITPID	RINITVAL	

Pid With External Reset Feedback

The parameters of the Pid With External Reset Feedback control algorithm are listed below in Alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	ADVSP (F)	CNFMU	ESWAUTO	LOCALMAN
\$AUXUNIT (F)	ADVSP (F)	CNFP	ESWCAS	MANMODFL
\$BADOCMD	ALENBST (F)	CODSTN	ESWENBST	MODATTR
\$CDETAIL	ARWNET	CONTCUT (F)	ESWMAN	MODE
\$DHSELECT (F)	ARWOP	CTLACTION	EUDESC (F)	MODEAPPL
\$DLBADAL (F)	ASPPROC (F)	CTLALGID	EXTSWOPT	MODEPERM
\$DLSELECT (F)	ASSOCDSP	CTLEQN	GAINOPT	MODNUM
\$HHSELECT (F)	AUTMODFL	CTRLINIT	GAPHI	NAME
\$HISELECT (F)	BADCTFL	CV	GAPLO	NLFM
\$LLSELECT (F)	BADCTLOP	CVEUHI	HIGHAL (F)	NLGAIN
\$LOSELECT (F)	BADPVFL	CVEULO	HIGHALPR (F)	NMODATTR
\$MODESEL	BADPVPR (F)	DELCV	INITMAN	NMODE
\$OPTOL	BCAMODFL (F)	DEV	K	NOCINPTS
\$REALARM (F)	BIAS	DEVHIFL	K1	NOCOPTS
\$RNSELECT (F)	BSHLM	DEVHIPR (F)	KEXT	NODENUM
\$RPSELECT (F)	BSLOLM	DEVHITP (F)	KEYWORD	NOETYP
\$SPTOL	CASMODFL	DEVLOFL	KGAP	NORMCYCL
ADVDEVFL	CASREQ	DEVLOPR (F)	KLIN	NRMATRFL
ADVDEVPR (F)	CIDSTN	DEVLOTP (F)	KNL	NRMODFL
ADVDEVTP	CISRC	DLYTIME (F)	LASTPV	NTWKNUM

Pid With External Reset Feedback (Continued)

OP	PSDLYFL	PVROCNFL	SHEDMODE
OPALDB (F)	PTDESC	PVROCNP (F)	SHEDTIME
OPEU	PTXECST	PVROCNTP (F)	SHUTDOWN
OPHAFL (F)	PTINAL	PVROCPFL	SLOTNUM
OPHIFL	PTORST	PVROCPPR (F)	SP
OPHILM	PV	PVROCTP (F)	SPEUHI
OPHIPR (F)	PVALDB (F)	PVSGCHTP (F)	SPEULO
OPHITP (F)	PVALDBEU (F)	PVSOURCE (F)	SPFORMAT
OPLAFL (F)	PVAUTO	PVSRCOPT (F)	SPHIFL
OPLOFL	PVAUTOST	PVSTS	SPHILM
OPLOLM	PVEUHI	PVTRACK	SPLOFL
OPLOPR (F)	PVEULO	RAMPTIME	SPLOLM
OPLOTP (F)	PVFORMAT	RARWSTS	SPOPT
OPMCHLM	PVHHFL	RATIO	SPP
OPRATRFL	PVHHPR (F)	RBOPT	SPTV
OPROCLM	PVHHTP (F)	RCASOPT	SPTVP
OVERVAL (F)	PVHIFL	RCASSHED	STDBYMAN
PERIOD	PVHIPR (F)	REDTAG (F)	STSMMSG
PIDFORM	PVHITP (F)	RFB	T1
PIDLYFL	PVLLFL	RINITREQ	T2
PNTFORM	PVLLPR (F)	RINITVAL	TRFB
PNTMODTY	PVLLTP (F)	RTHILM	TVPROC
PNTNODTY	PVLOFL	RTLLOLM	UNIT
PNTSTATE	PVLOTP (F)	S1	USERID
PNTTYPE	PVLOPR (F)	SAFEOP	
PRGATRFL	PVP	SCHSTS	

Pid With Feed Forward

The parameters of the Pid With Feed Forward control algorithm are listed below in Alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	ADVDEVTP	CISRC	DLYTIME (F)	KGAP
\$AUXUNIT (F)	ADVSP (F)	CNFMU	ESWAUTO	KLIN
\$BADOCMD	ADVSP (F)	CNFPV	ESWCAS	KNL
\$CDETAIL	ALENBST (F)	CODSTN	ESWENBST	LASTPV
\$DHSELECT (F)	ARWNET	CONTCUT (F)	ESWMAN	LOCALMAN
\$DLBADAL (F)	ARWOP	CTLACTN	EUDESC	MANMODFL
\$DLSELECT (F)	ASPPROC (F)	CTLALGID	EXTSWOPT	MODATTR
\$HHSELECT (F)	ASSOCDSP	CTLEQN	FF	MODE
\$HISELCT (F)	AUTMODFL	CTRLINIT	FFOPT	MODEAPPL
\$LSELECT (F)	BADCTLFL	CV	GAINOPT	MODEPERM
\$LOSELCT (F)	BADCTLOP	CVEUHI	GAPHI	MODNUM
\$MODESEL	BADPVFL	CVEULO	GAPLO	NAME
\$OPTOL	BADPVPR (F)	DELCV	HIGHAL (F)	NLFM
\$REALARM (F)	BFF	DEV	HIGHALPR	NLGAIN
\$RNSLCT (F)	BIAS	DEVHIFL	(F)	NMODATTR
\$RPSELCT (F)	BSHILM	DEVHIPR (F)	INITMAN	NMODE
\$SPTOL	BSLOLM	DEVHITP (F)	K	NOCINPTS
ADVDEVFL	CASMODFL	DEVLOFL	KEXT	NOCOPTS
ADVDEVPR	CASREQ	DEVLOPR (F)	KEYWORD	(continued)
(F)	CIDSTN	DEVLOTP (F)	KFF	

Pid With Feed Forward (Continued)

NODENUM	PNTNODTY	PVLOPR (F)	SHUTDOWN
NODETYP	PNTSTATE	PVP	SLOTNUM
NORMCYCL	PNTTYPE	PVROCNFL	SP
NRMATRFL	PRGATRFL	PVROCNPR (F)	SPEUHI
NRMODFL	PSDLYFL	PVROCNTF (F)	SPEULO
NTWKNUM	PTDESC	PVROCPFL	SPFORMAT
OP	PTEXECST	PVROCPPR (F)	SPHIFL
OPALDB (F)	PTINAL	PVROCPTP (F)	SPHILM
OPEU	PTORST	PVSGCHTP (F)	SPLOFL
OPHAFL (F)	PV	PVSOURCE (F)	SPLOLM
OPHIFL	PVALDB (F)	PVSRCOPT (F)	SPOPT
OPHILM	PVALDBEU (F)	PVSTS	SPP
OPHIPR (F)	PVAUTO	PVTRACK	SPTV
OPHITP (F)	PVAUTOST	RAMPTIME	SPTVP
OPLAFL (F)	PVEUHI	RARWSTS	STDBYMAN
OPLOFL	PVEULO	RATIO	STSMMSG
OPLOLM	PVFORMAT	RBOPT	T1
OPLOPR (F)	PVHHFL	RCASOPT	T2
OPLOTP (F)	PVHHPR (F)	RCASSHED	TVPROC
OPMCHLM	PVHHTP (F)	REDTAG (F)	UNIT
OPRATRFL	PVHIFL	RINITREQ	USERID
OPROCLM	PVHIPR (F)	RINITVAL	
OVERVAL (F)	PVHITP (F)	RTHILM	
PERIOD	PVLLFL	RTLOLM	
PIDFORM	PVLLPR (F)	SAFEOP	
PDFLYFL	PVLLTP (F)	SCHSTS	
PNTFORM	PVLOFL	SHEDMODE	
PNTMODTY	PVLOTP (F)	SHEDTIME	

Pid With Position Proportional

The parameters of the Position Proportional control algorithm are listed below in Alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	ASSOCDSP	DELCV	KGAP
\$AUXUNIT (F)	AUTMODFL	DEV	KLIN
\$BADOCMD	BADCTLFL	DEVHIFL	KNL
\$CDETAIL	BADCTL0P	DEVHIPR (F)	LASTPV
\$DHSELECT (F)	BADPVFL	DEVHITP (F)	LMSRC
\$DLBADAL (F)	BADPVPR	DEVLOFL	LOCALMAN
\$DLSELECT (F)	BADPVR (F)	DEVLOPR (F)	LOWERTIM
\$HHSELECT (F)	BCAMODFL	DEVLOTP (F)	LOWRDSTN
\$HISELECT (F)	BIAS	DLYTIME (F)	LOWRRATE
\$LLSELECT (F)	BSHILM	ESWAUTO	MANMODFL
\$LOSELECT (F)	BSLOLM	ESWCAS	MANOPCMD
\$MODESEL	CASMODFL	ESWENBST	MANOPTIM
\$REALARM (F)	CASREQ	ESWMAN	MAXPULSE
\$RNSELECT (F)	CIDSTN	EUDESC	MINPULSE
\$RPSELECT (F)	CISRC	EXTSWOPT	MODATTR
\$SPTOL	CNFMU	GAINOPT	MODE
ADVDEVFL	CNFPU	GAPHI	MODEAPPL(continued)
ADVDEVPR (F)	CODSTN	GAPLO	
ADVDEVTP (F)	CONTCUT (F)	HIGHAL (F)	
ADVSP (F)	CTLALGID	HIGHALPR (F)1	
ADVSP (F)	CTLEQN	INITMAN	
ALENBST (F)	CTRLINIT	K	
ARWNET	CYCLETIM	K1	
ARWOP	DEADBAND	KEXT	
ASPPROC (F)	DEADTIME	KEYWORD	

PID With Position Proportional (Continued)

MODEPERM	PFDLYFL	PVHITP (F)
MODNUM	PERIOD	PVLLFL
NAME	PNTFORM	PVLLPR (F)
NLFM	PNTMODTY	PVLLTP (F)
NLGAIN	PNTNODTY	PVLOFL
NMODATTR	PNTSTATE	PVLOPR (F)
NMODE	PNTTYPE	PVLOTP (F)
NOCINPTS	PRGATRFL	PVP
NOCOPTS	PRIMMOD (F)	PVROCNFL
NODENUM	PSDLYFL	PVROCNPR (F)
NODETYP	PTDESC (F)	PVROCNP (F)
NORMCYCL	PTEXECST	PVROCPFL
NRMATRFL	PTINAL	PVROCPPR (F)
NRMMODFL	PTORST	PVROCPTP (F)
NTWKNUM	PV	PVSGCHTP (F)
OPCMD	PVALDB (F)	PVSOURCE (F)
OPHIFL	PVALDBEU (F)	PVSRCOPT (F)
OPHISRC	PVAUTO	PVSTS
OPLOFL	PVAUTOST	PVTRACK
OPLOSRC	PVEUHI	RAISDSTN
OVERVAL (F)	PVEULO	RAISETIM
OPCMD	PVFORMAT	RAISRATE
OPHIFL	PVHHFL	RAMPTIME
OPHISRC	PVHHPR (F)	RARWSTS
OPLOFL	PVHHTP (F)	RATIO
OPLOSRC	PVHIFL	RBOPT (Continued)
OVERVAL (F)	PVHIPR (F)	

PID With Position Proportional (Continued)

RCASOPT	SHEDMODE SHEDTIME	SPOPT
RCASSHED	SHUTDOWN	SPP
REDTAG (F)	SLOTNUM	SPTV
RINITREQ	SP	SPTVP
RINITVAL	SPEUHI	STDBYMAN
RP	SPEULO	STMSG
RT	SPFORMAT	T1
RTHILM	SPHIFL	T2
RTLOLM	SPHILM	TVPROC
SAFEOPCMD	SPLOFL	UNIT
SCHSTS	SPLOLM	USERID

Position Proportional

The parameters of the Position Proportional control algorithm are listed below in Alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	ADVSP (F)	CONTCUT (F)	HIGHAL (F)	MODNUM
\$AUXUNIT (F)	ADVSP (F)	CTLALGID	HIGHALPR (F)1	NAME
\$BADOCMD	ALENBST (F)	CTRLINIT	INITMAN	NMODATTR
\$CDETAIL	ARWNET	CYCLETIM	KEYWORD	NMODE
\$DHSELECT (F)	ARWOP	DEADBAND	LASTPV	NOCINPTS
\$DLBADAL (F)	ASPPROC (F)	DEADTIME	LMSRC	NOCOPTS
\$DLSELECT (F)	ASSOCDSP	DEV	LOCALMAN	NODENUM
\$HHSELECT (F)	AUTMODFL	DEVHIFL	LOWERTIM	NODETYP
\$HISELCT (F)	BADCTLFL	DEVHIPR (F)	LOWRDSTN	NORMCYCL
\$LSELECT (F)	BADCTLOP	DEVHITP (F)	LOWRRATE	NRMMODFL
\$LOSELCT (F)	BADPVFL	DEVLOFL	LTIMHILM	NTWKNUM
\$MODESEL	BADPVR (F)	DEVLOPR (F)	MANMODFL	OPCMD
\$REALARM (F)	BCAMODFL	DEVLOTP (F)	MANOPCMD	OPHIFL
\$RNSELECT (F)	CASMODFL	DLYTIME (F)	MANOPTIM	OPHISRC
\$RPSELECT (F)	CASREQ	ESWAUTO	MAXPULSE	OPLOFL
ADVDEVFL	CIDSTN	ESWCAS	MINPULSE	OPLOSRC
ADVDEVPR	CISRC	ESWENBST	MODATTR	OVERVAL (F)
(F)	CNFMU	ESWMAN	MODE	PERIOD
ADVDEVTP	CNFPU	EUDESC	MODEAPPL	(Continued)
(F)	CODSTN	EXTSWOPT	MODEPERM	

Position Proportional (Continued)

PFPLYFL	PVLLFL	RP
PNTFORM	PVLLPR (F)	RT
PNTMODTY	PVLLTP (F)	SAFOPCMD
PNTNODTY	PVLOFL	SCHSTS
PNTSTATE	PVLOPR (F)	SHEDMODE
PNTTYPE	PVLOTP (F)	SHEDTIME
PRGATRFL	PVP	SHUTDOWN
PSDLYFL	PVROCNFL	SLOTNUM
PRIMMOD (F)	PVROCNPR (F)	SP
PTDESC	PVROCNP (F)	SPEUHI
PTEXECST	PVROCPFL	SPEULO
PTINAL	PVROCPPR (F)	SPFORMAT
PTORST	PVROCPTP (F)	SPHIFL
PV	PVSGCHTP (F)	SPHILM
PVALDB (F)	PVSOURCE (F)	SPLOFL
PVALDBEU (F)	PVSRCOPT (F)	SPLOLM
PVAUTO	PVSTS	SPOPT
PVAUTOST	RAISDSTN	SPP
PVEUHI	RAISETIM	SPTV
PVEULO	RAISRATE	SPTVP
PVFORMAT	RAMPTIME	STDBYMAN
PVHHFL	RARWSTS	STSMSG
PVHHPR (F)	RCASOPT	TVPROC
PVHHTP (F)	RCASSHED	UNIT
PVHITP (F)	REDTAG (F)	USERID
PVHIFL	RINITREQ	
PVHIPR (F)	RINITVAL	

Ramp Soak

The parameters of the Ramp Soak control algorithm are listed below in alphabetical Order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	AUTMODFL	DEVLOTP (F)	NMODATTR
\$AUXUNIT (F)	BADCTLFL	DLYTIME (F)	NMODE
\$BADO CMD	BCAMODFL	ESW AUTO	NOCINPTS
\$CDETAIL	CASMODFL	ESWCAS	NOCOPTS
\$DHSELECT (F)	CASREQ	ESWENBST	NODENUM
\$DLSELECT (F)	CIDSTN	ESWMAN	NODETYP
\$HHSELECT (F)	CISRC	EUDESC (F)	NORMCYCL
\$HISELECT (F)	CNFMU	EXTSWOPT	NORSSEQ
\$LSELECT (F)	CNFPU	HIGHAL (F)	NRMATRFL
\$LOSELECT (F)	CODSTN	HIGHALPR (F)	NRMODFL
\$MODESEL	CONTCUT (F)	HOLD CMD	NTWKNUM
\$REALARM (F)	CTLALGID	INITMAN	NXTSOAKV
\$RSELECT (F)	CTRLINIT	KEYWORD	OP
\$RPSELECT (F)	CURSEGID	LASTPV	OPEU
ADVDEVFL	CV	LOCALMAN	OPHIFL
ADVDEVPR (F)	CVEUHI	MANMODFL	OPHILM
ADVDEVTP (F)	CVEULO	MODATTR	OPLOFL
ADVSP (F)	CYCLOPT	MODE	OPLOLM
ADVSP (F)	DEV	MODEAPPL	OPMCHLM
ALNBST (F)	DEVHPR (F)	MODEPERM	OPRATRFL
ARWNET	DEVHIFL	MODNUM	OPROCLM
ARWOP	DEVHITP (F)	MXRMPDEV`	OVERVAL (F)
ASPPROC (F)	DEVLOFL	MXSOKDEV	PERIOD
ASSOCDSP	DEVLOPR (F)	NAME	PFDLYFL (Continued)

Ramp Soak (Continued)

PNTFORM	RATE9	SOAKT8	SPTVP
PNTMODTY	RATE10	SOAKT9	STDBYMAN
PNTNODTY	RATE11	SOAKT10	STMSG
PNTSTATE	RATE12	SOAKT11	TVPROC
PNTTYPE	REDTAG (F)	SOAKT12	UNIT
PRGATRFL	REMSOAKT	SOAKV1	USERID
PRIMMOD	RINITREQ	SOAKV2	
PSDLYFL	RINITVAL	SOAKV3	
PTDESC	S1	SOAKV4	
PTEXECST	S1BGNTIM	SOAKV5	
PTINAL	S1ENDTIM	SOAKV6	
PTORST	S1SEGID	SOAKV7	
PV	S2	SOAKV8	
PVEUHI	S2BGNTIM	SOAKV9	
PVEULO	S2ENDTIM	SOAKV10	
PVFORMAT	S2SEGID	SOAKV11	
PVP	SAFEOP	SOAKV12	
PVSTS	SCHSTS	SP	
RAMPTIME	SEGTYPE	SPEUHI	
RARWSTS	SHUTDOWN	SPEULO	
RATE1	SLOTNUM	SPFORMAT	
RATE2	SOAKT1	SPHIFL	
RATE3	SOAKT2	SPHILM	
RATE4	SOAKT3	SPLOFL	
RATE5	SOAKT4	SPLOLM	
RATE6	SOAKT5	SPOPT	
RATE7	SOAKT6	SPP	
RATE8	SOAKT7	SPTV	

Ratio Control

The parameters of the Ratio Control control algorithm are listed below in Alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	BADPVFL	DLYTIME (F)	NMODE
\$AUXUNIT (F)	BADPVPR (F)	ESWAUTO	NOCINPTS
\$BADOCMD	BCAMODFL	ESWCAS	NOCOPTS
\$CDETAIL	CASMODFL	ESWENBST	NODENUM
\$DLBADAL (F)	CASREQ	ESWMAN	NODETYP
\$MODESEL	CIDSTN	EUDESC (F)	NORMCYCL
\$OPTOL	CISRC	EXTSWOPT	NRMATRFL
\$REALARM (F)	CNFMU	HIGHAL (F)	NRMMODFL
\$SPTOL	CNFPU	HIGHALPR (F)	NTWKNUM
ADVDEVFLC	CODSTN	INITMAN	OP
ADVDEVPR (F)	CONTCUT (F)	K1	OPALDB (F)
ADVDEVTP (F)	CTLALGID	K2	OPEU
ADVSP (F)	CTRLINIT	KEYWORD	OPHAFL (F)
ADVSP (F)	CV	LASTPV	OPHIFL
ALENBST (F)	CVEUHI	LOCALMAN	OPHILM
ARWNET	CVEULO	MANMODFL	OPHIPR (F)
ARWOP	DEV	MODATTR	(Continued)
ASPPROC (F)	DEVHIFL	MODE	
ASSOCDSP	DEVHIPR	MODEAPPL	
AUTMODFL	DEVHITP (F)	MODEPERM	
B1	DEVLOFL	MODNUM	
B2	DEVLOPR (F)	NAME	
BADCTLFL	DEVLOTP (F)	NMODATTR	

Ratio Control (Continued)

OPHITP (F)	PVAUTO	PVSTS	STSMMSG
OPLAFL (F)	PVAUTOST	RAMPTIME	TVPROC
OPLOFL	PVEUHI	RARWSTS	UNIT
OPLOLM	PVEULO	RATE1	USERID
OPLOPR (F)	PVFORMAT	RCASOPT	X2
OPLOTP (F)	PVHHFL	RCASSHED	X2FILT
OPMCHLM	PVHHPR (F)	REDTAG (F)	X2TF
OPRATRFL	PVHHTP (F)	RINITREQ	
OPROCLM	PVHIFL	RINITVAL	
OVERVAL (F)	PVHIPR (F)	SAFEOP	
PERIOD	PVHITP (F)	SHEDMODE	
PFDLYFL	PVLLFL	SHEDTIME	
PNTFORM	PVLLPR (F)	SHUTDOWN	
PNTMODTY	PVLLTP (F)	SLOTNUM	
PNTNODTY	PVLOFL	SP	
PNTSTATE	PVLOPR (F)	SPEUHI	
PNTTYPE	PVLOTP (F)	SPEULO	
PRIMMOD (F)	PVP	SPFORMAT	
PSDLYFL	PVROCNFL	SPHIFL	
PTDESC	PVROCNPR (F)	SPHILM	
PTEXECST	PVROCNTP (F)	SPLOFL	
PTINAL	PVROCPFL	SPLOLM	
PTORST	PVROCPPR (F)	SPOPT	
PRGATRFL	PVROCPTP (F)	SPP	
PV	PVSGCHTP (F)	SPTV	
PVALDB (F)	PVSOURCE (F)	SPTVP	
PVALDBEU (F)	PVSRCOPT (F)	STDBYMAN	

Summer (RegCtl)

The parameters of the Summer Regulatory Control algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$AUXUNIT (F)	B	DLTIME (F)	MODEPERM
\$BADOCMD	BADCTLFL	ESWAUTO	MODNUM
\$CDETAIL	BADCTL0P	ESWCAS	NAME
\$DHSELECT (F)	BADCTLPR (F)	ESWENBST	NMODATTR
\$DLBADAL (F)	BCAMODFL	ESWMAN	NMODE
\$DLSELECT (F)	CASMODFL	EUDESC	NOCINPTS
\$HHSELECT (F)	CASREQ	EXTSWOPT	NODENUM
\$HISELECT (F)	CIDSTN	HIGHAL (F)	NODETYP
\$LSELECT (F)	CISRC	HIGHALPR (F)	NORMCYCL
\$LOSELECT (F)	CNFMU	INITMAN	NRMATRFL
\$MODESEL	CNFPU	K	NRMMODFL
\$REALARM (F)	CODSTN	K1, K2, K3, K4	NTWKNUM
\$RNSELECT (F)	CONTCUT (F)	KEYWORD	OP
\$RPSELECT (F)	CTALGID	LOCALMAN	OPALDB (F)
ALENBST (F)	CTLEQN	M	OPEU
ARWNET	CTRLINIT	MANMODFL	OPHAFL (F)
ARWNOP	CV	MODATTR	OPHIFL
ASSOCDSP	CVEUHI	MODE	(Continued)
AUTMODFL	CVEULO	MODEAPPL	

Summer (RegCtl) (Continued)

OPHILM	PTORST
OPHIPR (F)	RARWSTS
OPHITP (F)	RATE1
OPLAFL (F)	RCASOPT
OPLOFL	REDTAG (F)
OPLOLM	RINITREQ
OPLOPR (F)	RINITVAL
OPLOTP (F)	SAFEOP
OPMCHLM	SCHSTS
OPRATRFL	SHEDMODE
OPROCLM	SHEDTIME
OUTIND	SHUTDOWN
OVERVAL (F)	SLOTNUM
PERIOD	STDBYMAN
PFDLYFL	STSMMSG
PNTFORM	UNIT
PNTMODTY	USERID
PNTNODTY	X1, X2, X3, X4
PNTSTATE	XEUHI
PNTTYPE	XEULO
PRGATRFL	
PRIMMOD (F)	
PSDLYFL	
PTDESC (F)	
PTEXECST	
PTINAL	

Summer (RegPV)

The parameters of the Summer PV algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	C2	NODETYP	PISRC
\$AUXUNIT (F)	C3	NOPINPTS	PNTFORM
\$CDETAIL	C4	NTWKNUM	PNTMODTY
\$DHSELECT (F)	C5	OVERVAL (F)	PNTNODTY
\$DLBADAL (F)	C6	P1	PNTSTATE
\$DLSELECT (F)	CNFMU	P1STS	PNTTYPE
\$HHSELECT (F)	CNFPU	P2	PRIMMOD (F)
\$HISELECT (F)	CONTCUT	P2STS	PSDLYFL
\$LLOSELECT (F)	D	P3	PTDESC
\$LOSELECT (F)	DLYTIME (F)	P3STS	PTEXECST
\$REALARM (F)	EUDESC	P4	PTINAL
\$RNSSELECT (F)	HIGHAL (F)	P4STS	PV
\$RPSSELECT (F)	HIGHALPR (F)	P5	PVALDB (F)
ALENBST (F)	KEYWORD	P5STS	PVALDBEU (F)
ASSOCDSP	LASTPV	P6	PVALGID (Continued)
BADPVFL	N	P6STS	
BADPVPR (F)	MODNUM	PERIOD	
C	NAME	PFDLYFL	
C1	NODENUM	PIDSTN	

Summer (RegPV) (Continued)

PVAUTO	PVROCPFL
PVAUTOST	PVROCPPR (F)
PVCALC	PVROCPPT (F)
PVCLAMP	PVSGCHTP (F)
PVEQN	PVSOURCE (F)
PVEULO	PVSRCOPT (F)
PVEUHI	PVSTS
PVEXEUHI	PVTV (F)
PVEXEULO	PVTVP (F)
PVEXHIFL	SCHSTS
PVEXLOFL	SLOTNUM
PVFORMAT	STSMMSG
PVHHFL	TF
PVHHPR (F)	UNIT
PVHHTP (F)	USERID
PVHIFL	
PVHIPR (F)	
PVHITP (F)	
PVINIT	
PVLLFL	
PVLLPR (F)	
PVLLTP (F)	
PVLOFL	
PVLOPR (F)	
PVLOTP (F)	
PVP	
PVROCNFL	
PVROCNPR (F)	
PVROCNTP (F)	

Switch

The parameters of the Switch control algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$AUXUNIT (F)	CODSTN	MODATTR
\$BADOCMD	CONTCUT (F)	MODE
\$CDETAIL	CTLALGID	MODEAPPL
\$DLBADAL (F)	CTLEQN	MODEPERM
\$MODESEL	CTRLINIT	MODNUM
\$OPTOL	CV	NAME
\$REALARM (F)	CVEUHI	NMODATTR
ALENBST (F)	CVEULO	NMODE
ARWNET	DLYTIME (F)	NRMATRFL
ARWOP	ESWAUTO	NRMMODFL
ASSOCDSP	ESWCAS	NOCINPTS
AUTMODFL	ESWENBST	NOCOPTS
BADCTFL	ESWMAN	NODENUM
BADCTLDP	EUDESC	NODEtyp
BADCTLPR (F)	EXTSWOPT	NTWKNUM
BCAMODFL	HIGHAL (F)	OP
CASMODFL	HIGHALPR (F)	OPALDB (F)
CASREQ	INITMAN	OPEU
CIDSTN	KEYWORD	OPHAFL
CISRC	LOCALMAN	OPHIFL
CNFMU	M	OPHILM
CNFPU	MANMODFL	OPHIPR (F)(Continued)

Switch (Continued)

OPHITP (F)	RINITVAL
OPLAFL (F)	S1
OPLOFL	S2
OPLOLM	S3
OPLOPR (F)	S4
OPLOTP (F)	SAFEOP
OPMCHLM	SCHSTS
OPRATRFL	SELXINP
OPROCLM	SHEDMODE
OVERVAL (F)	SHEDTIME
PERIOD	SHUTDOWN
PFDLYFL	SLOTNUM
PNTFORM	STDBYMAN
PNTMODTY	STSMMSG
PNTNODTY	TRACKING
PNTSTATE	UNIT
PNTTYPE	USERID
PRGATRFL	X1
PRIMMOD (F)	X2
PTDESC	X3
PTEXECST	X4
PTINAL	XUHI
PTORST	XULO
RARWSTS	
RCASOPT	
RCASSHED	
REDTAG	
RINITREQ	

Totalizer

The parameters of the Totalizer PV algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDOPT (F)	CNFPU	PIDSTN
\$AUTROPT	CUTOFFLM	PISRC
\$AUTRTIM	DLYTIME (F)	PNTFORM
\$AUXUNIT (F)	EUDESC	PNTMODTY
\$CDETAIL	HIGHAL (F)	PNTNODTY
\$DLBADAL (F)	HIGHALPR (F)	PNTSTATE
\$REALARM (F)	KEYWORD	PNTTYPE
ACCTYPE	LASTPV	PRIMMOD (F)
ALENBST (F)	MODNUM	PSDLYFL
ASSOCDSP	NAME	PTDESC
AVDEV1FL	NODENUM	PTEXECST
AVDEV1TP	NODETYP	PTINAL
AVDEV2FL	NOPINPTS	PV
AVDEV2TP	NORMCYCL	PVALDB (F)
AVTV	NTWKNUM	PVALDBEU
AVTVFL	OLDAV	PVALGID
BADPVFL	OVERVAL (F)	PVAUTO
BADPVPR (F)	P1	PVAUTOST
C	P1STS	PVCALC
COMMAND	P2	PVCLAMP
CONTCUT (F)	P2STS	(Continued)
CNFMU	PERIOD	

Totalizer (Continued)

PVEQN	PVROCPPT (F)
PVEUHI	PVSGCHTP (F)
PVEULO	PVSOURCE (F)
PVEXEUHI	PVSRCOPT (F)
PVEXEULO	PVSTS
PVEXHIFL	PVTV (F)
PVEXLOFL	PVTVP (F)
PVFORMAT	RESETFL
PVHHFL	RESETVAL
PVHHPR (F)	SCHSTS
PVHHTP (F)	SLOTNUM
PVHIFL	STARTFL
PVHIPR (F)	STATE
PVHITP (F)	STOPFL
PVINIT	STSMMSG
PVLLFL	TF
PVLLPR (F)	TIMEBASE
PVLLTP (F)	UNIT
PVLOFL	USERID
PVLOPR (F)	
PVLOTP (F)	
PVP	
PVROCNFL	
PVROCNPR (F)	
PVROCNTP (F)	
PVROCPFL	
PVROCPPR (F)	

Variable Dead Time With Lead/Lag

The parameters of the Variable Dead Time With Lead/Lag PV algorithm are listed below in Alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	C2	NODENUM	PNTSTATE
\$AUXUNIT (F)	CNFMU	NODETYP	PNTTYPE
\$CDETAIL	CNFPU	NOPINPTS	PRIMMOD (F)
\$DLBADAL (F)	CONTCUT (F)	NORMCYCL	PSDLYFL
\$HHSELECT (F)	CUTOFFLM	NTWKNUM	PTDESC (F)
\$HISELECT (F)	D	OVERVAL (F)	PTEXECST
\$LLSELECT (F)	D1	P1	PTINAL
\$LOSELECT (F)	D2	P1STS	PV
\$REALARM (F)	DLYTIME (F)	P2	PVALDB (F)
\$RNSELECT (F)	EUDESC	P2STS	PVALDBEU (F)
\$RPSELECT (F)	HIGHAL (F)	PERIOD	PVALGID
ALENBST (F)	HIGHALPR (F)	PFDLYFL	PVAUTO
ASSOCDSP	KEYWORD	PIDSTN	PVAUTOST
BADPVFL (F)	LASTPV	PISRC	PVCLAMP
BADPVPR (F)	MODNUM	PNTFORM	PVEQN
C	NAME	PNTMODTY	(Continued)
C1	NLOC	PNTNODTY	

Variable Dead Time With Lead/Lag (Continued)

PVEUHI	PVLLFL	PVSRCOPT (F)
PVEULO	PVLLPR (F)	PVSTS
PVEXEUHI	PVLLTP (F)	PVTV (F)
PVEXEULO	PVLOFL	PVTVP (F)
PVEXHIFL	PVLOPR (F)	SCHSTS
PVEXLOFL	PVLOTP (F)	SLOTNUM
PVFORMAT	PVP	STSMMSG
PVHHFL	PVROCNFL	TD
PVHHPR (F)	PVROCNPR (F)	TF
PVHHTP (F)	PVROCNTF (F)	TLG1
PVHIFL	PVROCPFL	TLG2
PVHIPR (F)	PVROCPR (F)	UNIT
PVHITP (F)	PVROCPTP (F)	USERID
PVINIT	PVSOURCE (F)	

Parameter	Description	Type	Lock	(Default) and Range
\$ADD	Add last parameter indicator	L	PB	(On); On Off
\$ALDLOPT	Alarm Delay Option (R620 & later)	e:	Eng	(None); OffDlyLo, OffDlyHi, OffDlyEm, OnDlyLo, OnDlyHi, OnDlyEm
\$AUXUNIT	Auxiliary Unit (R520 & later)	e:	Oper	(Null); Any valid Unit ID
\$BADOCMD	Bad Output Connection Mode (R680 & later)	e:	Eng	(SHEDMAN); 15_SEC, 60_SEC, NO_SHED
\$CDETAIL	Custom Schematic Name (R620 & later)	S	Eng	(8 space characters); Any 8 character string valid for a schematic name
\$CDEF1	Default Output Value for \$CV1	R	Eng	(NaN); CVEULO to CVEUHI, NaN
\$CDEF2	Default Output Value for \$CV2	R	Eng	(NaN); CVEULO to CVEUHI, NaN
\$CDEF3	Default Output Value for \$CV3	R	Eng	(NaN); CVEULO to CVEUHI, NaN
\$CDEF4	Default Output Value for \$CV4	R	Eng	(NaN); CVEULO to CVEUHI, NaN
\$CV1	Calculated Variable for Output 1	R	View	(NaN); N/A
\$CV2	Calculated Variable for Output 2	R	View	(NaN); N/A
\$CV3	Calculated Variable for Output 3	R	View	(NaN); N/A
\$CV4	Calculated Variable for Output 4	R	View	(NaN); N/A
\$DBVALID	HPM Database Valid	e:	Eng	(DBInvalid); DB_Valid, DBInvalid
\$DEVIDX	FTE Device Index (R684 & later - EUCN)	I	PB	(0); 0 - 509
\$DLBADAL	Delay for BADPV and BADCTL (R681 & later)	e:	Eng	(NONE); None, Offdelay
\$DHSELCT	Deviation High Selective Cutout (R681 & later)	e:	Eng	(Cutout); Cutout, Allow
\$DLSELCT	Deviation Low Selective Cutout (R681 & later)	e:	Eng	(Cutout); Cutout, Allow

Parameter	Description	Type	Lock	(Default) and Range
\$DLYOPT	Digital Input Alarm Delay Option (R660 & later)	e:	Eng	(None); PmOffDly, NmOffDly, NmOnDly If you migrate to R660, the default is PmOffDly
\$HHSELECT	PV High High Selective Cutout (R681 & later)	e:	Eng	(Cutout); Cutout, Allow
\$HSELECT	PV High Selective Cutout (R681 & later)	e:	Eng	(Cutout); Cutout, Allow
\$INITOPT	Initialization Option (R630 and later)	e:	Eng/PB	(Normal); Normal, HoldOp
\$IOMPADD(n)	IOP Address (n = 1 - 168)	l	View	(); 0, 129-255
\$LLSELECT	PV Low Low Selective Cutout (R681 & later)	e:	Eng	(Cutout); Cutout, Allow
\$LOSELECT	PV Low Selective Cutout (R681 & later)	e:	Eng	(Cutout); Cutout, Allow
\$MODESEL	Mode Selection List (R630 and later) Refer PM Family Parameter Reference Dictionary for more information.	l	Eng	All the modes and mode attributes applicable for a point type that can be changed from a display.
\$NSFPMS	The number of HPM Process Module slots that are to be processed twice a second. (R682 and later)	l	PB	(0); 0 – 100. Cannot be more than the number of HPM Process Module slots (NPMSLOT).
\$NNUMALM	Maximum number of HPM Box numeric slots available for PV trip point alarming (R660 and later)	l	PB	(0); 0 – 2047. Cannot be more than number of box numerics specified by NNUMERIC parameter value.
\$NOPCONN	Number of Output Connections (PUSH + FETCH)	l	PB	(1); 1 to 4

Parameter	Description	Type	Lock	(Default) and Range
\$OFSELECT	Off Normal Selective Cutout (R681 & later)	e:	Eng	(Cutout); Cutout, Allow
\$OP1	Output 1	R	View	(0.0); -6.9 to 106.9%
\$OP2	Output 2	R	View	(0.0); -6.9 to 106.9%
\$OP3	Output 3	R	View	(0.0); -6.9 to 106.9%
\$OP4	Output 4	R	View	(0.0); -6.9 to 106.9%
\$PMDLYTM	Value of IOP DLYTIME parameter for Digital Input points that have been configured as STATUS points (R660 and later)	I	View	(5); 0 - 60 Seconds
\$OLDEVDS	Open-Line Detect Event Disable (AnalogIn) (R640 and later)	e:	Eng	(Enable); Enable, Disable (for the LLAI / LLMUX AI points having sensor type of Thermocouple or RTD). (NoOTDetc); for all other AI points.
	Open-Line Detect Event Disable (AnalogOut) (R640 and later)	e:	Eng	(Enable); Enable, Disable
\$OPTOL	Output Tolerance (AnalogOut)	R	Eng	(0.0); 0.0 to 106.9%
	Output Tolerance (RegCtl)	R	Eng	(0.0); >=0.0 (in EU)
\$REALARM (F)	Re-alarms Interval (R660 & later)	I	Eng	(0) No alarm; 0 through 9999 minutes (if configured, value ranges from one minute to approximately 167 hours)
\$RNSELECT	PV Negative Rate of Change Selective Cutout (R681 & later)	e:	Eng	(Cutout); Cutout, Allow
\$RPSELECT	PV Positive Rate of Change Selective Cutout (R681 & later)	e:	Eng	(Cutout); Cutout, Allow

\$SELCTOP	Selected Output	e:	Oper	(SELOP1); 0-SELOP1, 1-SELOP2, 2-SELOP3, 3-SELOP4
\$SPTOL	Setpoint Tolerance	R	Eng	(0.0); >=0.0
\$UCNLSBn	Local UCN Communications Statistics (n = 1 – 50)	R	View	N/A
AB_DATA1	A-B PLC Family type: 2.0, 3.0, or 5.0	R	Eng	(NaN); N/A
AB_DATA2	A-B PLC File number; NaN for PLC-2	R	Eng	(NaN); 0 – 999, NaN
AB_DATA3	A-B PLC-3 Section ID, or PLC-2 or 5 data type	R	Eng	(NaN); 0 - 13, NaN
AB_DATA4	A-B Data PLC Scan Frequency in seconds.	L	Eng	(NaN); 0 – 256, NaN
ABHEMSD	Abnormal Handler Emergency Shutdown Enable Flag	L	View	(Off); On – Off
ABHHOLD	Abnormal Handler Hold Enable Flag	L	View	(Off); On – Off
ABHRSTR	Abnormal Handler Restart Enable Flag	L	View	(Off); On – Off
ABHSHDN	Abnormal Handler Shtdn Enable Flag	L	View	(Off); On – Off
ACCELTIM	Acceleration Time	T	View	(0); 0 – 4000 days
ACCTYPE	Accumulator Operation Mode	e:	Eng/PB	(Analog); Pulse, Analog
ACP	Advanced Control Data Point	E	PB	(Null); A-Z, 0-9,
ACTPRIM(n)	Acting Primary I/O Module (n = 1 - 40)	e:	View	(); IOM_A, IOM_B
ADVDEVFL	Advisory Deviation Alarm Flag	L	View	(Off); On – Off
ADVDEVPR	Advisory Deviation Alarm Priority	e:	Eng	(NoAction – R670); Low, Emergency, High, Journal, NoAction, Printer, JnlPrint
ADVDEVTP	Advisory Deviation Alarm Trip Point	R	Supr	(NaN); ≥ 0.0, NaN

ADVSP	Advisory Setpoint in Engineering Units	R	Supr	(N/A); SPLOLM – SPHILM
ADVSP	Advisory Setpoint in Percent	R	View	(N/A); N/A
ALENBST	Alarm Enable Status	e:	Oper	(Enable); Enable, Disable, Inhibit
ALMOPT	Alarming Option (DigComp) Alarming Option (DigIn)	e: e:	Eng/PB Eng/PB	(None); Offnorml, Cmddis, None (None); Offnorml, None
ALPRIOR	Alarm Priority	e:	Eng	(Low); Low, Emergency, High, Journal, NoAction, Printer, JnlPrint
ANAME(n)	Abnormal Sequence Name (n = 1 - 3)	S	View	Spaces; N/A
AOCALIB(n)	AO Calibration in Prog. Flag (n = 1 - 168)	L	Eng/PB	(); Off, - On
ARWNET	Windup Status of the Input	e:	View	(Normal); Normal, Hi, Lo, HiLo
ARWOP	Windup Status of the Output	e:	View	(Normal); Normal, Hi, Lo, HiLo
ASSOCDSP	Associated Display	S	Eng	(Blank); N/A
ASPPROC	Advisory SP Processor State	e:	Supr	(Disable); Disable, Enable
ASTEP(n)	Abnormal Step Name (n = 1 - 3)	S	View	(Blank); N/A
ASTMT(n)	Abnormal Statement Number (n = 1 - 3)	I	View	(Blank); 0 – 255
AUTMODFL	Automatic Mode Flag	L	View	(N/A); Off – On
AUXDATA1	Modbus Keep Alive address	R	Eng	(NaN); 1 - 9999, NaN
AUXDATA2	Modbus Retry interval, NaN = 1.5 sec.	R	Eng	(NaN); .25 - 5 Sec., NaN
AUXDATA3	Modbus Protocol.Modem control (0 = off).	R	Eng	(NaN); 232.0, 232.1, 485.0
AUXDATA4	Modbus Baud Rate.Parity (0 = none). baud/odd parity	R	Eng	(NaN); 1200, 2400, 4800, 9600, 19,200. Decimal = .0, .1, or .2
AV	Accumulated Value in Engineering Units	I	Oper	(0); 0 – 32767
AVDELTHS	The Last Half-Second's AV	I	View	(0); ≥ 0

AVDEV1FL	Accumulated Value – 1st Deviation Flag	L	View	(N/A); Off – On
AVDEV2FL	Accumulated Value – 1st Deviation Trip Point	R	Supr	(NaN); ≥ 0.0, NaN
AVDEV1TP	Accumulated Value – 2nd Deviation Flag	L	View	(N/A); Off – On
AVDEV2TP	Accumulated Value – 2nd Dev. Trip Point	R	Supr/PB	(NaN); ≥ 0.0, NaN
AVGPU	Average PUs for Point Processing	R	View	(0); N/A
AVGTF	Avg. Statistics Single Lag Filter Time Constant	R	View	(1.00 minutes); N/A
AVSTS	Value Status of AV	E:	View	(Bad); Bad, Normal
AVTV	Accumulator Target Value (DigIn) Accumulator Target Value (Totalizr)	I R	Oper Oper/PB	(0); 0 - 32767 (NaN); N/A, NaN
AVTVFL	Accumulated Value Target Reached Flag	L	View	(N/A); Off – On
B	Overall Bias	R	Oper/PB	(0.0); N/A
B0	Last Operator Entered Output Bias	R	View	(0.0); N/A
B1	Output Bias Constant	R	Supr/PB	(0.0); N/A
B2	Bias for Input X2	R	Supr/PB	(0.0); N/A
BADCTLFL	Bad Control Alarm Flag	L	View	(Off); Off – On
BADCTL0P	Bad Control Option	e:	Eng	(No_Shed); No_Shed, ShedHold, ShedLow, ShedHigh, ShedSafe
BADCTLPR	Bad Control Alarm Priority	e:	Eng	(NoAction – R670); Low, Emergency, High, Journal, NoAction, Printer, JnlPrint
BADOCFL	Bad Output Connection Flag Alarm	L	View	(Off); On – Off
BADOCnFL	Bad Output Connection Flag n. (n = 1 - 4)	L	View	(Off); On – Off

BADOCPR	Bad Output Conn. Alarm Priority	e:	Eng	(NoAction – R670); Low, Emergency, High, Journal, NoAction, Printer, JnlPrint
BADOCOPT	Bad Output Conn. Alarm Option	L	Eng/PB	(Off); On – Off
BADPVFL	Bad PV Alarm Flag	L	View	(Off); Off – On
	SI Database Status Flag (Array)	L	View	(special); Off – On
BADPVPR	Bad PV Alarm Priority	e:	Eng	(NoAction – R670); Low, Emergency, High, Journal, NoAction, Printer, JnlPrint
BCAMODFL	Backup Cascade Mode Flag	L	View	(N/A); On – Off
BADPVTXT	Bad PV Text Descriptor	S	PB	(BAD); A-Z, 0-9
BADSVFL	Bad SV Alarm Flag	L	View	(Off); Off, On
BADSVPR	Bad SV Alarm Priority	e:	Eng	(NoAction – R670); Low, Emergency, High, Journal, NoAction, Printer, JnlPrint
BFF	Feed Forward Input Bias	R	Supr	(0.); N/A
BHALMF(n)	Alarm Flags (n = 1 - 7)	S	View	(); 0 0-FF
BIAS	Bias	R	Oper/PB	(0.0); BSLOLM – BSHILM
BNDRESET	Bounds Statistics Reset Flag	L	Oper	(Off); Off/On
BNDRSTIM	Last Bounds Statistics Reset Time	T	View	(HPM Startup Time); N/A
BOXCLR(n)	Box Color for Digital Displays (DigComp)	e:	Eng/PB	(Green – Upper Box Default, State 1); (Red – Lower Box Default, State 2); (Yellow – Middle Box Default, State 0); Red, Green, White, Black, Cyan, Yellow, Blue, Magenta
	Box Color for Digital Displays (DigIn, Flag)	E:	Eng/PB	(Green – Upper Box Default, State 1); (Yellow – Lower Box Default, State 0); Red, Green, White, Black, Cyan, Yellow, Blue, Magenta
BSHILM	Bias High Limit	R	Supr	(50.0); ≥ BSLOLM, NaN

BSLOLM	Bias Low Limit	R	Supr	(-50.0); <BSHILM, NaN
BYPASS	Interlock Bypass Override Input Bypass Enable	L	Oper	(Off); Off – On
BYPASSX1-4	Bypass ORSel's X1 - X4 Input	L	Oper	(BYPASSX1 = Off); Off-On (BYPASSX2-X4 = On);
C	Scaling Factor	R	Supr	(1.0); Anything except NaN
C1-C2	Correction Constant (FlowComp)	R	Supr	(1.0); C1 ≥0.1, C2 ≥0.1
	Scaling Constant for Input P1-P2 (VdtLdLag)	R	Supr	(1.0); ≥0.0
	Scaling Constants Used to Calculate PVCALC (PI)	R	Supr	(1.0); C1 ≥0, C2 > 0
C1-C4	Intermediate Results of Calculations (CalCuLtr)	R	Supr	(N/A); N/A
C1-C6	Scaling Constants 1-6 (Summer)	R	Supr	(1.0); N/A
CnDESC	Custom Alarm Descriptors, (n = 1- 4)	S	Eng	(Blank); 8-char string
CnFL	Custom Alarm Flag, (n = 1- 4)	L	Prog	(Off); Off, On
CnPR	Custom Alarm Priorities, (n = 1- 4)	e:	Eng	(NoAction – R670); Low, Emergency, High, Journal, NoAction, Printer, JnlPrint
CnSRC	Custom Alarm Source, (n = 1- 4)	e:	PB	(None); None, L1 - L12, SO1 - SO24, FL1 - FL24
CABLESTS	Overall Cable Status for UCN Node	I	View	(N/A); 0, 1, 2 or 3
CALCEXP	Calculator Expression	S	Eng/PB	(Blank); N/A
CALIBALL(n)	Full Calibration Enable Flag (n = 1 - 168)	L	Eng/PB	(Off); Off – On
CALIBRJ(n)	Reference Junction Calibration Enable Flag (n = 1 - 168)	L	Eng/Pb	(Off); Off – On
CASMODFL	Cascade Mode Flag	L	View	(N/A); Off – On
CASREQ	Remote Cascade Request	e:	Prog	(NotReq); NotReq, Request

CHPINHWY	Automatic Checkpoint Inhibit	e:	Supr	(Enable); Enable, Inhibit
CHPINOPR	Automatic Checkpoint Inhibit Operation	e:	Supr	(Enable); Enable, Inhibit
CIDSTN(n)	Control Input Connection Destination (n = 1 - 40)	P	PB	(Varies by Algo Type, Equation); N/A
CISRC(n)	Control Input Connection Source (n = 1 - 40)	E	PB	(Null.Null); "TagName.Parameter"
CLBACK	Number of Backward Branches	I	Eng/PB	(0); 0 – 240
CLPZMXC	Overall Cable Status for UCN Cable A	L	Eng	(N/A); Off – On
CLPZMXP	Overall Cable Status for UCN Cable B	L	View	(N/A); Off – On
CMD	Command Fail Alarm Flag (RegCtl)	L	View	(Off); Off – On
CMDDISFL	Command Disagree Alarm Flag	L	Special	(Off); Off – On
CMDDISPR	Command Disagree Alarm Priority	E:	Eng	(NoAction – R670); Low, Emergency, High, Journal, NoAction, Printer, JnlPrint
CMDFALFL	Command Fail Alarm Flag (DevCtl, DigComp)	L	View	(Off); Off – On
CMDFALTM	Command Fail Timeout	I	Special	(0); 0 - 999 seconds
CMDHWREV	HPMM Com. Daughter Card Revision	S	View	(); 00 – FF
CMPLTIME	Sequence Compile Time	T	View	(0); N/A
CNFLUA(n)	Configured Link Units on Link A n = 1 - 576	R	View	(0); N/A
CNFLUB(n)	Configured Link Units on Link B n = 1 - 576	R	View	(0); N/A
CNFMU	Configured Memory Units	I	View	(0); N/A
CNTLLOCK	Control Lock	e:	Eng	(Operator); Operator, Supervis

CNFPU(n)	Configured Process Units per cycle n = 1 - 64	R	View	(0); N/A
CNFPUP	Configured Process Units Percent	R	View	(0); N/A
CODSTN(n)	Control Output Connection Destination (n = 1 - 4)	E	PB	(Null.Null); "TagName.Parameter" or "IMTmmSss.Parameter"
COMCFAVG	Avg. HPM Comm. CPU Free %	R	View	(NaN); 0 – 100
COMCFMAX	Max. HPM Comm. CPU Free %	R	View	0 – 100
COMCFMIN	Min. HPM Comm. CPU Free %	R	View	0 – 100
COMMAND	Accumulator Commands (DigIn, Totalizr)	e:	Oper	(None); None, Start, Stop, Reset
	Timer Commands (Timer)	e:	Oper	(None); None, Start, Stop, Reset, RestStrt
	STI Point/Database Transfer; STI Calibration	e:	Oper	(None); None, DnLoadDb, UpLoadDb, Set_LRV, Set_URV, Cor_LRV, Cor_URV, Cor_Inpt, RstCor
COMPHILM	Compensation Term High Limit	R	Supr	(1.25); COMPLOLM - 10.0, NaN
COMPLOLM	Compensation Term Low Limit	R	Supr	(0.8); 0.0 - COMPHILM, NaN
COMPTERM	Compensation Term	R	View	(1.0); COMPLOLM – COMPHILM
CONTCUT	Contact Cutout	L	Prog	(Off); Off – On
COUNTDOWN	Accumulator Count Down Flag	L	Eng/PB	(Off); Off – On
CPMSGSEC	Number of Checkpoint Messages	R	View	(0); N/A
CRIOLORN	Current Hour I/O LinkFetch/Store Overrun Counter	I	View	(0); ≥ 0
CRPPXORN(n)	Current Hr Pt. Processing Overrun Counter (n = 0 - 8)	I	View	(0); ≥ 0
CRUCNORN	Current Hour UCN Fetch/Store Overrun Counter	I	View	(0); ≥ 0
CTLACTN	Control Action	e:	Eng/PB	(Reverse); Direct, Reverse

CTLALGID	Control Algorithm Identifier	e:	PB	(Null); Null, Pid, PidErfb, PidFF, RatioCTL, IncrSum, Switch, PosProp, AutoMan, RampSoak, ORSel, PidPosProp, Muldiv, Summer, OPSelect
CTLCFAVG	Avg. HPM Ctl. Processor Free %	R	View	(NaN); 0 – 100
CTLCFMAX	Max. HPM Ctl. Processor Free %	R	View	(NaN); 0 – 100
CTLCFMIN	Min. HPM Ctl. Processor Free %	R	View	(NaN); 0 – 100
CTLEQN	Control Equation Type (AutoMan, ORSel, Switch)	e:	PB	(EqA); EqA, EqB
	Control Equation Type (Pid algos)	e:	PB	(EqA); EqA, EqB, EqC, EqD
CTLOPT	HPMM Control Processor Option	L	PB	(On); Off – On
CTLREDUN	HPMM Control Redundancy Present Flag	L	View	(NaN); Off- On
CTRLINIT	Control Initialization Request Flag	L	Prog	(Off); Off- On
CURPINAMn	Current Personality Image Filename	S	View	(N/A); N/A
CURSEGID	Current Segment ID	e:	Oper	(Ramp1); Ramp1/Soak1 to Ramp12/Soak12
CUTOFFLM	Zero-Flow/Belt-Speed Cut-Off Limit	R	Supr	(0.0); < 0.0, NaN
CV	Calculated Variable	R	Prog	(NaN); N/A
CVEUHI	CV's High Limit in Engineering Units	R	Eng	(100.0); < CVEULO
CVEULO	CV's Low Limit in Engineering Units	R	Eng	(0.0); < CVEUHI
CYCLEOPT	Ramp Soak Cycle Option	e:	Oper	(Cyclic); Single, Cyclic
CYCLETIM	PosProp Output Cycle Time in Seconds	R	Supr	(10.0); 0.25 - 1000.0 Seconds
D	Overall Bias	R	Supr	(0.0); N/A

D1	Fixed Deadtime in Minutes (VdtLdLag)	R	Supr	(0.0); 0.0 - 400.0 Minutes
D1_0	Digital Input 1 Equal to a PV State of 0 (DigComp)	e:	View	(PVState0); PVState0, PVState1
D1_1	Digital Input 1 Equal to a PV State of 1 (DigComp)	E:	Eng/PB	(PVState0); PVState0, PVState1 (Off); Off – On
D1, D2	Status of Digital Inputs 1 & 2 (DigComp)	L	View	(0.0); < 0.0
D2	Bias for Input D2 (VdtLdLag)	R	Supr	(MovPV); MovPV, PVState0,
D2D1_00	D2_D1 Zero_Zero PV State	E:	Eng/PB	PVState1, PVState2, BadPV (PVState0); PVState0, MovPV,
D2D1_01	D2D1 Zero_One PV State	E:	Eng/PB	PVState1, PVState2, BadPV (PVState1); PVState1, MovPV
D2D1_10	D2D1 One_Zero PV State	E:	Eng/PB	PVState0, PVState2, BadPV (BadPV); BadPV, PVState0,
D2D1_11	D2D1 One_One PV State	E:	Eng/PB	PVState1, PVState2, MovPV (Off); Off – On
DAMPING	First Order PV Filtering Option for the Smart Transmitter	R	Supr/View	(N/A); N/A
DATE	Current Date/Time	T	View	(N/A); 1 – 31
DAY	Current Day	I	View	(Invalid); Valid, Invalid
DB_VALID(n)	Database Valid, (n = 1 - 40)	E:	Engr	(1.0); 0.0
DEADBAND	Deadband Value (Logic) (n = 1 - 24)	R	Supr	(5.0%); 0.0 - 100.0%
	Deadband in % of Full Scale (PosProp)	R	Supr	(0.0); 0.0 - 60.0 Seconds
DEADTIME	Deadtime Value for Raise Pulse	R	Supr	(10 ms); 0 - 50 ms

DEBOUNCE	Contact Debounce Time in Milliseconds	I	Eng/PB	(Pv_Sv_Db); PV, PV_Sv,
DECONF	Digitally Enhanced Configuration Mode	E:	Eng/View	PV_Db, Pv_Sv_Db
DELCV	Delta CV in Eng Units (IncrSum)	R	View	(N/A); N/A
	Delta CV in Percent (Pid)	R	View	(N/A); N/A
DEV	Deviation	R	View	(N/A); N/A
DEVADDR	Serial Link Device Address	R	PB	(NaN); N/A
DEVHIFL	Deviation High Alarm Flag	L	View	(Off); Off – On
DEVHIPR	Deviation High Alarm Priority	e:	Eng	(NoAction – R670); Low, Emergency, High, Journal, NoAction, Printer, JnlPrint
DEVHITP	Deviation High Alarm Trip Point	R	Supr	(NaN); (0.0, NaN
DEVLOFL	Deviation Low Alarm Flag	L	View	(Off); Off – On
DEVLOPR	Deviation Low Alarm Priority	e:	Eng	(NoAction – R670); JnlPrint, Printer, Emergency, High, Low, Journal, NoAction
DEVLOTP	Deviation Low Alarm Trip Point	R	Supr	(NaN); (0.0, NaN
DHTIMMAXn	Maximum time to Complete a Data Handler Request; n = 1 - 5	R	View	(0); N/A
DISP_SIM	Simulation Indicator Display Switch	L	Prog	(N/A) Off – On
DISRC(n)	DigComp Input-Connection Source (n = 1 - 2)	U	PB	(Null.Null); "TagName.Parameter" or "IMTmmSss.Parameter" or "\$NMhhBxx.Parameter"
DITYPE	Digital Input Type	e:	PB	(Status); Status, Latched, Accum

DLYTIME	Alarm Delay in Seconds (DigIn)	I	Supr	(5); 0 - 60 Seconds
	Alarm Delay in Seconds for Logic Blocks (Logic)	R	Supr	(1); 1 - 8000 Seconds
	Alarm Delay in Seconds (AI, RegCtl, RegPV) (R620 and later)	e:	Eng	(0); 0 - 9999 Seconds
DODSTN(n)	DigComp Output Connection Destination (n = 1 - 3)	U	PB	(Null.Null); "TagName.Parameter" or "MTmmSss.Parameter" or "NMhhBxx.Parameter"
DOTYPE	Digital Output Type	e:	PB	(Status); PWM, Status
DSA	Device Soft Address	I	View	(N/A); 1-40, 129-168
EIPPCODE	Event-Initiated Point Identifier	E	Eng	(Null); A-Z, 0-9, _
EQUOBJNM	Equipment List Object File	S	View	(Blank); N/A
ERRCODE	Serial Interface/Serial Link Communication Error Code	S	View	Spaces; N/A
ESWAUTO	External Switching Flag for Auto Mode	L	Prog	(Off); Off - On
ESWCAS	External Switching Flag for Cascade Mode	L	Prog	(Off); Off - On
ESWENBST	External Mode Switching Enable State	e:	Oper	(Disable); Disable, Enable
ESWMAN	External Switching Flag for Manual Mode	L	Prog	(Off); Off - On
EUDESC	Engineering Units Descriptor	S	PB	(Blank); A-Z 0-9 space ! % & ' () * + - / : ; > < = ? _ , . \$
EUNDESCn	IOP Generic Descriptor, n = 1 - 168	S	View	Blanks; 1-40 (pri); 129-168 (sec)
EVRCINPG	NIM Event Recovery in Progress Flag	L	View	(N/A); Off, On
EVTOPT	Event Reporting Option (DigComp)	e:	PB	(None); None, Eip

	Event Reporting Option (DevCtl, DigIn)	e:	PB	(None); None, Eip, Soe, Eip_Soe
EXTDATA	External Data Option	e:	PB	(None);None,IO_FL,IO_NN,IO_STR,UCN_FL,UCN_NN,UCN_STR
EXTSWOPT	External Mode Switching Option	e:	Eng/PB	(None); None, Ems, Emp
F	Flow Input (uncompensated)	R	View	(NaN); N/A
FAILCODE	I/O Processor Hard Fail Status	e:	View	(N/A); See XPM PRD
FAILOPT(n)	Failure Option for Outputs (n = 1 - 168)	e:	Eng/PB	(Unpower); Unpower, Hold
FBTIME	Feedback Time	I	Eng/PB	(1000); 0-1000 Seconds
FF	Feed Forward Algorithm Input	R	View	(N/A); N/A
FFOPT	Feed Forward Type	e:	Eng/PB	(Multiply); Multiply, Add
FL(n)	Box Flags FL(1) - FL(16,384)	L	Oper	(Off); Off – On
	Logic Slot Flags FL(1) - FL(12)	L	Special	(FL2 = On, rest = Off); Off – On
	Array Point Flags FL(i)	L	Special	(N/A); 1 ≤ i < NFLAG
	Process Module Flags FL(1) - FL(127)	L	Special	(Off); Off-On
FLDESC	FL Array Descriptor	S	PB	(spaces); N/A
FLSTIX	Flag Array Start Index	R	PB	(0); 0 - 99,000 or 0 - 16,384
FORCE	Forced Input Request Flag	L	Oper	(Off); Off - On
FRCPERM	Forced Input Permissive	L	Eng/PB	(Off); Off - On
FREQ6050	Frequency 60/50 Hz for LLMUX or STT	e:	Eng/PB	(60Hz); 0 - 60 Hz, 1 - 50 Hz
FRQUTAVG	Average UCN Fetch Request Trip Time	R	View	(NaN); N/A
FRQUTMAX	Maximum UCN Fetch Request Trip Time	R	View	(NaN); N/A
FRSPTAVG	Average UCN Fetch Response Trip Time	R	View	(NaN); N/A

FRSPTMAX	Max. UCN Fetch Response Trip Time	R	View	(NAN); N/A
FSELIN	Force Selected Input	e:	Oper/PB	{SelectP1}; SelectP1 - SelectP6,
FSTS	Flow Input Value Status	e:	View	(Bad); Bad, Normal, Uncertrn
FTAnTYPE	Type of FTA Connected to LLMUX; n=1 - 2	e:	View	(None); None, TC, RTD
FTACONN	FTA Connection to I/O Module This File	e:	View	(Conn_A); Conn_A, Conn_B
FTANUM	SI IOP FTA number	I	PB	(1); 1 – 10
FTAPRES(n)	IOP FTA Present Flag; n = 1 - 168	L	View	(); Off - On
G	Specific Gravity Input	R	View	(1.0); N/A
GAINOPT	Gain (K) Option	e:	Eng/PB	(Lin); Lin, Gap, NonLin, Ext
GAPHI	Gap High Limit	R	Supr	(0.0); < 0.0
GAPLO	Gap Low Limit	R	Supr	(0.0); < 0.0
GENDESC(n)	Generic Descriptor (n = 1 - 12)	S	PB	(Blanks); A-Z 0-9 Space ! % & ' () * + - : ; > < = ? _ , . \$
GENDESC(n)	Generic Descriptor (n = 1 - 40 or 129 - 168)	S	View	(Blanks); 1 - 40 = Acting Primary, 129 - 168 = Acting Secondary
GSTS	Gravity Input Value Status	e:	View	(Normal); Normal, Uncertrn, Bad
HIGHAL	Highest Alarm Detected (Analgn, Pl, RegCtl, RegPV)	e:	View	(NoAlarm); NoAlarm, AdvDev, DevHi, DevLo, PVRocN, PVRocP, PVHi, PVHH, PVLo, PVLL, BadCtl, BadPV, BOC
	Highest Alarm Detected (DigComp, DigIn, DevCtl, Flag, Logic)	e:	View	(NoAlarm); NoAlarm, OffNorm, UnCEvt, CmdDis BadPV, C1ALM - C4ALM, Chngofst, Cmdfail, SVHi, SVHH, BadSV, OVRDI2, OVRDI1, OVRDI0, OVRDSI0, BadCtl

HIGHALPR	Highest Level Alarm's Priority	e:	View	(NoAction); NoAction, Journal, Printer, JnlPrint, Low, High, Emergency
HISVPEAK	Highest Peak SECVAR Value	R	View	(0); < 0
HOLDCMD	Hold Command Flag	L	Prog	(Off); Off – On
HWYCTLST	UCN Network Functional State	e:	Supr	(Basic); Basic, Full
I0 - I2	Override Interlocks for Output States 0-2	L	Eng	(Off); On – Off
I0CONF	Override Interlock 0 Alarm Conf. flag	L	Oper	(Off); N/A
InDESC	I0 - I2 Alarm Descriptor; (n = 0 - 2)	S	Eng	(Blank); 8 Character String
I1CONF	Override Interlock 1 Alarm Conf. flag	L	Oper	(Off); N/A
I2CONF	Override Interlock 2 Alarm Conf. Flag	L	Oper	(Off); N/A`
IN0 - IN12	Input Coordinates 0-12	R	Supr	(NaN); > Previous INn but < Next INn. IN0 < IN1 < IN2 < IN12
INITMAN	Initialization Manual Flags	L	View	(On); Off – On
INITREQ	Initialization Request Flag (Array)	L	View	(Off); Off – On
	Initialization Request Flags (AO, DO)	L	View	(On); Off – On
INITREQ(i)	Initialization Request Flags (DigComp, DevCtl) (i = 0 - 2)	L	View	(On); Off – On
	Initialization Request Flags (RegCtl) (i = 1 - 4)	L	View	(Off); Off – On
INITVAL	Initialization Value	R	View	(N/A); N/A
INPTDIR	Input Direction	e:	Eng/PB	(Direct); Direct, Reverse
IOLASTS	I/O Link Cable A Status	L	View	(Off); Off – On
IOLBSTS	I/O Link Cable B Status	L	View	(Off); Off – On
IOLCHAER	I/O Link Channel A Error Count	I	View	(0); < 0
IOLCHASL	I/O Link Channel A Silence Count	I	View	(0); < 0
IOLCHBER	I/O Link Channel B Error Count	I	View	(0); < 0
IOLCHBSL	I/O Link Channel B Silence Count	I	View	(0); < 0

IOLCHERT	I/O Link Channel Error Threshold	I	EgOnly	(10); < 0
IOLCMD	I/O Link Command	e:	EgOnly	(None); None, SelChnA, SelChnB, EnbPerSw, DisPerSw, RslolCom
IOLPERSW	I/O Link Periodic Cable Swap	e:	View	(N/A); Enable, Disable
IOMACTYP(n)	IOP Actual Type	e:	View	(None); None, LLAI, HCAI, DI, DO, AO, HPMM, LLMUX, STIM, PI, FBUS
IOMCARD(n)	I/O Module Card Position for the Acting Primary/Secondary n = 1-40 for Acting Primaries; n = 129-168 for Act. Secondaries	I	View	(N/A); 1- 15
IOMCARDA(n)	I/O Module A Card Position (n = 1 – 40)	I	PtBld	(0); 0 – 15
IOMCARDB(n)	I/O Module B Card Position (n = 1 - 40)	I	PtBld	(0); 0 – 15
IOMCMD	IOP Module Command	e:	Oper	(None); None, Run, Idle, Swap
IOMCOMER(n)	IOP Communication Error Status; (n = 1- 168)	e:	View	(N/A); See XPM PRD
IOMFILE(n)	I/O Module File Position for the Acting Primary/Sec. (n = 1 - 40, 129 - 168)	I	View	(0); 0 – 8
IOMFILEA(n)	I/O Module File A Position for the Acting Primary/Secondary (n = 1 - 40)	I	PtBld	(0); 0 – 8
IOMFILEB(n)	I/O Module File B Position for the Acting Primary/Secondary (n = 1- 40)	I	PtBld	(0); 0 – 8

IOMFWREV(n)	IOP Card Firmware Revision Status 1-168	A	View	(N/A); X.Y (X=Range, Y=Revision)
IOMHWREV(n)	IOP Card Hardware Revision Status 1-168	A	View	(N/A); Hexadecimal "00" to "FF"
IOMLHFST(n)	IOP Card Last Hard Fail Status	e:	View	(N/A); Unknown, PowerDwn, AdClnCmp, AdOutOvf, AdOutUdf, BadDcLtc, Dmt_Tmot, MLtOutFl, BadDaRng, MstrTmot, InvPrgEx, EpromErr, RamCntEr, RamAdrEr, DpaError, DsaError, RxBufOfL, IOLJaber, BadPgJmp, AdCCalEr,
IOMNUM	IOP Card Number	I	PB	(N/A); 1 – 40
IOMOPER(n)	IOP in Operation (n = 1 -168)	e:	View	(N/A); Primary, Secondary
IOMREALT	Actual IOP Type	e:	View	(None); None, LLAI, HALAI, DI, DO, AO, LLMUX, STIM, PI
IOMRECHN(n)	IOP Receive Channel	e:	View	(N/A); ChannelA, Channel B
IOMSEVER(n)	Error Severity Based on IOP State (n = 1 -40; 129 - 168)	e:	View	(N/A); OK, Fail, Warning, Inform
IOMSTS(n)	IOP Status (n = 1 - 40; 129 - 168)	e:	View	(N/A); CommErr, ConfigMis, Idle, IdleSF, NonExist, NoResp, NotConfig, OK, PowerOn, SoftFail, UnAvail, Configerr
IOMTYPE(n)	IOP Type (IOP) (n = 1 - 168)	e:	View	(None); None, HLAI, LLAI, AO, DI, DO; St; LLMUX STIM, PI; AO16; DO32; DISOE
IOMTYPE	IOP Type (IOP) (n = 1 - 168)	e:	PB	(NotConfig); NotConfig, HLAI, LLAI, AO, DI, DO, LLMUX STIM, PI, FBUS
IOPDESC(n)	IOP Type (HPM Box)	S	View	(Spaces); 8 characters
IOPNUM	IOP Description; (n = 1 - 40)	I	PB	(N/A); 1 – 127

IOPSTR1(n)	Serial Intf. IOP Module Number	S	View	(Spaces); N/A
IOPSTR2(n)	IOP String For FTA #1 (n = 1-40)	S	View	(Spaces); N/A
IOREDOPT	IOP String For FTA #2 (n = 1-40)	e:	PB	(Nonredun); Redun, Nonredun
IOSCNPER(n)	I/O Module Redundancy Option	R	PB	(0); 0.0, 0.625, 0.125, 0.25, 0.5, 1.0
IOSTKNDR	IO Data Scan Period in seconds	I	View	(N/A); 0 – 32767
K	IOP Token Drop Count	R	Supr	(1.0); N/A
	Gain Constant for X2 Input (AutoMan)	R	Sup	(1.0); 0.0 - 240.0
	Overall Gain in % Per % (Pid) Gain Constant (PosProp)	R	Supr	(1.0); 0.0 - 10.0
K1	External Reset Feedback Gain (PidErb)	R	Supr	(0.0); 0.0 - 1.0
	External Reset Feedback Gain (PIDPosPr)	R	Supr	(1.0); 0.0 - 1.0
K1-K2	K1=Ratio Scale Factor; K2= Gain for X2 Input (RatioCtl)	R	Supr	(1.0); (0
K1-K3	Gain Constant for X1-X3 Inputs (MulDiv)	R	Supr	(1.0); N/A
K1-K4	Gain Constant for X1-X4 Inputs (IncrSum)	R	Supr	(1.0); (0.0
KEXT	External Gain Modifier	R	Prog	(1.0); 0.0 - 240.0
KEYWORD	Keyword Descriptor	S	PB	(Blank); A-Z, 0-9,
KFF	Gain for Feed Forward Input	R	Supr	(1.0); (0.0 to ≤ 1.0
KGAP	Gap Gain Factor	R	Supr	(1.0); 0.0 - 1.0
KLIN	Linear Gain Factor	R	PB	(1.0); 0.0 - 240.0
KNL	Non-linear Gain Factor	R	View	(N/A); N/A
L(n)	Value of the External Input (n = 1 – 12)	L	View	(N/A); Real

LASTPV	Last PV Value	R	View	(NaN); N/A
LCNRECHN	LCN Channel That NIM is Listening to	E:	View	(ChannelA); ChannelA, ChannelB
LIBADOPT	Logic Bad Input Handling Option	E:	PB	(Hold); Off, On, Hold
LIBRYNUM	NIM Library Number	I	PB	(N/A); 1 – 3
LIBRYTXT(n)	NIM Library Text, (n = 1 - 1000)	S	PB	(N/A); N/A
LIDESC(n)	Input Descriptor (n = 1 - 12)	S	Eng	(Blank); 8 Characters
LINEPERD(n)	Line Period in Microseconds (n = 1 - 168)	R	View	(N/A); 15616 - 21759 μ seconds
LISRC(n)	Logic Input Connection Source (n = 1 - 12)	U	PB	(Null.Null); "TagName.Parameter" or "IMTmmSss.Parameter" or "\$NMhhBxx.Parameter"
LMREV	Local Manual Polarity	e:	Eng/PB	(Direct); Direct, Reverse
LMSRC	Local Manual Source	U	PB	(Null.Null); See XPM PRD
LOADSCOP	Load Scope	e:	PB	(NIMOnly); NimOnly, NimAndPm
LOADSTAT	Load Status	e:	View	(); Not Loaded, Loaded, Loading, Unlding
LOCALMAN	Local Manual Flag (AO, RegCtl)	L	View	(Off); Off – On
	Local Manual Flag (DigComp, DevCtl)	L	Prog	(Off); Off – On
LOCUTOFF	Low Signal Cut Off for Flow Inputs	R	Eng/PB	(NaN); PVEULO - PVEUHI, > 0
LODSTN(n)	Logic Output-Connection Destination Logic (n = 1 - 12) DevCtl (n = 1 - 2)	R	PB	(Null.Null); "TagName.Parameter" or "IMTmmSss.Parameter", or "\$NMhhBxx.Parameter"

LOENBL(n)	Logic Output Enable, (Logic) (n = 1 - 12)	e:	PB	(FL2); FL1 - FL12, SO1 - SO16, L1 - L12
	Logic Output Enable, (DevCtl) (n = 1 - 2)	e:	PB	(FL2); See XPM PRD
LOGALGID(n)	Logic Block Algorithm Identifier (n = 1 - 24)	e:	PB	(Null); OR, NOT, NAND, NOR, XOR, AND, SWITCH, CheckBad, Pulse, Delay, OnDLY, OffDLY, QOR2, QOR3, EQ, NE, GT, GE, LT, LE, MinPulse, MaxPulse, WatchDog, FlipFlop, ChDetect, Null
LOGICSRC	Logic Source	E	PB	(Null); A-Z, 0-9, _
LOGMIX	Logic Mix	e:	PB	12 24 4, 12 16 8, 12 8 12
LOSRC(n)	Output - Connection Source			
	Logic (n = 1 - 12)	e:	Eng/PB	(FL1); L1 - L12, FL1 - FL12,
	DevCtl (n = 1 - 2)	e:	PB	NN1 - NN8, SO1 - SO24
LOWERTIM	Lower Output Pulse Time (Secs)	R	View	See XPM PRD
LOWRDSTN	Lower OP Pulse Destination	U	PB	(N/A); N/A
LOWRRATE	Lower OP Stroke Rate in %/Sec	R	Supr	(Null); ONPULSE, OFFPULSE
LRL	Lower Range Limit (STI)	R	View	(100.0); >0.0% / Second
LRV	Lower Range Value (STI)	R	Supr/ View	(NaN); Na, NaN (NaN); Na, NaN
LSEQNUMR	Last Sequence Number	I	Eng	(0) N/A
LSIOLORN(n)	Last Hour's I/O Link Fetch/Store Overruns (n = 1 - 4)	I	View	(0); { 0
LSPPXORN(n)	Last Hour's Point Processing Fetch/Store Overruns (n = 1 - 8)	I	View	(0); { 0
LSTWHNER	Last When Error	I	View	(0); { 0

LSUCNORN	Last Hour's UCN Access Overruns	I	View	(0); < 0
M	Number of Inputs	I	PB	(2); 2 – 4
MAINDAT	Maintenance Reset Statistics Date	T	Eng	(Time of pt. build) Time Stamp
MAINTOPT	Maintenance Option	L	PB	(Off); Off – On
MANMODFL	Manual Mode Flag	L	View	(Off); Off – On
MANOPCMD	Manual Output Pulse Command	e:	Oper	(None); Raise_1, Lower_1, None, Raise_10, Lower_10
MANOPTIM	Manual Output Pulse Time	R	Eng/PB	(1.0); 0.0 - 60.0 Seconds
MASKTIM	Masktime	I	Supr	(0.0); 0 - 1000 sec.
MAXCNFPU	Maximum Configurable PUs	R	View	(N/A); N/A
MAXPU	Maximum PUs	R	View	(0);
MAXPULSE	Maximum Pulse Time Limit	R	Supr	(60.0); MINPULSE to 60.0 Seconds, NaN
MAXSLOTS	Maximum Available Slots	R	View	(0); 0 – 127
MAXTIM0H	Maximum time Allowed in state 0	R	Supr	(0); N/A
MAXTIM1H	Maximum time Allowed in state 1	R	Supr	(0); N/A
MAXTIM2H	Maximum time Allowed in state 2	R	Supr	(0); N/A
MAXTRAN0-2	Max. number transitions into each state	T	Supr	(0.0); no limit
MINPULSE	Minimum Pulse Time Limit	R	PB	(0.0); 0.0 Seconds to MAXPULSE, NaN
MINUTE	Current Minute	I	View	(N/A); 0 – 59
MODATTR	Mode Attribute	e:	Oper	(Operator); Operator, Program, Normal, None
MODE	Mode (AnalogOut)	e:	Oper	(Man); Man, Cas, Normal
	Mode (DigComp, DevCtl)	e:	Oper	(Man); Man, Normal
	Mode (RegCtl)	e:	Oper	(Man); Man, Cas, Auto, Bcas Normal
MODEAPPL	Mode Applicability	L	View	(Man=On; Auto, Cas, & Bcas = Off, Static for DevCtl & DigComp); N/A

MODEPERM	Mode Permissive (DevCtl, DigComp, RegCtl)	e:	Eng	(Permit); Permit, NotPerm
	Mode Permissive (Analog Out)	e:	Eng/PB	(Permit); Permit, NotPerm
MODNUM	IOP Card Number	I	PB	(N/A); 0 – 40
MOMSTATE	Momentary Output States	e:	Eng/PB	(None); Mom_0, Mom_1, Mom_2, Mom_1_2, None
MONPER	Monitoring Period in seconds	I	Eng	(3600); 4 – 3600
MONTH	Current Month	I	View	(N/A); 1 – 12
MOVPFVL	Moving PV Flag	L	View	(Off); Off – On
MOVPTXT	Moving PV Text Descriptor	S	PB	(MOVING); A-Z, 0-9
MSGPEND	Sequence Message Pending	L	View	(none); N/A
MSGTXT(n)	Status Message Text (n = 0 - 15)	S	PB	(Blank); 0-15
MXRMPDEV	Maximum Ramp Deviation Value	R	Supr	(NaN); < 0.0, NaN
MXSOKDEV	Maximum Soak Deviation Value	R	Supr	(NaN); < 0.0, NaN
N	Number of Inputs (CalculTr)	I	PB	(1); 1 – 6
	Number of Inputs (HiloAvg & Summer)	I	PB	(2); 2 – 6
NAME	Tag Name	S	PB	(N/A); A-Z, 0-9
NARRSLOT	Number of Array Points in an HPM	I	PB	(0); 0 – 500
NCTLSLOT	Number of Regulatory Control Points	I	PB	(0); 0 – 250
NDCSLOT	Number of Digital Composite Points	I	PB	(0); 0 – 999
NDEVSLOT	Number of DevCtl. Points Configured	I	PB	(0); 0 – 400
NEIPRQU	No. of Event Initiated Processing Requests	R	View	(0); N/A
NFASTCTL	Number of Fast Reg Control Slots	I	PB	(0); 0 - 200 but < NCTLSLOT
NFASTDC	Number of Fast Digital Composite Slots	I	PB	(0); 0 - 999 but ≤ NDCSLOT
NFASTDEV	Number of Fast DevCtl Points	I	PB	(0); 0 - 200 but < NDEVSLOT
NFASTLOG	Number of Fast Logic Slots	I	PB	(0); 0 - 200 but ≤ NLOGSLOT

NFASTPV	Number of Fast Regulatory PV Slots	I	PB	(0); 0 - 200 but < NPVSLOT
NFLAG	Number of Flags (Box)	I	View	(16,384); 16,384
	Number of Flags (Array)	I	PB	(0); 0 - 512 if EXTDATA = IO_FL, else 0 - 1023 if EXTDATA ≠ IO_FL
NI0 - 2	Inverted Interlocks Value	L	Eng	(On); On, Off
NIMREV	Revision Number of the NIM personality	I	View	(0); N/A
NIMVERS	Version Number of the NIM personality	I	View	(0); N/A
NLFM	Nonlinearity Form	I	Supr	(1); 0 or 1
NLGAIN	Nonlinear Gain	R	Supr	(0.0); 0.0 - 240.0
NLOC	Number of Locations in Delay Table	I	Eng	(30); 2 - 30
NLOGSLOT	Number of Logic Points	I	PB	(0); 0 - 400
NMIN	Minimum Number of Good Inputs	I	PB	(1); 1 to Number Specified in N
NMODATTR	Normal Mode Attribute	e:	Engr	(None); None, Operator, Program, Normal
NMODE	Normal Mode (AnalogOut)	e:	Engr/PB	(None); None, Man, Cas
	Normal Mode (DigComp, DevCtl)	e:	View	(Man); Man
	Normal Mode (RegCtl)	e:	Engr	(None); Man, Auto, Bcas, Cas, None
NMSGTXT	Number of Message Text Items	I	PB	(0); 0 - 15
NN(n)	Numeric Value (ProcModl) (n = 1 - 80)	R	Special	(NaN); N/A
	Numeric Value (Box) (n = 1 - 16,384)	R	Oper	(NaN); N/A
	Numeric Value (Logic Point) (n = 1 - 8)	R	Supr	(NaN); N/A
	Numeric Value (DevCtl Point) (n = 1 - 8)	R	Supr	(NaN); N/A
	Numeric Value (Array Point) (n = i)	R	Special	(N/A); 1 ≤ i ≤ NNUMERIC
NNDESC	NN Array Descriptor	S	PB	(Spaces); N/A

NNINSET(n)	Numeric 1 - 10, n = 1 - 10	I	Supr	(0); 32767
NNSTIX	Numeric Array Start Index	R	PB	(0); 0 - 99,999 if EXTDATA = IO_NN, else 0 - value of NNUMERIC
NNUMERIC	Number of Numerics in HPM Box	I	PB	(0); 0 - 16,384
	Number of Numerics in Array Point	I	PB	(0); 0 - 16 (EXTDATA = IO_NN), else 0 - 240 if EXTDATA ≠ IO_NN
NOCINPTS	Number of Control Input Connections	I	PB	(Special); 0 - 4
NOCOPTS	Number of Control Output Conn.	I	PB	(1); 0 - 4
NOCOPTS (OPSelect)	Number of Control Outputs (PUSH Connections and the order of PUSH/FETCH Connections).	I	PB	(1); 0 to \$NOPCONN
NODEASSN	Node Assignment	e:	Eng	(ThisNIM); ThisNIM, RemotNIM,
NODECMD	Node Command	e:	Eng	(None); None, Run, Idle, Warmstrt, Coldstrt, Pause, and Resume
NODECONF	Node Configuration for the HPM (must always be set to Manual)	e:	View	(Manual); Manual, Auto
NODENUM	Node Number	I	PB	(N/A); 0, 1 - 64
NODEOPER	Node Operating Mode	e:	View	() Primary, Secndry
NODESC	Number of Generic Descriptors	I	PB	(0); 0 - 12
NODESTS	Node Summary Status	e:	View	(N/A); NotConf, PowerOn, OK, Alive, Fail, OffNet, Loading, ConfgMis, Idle, IOldL, Pf_IOldL, Pf_Idle, PartFail, CommFail, NoSynch, Unknown, "S_" = simulation.
NODESTS	NIM Node Summary Status	e:	View	(N/A); Offnet, OK
NODESTAT	Node Status (NIM)	e:	View	(N/A); Offnet, OK
	Node Status (HPM)	e:	View	(N/A); Offnet, OK
NODETYP	UCN Node Type (NIM)	e:	PB	(N/A); NIM,
	UCN Node Type (HPM Box)	e:	PB	(HPM); HPM

	UCN Node Type (HPM Points)	e:	PB	(HPM); HPM
NODFSTAT	UCN Node's Functional Status	e:	Supr	(Basic); Basic, Full
NODINPTS	Number of Digital Input Connections	I	PB	(1); 0, 1, 2
NODOPTS	Number of Digital Output Connections	I	PB	(1); 0, 1, 2, 3
NOGINPTS	Number of General Input Connections	N/A	N/A	(N/A); 0 – 4
NOGOPTS	Number of General Output Connections	N/A	N/A	(N/A); 0 – 4
NOLINPTS	Number of Logic Inputs	I	View	(Logic = 12, DevCtl = 0); 0 – 12
NOLOGBLK	Number of Logic Blocks	I	View	(N/A); 0 – 24
NOLOPTS	Number of Logic Output Connections	I	View	(N/A); Logic = 0 - 12, DevCtl = 0 – 2
NOOVRUN	Number of Overruns	I	View	(0); 0 – 4
NOPGATE	Number of Primary Gates	I	PB	(0); 0 – 4
NOPINPTS	Number of PV Input Connections	I	View	(Special); 0 – 6
NOPTS	Number of Points Per Cycle	I	View	(0); N/A
NORMCYCL	Normal Execution Cycle	I	PB	(); 1- 64
NORQUAVG	Avg. Number Nodes to which UCN Requests are made	R	View	(0) N/A
NORQUMAX	Max. Number Nodes to which UCN Requests are made	R	View	(0) N/A
NORSPAVG	Avg. Number Nodes to which UCN Responses are made	R	View	(0) N/A
NORSPMAX	Max. Number Nodes to which UCN Responses are made	R	View	(0) N/A
NORSSEQ	Number of Ramp/Soak Pairs in the Sequence	I	Eng/PB	(2); 2 – 12
NOSGATE	Number of Secondary Gates	I	PB	(0); 0 – 2
NOSIOVRD	Number of Safety Interlock Overrides	R	View	(0); 0 - No Limit

NOSTATES	Number of Digital States	I	PB	(2); 2 & 3
NOTRAAVG	Avg. Number of Nodes to which UCN Transactions are made	R	View	(0); N/A
NOTRAMAX	Max. Number of Nodes to which UCN Transactions are made	R	View	(0); N/A
NOTRANS(n)	Accumulated Transitions (n = 0 - 2)	R	View	(0); 0 - no limit
NPARAVG	Avg. Number of UCN Parameter Access per Second	R	View	(0); N/A
NPARMAX	Max. Number of UCN Parameter Access per Second	R	View	(0); N/A
NPMSLOT	Number of Process Module Points	I	PB	(0); 0 – 250
NPRQUAVG(n)	Avg. Number of UCN Parameter Requests per Second (n = 0 - 64)	R	View	(0); N/A
NPRQUMAX(n)	Max. Number of UCN Parameter Requests per Second (n = 0 - 64)	R	View	(0); N/A
NPRSPAVG(n)	Avg. Number of UCN Parameter Responses per Second (n = 0 - 64)	R	View	(0); N/A
NPRSPMAX(n)	Max. Number of UCN Parameter Responses per Second (n = 0 - 64)	R	View	(0); N/A
NPVSLLOT	Number of Regulatory PV Slots	I	PB	(20); 0 – 400
NRMATRFL	Normal Mode Attribute Flag	L	View	(On); On, Off
NRMODFL	Normal Mode Flag	L	View	(); On, Off
NSCANITM	Number of Scan Items in HPM Scan Table	I	View	(0); 0 – 50
NSIO	Inverted Interlocks Value	L	Engr	(On); On, Off
NSTRING	Number of Strings in HPM Box Point	I	PB	(0); 0 - 16,384
	Number of Strings in Array Point String Array	I	PB	(0); 0 - 8 if EXTDAT=IO_STR, else 0 - 240 if EXTDATA ≠ IO_STR
NTIME	Number of Times in HPM Box Point	I	PB	(0); 0 – 4096

	No. of Times in Array Point Time Array	I	PB	(0); 0 – 240
NTIMER	Number of Box Timer Points	I	View	(0); 0 – 64
NTRAAVG	Avg. Number of UCN Transactions	R	View	(0); N/A
NTRAMAX	Max. Number of UCN Transactions	R	View	(0); N/A
NTRQUAVG(n)	Avg. No. of UCN Transaction Requests	R	View	(0); N/A. (n = 0 - 64)
NTRQUMAX(n)	Max. No. of UCN Transaction Requests	R	View	(0); N/A. (n = 0 - 64)
NTRSPAVG(n)	Avg. No. of UCN Transaction Responses	R	View	(0); N/A. (n = 0 - 64)
NTRSPMAX(n)	Max. No. of UCN Transaction Responses	R	View	(0); N/A. (n = 0 - 64)
NTWKNUM	Network Number	I	PB	(N/A); 1 – 20
NXTSOAKV	Next Soak Value	R	View	(N/A); (0.0
OFFNRMFL	Off-Normal Alarm Flag	L	View	(Off); Off – On
OFFNRMPR	Off-Normal Alarm Priority	e:	Eng	(NoAction – R670); Emergency, High, Low, JnlPrint, Printer, Journal, NoAction
OFFPULSE	Off-Pulse Command	R	Oper	(N/A); 0.0 - 60.0 seconds
OLDAV	Old Accumulated Value (DigIn)	I	View	(N/A); (0
	Old Accumulated Value (Totalizr)	R	View	(N/A); (0.0
ONPULSE	On Pulse Command	R	Oper	(N/A); 0.0 - 60.0 Seconds
OP	Output in Percent (AnalogOut & RegCtl)	R	Oper	(-6.9% F/scale); -6.9 to 106.9%
	Digital State Output (DigComp, DevCtl)	SDE	Oper	(STATETXT0); STATETXT0, 1, 2 = Descriptor, STATETXT3= NONE
	Pulsed Digital Output (DigOut)	R	Prog	(0.0%); 0 to 100.0%

OPALDB	Output Alarm Dead Band (R510 & later)	R	Eng/PB	(5 Units); 0 - 25 Output Units
OPCHAR	Output Characterization Option	L	PB	(Off); Off – On
OPCMD	Output Command, (DevCtl, DigComp)	L	Prog	(Off); Off, On
	Output Command	e:	View	(N/A); Raise, Idle, Lower
OPEU	Output Value in Engineering Units	R	View	(N/A); N/A
OPFINAL	Final OP in % Sent to Control Element (Analog Output) (DevCtl, DigComp)	R SDE	View Oper	(-6.9%); N/A (Statetxt(0); Statetxt (0, 1, 2), None
OPHAFL	Output High Alarm Flag (R510 & >)	L	View	(Off); Off – On
OPHIFL	Output High Limit Flag	L	Prog	(Off); Off – On
OPHILM	Output High Limit in Percent	R	Supr	(105%); OPLOLM - 106.9%, NaN
OPHIPR	Output High Alarm Priority (R510 & >)	e:	Eng/PB	(NoAction – R670); Emergency, High, Low, JnlPrint, Printer, Journal, NoAction
OPHISRC	Output High Flag Input Source	U	PB	(Null); See Full PRD
OPHITP	Output High Alarm Trip Point (R510 & >)	R	Supr	(NaN); NaN, OPLOTP – OPHILM
OPIN0	Input Coordinate Number 0 in Percent	R	View	(-6.9%); N/A
OPIN1-4	Input Coordinates Number 1-4 in %	R	Supr	(N/A); (Prev. Coordinate but ≤ Next Coordinate
OPIN5	Input Coordinate Number 5 in %	R	View	(106.9%); N/A
OPLAFL	Output Low Alarm Flag (R510 & >)	L	View	(Off); Off – On
OPLOFL	Output Low Limit Flag	L	Prog	(Off); Off – On
OPLOLM	Output Low Limit in %	R	Supr	(-5.0%); -6.9% to OPHILM, NaN

OPLOPR	Output Low Alarm Priority (R510 & >)	e:	Eng/PB	(NoAction – R670); Emergency, High, Low, JnlPrint, Printer, Journal, NoAction
OPLOSRC	Output Low Flag Input Source	U	Null	(PB); See XPM PRD
OPLOTP	Output Low Alarm Trip Point (R510 & >)	R	Supr	(NaN); NaN, OPLOLM – OPHITP
OPMCHLM	Output Minimum Change Limit in %	R	Supr	(0.0); < 0.0, NaN
OPOUT0	Output Coordinate Number 0 in %	R	View	(-6.9%); N/A
OPOUT1-4	Output Coordinates Number 1-4 in %	R	Supr	(N/A); < Previous Coordinate but ≤ Next Coordinate
OPOUT5	Output Coordinate Number 5 in %	R	View	(106.9%); N/A
OPRATRFL	Operator Mode Attribute Flag	L	View	(N/A); Off – On
OPRINPUT	Last Operator Input per sequence message	R	Oper	(0.0); N/A
OPROCLM	OP Rate of Change Limit in %	R	Supr	(NaN); < 0.1, NaN
OPTDIR	Direct/Reverse Action	e:	Eng/PB	(Direct); Direct, Reverse
OROFFSET	Override Offset	L	Eng/PB	(On); Off – On
OROPT	Override Option	L	Eng/PB	(Off); Off – On
OUT0-12	Output Coordinates Number 0-12	R	Supr	(NaN); Anything but NaN
OUTIND	Direct/Reverse Action (R620 & later)	e:	Eng/PB	(Direct); Direct, Reverse
OVERFLOW	Accumulation Overflow Flag	L	View	(Off); Off – On
OVERLAP	Overlapping Array Slot Number	I	View	(0); 0 - Value of NARRSLOT
OVERPHAS	Override Current Phase	e:	Special	(Blank); Forward – Backward
OVERSTAT	Override Current Statement	e:	Special	(Blank); Forward – Backward
OVERSTEP	Override Current Step	e:	Special	(Blank); Forward – Backward
OVERVAL	Overview Value in Percent	I	Eng/PB	(25%); 0 - 100%
OVRCTIM	Time Over High Trip Limit	T	View	(0); 0 - 9999 days
OVRDALOP	Override Alarm Option	e:	Eng/PB	(None); None, Auto Rtn, Cnfm Rqd

OVRDALPR	Override Alarm Priority	e:	Eng	(NoAction – R670); JnlPrint, Printer, Emergency, High, Low, Journal, NoAction
OVRDCONF	Override Confirmation Flag	L	Oper	(Off); Off – On
OVRDESC	Override Alarm Descriptor	S	View	(Blank); SIO Desc, IO-I2 Desc, L1-L12 Desc
OVRDInFL	Override Alarm Flag (n = 0 - 2)	L	View	(Off); Off – On
OVRDSIFL	Safety Override Alarm Flag	L	View	(Off); Off – On
P	Pressure Input	R	View	(1.0); < 0.0
P0	Zero Reference for Pressure	R	Supr	(0.0); N/A, NaN
P0 - P2	Permissive Interlocks for Output State 0, 1, and 2	L	Engr	(On); Off – On
P1 - P6	PV Inputs 1-6 (RegPV)	R	View	(NaN); N/A
PnSTS	P1-P6 Status (n = 1 - 6)	e:	View	(Bad); Bad, Uncertn, Normal
PAUSETIM	State 0 Pause Time	I	Supr	(0); 0 – 1000
PERIOD	Period (ProcMod)	R	PB	(1.0); .0625 - 4.0 Seconds
	Period (DigOut)	R	Eng/PB	(10.0); 1.0 - 120.0 Seconds
	Period (RegPV, RegCtl)	R	View	(0.5); 0625 - 4.0 Seconds
	Period (Logic, DigComp, DevCtl)	R	PB	(0.25); 0625 - 4.0 Seconds
PFDLYFL	PreFetch Delayed Flag	R	View	(Off); Off – On
PGALGID(n)	Primary Gate Algorithm ID (n=1 - 4)	e:	PB	(NULL); NULL, AND, OR, NAND, NOR, XOR, PAND, POR, PNAND, PNOR, PXOR
PGDSTN(n)	Primary Gate Destination (n=1 - 4)	e:	PB	(NONE); NONE, SIO, IO, I1, I2, P0, P1, P2, SOCMD0, SOCMD1, SOCMD2, OPCMD, SG1, SG2
PGPLSWTHn	Primary Gate Pulse Width (n =1 - 4)	I	Supr	(0); 0 - 8000 seconds
PGSO(n)	Primary Gate Status Output (n =1 - 4)	L	View	(Off); On – Off
PHASE	Phase Name	S	View	(Spaces); N/A

PHASEAL	Phase Alarm	L	View	(Off); On – Off
PHASETIM	Phase Time	I	View	(0); 0 - 9999 Minutes
PHREMTIM	Phase Time Remaining	T	View	(0); N/A
PIALGID(n)	Primary Input Gate Algorithm ID (n=1 - 12)	e:	PB	(Null); Null, Invert, GT, GE, LT, LE, EQ, NE, GT2, GE2, LT2, LE2, EQ2, NE2, IN_SET
PIDEADB(n)	Primary Input Gate Deadband (n=1 - 12)	R	Supr	(1.0); > 0
PIDFORM	PID Controller Form	e:	Eng/PB	(Interact); Interact, Ideal
PIDSTN(n)	PV Input Connection Destination (n = 1 - 6)	P	View	(Varies by Algo Type, Equation, N); 1-8 Character Valid Parameter Name
PINN1-12	Primary Input Constants Numeric	R	Supr	(0.0); <> NaN
PISO1-12	Primary Input Gate Output Value	L	View	(Off); Off, On
PISRC(n)	PV Input Connection Source (n = 1 - 6)	E	PB	(Null.Null); "TagName.Parameter"
PISRC(n) (Continued)	Primary Input Source (DevCtl) (n = 1 - 12)	e:	PB	(Null); Null, L1 - L12
PIUOTDCF	Open Thermocouple Detection Enable (STI, LLMUX)	L	Eng/View	(On); On – Off
PIUOTDCF(n)	Open Thermocouple Detection Enable (LLAI) (n = 1 - 168)	L	Supr	(On); On – Off
PKGOPT	HPMM Hardware Packaging Option	e:	PB	(Redun_2F); Redun, Redun_2F Redun_IO, Nodefault
PMEVOVFL	HPMM Event Overflow Flag	L	View	(); Off, On
PMMCHAER	HPMM's I/O Link Chnl A Error Count	I	View	(0); < 0
PMMCHASL	HPMM's I/O Link Chnl A Silence Count	I	View	(0); < 0
PMMCHBER	HPMM's I/O Link Chnl B Error Count	I	View	(0); < 0

PMMCHBSL	HPMM's I/O Link Chnl B Silence Count	I	View	{0}; { 0
PMMCMD	HPMM Command	e:	OnProc	(None); None, Run, Idle, ShutDown, SwapPri, Coldstrt, SelChnA, SelChnB, Warmstrt, RsUCNLSb, RslolCom
PMMCOMER	HPMM's I/O Link Communication Error Status	e:	View	(N/A); InvAlert, InvDest, InvSource, InvChCnt, InvCmd, Checksum, No_Resp, ChTimOut, MsgOvRun, GapError, LpBckErr, NTH_0 TknRecov, RplBufOv, None
PMMCTLST	HPMM Control Processor Status	L	View	(Off); Off, On
PMMIOLST	I/O Link Status	e:	View	(); Notconfg, Confgmis,OK, Idle, Softfail, Idlest, Nonexist, Noresp, Poweron, Commerr, Unavail
PMMOPER	HPMM Operation	e:	View	(N/A); NonRedun, Primary, Secondary
PMMRECCH	HPMM's I/O Link Current Receive Channel	e:	View	(N/A); ChannelA, ChannelB
PMMRECHN	HPMM Active Receive Channel	e:	View	(N/A); ChannelA, ChannelB
PMMSTS	HPMM Primary Status	e:	View	(N/A); Offnet, Alive, OK, Idle,IdleSF, Fail, Loading, ConfgMis, AliveSF, SoftFail, Test, TestSF, S_Idle, S_Idle SF, S_OK, S_SFFail, S_Pause (S=Simulation)
PNTFORM	Point Form	e:	PB/View	(Full); Full, Componnt
PNTMODTY	Point's IOP Type	e:	View	(NotConf) HLAI, LLAI, STIM, DISOE, AO, AO_16, DI, DO, DO_32, PI, LLMUX, NotConfg, SI, HPMM, SI, FBUS
PNTNODTY	Point's Node Type	e:	View	(N/A); NIM, HPM, NotConfg
PNTSTATE	Point's Overall State	e:	View	(N/A); OK, Failed, Idle, Uncertn

PNTTYPE	Point Type	e:	PB	(Null); AnalIn, AnalOut, DigCom, DigIn, DigOut, ProcModl, RegPV, RegCtl, Logic, Null, DevCtl, Timer, ProcModl
POSITION	HPMM File Position	e:	View	(N/A); Left, Right, File_1, File_2, Pref, Non_Pref, None, Unknown
PR2PREFF	Peer-To-Peer Comm Efficiency %	R	View	(100); 0 – 100
PRGATRFL	Program Mode Attribute Flag	L	View	(N/A); On – Off
PRIMMOD	Primary Module Identifier	E	Eng	(Null); A-Z, 0-9, _
PRMDESC	Parameter Descriptor Assignmnt.	e:	Eng/PB	(N/A); L1-12, FL1-12, NN1-4, SO1-16
PROCMOD	Process Module Operating State	e:	Special	(Off); Off, Norm, Hold, Shdn, Emsd, Strt, Stop
PSDLYFL	Poststore Delayed Flag	L	View	(Off); On – Off
PSTS	Pressure Input Value Status	e:	View	(Normal); Normal, Uncertrn, Bad
PTDESC	Point Descriptor	S	PB	(Blank); A-Z 0-9 Space ! %& ' () + - / : ; > < = ? _ , . \$
PTEXECST	Point Execution State	e:	Supr	(Inactive); Inactive, Active
PTINAL	Point in Alarm Indicator	L	View	(Off); Off – On
PTORST	Point Override Status	e:	Prog	(NotCon); NotCon, Sel, NotSel
PTSTSIOL	Redundant Partner Status as seen from the IOL	e:	View	(); OffNet, ConfigMis, Idle, Idlesf, Ok, Fail, SoftFail, Powron, Alive, Alivesf, TestSF, Test, Loading, Notconfig, Nosynch, Unavail
PTSTSUCN	Redundant Partner Status as seen from the UCN	e:	View	(); Offnet, Configms, Idle, Idlesf, Ok, Softfail, Fail, Poweron, Alive, Alivesf, Loading, Notconfig, Nosynch, Unavail
PULSEWTH	Pulse Width for Point Outputs	R	Supr	(1.0); 0.0 - 60.0 Seconds

PV	Process Variable (AnalogIn, PI)	R	Oper	(NaN); PVEXEUHI - PVEXEULO, NaN
	Current State (DigComp, DevCtl)	e:	Oper	(BADPVTXT); PVSTATES(0)-(4)
	Current State (DigIn)	e:	Oper	(Off); STATETXT(0) or STATETXT(1)
	Current State (Flag)	e:	Oper	(Blank); STATETXT(0) or STATETXT(1)
	Process Variable (Numeric)	R	Oper	(NaN); N/A
	Process Variable (RegCtl)	R	View	(NaN); N/A
	Process Variable (RegPV)	R	Oper	(NaN); N/A
	Current Value (Timer)	I	View	(0); 0 to 32000 Seconds or Minutes
PVALDB	PV Alarm Deadband in Percent	e:	Eng/PB	(one); Half, One, Two, Three, Four, Five, EU
PVALDBEU	EU Value of Alarm Deadband	R	Eng/PB	(NaN); ≥ 0
PVALGID	PV Algorithm Identifier	e:	PB	(Null); DataAcq, FlowComp, MidOf3, HiLoAvg, Summer, VdtLdLag, TotalLiz, GenLin, CalcuLtr, Null
PVAUTO	PV Auto Value (AnalogIn, PI)	R	View	(NaN); N/A
	Current PV State (DigComp, DevCtl)	e:	View	(BADPVTXT); STATETXT(0), (1), (2), MOVPVTXT, BADPVTXT
	Current PV State (DigIn)	e:	View	(N/A); STATETXT(0) or STATETXT(1)
	PV Value Fetched Using Control Input Connection (RegCtl)	R	View	(NaN); N/A
	PV Auto Value (RegPV)	R	View	(NaN); N/A
	PV Auto Value (PosProp, PIDPosPr)	R	View	(NaN); N/A
PVAUTOST	PV Auto Value Status	e:	View	(Bad); Bad, Normal, Uncertain
PVCALC	Calculated PV (AnalogIn)	R	View	(NaN); PVEXEUHI - PVEXEULO
	Calculated PV (RegPV)	R	View	(NaN); N/A, NaN

PVCHAR	PV Characterization Option	e:	PB	(Linear); Sqroot, Btherm, Ethern, Jtherm, Ktherm, Rtherm, Stherm, Ttherm, Ntherm, RPherm, DinRtd, NickLRtd, CopprRtd, NiNiMOTC, Linear, JisRtd, Pt100DinRtd, Pt100JisRtd, Pt200Rtd, Pt500Rtd, CU10Rtd, CU25Rtd, W3W25TC, W5W26TC, RHRAD, RTD_Ohms
PVCHGDLY	PV Change Delay time in Seconds	I	Supr	(0); 0 – 60
PVCLAMP	PV Clamping Option	e:	Eng/PB	(NoClamp); Clamp, NoClamp
PVEQN	PV Equation Type (FlowComp)	e:	Eng/PB	(EqA); EqA – EqE
	PV Equation Type (HiLoAvg, MidOf3)	e:	Eng/PB	(EqA); EqA – EqC
	PV Equation Type (Summer)	e:	PB	(EqA); EqA & EqB
	PV Equation Type (Totalizr)	e:	Eng/PB	(EqA); EqA – EqF
	PV Equation Type (VdtLdLag)	e:	Eng/PB	(EqA); EqA – EqD
PVEUHI	PV High Range in Engineering Units	R	Eng	(100); PVEULO - PVEXEUHI
PVEULO	PV Low Range in Engineering Units	R	Eng	(0); PVEXEULO - PVEUHI
PVEXEUHI	PV Extended Hi Range in Engineering Units	R	Eng	(102.9); (PVEUHI
PVEXEULO	PV Extended Lo Range in Engineering Units	R	Eng	(-2.9); ≤ PVEULO
PVEXHIFL	PV Extended Hi Range Violation	L	View	(Off); Off – On
PVEXLOFL	PV Extended Lo Range Violation	L	View	(Off); Off – On
PVFL(n)	PV Flag (DigComp) (n = 0 - 2)	L	View	(Off); Off, On
PVFL	PV Flag (DigIn, Flag)	L	Oper	(Off); Off, On
PVFORMAT	PV Decimal Point Format	e:	Eng	(D1 = XXX.X); D0, D1 D2, D3
PVHHFL	PV High High Alarm Flag	L	View	(Off); Off – On

PVHHPR	PV High High Alarm Priority	e:	Eng	(NoAction – R670); JnlPrint, Printer, Emergency, High, Low, Journal, NoAction
PVHHTP	PV Hi Hi Alarm Trip Point (AnalogIn, RegPV)	R	Supr	(NaN); PVHITP - PVEXEUHI, NaN
	PV Hi Hi Alarm Trip Point (RegCtl PosProp, PIDPosPr)	R	Supr	(NaN); PVHITP - PVEUHI, NaN
PVHIFL	PV High Alarm Flag	L	View	(Off); Off – On
PVHIPR	PV High Alarm Priority	e:	Eng	(NoAction – R670); JnlPrint, Printer, Emergency, High, Low, Journal, NoAction
PVHITP	PV High Alarm Trip Point	R	Supr	(NaN); PVLOTP - PVHHTP, NaN
PVINIT	PV Initialization Request Flag	L	Prog	(Off); Off – On
PVLLFL	PV Low Low Alarm Flag	L	View	(Off); Off – On
PVLLPR	PV Low Low Alarm Priority	e:	Eng	(NoAction – R670); JnlPrint, Printer, Emergency, High, Low, Journal, NoAction
PVLLTP	PV Low Low Alarm Trip Point (AnalogIn, RegPV)	R	Supr	(NaN); PVEXEULO - PVLOTP, NaN
	PV Low Low Alarm Trip Point (RegCtl, PIDPosPr, PosProp)	R	Supr	(NaN); PVEULO - PVLOTP, NaN
PVLOFL	PV Low Alarm Flag	L	View	(Off); Off – On
PVLOPR	PV Low Alarm Priority	e:	Eng/PB	(NoAction – R670); JnlPrint, Printer, Emergency, Low, High, Journal, NoAction
PVLOTP	PV Low Alarm Trip Point	R	Supr	(NaN); PVLLTP - PVHITP, NaN
PVNORMAL	PV Normal State	e:	Supr	(N/A); STATETXT(0) - STATETXT(2), None (requires lock = Engr)
PVNORMFL	PV Value's Normal State Flag	L	View	(Off); Off – On

PVP	PV in Percent	R	View	(NaN); N/A
PVRAW	PV Raw Value (AnalogIn)	R	Oper	(NaN); N/A
	PV Raw Value (PI, STI)	R	View	(NaN); N/A
	Raw State of Field Contacts (DigIn)	L	View	(Off); Off-On
PVRAWHI	PV Raw High Range	R	Eng/PB	(NaN); PVRAWLO to 100 (for a 0_100_mV Input), PVRAWLO to 1 [for a Slidewire Input (ratio)]
PVRAWLO	PV Raw Low Range	R	Eng/PB	(NaN); 0.0 - PVRAWHI (0 to 100 Microvolts for a 0_100_mV Input, or 0 to 1 Ratio for a Slidewire Input)
PVROCFL	PV Negative Rate-of-Change Alarm Flag	L	View	(Off); Off – On
PVROCNP	PV Negative Rate-of-Change Alarm Priority	e:	Eng	(NoAction – R670); JnlPrint, Printer, Emergency, Low, High, Journal, NoAction
PVROCNP	PV Negative Rate-of-Change Trip Point	R	Supr	(NaN); ≥ 0.0, NaN
PVROCPL	PV Positive Rate-of-Change Alarm Flag	L	View	(Off); Off – On
PVROCPR	PV Positive Rate-of-Change Alarm Priority	e:	Eng	(NoAction – R670); JnlPrint, Printer, Emergency, Low, High, Journal, NoAction
PVROCPT	PV Positive Rate-of-Change Trip Point	R	Supr	(NaN); ≥ 0.0, NaN
PVSGCHTP	PV Significant Change Alarm Trip Point	R	Supr	(NaN); ≥ 0.0, NaN
PVSOURCE	PV Source	e:	Oper	(Auto); Auto, Man, Sub,Track
PVSRCOPT	PV Source Option	e:	Eng/PB	(OnlyAuto); All, OnlyAuto

PVSTATES(n)	PV State Descriptors (n = 0 - 4)	S	View	(N/A); N/A
PVSTS	Status of PV Input Value	e:	View	(Bad); Bad, Normal, Uncertn
PVTEMP	PV Temperature Scale	e:	PB	Degrees(C); C, F, R, K
PVTRACK	PV Tracking Option	e:	Eng/PB	(NoTrack); Track, NoTrack
PVTV	PV Target Value in Engineering Units	R	Oper	(NaN); PVEXEULO - PVEXEUHI, NaN
PVTVP	PV Target Value in Percent	R	View	(NaN); ≥ 0.0, NaN
PVTXTOPT	PV Text Option	L	PB	(Off); Off, On
Q	Steam Quality Factor Input	R	View	(1.0); ≥ 0.0, NaN
QSTS	Q Input Value Status	e:	View	(Normal); Normal, Uncertn, Bad
R1(n)-R2(n)	Real Input Number 1 - 2 (n = 1 - 24)	e:	PB	(L1); L1 - L12 & NN1 - NN8
RAISDSTN	Raise Output Pulse Destination	U	PB	(Null); ONPULSE – OFFPULSE
RAISTIM	Raise Output Pulse Time	R	View	(N/A); N/A, NaN
RAISRATE	Raise OP Stroke Rate in %/Sec	R	Supr	(100.0); > 0.0
RAMPTIME	Ramp Time in Minutes	R	Oper	(0.0); ≥ 0.0
RARWSTS	Remote Anti-Reset Windup Status	e:	View	(Normal); Normal, Hi, Lo, HiLo
RATE1	Rate at Which Bias Ramps Down (AutoMan)	R	Supr	(0.0); ≥ 0.0, NaN
	Rate at Which Bias Ramps Down (RatioCtl)	R	Supr	(NaN); ≥ 0.0, NaN
RATE1-12	Ramp Rates for RampSoak Segments 1-12 (RampSoak)	R	Supr	(NaN); N/A
RATIO	Ratio	R	Oper	(1.0); RTL0LM – RTHILM
RBOPT	Ratio Bias Option	e:	Eng/PB	(NoRatBi); NoRatBi, FixRatBi, AutoRat, AutoBi
RCASOPT	Remote Cascade Option (AnalgOut)	e:	Eng/PB	(None); None, Ddc
	Remote Cascade Option (RegCtl)	e:	Eng/PB	(None); None, Spc, Ddc, DdcRsp, Rsp
RCASSHED	Remote Cascade Shed	L	View	(Off); Off – On
REDTAG	Red Tag State	e:	Supr	(Off); Off – On
REMSOAKT	Remaining Soak Time	R	Oper	(0.0); 0.0 - 720.0 Minutes

RESETFL	Reset Flag (DigIn, Totalizr)	L	Prog	(Off); Off – On
	Reset Flag (DevCtl, DigComp)	L	Oper	(Off); Off – On
RESETVAL	Accumulator Reset Value (DigIn)	I	Oper	(0); 0 – 32767
	Reset Value (Totalizr)	R	Oper	(0.0); N/A
RESTART	Process Module Restart State	e:	View	(None); None, Failover, Warm, Cold, PTACTVN
RFB	Reset Feedback Input in %	R	View	(N/A); $\geq 0.0\%$
RG	Reference Specific Gravity	R	Supr	(1.0); N/A
RINITREQ	Remote Initialization Request (PosProp, PIDPosPr)	L	View	(On); Off – On
RINITVAL	Remote Initialization Value	R	View	(NaN); N/A, NaN
RJRAW	Reference Junction's Raw Count in μ Volts	R	View	(NaN); N/A
RJTEMP	Reference Junction's Temperature	R	View	(); N/A
RP	Minimum Pulse Ratio (PosProp)	R	Supr	(1.0); 0.01 – 100
	Reference Pressure (Flowcomp)	R	Supr	(1.0); N/A
RQ	Reference Steam Quality Factor	R	Supr	(1.0); N/A
RSPBGP\$\$	Ramp/Soak Percent Bar Graph Parameter	R	View	(N/A); ≥ 0
RSTROPT	Restart Option	e:	Eng	(Off); Off, Restart, Stop
RT	Dead Time Ratio (PosProp)	R	Supr	(1.0); 0.01 - 100.0
	Reference Temperature (Flowcomp)	R	Supr	(1.0); N/A
RTHILM	Ratio High Limit	R	Supr	(100); RTLOLM - 100, NaN
RTLOLM	Ratio Low Limit	R	Supr	(0.0001); 0.0001 - RTHILM, NaN
RUNSTATE	Run State	L	View	(Off); Off, On
RV	Remaining Time	I	View	(0); >0
RX	Reference Steam Compressibility	R	Supr	(1.0); anything but NaN

S0BOXCLR S1BOXCLR S2BOXCLR	State Box Color	e:	View	(N/A); Red, Green, White, Black, Cyan, Yellow, Blue, Magenta
S1	Tracking Switch (PidErfb)	L	Prog	(Off); On – Off
	Transmitter Status (STI)	S	View	(Blank); Blank, N/A
S1, S2	Mark 1 and Mark 2 Flags (RampSoak)	L	View	(Off); On – Off
S1 through S4 (OPSelect)	Output Select Flags 1 – 4	L	Oper	(S1=ON, S2 to S4=OFF); OFF, ON
S1(n)-S4(n)	Status Inputs 1-4 (Logic) (n = 1 - 24)	e:	PB	(L1); L1 - L12, FL1 - FL12, SO1 - SO24
	Select X1-X4 Request Flag (Switch)	L	Oper	(On); Off – On
S1BGNTIM, S2BGNTIM	Mark 1 and Mark 2 Begin Times	R	Supr	(0.0); 0 - 120 Minutes
S1ENDTIM, S2ENDTIM	Mark 1 and Mark 2 End Times	R	Supr	(0.0); 0 - 120 Minutes
S1REV(n) - S3REV(n)	S1, S2, S3 Inputs Reversed (n = 1 - 24)	L	PB	(Off); On – Off
S1SEGID, S2SEGID	Mark 1 and Mark 2 Segment Identifiers	e:	Supr	(Ramp1); Ramp1 - Ramp12,
SAFEOP	Safe Operation for Safety Shutdown	R	Engr	Soak1 - Soak12
SAFEOPCMD	Safe Operation Command	e:	Engr	(N/A); -6.9 - 106.9%, NaN
SCANPER	SI Data Scan Period	R	PB	(Idle); Idle, Raise, Lower
SCANPRI	SI Data FTA Scan Priority	e:	PB	(1.0); .25, .5, 1.0 seconds
SCANRATE	Scan Rate	e:	PB	(Low); Low, High (Reg1Log1); Reg1Log1, Reg1Log2, Reg1Log4, Reg2Log2, Reg2Log4, Reg4Log4, Null
SEALOPT	Seal in Circuit Option	e:	Eng/PB	(None); None, Sealin
SECOND	Current Second	I	View	(N/A); 0 – 59

SECSYNC	Secondary Synchronization Status	e:	View	(); Synched, NoSynch
SECVAR	Secondary Variable	R	View	(NaN); N/A, NaN
	Secondary Variable (DevCtl)	R	View	(0.0); Real numbers including NaN
SEGTOT	Total Number of Segments	I	Supr	(1); 1- 12
SEGTYPE	Segment Type	e:	View	(N/A); Ramp, Soak
SELINP	Selected Input (HiLoAvg)	e:	View	(SelectP1); SelectP1 - SelectP6
	Selected Input (MidOf3)	e:	View	(SelectP1); SelectP1 - SelectP3
SELXINP	Selected X Input (ORSel)	e:	View	(SelectX1); SelectX1 - SelectX4
	Selected X Input (Switch)	e:	Oper	(SelectX1); SelectX1 - SelectX4
SENSRYTP	Sensor Type (HLAI & LLAI)	e:	PB	(1_5_V); 1_5_V, 0_5_V, P4_2_V, 5_V 0_100_mV, Thermcpl, RTD, Slidwire
	Sensor Type (LLMUX)	e:	PB	(0_100_mV); 0_100_mV, Thermcpl, RTD
	Sensor Type (STI)	e:	PB	(Spt_Dp); Spt_Dp, Spt_Gp, Spt_Ap, Spt_Sfm
SEQERR	Sequence Error	I	View	(0); 0 - 255, as Follows: 0 - No Error 1-100 - Not Used Error Codes 101 - Not Used 102 - Array Index Error 103 - Illegal IMD Code 104 - Illegal Variable/Operator Code 105 - Interpreter Stack Overflow 106 - GOTO Destination Error 107 - Key Level Error 108 - Configuration Mismatch Error 109 - I/O Link Prefetch Overflow 110 - Subroutine Nesting Level Error 111 - Illegal Value Error

SEQERR	Sequence Error	I	View	112 - Fail Statement 113 - (IOL - Prefetch buffer full) 114 - (IOL - Poststore buffer full) 115 - (UCN - Prefetch buffer full) 116 - (UCN - Poststore buffer full) 117-164 - Not Used 165 - Sequence Halted by Operator 166 - Sequence Jumped to an Abnormal Condition Handler That was Not Enabled 167 - Not Used Failure Codes 168 - Timeout Condition on WAIT Statement 169 - Attempt was Made to Start a Sequence that was Not Loaded 170 - Communication Error in READ/WRITE Statement 171 - Communication Error During I/O Link Access; also generated for all Post-Store problems 172 - Range Error 173 - Attempt was Made to Write to a Point That was Not in the Proper Mode 174 - Interlock Error 175-255 - Not Used
SEQEXEC	Sequence Execution State	e:	View	(NL); NL, DLL, Loaded, Run, Pause, Error, Fail, End
SEQMODE	Sequence Execution Mode	e:	Special	(Auto); Auto, SemiAuto, SnglStep
SEQNAME	Sequence Name	S	View	(Blank); N/A

SEQOBSZ	Sequence Prog. Size	I	View	(0); >0
SEQPR	Sequence Priority	e:	Eng	(NoAction – R670); JnlPrint, Printer, Emergency, Low, High, Journal, NoAction
SEQPRGSZ	Sequence Prog. Size	I	View	(N/A); N/A
SEQPROC	Sequence Processing	e:	PB	(1_PU); 1_PU, 2_PU
SEQSLTSZ	Sequence Slot Size	I	PB	(0); ≥0
SERIALNO	Serial No./PROM Number of the Smart Transmitter	S	View	(0); ≥0 (Blank); N/A
SGALGID(n)	Secondary Gate ID (n = 1 - 2)	e:	PB	(None); Null, AND, OR, NAND, NOR, XOR, PAND, POR, PNAND, PNOR, PXOR
SGDSTN(n)	Secondary Gate Destination (n = 1 - 2)	e:	PB	(None); None, SIO, IO, I1, I2, P0, P1, P2, SOCMD0-2, OPCMD
SGPLSWTH(n)	Pulse Width for Secondary Gate (n = 1 - 2)	I	Supr	(0); 0-8000
SGSO(n)	Status Output for Secondary Gates (n = 1 - 2)	L	View	(Off); Off, On
SHEDMODE	Shed Mode (RegCtl)	e:	Eng	(Man); Man, Bcas, Auto
SHEDTIME	Remote Cascade Shed Time	I	Eng/PB	(0); 0 - 1000 Seconds
SHUTDOWN	Shutdown Command Flag	L	Prog	(Off); Off – On
SIO	Safety Override Interlock Flag	L	Eng	(Off); Off – On
SIOALOPT	Safety Override Alarm	e:	Eng/PB	(None); None, Auto_Rtn, Cnfm_Rqd
SIOALPR	Safety Override Alarm Priority	e:	Eng	(NoAction – R670); JnlPrint, Printer, Emergency, High, Low, Journal, NoAction

SIALGID(n)	Secondary Input Gate Algorithm ID (n = 1 - 12)	e:	PB	(Null); Null, Dly, Ondly, Offdly, Pulse, Maxpulse, Minpulse
SIDLYTIM(n)	Secondary Input Gate Delay/Pulse Width (n = 1 - 12)	l	Supr	(0); 0-8000
SIDSTN(n)	Secondary Input Gate Destination	e:	PB	(None); SIO, I0-I2, P0-P2, SOCMD0-2, OPCMD, SG1-SG2, PG1-PG4
SIM_TXT	Simulation Indicator	S	View	(N/A); N/A
SI0CONF	Safety Override Interlock Alarm Confirmation flag	L	Oper	(Off); N/A
SISO(n)	Status Output for Secondary Input Gate (n = 1 - 12)	L	View	(Off); Off, On

SLOTNUM	Slot Number	I	PB	(N/A); HLA and STI = 1 - 16 LLAI = 1 - 8 AnalogOut = 1 - 8 or 1 - 16 Array = 1 - 500 but ≤ NARSLOT Box Numeric = 1 - 2047 Box Timer = 1 - 64 but ≤ NTIMER DevCtl = 1 - 400 but ≤ NDEVSLT DigComp = 1 - 999 but ≤ NDCSLOT DigIn = 1 - 32 DigOut = 1 - 16 or 1 - 32 Logic = 1 - 400 but ≤ NLOGSLOT ProcMod = 1 - 250 but ≤ NPMSLOT Box Timer 1 - 64 (N/A); RegCtl = 1 - 250 but ≤ NCTLSLOT RegPV = 1 - 400 but ≤ NPVSLOT Box Flag = 1 - 2047 LLMUX = 1 - 32 PI = 1 - 8
SLWSRCID	Slidewire Voltage Source Identifier	I	Eng/PB	(1); 1 - 16
SNAME(n)	Subroutine Name (ProcMod) (n = 1-2)	S	View	(spaces); N/A
SO	Status Output (Digout)	L	Oper	(Off); Off - On
	Status Output (Timer)	L	View	(Off); Off - On
SO1 - SO24	Logic Block Status Output	L	View	(Off); On - Off
SO(I)	Status Output Array DevCtl, DigComp (I = State)	L	View	(Off); On - Off
SOAKT1-12	Soak Time for Soak Segments 1-12	R	Supr	(0.0); 0.0 - 120.0 Minutes
SOAKV1-12	Soak Value for Soak Segments 1-12	R	Supr	(NaN); N/A

SOCMD(I)	Digital Composite Output Status Command (I = State)	L	Prog	(Off); Off – On
SP	Setpoint of the PV in Engineering Units (RegCt)	R	Oper	(0.0); SPLOLM-SPHILM
	Preset Time (Timer)	I	Oper	(0); 0 – 32000
SPEUHI	Setpoint Engineering Unit Range High	R	View	(N/A); ≥ SPEULO
SPEULO	Setpoint Engineering Unit Range Low	R	View	(N/A); ≤ SPEUHI
SPFORMAT	Setpoint Decimal Point Format	e:	View	(N/A); D0, D1, D2, D3
SPHIFL	Setpoint High Limit Violation Flag	L	View	(Off); Off – On
SPHILM	Setpoint High Limit	R	Supr	(NaN); SPLOLM - SPEUHI, NaN
SPLOCK	Setpoint Lock	e:	Eng	(Operator); Operator, Supervis, Engineer, Program
SPLOFL	Setpoint Low Limit Violation Flag	L	View	(Off); Off – On
SPLOLM	Setpoint Low Limit	R	Supr	(NaN); SPEULO - SPHILM, NaN
SPOPT	Setpoint Option	e:	Eng/PB	(None); None, TV, Asp
SPP	Setpoint In Percent	R	View	(N/A); N/A
SPTV	Setpoint Target Value in Engineering Units	R	Oper	(N/A); SPLOLM - SPHILM, NaN
SPTVP	Set Point Target Value in %	R	View	(N/A); ≥ 0.0%
SRQUTAVG	Avg. UCN Store Request Trip Time	R	View	(NaN); N/A
SRQUTMAX	Max. UCN Store Request Trip Time	R	View	(NaN); N/A
SRSPTAVG	Avg. UCN Store Resp. Trip Time	R	View	(NaN); N/A
SRSPTMAX	Max. UCN Store Resp. Trip Time	R	View	(NaN); N/A
SSTEP(n)	Subroutine Step Name (n = 1 - 2)	S	View	(Blank); N/A
SSTMT(n)	Subroutine Statement Number (n = 1 - 2)	I	View	(Blank); 0 – 255

ST0_OP1 through ST2_OP3	State 0 - Output 1 Through State 2 - Output 3	L	Eng/PB	(Off); Off – On
STARTFL	Start Command Flag	L	Prog	(Off); Off – On
STATE	Timer State (Timer, DigIn, Totalizr)	e:	View	(Stopped); Stopped, Running
	Current State (STI)	e:	View	(N/A); Loading, Loadcomp, Loadfail, Calib, Calcomp, Calfail, OK, DBChange
STATE0 through STATE2	Current State	S	View	(On, Off, State2); N/A
STATETXT(n)	State Descriptor 0 - 3 Text	S	PB	STATETXT(0) = Off, STATETXT(1) = On, STATETXT(2) = STATE2 text/\$Null STATETXT(3) = None
STATEMENT	Statement	I	View	(0); 1 – 255
STATTIMn	State Time (n = 0 - 2)	T	View	(0); 0 - 4000 days
STCHGOPT	State Change Option	e:	Eng/PB	(None); None, STATE0
STDBYMAN	Standby Manual Flag	L	View	(Off); Off – On
STDBYSTS(n)	Standby Status Flag (n = 1 -168)	L	View	(); Off – On
STEP	Step	S	View	(Blank); N/A

STI_EU	Smart Transmitter Engineering Units	e:	Eng	(InH2O); InH2O, MMHG, PSI, KPA, MBar, Bar, G_SQCM, KG_SQCM, MPA, MMH20, INHG, Deg_C, Deg_F, Deg_K, Deg_R, MV, V, Ohms, CM_HR, Gal_HR, LIT_HR, CC_HR, CM_Min, Gal_Min, Lit_Min, CC_Min, CM_DAY, Gal_Day, KGal_Day, BRL_Day, CM_Sec, Ft_Sec, M_Sec, PRCNT, BLANK, LBS, KG, TONS, GRAMS, OZ, GAL, BRL, CUB_M, LITERS, MLITRES, FL_OZ, FEET, METERS, MM, INCHES, KG_CUM, G_CUM, LBS_CUFT, LBS_CUIN
STISWVER	Software Revision Level of the Smart Transmitter	S	View	(Blank); N/A, MPA
STITAG	Transmitter Tag Name of the Smart Transmitter	S	Eng/PB	(Spaces); A - Z and 0 - 9
STOPFL	Stop Command Flag	L	Prog	(Off); Off - On
STR8(n)	Box String Variables HPM Box, (n = 1 - 16384)	S	Oper	(Spaces); N/A
	Local String Variables (n = 1 - 16)	S	Special	(Spaces); N/A
STR16(n)	Local String Variables (n = 1 - 8)	S	Special	(Spaces); N/A
STR32(n)	Local String Variables (n = 1 - 4)	S	Special	(Spaces); N/A
STR64(n)	Local String Variables (n = 1 - 2)	S	Special	(Spaces); N/A
STR8(i)	Array Point String Variables	S	Special	(N/A); $1 \leq i \leq (NSTRING)/(8/STRLEN)$
STR16(i)	Array Point String Variables	S	Special	(N/A); $1 \leq i \leq (NSTRING)/(16/STRLEN)$

STR32(i)	Array Point String Variables	S	Special	(N/A); $1 \leq i \leq (\text{NSTRING})/(32/\text{STRLEN})$
STR64(i)	Array Point String Variables	S	Special	(N/A); $1 \leq i \leq (\text{NSTRING})/(64/\text{STRLEN})$
STRDESC	String Array Descriptor	S	PB	(Spaces; N/A)
STRLEN	String Length	I	PB	(8); 8, 16, 32, 64
STRSTIX	String Array Start Index	R	PB	(0); 0 - NSTRING or 0 - 99,999
STRTFAIL	Startup/Failover Information	S	View	(); 00 - FF (hexidecimal)
STSMMSG	Status Message	e:	Oper	(MSGTXT(0); to MSGTXT(15)
SUMSLTSZ	Total Configured Memory for Sequence Programs	I	View	(0); >0
SUSPSTAT	Suspend State	e:	View	(None); None, ConfMsg, Wait, InputMsg, Feedback
SUSPTIME	Suspension Timer	I	View	(0); >0 - 32,767
SVALDB	Secvar Alarm Deadband (DevCtl)	e:	Eng/PB	(One); Half, One, Two, Three, Four, Five, EU
SVALDB	Secvar Alarm Deadband (DevCtl)	e:	Eng/PB	(One); Half, One, Two, Three, Four, Five, EU
SVALDBEU	Secvar Alarm Deadband in Eng Units	R	Eng/PB	(0); Allowable Eng. Units
SVDESC	Secvar Descriptor	S	PB	(Blank); 8 Characters
SVEUDISC	Secvar Eng. Unit Descriptor	S	PB	(Blank); 8 Characters
SVEUHI	Secvar Range High	R	Eng/PB	(NaN); <> NaN
SVEULO	Secvar Range Lo	R	Eng/PB	(NaN); <> NaN
SVHHFL	Secvar High High Alarm Flag	L	View	(Off); Off, On

SVHHPR	Secvar High High Alarm Priority	e:	Engr	(NoAction – R670); JnlPrint, Printer, Emergency, High, Low, Journal, NoAction
SVHHTP	Secvar High High Alarm Trip Point	R	Supr	(NaN); > SVHITP or NaN
SVHHTPP	Secvar High High Alarm Trip Point Percent	R	Supr	(NaN); 0 – 100
SVHIFL	Secvar High Alarm Flag	L	View	(Off); Off, On
SVHIPR	Secvar High Alarm Priority	e:	Engr	(NoAction – R670); JnlPrint, Printer, Emergency, High, Low, Journal, NoAction
SVHITP	Secvar High Alarm Trip Point	R	Supr	(NaN); 0 – 100
SVHITPP	Secvar High Alarm Trip Point Percent	R	Supr	(NaN); 0 – 100
SVP	Secvar in Percent of Eng. Range	R	View	(NaN); 0 – 100
SVPEAK	Peak Value of Secvar	R	View	(NaN); 0 – 100
SVSRC	Secvar Input Connection	U	PB	(Null); See XPM PRD
SVTV	Secondary Variable Target Value	R	Oper	(NaN); SVEULO to SVEUHI
SVTVP	Secondary Variable Target Value in %	R	Oper	(NaN); 0 – 100
SWTCHACT(n)	IOP Synchronization (n = 1 - 40)	L	View	(On); Off, On
SYNCHSTS	Primary/Secondary Database Synchronization Status	e:	View	(None); OK, Warning, Fail
T	Temperature Input	R	View	(1); ≥ 0.0
T0	Zero Reference for Temperature	R	Supr	(0.0); N/A
T1	Integral Time in Minutes	R	Supr	(0.0); 0.0 - 1440.0 Minutes
T2	Derivative Time in Minutes	R	Supr	(0.0); 0.0 - 1440.0 Minutes

TCRNGOPT	Thermocouple Range Option	e:	Eng/PB	(Normal); Normal, Extended
TD	Total Dead Time in Minutes	R	Supr	(0.0); ≥ 0.0 Minutes
TF	PV Filter Lag Time in Minutes	R	Supr	(0.0); 0.0 - 60.0 Minutes
TIME(n)	Box Time Variables (n = 1- 4095)	T	Oper	(0); N/A
	ProcMod Local Time Variables (n = 1-4)	T	Special	(0); N/A
	Array Points Time Variables TIME (i)	T	Special	(N/A); $1 < i < NTIME$
TIMEBASE	Time Base (Timer)	e:	Eng	(Seconds); Seconds, Minutes
	Time Base (Totalizr, PI)	e:	Eng/PB	(Minutes); Seconds, Minutes, Hours
TIMEDESC	Time Array Descriptor	S	PB	(Spaces); N/A,
TIMESECS(n)	Array Point Time Variables (n = 1- 240)	T	Special	PB(N/A); $1 < i < NTIME$
TIMESTIX	Time Array Start Index	R	PB	(0); 0 – NTIME
TIMESYNCH	Timesynch Control	e:	PB	(Disable); Enable, Disable
TLD	Lead Time Constant in Minutes	R	Supr	(0.0); -1440.0 to +1440.0 Minutes
TLG1, TLG2	Lag Time Constants 1 and 2 in Minutes	R	Supr	(0.0); 0.0 - 1440.0 Minutes
TMCMD(n)	Timer Commands for Timers 1-64	e:	Oper	(N/A); None, Start, Stop, Reset, ResetStrt
TMPV(n)	Timer PV in Seconds or Minutes for Timers 1-64	I	View	(0); > 0
TMRV(n)	Timer RV – Remaining Time for Timers 1-64	I	View	(0); > 0
TMSO(n)	Timer Status Outputs for Timers 1-64	L	View	(Off); Off – On
TMSP(n)	Timer SP in Seconds/Minutes for Timers 1-64	I	Oper	(0); 0 – 32000

TMST(n)	Timer States for Timers 1-64	e:	View	(Stopped); Stopped, Running
TMTB(n)	Time Base for Timers 1-64	e:	Engr	(Seconds); Seconds, Minutes
TOTLUAVG	Average IOL Utilization in % per I/O Link	R	View	(0.0); 0 – 100
TOTLUMAX	Max. IOL Utilization in % per I/O Link	R	View	(0.0); 0 – 100
TRACKING	Selected Input Tracking	L	Eng/PB	(Off); Off – On
TRANTIM0-2	Transition Time	T	View	(0); Time Stamp
TRATAVG	Avg. UCN Transaction Trip Time	R	View	(NaN); N/A
TRATMAX	Max. UCN Transaction Trip Time	R	View	(NaN); N/A
TRFB	Tracking Feedback Input in EU	R	View	(NaN); N/A
TSCOMP	Time Stamp, CL Source Compatibility	T	View	(0); N/A
TSSRC	Time Stamp, CL Source	T	View	(0); N/A
TSTS	Temperature Input Value Status	e:	View	(Normal); Normal, Uncertn, Bad
TSUNICHG	Time Stamp, Unit Change	T	View	(0); N/A
TVPROC	Target Value Processor State	e:	Oper	(Off); Off, Preset, Run
UCNRECHN	UCN Receive Channel	e:	View	(ChannelA); ChannelA -ChannelB
UCNSCANT	Peer-to-Peer Scan Period in seconds	R	Eng/PB	(0.5); 0.5, 1.0
UCNWRTLK	HPM Write Lockout	e:	Eng	(WrtLkOff); WrtLkOn, WrtLkOff
UNCMDFL	Uncommanded Change Alarm Flag	L	View	(Off); Off – On
UNIT	Unit Identifier	S	PB	(N/A); A-Z, 0-9 (Max of 100 Unit Identifiers)
UPGRADE	NIM Upgrade Status	e:	Oper	(OK); OK, Upgrade
URL	Upper Range Limit	R	Eng/View	(N/A); N/A – NaN
URV	Upper Range Value	R	Supr/View	(NaN); N/A – NaN

USERID	User ID Reservation	S	Oper	(Dashes); 16 Characters
UTSDRIFT	UCN Node Clock Drift	I	View	(N/A)
UTSNODE	Last UCN Syncher Node	I	View	0; 0, 1 – 64
UTSTBCRV	TBC Revision	S	View	(N/A); 5 – 15
UTSTIMST	Timesynch State of UCN Node	e:	View	0; Initial, Failed, Degraded, LCN Bad, LCN OK, OK
UTSTIME	Current Time in LCN Node	T	View	(N/A); N/A
WARMSTRT	Warm start flag	L	View	(N/A); On – Off
WEEKDAY	Current Weekday	I	View	(N/A); 1 - 7 (1 = Sunday)
WITHBIASn	I/O Module Physical Bias State (n=1 - 40)	L	View	(On); On – Off
X	Steam Compressibility Input (FlowComp)	R	View	(1.0); ≥ 0.0
X1	X1 Input Value to be Biased (AutoMan)	R	Prog	(NaN); ≥ 0.0, N/A
X1 (OPSelect)	Input Value	R	Prog	(NaN); N/A
X1 - X3	Inputs 1-3 (MulDiv)	R	Prog	(NaN); ≥ 0.0, NaN
X1 - X4	Inputs 1-4 (IncrSum, OrSel)	R	Prog	(NaN); ≥ 0.0, NaN
X2	Bias Adjustment Input (AutoMan)	R	View	(N/A); N/A
	Input Number 2 (RatioCtl)	R	View	(N/A); N/A
X2FILT	Filtered value of the x2 input	R	View	(N/A); N/A
X2TF	X2 input filter lag time in minutes	R	Supr	(0.0); 0 - 60 minutes
XEUHI	X Input High Range in Engineering Units	R	Eng	(100.0, Equivalent to 100%); >XEULO

XEULO	X Input Low Range in Engineering Units	R	Eng	(0.0, Equivalent to 0%); < XEUHI
XSTS	X Input Value Status	e:	View	(Normal); Normal, Uncertn, Bad
YEAR	Current Year	I	View	(N/A); 1979 - 2115