
Honeywell

PM/NIM
Parameters Pocket Guide
PM09-641
09/08

CONTENTS

Introduction	2
Description of Parameter Definitions	2
Point Types	4
Algorithms	5
Parameters Per Point Type	6
Parameters Per Algorithm Type	22
Parameter Definitions	59

Introduction

This guide contains definitions of the parameters for TPN Release 681 used in the Process Manager (PM) and Network Interface Module (NIM). This guide is a condensed version of the PM parameters that are defined in the *PM Family Parameter Reference Dictionary*.

Description of Parameter Definitions

The parameter definitions in this guide are listed alphabetically by parameter name. Each parameter definition contains the parameter name, description, data type, access lock, default, and range.

Parameter

The **Parameter** column contains the short name (up to 8 characters) of the parameters. The parameter names are listed in alphabetical order.

Description

The **Description** column contains the long name of the parameter.

Type

Abbreviations in the **Type** column have the following meaning:

A = ASCII	I = Integer	S = String
BR = Blind Record	L = Logical	SDE =Self Defining Enumeration
e: = enumeration	P = Parameter Identifier	SU =Universal Entity.Parameter
E = Entity.Parameter	R = Real	

Lock

Entries in the **Lock** column define who or what can change the parameter's value or option.

The following chart shows who/what can change the parameter's value for each access lock. Access level defines who or what is requesting a parameter value or option change.

Access Level							
Lock	Oper	Supr	Engr	Cont	PMMCC	Prog	PB
Oper	*	*	*	*	*	*	*
Supr		*	*	*	*	*	*
Eng or Eg			*	*	*	*	*
OnProc	*	*	*				
Supr/Eng		*	*				
EgOnly			*				
Prog				*	*	*	*
Eng/PB			*				*
PB						*	
View							

Note:

Cont = Continuous_Control (from a Module on the LCN)
Eng/PB = Engineer or Point Builder
EgOnly = Engineer Only
Engr or Eg = Engineer
OnProc = On Process
Oper = Operator

PB = Point Builder
PMMCC = PMM_Continuous_Control (from PMM)
Prog = CL/PM Sequence Program
Supr = Supervisor
Supr/Eng = Supervisor or Engineer
View = Read Only

Default and Range

The default value and range for the parameter are listed in this column. The default value is the value assigned by the system when the user does not make an entry for the respective parameter. The default value is enclosed by parentheses (). The range of the value is listed to the right of the parentheses.

Point Types			
Abbreviation	Definition	Abbreviation	Definition
AnalogIn	Analog Input	LLMUX	Low Level Multiplexer*
AnalogOut	Analog Output	Logic	Logic
Box	PM Box	NIM	Network Interface Module
DigComp	Digital Composite	Numeric	Box Numeric
DigIn	Digital Input	PI	Pulse Input*
DigOut	Digital Output	ProcMod	Process Module
Flag	Box Flag	RegCtl	Regulatory Control
IOP	Input/Output Processor	RegPV	Regulatory PV
		SDI	Serial Device Interface
		STI	Smart Field Transmitter*
		Timer	Box Timer
		UCN	Universal Control Network

*These are subsets of the Analog Input type

Algorithms

Abbreviation	Definition
AutoMan	Auto Manual Ctl Algo
CaLcuLtr	Calculator PV Algo
DataAcq	Data Acquisition PV Algo
FlowComp	Flow Compensation PV Algo
GenLin	General Linearity PV Algo
HiLoAvg	High-Low Average PV Algo
IncrSum	Incremental Summer Ctl Algo
ModOf3	Middle Of Three PV Algo
ORSel	Override Selector Ctl Algo
Pid	Proportional, Integral, and Derivative Ctl Algo
PidErfb	PID With External Reset Feedback Ctl Algo
PidFf	PID With Feedforward Ctl Algo
PosProp	Position Proportional Ctl Algo
RampSoak	Ramp Soak Ctl Algo
RatioCtl	Ratio Control Ctl Algo
Summer	Summer PV Algo
Switch	Switch Ctl Algo
Totalizr	Totalizer PV Algo
VdtLdLag	Variable Deadtime With Lead Lag PV Algo

Parameters Per Point Type

Analog Input

The parameters of the Analog Input Data point are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT	DECONF	PNTTYPE
\$CDETAIL	DLTIME	PRIMMOD (F)
\$DLBADAL	EUDESC (F)	PTDESC (F)
\$HHSELECT (F)	HIGHAL (F)	PTEXECST
\$HISELECT (F)	HIGHALPR (F)	PTINAL
\$LSELECT (F)	INPTDIR	PV
\$LOSELECT (F)	KEYWORD (F)	PVALDB (F)
\$OLDEVDS	LASTPV	PVALDBEU (F)
\$REALARM (F)	LOCUTOFF	PVAUTO
\$RNSELECT (F)	LRL	PVAUTOST
\$RPSELECT (F)	LRV	PVCALC
ALENBST (F)	MODNUM	PVCHAR
ASSOCDSP	NAME	PVCLAMP
AVDELTHS	NODENUM	PVEUHI
AVSTS	NODETYP	PVEULO
BADPVFL (F)	NTWKNUM	PVEXEUHI
BADPVPR (F)	OTDENBLE	PVEXEULO
C1	OVERVAL (F)	PVEXHIFL
C2	PIUOTDCF	PVEXLOFL
CJTACT	PNTFORM	PVFORMAT
COMMAND	PNTMODTY	PVHHFL
CONTCUT (F)	PNTNODTY	PVHHPR (F) (Continued)
DAMPING	PNTSTATE	

Analog Input (Continued)

The parameters of the Analog Input Data point are listed below in alphabetical order.

(F) indicates that the parameter is applicable when the PNTFORM = Full.

PVHHTP (F)	PVROCNPR (F)	SERIALNO
PVHIFL	PVROCNTF (F)	SFSTS
PVHIPR (F)	PVROCPFL	SLOTNUM
PVHITP (F)	PVROCPRF (F)	SLWSRCID
PVLLFL	PVROCPTF (F)	SP
PVLLPR	PVSOURCE (F)	STATE
PVLLTP (F)	PVSRCOPT (F)	STI_EU
PVLOFL	PVSTS	STISWVER
PVLOPR (F)	PVTEMP	STITAG
PVLOTP (F)	PVTVP (F)	TCRNGOPT
PVP	PVTVP (F)	TF
PVRAW	RJRAW	TIMEBASE
PVRAWHI	RJTEMP	UNIT
PVRAWLO	S1	URL
PVROCNFL	SECVAR	URV

Analog Output

The parameters of the Analog Output Data point are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$CDETAIL	NODENUM	OPOUT5
\$MODESEL (F)	NODETYP	OPTDIR
\$OLDEVDS	NTWKNUM	OUTIND
ASSOCDSP	OP	PNTFORM
CASREQ (F)	OPCHAR	PNTMODTY
DISPTYPE	OPFINAL	PNTNODTY
EUDESC (F)	OPIN0	PNTSTATE
KEYWORD (F)	OPIN1	PNTTYPE
LOCALMAN	OPIN2	PTDESC (F)
MODATTR (F)	OPIN3	PTEXCST
MODE (F)	OPIN4	RCASOPT
MODEAPPL (F)	OPIN5	REDTAG (F)
MODEPERM (F)	OPOUT0	RINITREQ (F)
MODNUM	OPOUT1	SLOTNUM
NAME	OPOUT2	STDBYMAN
NMODATTR (F)	OPOUT3	UNIT
NMODE (F)	OPOUT4	

PM Box

The parameters of the Process Manager Box Data Point are listed below in alphabetical order.

BADPVTXT	IOMCHAER	IOTKNSTL	NODENUM	PMMRECCH
CHPINOPR	IOMCHASL	LSIOLORN	NODESTS	PMMSEVER
CRIOLORN	IOMCHBER	LSPPXORN	NODETYP	PMMSFSTS
CRPPXORN	IOMCHBSL	LSUCNORN	NODFSTAT	PMMSTS
CRUCNORN	IOMCMD	MOVPTXT	NPMSLOT	PMSEVER
CTLOPT	IOMCOMER	NCTLSLOT	NPVSLOT	SCANRATE
FL	IOMFILE	NDCSLOT	NTIMER	SEQPRGSZ
IOLASTS	IOMOPER	NFASTCTL	PKGOPT	SEQPROC
IOLBSTS	IOMREALT	NFASTDC	PMMCHAER	TMCMD
IOLCHAER	IOMRECHN	NFASTLOG	PMMCHASL	TMPV
IOLCHASL	IOMSEVER	NFASTPV	PMMCHBER	TMRV
IOLCHBER	IOMSTS	NFLAG	PMMCHBSL	TMSP
IOLCHBSL	IOMTYPE	NLOGSLOT	PMMCMD	TMSO
IOLCHERT	IONTOKEN	NN	PMMCOMER	TMST
IOLCMD	IOP	NNUMERIC	PMMCTLST	TMTB
IOLPERSW	IOSTKNDR	NODEASSN	PMMFLPOS	
IOMCARD	IOSSTS	NODECMD	PMMOPER	

Some of the parameters in the listing above are arrays that are not defined in this publication.

Box Flag

The parameters of the Box Flag Data Point are listed below in alphabetical order. (F) indicates that the Parameter is applicable when the PNTFORM = Full; an * indicates that the parameter is applicable to Flag slots 1-128.

\$CDETAIL	HIGHAL (F)*	PVFL
\$OFSELECT (F)	KEYWORD (F)	S0BOXCLR
\$REALARM (F)	NAME	S1BOXCLR
ALENBST (F)*	NODENUM	SLOTNUM
ALPRIOR (F)*	NODETYP	STATE0
ASSOCDSP	NTWKNUM	STATE1
BOXCLR	PNTFORM	STATETXT
CONTCUT (F)*	PRIMMOD (F)*	UNIT
EIPPCODE (F)*	PTDESC (F)	
EUDESC (F)	PV	

Box Numeric

The parameters of the Box Numeric Data Point are listed below in Alphabetical order.

\$CDETAIL	KEYWORD	PTDESC
\$HISELCT (F)	NAME	PV
\$LOSELCT (F)	NODENUM	PVFORMAT
ASSOCDSP	NODETYP	SLOTNUM
EUDESC	NTWKNUM	UNIT

Box Timer

The parameters of the Box Timer Data Point are listed below in alphabetical order.

\$CDETAIL	PV
ASSOCDSP	RV
COMMAND	SLOTNUM
EUDESC	SO
KEYWORD	SP
NAME	STATE
NODENUM	TIMEBASE
NODETYP	UNIT
NTWKNUM	
PERIOD	
PTDESC	

Digital Composite

The parameters of the Digital Composite Data Point are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$CDETAIL		D2D1_10	(#Inputs=2)
\$MODESEL	(#Outputs>0)	D2D1_11	(#Inputs=2)
\$OFSELECT (F)		DISRC	(#Inputs>0)
\$REALARM (F)*		DODSTN	(#Outputs>0)
ALENBST (F)		EIPPCODE (F)	
ALMOPT (F)		EUDESC (F)	
ASSOCDSP		EVOPT (F)	(#Inputs>0)
BADPVFL (F)	(#Inputs>0)	FBTIME (F)	
BADPVPR (F)		HIGHAL (F)	
BOXCLR		I0	(#Outputs>0)
BYPASS	(#Outputs>0)	I1	(#Outputs>0)
CMDDISFL		I2	(#Outputs>0)
CMDDISPR		INITMAN	
CONTCUT (F)		INITREQ	
D1	(#Inputs>0)	KEYWORD (F)	
D1_0	(#Inputs=1)	LOCALMAN	(#Outputs>0)
D1_1	(#Inputs=1)	LOGICSRC	
D2	(#Inputs=2)		(Continued)
D2D1_00	(#Inputs=2)		
D2D1_01	(#Inputs=2)		

Digital Composite (Continued)

Continuation of the parameters of the Digital Composite Data Point is listed below in alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

MODATTR	(#Outputs>0)	NODETYPE	
MODE	(#Outputs>0)	NODINTPS	
MODEAPPL	(#Outputs>0)	NODOPTS	
MODEPERM	(#Outputs>0)	NOSTATES	
MODNUM		NTWKNUM	
MOMSTATE	(#Outputs>0)	OFFNRMFL	
MOVPVFL	(#Inputs>0)	OFFNRMPR	
NAME		OP	(#Outputs>0)
NMODATTR	(#Outputs>0)	OPRATRFL	(#Outputs>0)
NMODE	(#Outputs>0)	OROPT	(#Outputs>0)
NODENUM			

(Continued)

Digital Composite (Continued)

Continuation of the parameters of the Digital Composite Data Point is listed below in alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

P0	(#Outputs>0)	PTINAL	
P1	(#Outputs>0)	PULSEWIDTH	(#Outputs>0)
P2	(#Outputs>0)	PV	(#Inputs>0)
PERIOD		PVAUTO	(#Inputs>0)
PNTFORM		PVFL	(#Inputs>0)
PNTMODTY		PVNORMAL (F)	
PNTNODTY		PVSOURCE (F)	(#Inputs>0)
PNTSTATE		PVSRCOPT (F)	(#Inputs>0)
PNTTYPE		PVSTATES	(#Inputs>0)
PRIMMOD (F)		REDTAG (F)	(#Outputs>0)
PTDESC (F)		S0BOXCLR	
PTEXECST (F)		S1BOXCLR	
		S2BOXCLR	
		SLOTNUM	
			(Continued)

Digital Composite (Continued)

Continuation of the parameters of the Digital Composite Data Point is listed below in alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

SO		UNCMDFL
SOCMD		UNIT
ST0_OP1	(#Outputs>0)	
ST0_OP2	(#Outputs>=2)	
ST0_OP3	(#Outputs>=3)	
ST1_OP1	(#Outputs>0)	
ST1_OP2	(#Outputs>=2)	
ST1_OP3	(#Outputs>=3)	
ST2_OP1	(#Outputs>0)	
ST2_OP2	(#Outputs>=2)	
ST2_OP3	(#Outputs>=3)	
STATE0		
STATE1		
STATE2		
STATETXT		

Digital Input

The parameters of the Digital Input Data Point are listed below in alphabetical order.
(L), (S), or (A)—parameter applies only when DITYPE = Latched, Status, or Accum.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$CDETAIL	INPTDIR (F)	PVRAW
\$DLYOPT	KEYWORD (F)	PVSOURCE (L) (F)
\$OFSELECT (F)	MODNUM	PVSRCOPT (S) (L) (F)
\$PMDLYTM	NAME	RESETFL (A)
\$REALARM (F)	NODENUM	RESETVAL (A)
ALENBST (S) (F)	NODETYP	S0BOXCLR (S) (L)
ALMOPT (S) (F)	NTWKNUM	S1BOXCLR (S) (L)
ALPRIOR	OFFNRMFL (S)	SLOTNUM
ASSOCDSP	OLDAV (A)	STARTFL (A)
AV (A)	OVERFLOW (A)	STATE (A)
AVTV (A)	OVERVAL (A) (F)	STATE0 (S) (L)
AVTVFL (A)	PNTFORM	STATE1 (S) (L)
BADPVFL	PNTNODTY	STATETXT (S) (L)
BADPVPR	PNTMODTY	STOPFL (A)
BOXCLR (L)	PNTSTATE	UNIT
COMMAND (A)	PNTTYPE	
CONTCUT (S) (F)	PRIMMOD (S) (F)	
COUNTDOWN (A)	PTDESC (F)	
DITYPE (F)	PTEXCST	
DLYTIME (S) (F)	PV (S) (L)	
EIPPCODE (S) (L) (F)	PVAUTO (S) (L)	
EUDESC (S) (L) (A)	PVFL (S) (L)	
EVTOP (L) (F)	PVNORMAL (S) (F)	
HIGHAL (S)	PVNORMFL (S)	

Digital Output

The parameters of the Digital Output Data Point are listed below in alphabetical order. (S) or (P) parameter applies only when DOTYPE = Status or Pulse Width Modulated (PWM). This point type is available only in the component form.

\$CDETAIL	NODENUM	PNTFORM	S1BOXCLR (S)
ASSOCDSP	NODETYP	PNTMODTY	SLOTNUM
DOTYPE	NTWKNUM	PNTNODTY	SO (S)
EUDESC	OFFPULSE (S)	PNTSTATE	STATE0 (S)
INITREQ	ONPULSE (S)	PNTTYPE	STATE1 (S)
KEYWORD	OP (P)	PTDESC	STDBYMAN
MODNUM	OPTDIR (P)	PTEXECST	UNIT
NAME	PERIOD (P)	S0BOXCLR (S)	

Input/Output Processor

The parameters of the Input/Output Processor Point are listed below in alphabetical order.

CALIBALL	IOMFWREV	IONTOKEN	SLOT0SF
CALIBRJ	IOMHWREV	IORECCHN	STDBYSTS
FAILOPT	IOMLHFST	LINEPERD	SWTCHACT
FTAPRES	IOMOPER	NODETYP	WARMSTRT
FREQ6050	IOMTYPE	PIUOTDCF	
IOMACTYP	IOMSTS	RJRAW	

Logic

The parameters of the Logic Data Point (otherwise referred to as the Logic Slot) are listed below in alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$CDETAIL	NOLOGBLK	SO 1-16
\$REALARM (F)	NOLOPTS	UNIT
ASSOCDSP	NTWKNUM	
DEADBAND 1-16	PERIOD	
DLYTIME 1-16	PNTFORM	
FL1-12	PNTMODTY	
GENDESC 1-12 (F)	PNTNODTY	
L1-12	PNTSTATE	
LIBADOPT	PNTTYPE	
LISRC 1-12	PRMDESC (F)	
LODSTN 1-12	PTDESC (F)	
LOENBL 1-12	PTEXECST	
LOGALGID 1-16	R1 1-16	
LOGMIX	R2 1-16	
LOSRC 1-12	S1 1-16	
MODNUM	S1REV 1-16	
NAME	S2 1-16	
NN1-4	S2REV 1-16	
NODENUM	S3 1-16	
NODETYP	S3REV 1-16	
NODESC (F)	S4 1-16	
NOLINPTS	SLOTNUM	

Network Node

The parameters of the UCN Network Node Data Point are listed below in alphabetical order.

\$UCNANSY
\$UCNASIL
\$UCNBNSY
\$UCNBSIL
CABLESTS
CLPZMXC
CLPZMXP
LOADSCOP
NODESTAT
NODESTS
NODETYP
UCNRECHN
UPGRADE

Process Module

The parameters of the Process Module Data Point are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

ABHEMSD	NODETYP	SEQERR
ABHHOLD	OPRINPUT	SEQEXEC
ABHRSTR	OVERPHAS	SEQNAME
ABHSHDN	OVERSTAT	SEQSLTSZ
ACP (F)	OVERSTEP	SLOTNAME
ALPRIOR (F)	PERIOD	SLOTNUM
ASTEP	PHASE	SPLOCK
ASTEPIDX	PHASEAL	SSTEP
ASTMT	PHASEIDX	SSTMT
BATCHID (F)	PHASETIM	STATMENT
BHP	PNTFORM	STEP
CNTLLOCK	PNTTYPE	STEPIDX
FL	PROCMOD	SUSPSTAT
MSGPEND	PTDESC (F)	UNIT
NAME (F)	RESTART	
NN	RSTROPT	

Some of the parameters in the listing above are arrays that are not defined in this publication.

Universal Control Network

The parameters of the UCN Data Point are listed below in alphabetical order.

CHPINHWY
CLPZMXC
CLPZMXP
HWYCTLST
UPGRADE

Parameters Per Algorithm Type

Auto Manual

The parameters of the Auto Manual algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$CDETAIL	CONTCUT (F)	K
\$DLBADAL (F)	CTLALGID	KEYWORD (F)
\$MODESEL	CTLEQN	LOCALMAN
\$REALARM (F)	CTRLINIT	MANMODFL
ALENBST (F)	CV	MODATTR
ARWNET	CVEUHI	MODE
ARWOP	CVEULO	MODEAPPL
ASSOCDSP	DLYTIME (F)	MODEPERM
AUTOMODFL	ESWAUTO	MODNUM
B	ESWCAS	NAME
B0	ESWENBST	NMODATTR
BADCTLFL	ESWMAN	NMODE
BADCTLPR (F)	EUDESC (F)	NOCINPTS
CASREQ	EXTSWOPT	
CIDSTN	HIGHAL (F)	(Continued)
CISRC	HIGHALPR (F)	
CODSTN	INITMAN	

Auto Manual (Continued)

NOCOPTS
NODENUM
NODETYP
NTWKNUM
OP
OPALDB
OPEU
OPHAFL
OPHIFL
OPHILM
OPHIPR
OPHITP
OPLAFL
OPLOFL
OPLOLM
OPLOPR
OPLOTP
OPMCHLM
OPRATRFL
OPROCLM
OUTIND
OVERVAL (F)
PERIOD
PNTFORM
PNTMODTY
PNTNODTY
PNTSTATE

PNTTYPE
PRIMMOD (F)
PTDESC (F)
PTEXECST
PTINAL
PTORST
RARWSTS
RATE1
RCASOPT
RCASSHED
REDTAG (F)
RINITREQ
RINITVAL
SAFEOP
SHEDMODE
SHEDTIME
SHUTDOWN
SLOTNUM
STDBYMAN
UNIT
X1
X2
XEUHI
XEULO

Calculator

The parameters of the Calculator PV algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	LASTPV	PNTMODTY
\$CDETAIL	MODNUM	PNTNODTY
\$DLBADAL (F)	N	PNTSTATE
\$HISELCT (F)	NAME	PNTTYPE
\$HHSELCT (F)	NODENUM	PRIMMOD (F)
\$LLOSELCT (F)	NODETYP	PTDESC (F)
\$LOSELCT (F)	NOPINPTS	PTEXECST
\$REALARM (F)	NTWKNUM	PTINAL
\$RNSLCT (F)	OVERVAL (F)	
\$RPSELCT (F)	P1	(Continued)
ALENBST (F)	P1STS	
ASSOCDSP	P2	
BADPVFL (F)	P2STS	
BADPVPR (F)	P3	
C1	P3STS	
C2	P4	
C3	P4STS	
C4	P5	
CALCEXP	P5STS	
CONTCUT (F)	P6	
DLYTIME (F)	P6STS	
EUDESC (F)	PERIOD	
HIGHAL (F)	PIDSTN	
HIGHALPR (F)	PISRC	
KEYWORD (F)	PNTFORM	

Calculator (Continued)

PV
PVALDB (F)
PVALDBEU (F)
PVALGID
PVAUTO
PVAUTOST
PVCALC
PVCLAMP
PVEUHI
PVEULO
PVEXEUHI
PVEXEULO
PVEXHIFL
PVEXLOFL
PVFORMAT

PVHHFL
PVHHPR (F)
PVHHTP (F)
PVHIFL
PVHIPR (F)
PVHITP (F)
PVINIT
PVLLFL
PVLLPR (F)
PVLLTP (F)
PVLOFL
PVLOPR (F)
PVLOTP (F)
PVP
PVROCFL

PVROCNP (F)
PVROCNP (F)
PVROCPFL
PVROCPPR (F)
PVROCP (F)
PVSGCHTP (F)
PVSOURCE (F)
PVSRCOPT (F)
PVSTS
PVT (F)
PVTVP (F)
SLOTNUM
TF
UNIT

Data Acquisition

The parameters of the Data Acquisition PV algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	NODENUM	PVAUTO	PVLOTP (F)
\$CDETAIL	NODETYP	PVAUTOST	PVP
\$DLBADAL (F)	NOPINPTS	PVCALC	PVROCNFL
\$HHSELECT (F)	NTWKNUM	PVCLAMP	PVROCNPR (F)
\$HISELCT (F)	OVERVAL (F)	PVEUHI	PVROCNTP (F)
\$LSELECT (F)	P1	PVEULO	PVROCPFL
\$LOSELCT (F)	P1STS	PVEXEUHI	PVROCPPR (F)
\$REALARM (F)	PERIOD	PVEXEULO	PVROCPTP (F)
\$RNSELECT (F)	PIDSTN	PVEXHIFL	PVSGCHTP (F)
\$RPSELECT (F)	PISRC	PVEXLOFL	PVSOURCE (F)
ALENBST (F)	PNTFORM	PVFORMAT	PVSRCOPT (F)
ASSOCDSP	PNTMODTY	PVHHFL	PVSTS
BADPVFL (F)	PNTNODTY	PVHHPR (F)	PVTV (F)
BADPVPR (F)	PNTSTATE	PVHHTP (F)	PVTVP (F)
CONCUT (F)	PNTTYPE	PVHIFL	SLOTNUM
DLYTIME (F)	PRIMMOD (F)	PVHIPR (F)	TF
EUDESC (F)	PTDESC (F)	PVHITP (F)	UNIT
HIGHAL (F)	PTEXECST	PVINIT	
HIGHALPR (F)	PTINAL	PVLLFL	
KEYWORD (F)	PV	PVLLPR (F)	
LASTPV	PVALDB (F)	PVLLTP (F)	
MODNUM	PVALDBEU (F)	PVLOFL	
NAME	PVALGID	PVLOPR (F)	

Flow Compensation

The parameters of the Flow Compensation PV algorithm are listed below in alphabetical order.

(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	DLTIME (F)	PNTFORM
\$CDETAIL	EUDESC (F)	PNTMODTY
\$DLBADAL (F)	F	PNTNODTY
\$HHSELECT (F)	FSTS	PNTSTATE
\$HISELECT (F)	G	PNTTYPE
\$LSELECT (F)	GSTS	PRIMMOD (F)
\$LOSELECT (F)	HIGHAL (F)	PTDESC (F)
\$REALARM (F)	HIGHALPR (F)	PTEXCST
\$RNSELECT (F)	KEYWORD (F)	PTINAL
\$RPSELECT (F)	LASTPV	PV
ALNBST (F)	MODNUM	PVALDB (F)
ASSOCDSP	NAME	PVALDBEU (F)
BADPVFL (F)	NODENUM	PVALGID
BADPVPR (F)	NODETYP	PVAUTO
C	NOPINPTS	PVAUTOST
C1	NTWKNUM	PV CALC
C2	OVERVAL (F)	PVCLAMP
COMPFILM	P1STS	
COMPLOLM	PERIOD	
COMPTERM	PIDSTN	
CONTCUT (F)	PISRC	

(Continued)

Flow Compensation (Continued)

PVEUHI	PVLLTP (F)	PVTVP (F)
PVEULO	PVLOFL	Q
PVEXEUHI	PVLOPR (F)	QSTS
PVEXEULO	PVLOTP (F)	RG
PVEXHIFL	PVP	RP
PVEXLOFL	PVROCNFL	RQ
PVFORMAT	PVROCNPR (F)	RT
PVHHFL	PVROCNTP (F)	RX
PVHHPR (F)	PVROCPFL	SLOTNUM
PVHHTP (F)	PVROCPPR (F)	T
PVHIFL	PVROCPTP (F)	T0
PVHIPR (F)	PVSGCHTP (F)	TF
PVHITP	PVSOURCE (F)	TSTS
PVINIT	PVSRCOPT (F)	UNIT
PVLLFL	PVSTS	X
PVLLPR (F)	PVTV (F)	XSTS

General Linearization

The parameters of the General Linearization PV algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	IN3	OUT4
\$CDETAIL	IN4	OUT5
\$DLBADAL (F)	IN5	OUT6
\$HHSELECT (F)	IN6	OUT7
\$HISELECT (F)	IN7	OUT8
\$LSELECT (F)	IN8	OUT9
\$LOSELECT (F)	IN9	OUT10
\$REALARM (F)	IN10	OUT11
\$RSELECT (F)	IN11	OUT12
\$RPSELECT (F)	IN12	OVERVAL (F)
ALENBST (F)	KEYWORD (F)	P1
ASSOCDSP	LASTPV	P1STS
BADPVFL (F)	MODNUM	PIDSTN
BADVPR (F)	NAME	PISRC
CONTCUT (F)	NODENUM	PNTFORM
DLTIME (F)	NODETYP	PNTMODTY
EUDESC (F)	NOPINPTS	PNTNODTY
HIGHAL (F)	NTWKNUM	PNTSTATE
HIGHALPR (F)	OUT0	
IN0	OUT1	
IN1	OUT2	
IN2	OUT3	

(Continued)

General Linearization (Continued)

PNTTYPE	PVEXHIFL	PVROCNFL
PRIMMOD (F)	PVEXLOFL	PVROCNPR (F)
PTDESC (F)	PVFORMAT	PVROCNTP (F)
PTEXECST	PVHHFL	PVROCPFL
PTINAL	PVHHPR (F)	PVROCPPR (F)
PV	PVHHTP (F)	PVROCPTP (F)
PVAUTO	PVHIIFL	PVSGCHTP (F)
PVALDB (F)	PVHIIPR (F)	PVSOURCE (F)
PVALDBEU (F)	PVHITP (F)	PVSRCOPT (F)
PVALGID	PVINIT	PVSTS
PVAUTOST	PVLLFL	PVTV (F)
PVCALC	PVLLPR (F)	PVTVP (F)
PVCLAMP	PVLLTP (F)	SEGTOT
PVEUHI	PVLOFL	SLOTNUM
PVEULO	PVLOPR (F)	TF
PVEXEUHI	PVLOTP (F)	UNIT
PVEXEULO	PVP	

High-Low Average

The parameters of the High-Low Average PV algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	LASTPV	PISRC
\$CDETAIL	MODNUM	PNTFORM
\$DLBADAL (F)	N	PNTMODTY
\$HHSELECT (F)	NAME	PNTNODTY
\$HISELCT (F)	NMIN	PNTSTATE
\$LLSELECT (F)	NODENUM	PNTTYPE
\$LOSELCT (F)	NOPINPTS	PRIMMOD (F)
\$REALARM (F)	NTWKNUM	PTDESC (F)
\$RNSELCT (F)	OVERVAL (F)	PTEXCST
\$RPSELCT (F)	P1	PTINAL
ALENBST (F)	P1STS	PV
ASSOCDSP	P2	
BADPVFL (F)	P2STS	(Continued)
BADPVPR (F)	P3	
CONTCUT (F)	P3STS	
DLYTIME (F)	P4	
EUDESC (F)	P4STS	
FORCE	P5	
FRCPERM	P5STS	
FSELIN	P6	
HIGHAL (F)	P6STS	
HIGHALPR (F)	PERIOD	
KEYWORD (F)	PIDSTN	

High-Low Average (Continued)

PVALDB (F)
PVALDBEU (F)
PVALGID
PVAUTO
PVAUTOST
PVCALC
PVCLAMP
PVEQN
PVEUHI
PVEULO
PVEXEUHI
PVEXEULO
PVEXHIFL
PVEXLOFL
PVFORMAT

PVHHFL
PVHHPR (F)
PVHHTP (F)
PVHIFL
PVHIPR (F)
PVHITP (F)
PVINIT
PVLLFL
PVLLPR (F)
PVLLTP (F)
PVLOFL
PVLOPR (F)
PVLOTP (F)
PVP
PVROCNFL

PVROCNPR (F)
PVROCNTP (F)
PVROCPFL
PVROCPPR (F)
PVROCPTP (F)
PVSGCHTP (F)
PVSOURCE (F)
PVSRCOPT (F)
PVSTS
PVTV (F)
PVTVP (F)
SELINP
SLOTNUM
TF
UNIT

Incremental Summer

The parameters of the Incremental Summer control algorithm are listed below in alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$CDETAIL	CV	KEYWORD (F)
\$MODESEL	CVEUHI	LOCALMAN
\$REALARM (F)	CVEULO	M
ALENBST (F)	DELCV	MANMODFL
ARWNET	ESWAUTO	MODATTR
ARWOP	ESWCAS	MODE
ASSOCDSP	ESWENBST	MODEAPPL
AUTMODFL	ESWMAN	MODEPERM
BADCTLFL	EUDESC (F)	MODNUM
BADCTLPR (F)	EXTSWOPT	NAME
CASREQ	HIGHAL (F)	NMODATTR
CIDSTN	HIGHALPR (F)	NMODE
CISRC	INITMAN	NOCINPTS
CODSTN	K1	
CONTCUT (F)	K2	(Continued)
CTLALGID	K3	
CTRLINIT	K4	

Incremental Summer (Continued)

NOCOPTS	OPMCHLM	RCASSHED
NODENUM	OPRATRFL	REDTAG (F)
NODETYP	OPROCLM	RINITREQ
NTWKNUM	OVERVAL (F)	RINITVAL
OP	PERIOD	SAFEOP
OPALDB	PNTFORM	SHEDMODE
OPEU	PNTMODTY	SHEDTIME
OPHAFL	PNTNODTY	SHUTDOWN
OPHIFL	PNTSTATE	SLOTNUM
OPHILM	PNTTYPE	STDBYMAN
OPHIPR	PRIMMOD (F)	UNIT
OPHITP	PTDESC (F)	X1
OPLAFL	PTEXECST	X2
OPLOFL	PTINAL	X3
OPLOLM	PTORST	X4
OPLOPR	RARWSTS	XEUHI
OPLOTP	RCASOPT	XEULO

Middle-Of-3

The parameters of the Middle-Of-3 PV algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDOPT (F)	NODENUM	PV	PVLLFL
\$CDETAIL	NODETYP	PVALDB (F)	PVLLPR (F)
\$DLBADAL (F)	NOPINPTS	PVALDBEU (F)	PVLLTP (F)
\$HHSELECT (F)	NTWKNUM	PVALGID	PVLOFL
\$HISELCT (F)	OVERVAL (F)	PVAUTO	PVLOPR (F)
\$LSELECT (F)	P1	PVAUTOST	PVLOTP (F)
\$LOSELCT (F)	P1STS	PVCALC	PVP
\$REALARM (F)	P2	PVCLAMP	PVROCNFL
\$RNSLCT (F)	P2STS	PVEQN	PVROCNPR (F)
\$RPSLCT (F)	P3	PVEUHI	PVROCNTP (F)
ALENBST (F)	P3STS	PVEULO	PVROCPFL
ASSOCDSP	PERIOD	PVEXEUHI	PVROCPPR (F)
BADPVFL (F)	PIDSTN	PVEXEULO	PVROCPTP (F)
BADPVPR (F)	PISRC	PVEXHIFL	PVSGCHTP (F)
CONTCUT (F)	PNTFORM	PVEXLOFL	PVSOURCE (F)
DLYTIME (F)	PNTMODTY	PVFORMAT	PVSRCOPT (F)
EUDESC (F)	PNTNODTY	PVHHFL	PVSTS
HIGHAL (F)	PNTSTATE	PVHHPR (F)	PVTVP (F)
HIGHALPR (F)	PNTTYPE	PVHHTP (F)	PVTVP (F)
KEYWORD (F)	PRIMMOD (F)	PVHIFL	SELINP
LASTPV	PTDESC (F)	PVHIPR (F)	SLOTNUM
MODNUM	PTEXECST	PVHITP (F)	TF
NAME	PTINAL	PVINIT	UNIT

Override Selector

The parameters of the Override Selector control algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$CDETAIL	CODSTN	LOCALMAN
\$DLBADAL (F)	CONTCUT (F)	M
\$MODESEL	CTALGID	MANMODFL
\$REALARM (F)	CTLEQN	MODATTR
ALENBST (F)	CTRLINIT	MODE
ARWNET	CV	MODEAPPL
ARWOP	CVEUHI	MODEPERM
ASSOCDSP	CVEULO	MODNUM
AUTMODFL	DLYTIME (F)	NAME
BADCTLFL	ESWAUTO	NMODATTR
BADCTLPR (F)	ESWCAS	NMODE
BYPASS	ESWENBST	NOCINPTS
BYPASSX1	ESWMAN	
BYPASSX2	EUDESC (F)	
BYPASSX3	EXTSWOPT	
BYPASSX4	HIGHAL (F)	
CASREQ	HIGHALPR (F)	
CIDSTN	INITMAN	
CISRC	KEYWORD (F)	

(Continued)

Override Selector (Continued)

NOCOPTS	OPRATRFL	RCASSHED
NODENUM	OPROCLM	REDTAG (F)
NODETYP	OROFFSET	RINITREQ
NTWKNUM	OROPT	RINITVAL
OP	OVERVAL (F)	SAFEOP
OPALDB	PERIOD	SELXINP
OPEU	PNTFORM	SHEDMODE
OPHAFL	PNTMODTY	SHEDTIME
OPHIFL	PNTNODTY	SHUTDOWN
OPHILM	PNTSTATE	SLOTNUM
OPHIPR	PNTTYPE	STDBYMAN
OPHITP	PRIMMOD (F)	UNIT
OPLAFL	PTDESC (F)	X1
OPLOFL	PTEXECST	X2
OPLOLM	PTINAL	X3
OPLOPR	PTORST	X4
OPLOTP	RARWSTS	XEUHI
OPMCHLM	RCASOPT	XEULO

Pid

The parameters of the Pid control algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	ASSOCDSP	DEVHIFL	KGAP
\$CDETAIL	AUTMODFL	DEVHIPR (F)	KLIN
\$DHSELECT (F)	BADCTFL	DEVHITP (F)	KNL
\$DLBADAL (F)	BADPVFL (F)	DEVLOFL	LASTPV
\$DLSELECT (F)	BADPVPR (F)	DEVLOPR (F)	LOCALMAN
\$HHSELECT (F)	BIAS	DEVLOTP (F)	MANMODFL
\$HISELECT (F)	BSHILM	DLYTIME (F)	MODATTR
\$LSELECT (F)	BSLOLM	ESWAUTO	MODE
\$LOSELECT (F)	CASREQ	ESWCAS	MODEAPPL
\$MODESEL	CIDSTN	ESWENBST	MODEPERM
\$REALARM (F)	CISRC	ESWMAN	MODNUM
\$RNSELECT (F)	CODSTN	EUDESC (F)	NAME
\$RPSELECT (F)	CONTCUT (F)	EXTSWOPT	NLFM
ADVDEVFL	CTLACTN	GAINOPT	NLGAIN
ADVDEVPR (F)	CTLALGID	GAPHI	NMODATTR
ADVDEVTP (F)	CTLEQN	GAPLO	NMODE
ADVSP (F)	CTRLINIT	HIGHAL (F)	NOCINPTS
ADVSP (F)	CV	HIGHALPR (F)	NOCOPTS
ALENBST (F)	CVEUHI	INITMAN	NODENUM
ARWNET	CVEULO	K	NODETYP
ARWOP	DELCV	KEXT	(Continued)
ASPPROC (F)	DEV	KEYWORD (F)	

Pid (Continued)

NTWKNUM	PNTTYPE	PVLOPR (F)	SAFEOP
OP	PTDESC (F)	PVP	SHEDMODE
OPALDB	PTEXCST	PVROCNFL	SHEDTIME
OPEU	PTINAL	PVROCNPR (F)	SHUTDOWN
OPHAFL	PTORST	PVROCNTF (F)	SLOTNUM
OPHIFL	PV	PVROCPFL	SP
OPHILM	PVALDB (F)	PVROCPPR (F)	SPEUHI
OPHIPR	PVALDBEU (F)	PVROCPTP (F)	SPEULO
OPHITP	PVAUTO	PVSGCHTP (F)	SPFORMAT
OPLAFL	PVAUTOST	PVSOURCE (F)	SPHIFL
OPLOFL	PVEUHI	PVSRCOPT (F)	SPHILM
OPLOLM	PVEULO	PVSTS	SPLOFL
OPLOPR	PVFORMAT	PVTRACK	SPLOLM
OPLOTP	PVHHFL	RAMPTIME	SPOPT
OPMCHLM	PVHHPR (F)	RARWSTS	SPP
OPRATRFL	PVHIFL	RATIO	SPTV
OPROCLM	PVHIPR (F)	RBOPT	SPTVP
OVERVAL (F)	PVHHTP (F)	RCASOPT	STDBYMAN
PERIOD	PVHITP (F)	RCASSHED	T1
PIDFORM	PVLLFL	REDTAG (F)	T2
PNTFORM	PVLLPR (F)	RINITREQ	TVPROC
PNTMODTY	PVLLTP (F)	RINITVAL	UNIT
PNTNODTY	PVLOFL	RTHILM	
PNTSTATE	PVLOTP (F)	RTLOLM	

Pid With External Reset Feedback

The parameters of the Pid With External Reset Feedback control algorithm are listed below in Alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	AUTMODFL	DEVHITP (F)	KNL
\$CDETAIL	BADCTLFL	DEVLOFL	LASTPV
\$DHSELECT (F)	BADPVFL (F)	DEVLOPR (F)	LOCALMAN
\$DLBADAL (F)	BADPVPR (F)	DEVLOTP (F)	MANMODFL
\$DLSELECT (F)	BIAS	DLYTIME (F)	MODATTR
\$HHSELECT (F)	BSHILM	ESWAUTO	MODE
\$HSELECT (F)	BSLOLM	ESWCAS	MODEAPPL
\$LLSELECT (F)	CASREQ	ESWENBST	MODEPERM
\$LOSELECT (F)	CIDSTN	ESWMAN	MODNUM
\$MODESEL	CISRC	EUDESC (F)	NAME
\$REALARM (F)	CODSTN	EXTSWOPT	NLFM
\$RNSELECT (F)	CONTCUT (F)	GAINOPT	NLGAIN
\$RPSELECT (F)	CTLACTN	GAPHI	NMODATTR
ADVDEVFL	CTLALGID	GAPLO	NMODE
ADVDEVPR (F)	CTLEQN	HIGHAL (F)	NOCINPTS
ADVDEVTP	CTRLINIT	HIGHALPR (F)	NOCOPTS
ADVSP (F)	CV	INITMAN	NODENUM
ADVSP (F)	CVEUHI	K	NODETYP
ALENBST (F)	CVEULO	K1	NTWKNUM
ARWNET	DELCV	KEXT	OP
ARWOP	DEV	KEYWORD (F)	OPALDB
ASPPROC (F)	DEVHIFL	KGAP	
ASSOCDSP	DEVHIPR (F)	KLIN	(Continued)

Pid With External Reset Feedback (Continued)

OPEU	PTINAL	PVROCNPR (F)	SHEDMODE
OPHAFL	PTORST	PVROCNTP (F)	SHEDTIME
OPHIFL	PV	PVROCPFL	SHUTDOWN
OPHILM	PVALDB (F)	PVROCPPR (F)	SLOTNUM
OPHIPR	PVALDBEU (F)	PVROCPTP (F)	SP
OPHITP	PVAUTO	PVSGCHTP (F)	SPEUHI
OPLAFL	PVAUTOST	PVSOURCE (F)	SPEULO
OPLOFL	PVEUHI	PVSRCOPT (F)	SPFORMAT
OPLOLM	PVEULO	PVSTS	SPHIFL
OPLOPR	PVFORMAT	PVTRACK	SPHILM
OPLOTP	PVHHFL	RAMPTIME	SPLOFL
OPMCHLM	PVHHPR (F)	RARWSTS	SPLOLM
OPRATRFL	PVHHTP (F)	RATIO	SPOPT
OPROCLM	PVHIFL	RBOPT	SPP
OVERVAL (F)	PVHIPR (F)	RCASOPT	SPTV
PERIOD	PVHITP (F)	RCASSHED	SPTVP
PIDFORM	PVLLFL	REDTAG (F)	STDBYMAN
PNTFORM	PVLLPR (F)	RFB	T1
PNTMODTY	PVLLTP (F)	RINITREQ	T2
PNTNODTY	PVLOFL	RINITVAL	TRFB
PNTSTATE	PVLOTP (F)	RTHILM	TVPROC
PNTTYPE	PVLOPR (F)	RTLOLM	UNIT
PTDESC (F)	PVP	S1	
PTEXECST	PVROCNFL	SAFEOP	

Pid With Feed Forward

The parameters of the Pid With Feed Forward control algorithm are listed below in Alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	BIAS	DEVLOTP (F)	KNL
\$CDETAIL	BSHILM	DLYTIME (F)	LASTPV
\$DHSELECT (F)	BSLOLM	ESWAUTO	LOCALMAN
\$DLBADAL (F)	CASREQ	ESWCAS	MANMODFL
\$DLSELECT (F)	CIDSTN	ESWENBST	MODATTR
\$MODESEL	CISRC	ESWMAN	MODE
\$REALARM (F)	CODSTN	EUDESC (F)	MODEAPPL
ADVDEVFL	CONTCUT (F)	EXTSWOPT	MODEPERM
ADVDEVPR (F)	CTLACTN	FF	MODNUM
ADVDEVTP	CTLALGID	FFOPT	NAME
ADVSP (F)	CTLEQN	GAINOPT	NLFM
ADVSP (F)	CTRLINIT	GAPHI	NLGAIN
ALENBST (F)	CV	GAPLO	NMODATTR
ARWNET	CVEUHI	HIGHAL (F)	NMODE
ARWOP	CVEULO	HIGHALPR (F)	NOCINPTS
ASPPROC (F)	DELCV	INITMAN	NOCPTS
ASSOCDSP	DEV	K	NODENUM
AUTMODFL	DEVHIFL	KEXT	NODETYP
BADCTLFL	DEVHIPR (F)	KEYWORD (F)	(Continued)
BADPVFL (F)	DEVHITP (F)	KFF	
BADPVPR (F)	DEVLOFL	KGAP	
BFF	DEVLOPR (F)	KLIN	

Pid With Feed Forward (Continued)

NTWKNUM	PTINAL	PVROCPPR (F)	SPHIFL
OP	PTORST	PVROCPTP (F)	SPHILM
OPALDB (F)	PV	PVSGCHTP (F)	SPLOFL
OPEU	PVALDB (F)	PVSOURCE (F)	SPLOLM
OPHAFL	PVALDBEU (F)	PVSRCOPT (F)	SPOPT
OPHIFL	PVAUTO	PVSTS	SPP
OPHILM	PVAUTOST	PVTRACK	SPTV
OPHIPR	PVEUHI	RAMPTIME	SPTVP
OPHITP	PVEULO	RARWSTS	STDBYMAN
OPLAFL (F)	PVFORMAT	RATIO	T1
OPLOFL	PVHHFL	RBOPT	T2
OPLOLM	PVHHPR (F)	RCASOPT	TVPROC
OPLOPR	PVHHTP (F)	RCASSHED	UNIT
OPLOTP	PVHIFL	REDTAG (F)	
OPMCHLM	PVHIPR (F)	RINITREQ	
OPRATRFL	PVHITP (F)	RINITVAL	
OPROCLM	PVLLFL	RTHILM	
OVERVAL (F)	PVLLPR (F)	RTLQLM	
PERIOD	PVLLTP (F)	SAFEOP	
PIDFORM	PVLOFL	SHEDMODE	
PNTFORM	PVLOTP (F)	SHEDTIME	
PNTMODTY	PVLOPR (F)	SHUTDOWN	
PNTNODTY	PVP	SLOTNUM	
PNTSTATE	PVROCNFL	SP	
PNTTYPE	PVROCNP (F)	SPEUHI	
PTDESC (F)	PVROCNT (F)	SPEULO	
PTEXECST	PVROCPFL	SPFORMAT	

Position Proportional

The parameters of the Position Proportional control algorithm are listed below in Alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	BADCTLFL	ESWAUTO	MODNUM
\$CDETAIL	BADPVFL	ESWCAS	NAME
\$DHSELECT (F)	BADPVR (F)	ESWENBST	NMODATTR
\$DLBADAL (F)	CASREQ	ESWMAN	NMODE
\$DLSELECT (F)	CIDSTN	EUDESC (F)	NOCINPTS
\$HHSELECT (F)	CISRC	EXTSWOPT	NOCOPTS
\$HSELECT (F)	CODSTN	HIGHAL (F)	NODENUM
\$LLSELECT (F)	CONTCUT (F)	HIGHALPR (F)	NODETYP
\$LOSELCT (F)	CTLALGID	INITMAN	NTWKNUM
\$MODESEL	CTRLINIT	KEYWORD (F)	OP
\$REALARM (F)	CV	LASTPV	OPCMD
\$RNSLECT (F)	CVEUHI	LOCALMAN	OPEU
\$RPSLECT (F)	CVEULO	LOWERTIM	OPHIFL
ADVDEVFL	CYCLETIM	LOWRDSTN	OPHILM
ADVDEVPR (F)	DEADBAND	LOWRRATE	OPLOFL
ADVDEVTP (F)	DEADTIME	MANMODFL	OPLOLM
ADVSP (F)	DEV	MANOPCMD	OPMCHLM
ADVSP (F)	DEVHIFL	MANOPTIM	OPRATRFL
ALBNBST (F)	DEVHIPR (F)	MAXPULSE	OPROCLM
ARWNET	DEVHITP (F)	MINPULSE	OVERVAL (F)
ARWOP	DEVLOFL	MODATTR	(Continued)
ASPPROC (F)	DEVLOPR (F)	MODE	
ASSOCDSP	DEVLOTP (F)	MODEAPPL	
AUTMODFL	DLYTIME (F)	MODEPERM	

Postion Proportional (Continued)

PERIOD
PNTFORM
PNTMODTY
PNTNODTY
PNTSTATE
PNTTYPE
PRIMMOD (F)
PTDESC (F)
PTEXECST
PTINAL
PTORST
PV
PVALDB (F)
PVALDBEU (F)
PVAUTO
PVAUTOST
PVEUHI
PVEULO
PVFORMAT
PVHHFL
PVHHPR (F)
PVHHTP (F)
PVHITP (F)
PVHIFL
PVHIPR (F)
PVLLFL
PVLLPR (F)

PVLLTP (F)
PVLOFL
PVLOPR (F)
PVLOTP (F)
PVP
PVROCNFL
PVROCNPR (F)
PVROCNTP (F)
PVROCPFL
PVROCPPR (F)
PVROCTP (F)
PVSGCHTP (F)
PVSOURCE (F)
PVSRCOPT (F)
PVSTS
RAISDSTN
RAISETIM
RAISRATE
RAMPTIME
RARWSTS
RCASOPT
RCASSHED
REDTAG (F)
RINITREQ
RINITVAL
RP

RT
SAFEOP
SHEDMODE
SHEDTIME
SHUTDOWN
SLOTNUM
SP
SPEUHI
SPEULO
SPFORMAT
SPHIFL
SPHILM
SPLOFL
SPLOLM
SPOPT
SPP
SPTV
SPTVP
STDBYMAN
TVPROC
UNIT

Ramp Soak

The parameters of the Ramp Soak control algorithm are listed below in alphabetical Order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	CODSTN	EUDESC (F)	NOCOPTS
\$CDETAIL	CONTCUT (F)	EXTSWOPT	NODENUM
\$DHSELECT (F)	CTLALGID	HIGHAL (F)	NODETYP
\$DLSELECT (F)	CTRLINIT	HIGHALPR (F)	NORSSEQ
\$MODESEL	CURSEGID	HOLDCMD (F)	NTWKNUM
\$REALARM (F)	CV	INITMAN	NXTSOAKV
ADVDEVFL	CVEUHI	KEYWORD (F)	OP
ADVDEVPR (F)	CVEULO	LASTPV	OPEU
ADVDEVTP (F)	CYCLEOPT	LOCALMAN	OPHIFL
ADVSP (F)	DEV	MANMODFL	OPHILM
ADVSP (F)	DEVHPR (F)	MODATTR	OPLOFL
ALNBST (F)	DEVHIFL	MODE	OPLOLM
ARWNET	DEVHITP (F)	MODEAPPL	OPMCHLM
ARWOP	DEVLOFL	MODEPERM	OPRATRFL
ASPPROC (F)	DEVLOPR (F)	MODNUM	OPROCLM
ASSOCDSP	DEVLOTP (F)	MXRMPDEV	OVERVAL (F)
AUTMODFL	DLYTIME (F)	MXSOKDEV	PERIOD
BADCTLFL	ESWAUTO	NAME	PNTFORM
CASREQ	ESWCAS	NMODATTR	
CIDSTN	ESWENBST	NMODE	(Continued)
CISRC	ESWMAN	NOCINPTS	

Ramp Soak (Continued)

PNTMODTY	RATE11	SOAKT10	STDBYMAN
PNTNODTY	RATE12	SOAKT11	TVPROC
PNTSTATE	REDTAG (F)	SOAKT12	UNIT
PNTTYPE	REMSOAKT	SOAKV1	
PRIMMOD	RINITREQ	SOAKV2	
PTDESC (F)	RINITVAL	SOAKV3	
PTEXECST	S1	SOAKV4	
PTINAL	S1BGNTIM	SOAKV5	
PTORST	S1ENDTIM	SOAKV6	
PV	S1SEGID	SOAKV7	
PVEUHI	S2	SOAKV8	
PVEULO	S2BGNTIM	SOAKV9	
PVFORMAT	S2ENDTIM	SOAKV10	
PVP	S2SEGID	SOAKV11	
PVSTS	SAFEOP	SOAKV12	
RAMPTIME	SEGTYPE	SP	
RARWSTS	SHUTDOWN	SPEUHI	
RATE1	SLOTNUM	SPEULO	
RATE2	SOAKT1	SPFORMAT	
RATE3	SOAKT2	SPHIFL	
RATE4	SOAKT3	SPHILM	
RATE5	SOAKT4	SPLOFL	
RATE6	SOAKT5	SPLOLM	
RATE7	SOAKT6	SPOPT	
RATE8	SOAKT7	SPP	
RATE9	SOAKT8	SPTV	
RATE10	SOAKT9	SPTVP	

Ratio Control

The parameters of the Ratio Control control algorithm are listed below in Alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	AUTMODFL	DLYTIME (F)	NMODE
\$CDETAIL	B1	ESWAUTO	NOCINPTS
\$DHSELECT (F)	B2	ESWCAS	NOCOPTS
\$DLBADAL (F)	BADCTLFL	ESWENBST	NODENUM
\$DLSELECT (F)	BADPVFL	ESWMAN	NODETYP
\$HHSELECT (F)	BADPVPR (F)	EUDESC (F)	NTWKNUM
\$HISELECT (F)	CASREQ	EXTSWOPT	OP
\$LSELECT (F)	CIDSTN	HIGHAL (F)	OPALDB
\$LOSELECT (F)	CISRC	HIGHALPR (F)	OPEU
\$MODESEL	CODSTN	INITMAN	OPHAFL
\$REALARM (F)	CONTCUT (F)	K1	OPHIFL
\$RNSELECT (F)	CTLALGID	K2	OPHILM
\$RPSELECT (F)	CTRLINIT	KEYWORD (F)	OPHIPR
ADVDEVFL	CV	LASTPV	(Continued)
ADVDEVPR (F)	CVEUHI	LOCALMAN	
ADVDEVTP	CVEULO	MANMODFL	
ADVSP (F)	DEV	MODATTR	
ADVSP (F)	DEVHIFL	MODE	
ALENBST (F)	DEVHIPR (F)	MODEAPPL	
ARWNET	DEVHITP (F)	MODEPERM	
ARWOP	DEVLOFL	MODNUM	
ASPPROC (F)	DEVLOPR (F)	NAME	
ASSOCDSP	DEVLOTP (F)	NMODATTR	

Ratio Control (Continued)

OPHITP	PVAUTOST	PVSRCOPT (F)	SPTVP
OPLAFL	PVEUHI	PVSTS	STDBYMAN
OPLOFL	PVEULO	RAMPTIME	TVPROC
OPLOLM	PVFORMAT	RAWSTS	UNIT
OPLOPR	PVHHFL	RCASOPT	X2
OPLOTP	PVHHPR (F)	RCASSHED	
OPMCHLM	PVHHTP (F)	REDTAG (F)	
OPRATRFL	PVHIFL	RINITREQ	
OPROCLM	PVHIPR (F)	RINITVAL	
OVERVAL (F)	PVHITP (F)	SAFEOP	
PERIOD	PVLLFL	SHEDMODE	
PNTFORM	PVLLPR (F)	SHEDTIME	
PNTMODTY	PVLLTP (F)	SHUTDOWN	
PNTNODTY	PVLOFL	SLOTNUM	
PNTSTATE	PVLOPR (F)	SP	
PNTTYPE	PVLOTP (F)	SPEUHI	
PRIMMOD (F)	PVP	SPEULO	
PTDESC (F)	PVROCNFL	SPFORMAT	
PTEXECST	PVROCNPR (F)	SPHIFL	
PTINAL	PVROCNTP (F)	SPHILM	
PTORST	PVROCPFL	SPLOFL	
PV	PVROCPPR (F)	SPLOLM	
PVALDB (F)	PVROCPPT (F)	SPOPT	
PVALDBEU (F)	PVSGCHTP (F)	SPP	
PVAUTO	PVSOURCE (F)	SPTV	

Summer

The parameters of the Summer PV algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	C4	OVERVAL (F)	PNTNODTY
\$CDETAIL	C5	P1	PNTSTATE
\$DLBADAL(F)	C6	P1STS	PNTTYPE
\$HHSELECT (F)	CONTCUT	P2	PRIMMOD (F)
\$HISELCT (F)	D	P2STS	PTDESC (F)
\$LSELECT (F)	DLYTIME (F)	P3	PTEXCST
\$LOSELCT (F)	EUDESC (F)	P3STS	PTINAL
\$REALARM (F)	HIGHAL (F)	P4	PV
\$RNSLCT (F)	HIGHALPR (F)	P4STS	PVALDB (F)
\$RPSLCT (F)	KEYWORD (F)	P5	PVALDBEU (F)
ALENBST (F)	LASTPV	P5STS	PVALGID
ASSOCDSP	N	P6	PVAUTO
BADPVFL (F)	MODNUM	P6STS	PVAUTOST
BADPVPR (F)	NAME	PERIOD	PVCALC (Continued)
C	NODENUM	PIDSTN	
C1	NODETYP	PISRC	
C2	NOPINPTS	PNTFORM	
C3	NTWKNUM	PNTMODTY	

Summer (Continued)

PVCLAMP	PVROCPPR (F)
PVEQN	PVROCPTP (F)
PVEULO	PVSGCHTP (F)
PVEUHI	PVSOURCE (F)
PVEXEUHI	PVSRCOPT (F)
PVEXEULO	PVSTS
PVEXHIFL	PVTV (F)
PVEXLOFL	PVTVP (F)
PVFORMAT	SLOTNUM
PVHHFL	TF
PVHHPR (F)	UNIT
PVHHTP (F)	
PVHIFL	
PVHIPR (F)	
PVHITP (F)	
PVINIT	
PVLLFL	
PVLLPR (F)	
PVLLTP (F)	
PVLOFL	
PVLOPR (F)	
PVLOTP (F)	
PVP	
PVROCNFL	
PVROCNPR (F)	
PVROCNTP (F)	
PVROCPFL	

Switch

The parameters of the Switch control algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$CDETAIL	CVEUHI	MODNUM
\$DLBADAL (F)	CVEULO	NAME
\$MODESEL	DLYTIME (F)	NMODATTR
\$REALARM (F)	ESWAUTO	NMODE
ALENBST (F)	ESWCAS	NOCINPTS
ARWNET	ESWENBST	NOCOPTS
ARWOP	ESWMAN	NODENUM
ASSOCDSP	EUDESC (F)	NODETYP
AUTMODFL	EXTSWOPT	NTWKNUM
BADCTFL	HIGHAL (F)	OP
BADCTLPR (F)	HIGHALPR (F)	OPALDB
CASREQ	INITMAN	OPEU
CIDSTN	KEYWORD (F)	OPHAFL
CISRC	LOCALMAN	OPHIFL
CODSTN	M	OPHILM
CONTCUT (F)	MANMODFL	OPHIPR
CTLALGID	MODATTR	OPHITP
CTLEQN	MODE	(Continued)
CTRLINIT	MODEAPPL	
CV	MODEPERM	

Switch (Continued)

OPLAFL	S2
OPLOFL	S3
OPLOLM	S4
OPLOPR	SAFEOP
OPLOTP	SELXINP
OPMCHLM	SHEDMODE
OPRATRFL	SHEDTIME
OPROCLM	SHUTDOWN
OVERVAL (F)	SLOTNUM
PERIOD	STDBYMAN
PNTFORM	TRACKING
PNTMODTY	UNIT
PNTNODTY	X1
PNTSTATE	X2
PNTTYPE	X3
PRIMMOD (F)	X4
PTDESC (F)	XEUHI
PTEXECST	XEULO
PTINAL	
PTORST	
RARWSTS	
RCASOPT	
RCASSHED	
REDTAG	
RINITREQ	
RINITVAL	
S1	

Totalizer

The parameters of the Totalizer PV algorithm are listed below in alphabetical order.
(F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	COMMAND	PISRC
\$CDETAIL	CONTCUT (F)	PNTFORM
\$DLBADAL (F)	CUTOFFLM	PNTMODTY
\$HHSELECT (F)	DLYTIME (F)	PNTNODTY
\$HISELCT (F)	EUDESC (F)	PNTSTATE
\$LSELECT (F)	HIGHAL (F)	PNTTYPE
\$LOSELCT (F)	HIGHALPR (F)	PRIMMOD (F)
\$MODESEL	KEYWORD (F)	PTDESC (F)
\$REALARM (F)	LASTPV	PTEXECST
\$RNSLCT (F)	MODNUM	PTINAL
\$RPSELCT (F)	NAME	PV
ACCTYPE	NODENUM	PVALDB (F)
ALENBST (F)	NODETYP	PVALDBEU
ASSOCDSP	NOPINPTS	PVALGID
AVDEV1FL	NTWKNUM	PVAUTO
AVDEV1TP	OLDAV	PVAUTOST
AVDEV2FL	OVERVAL (F)	PVCALC
AVDEV2TP	P1	PVCLAMP
AVTV	P1STS	PVEQN
AVTVFL	P2	PVEUHI
BADPVFL	P2STS	(Continued)
BADPVPR (F)	PERIOD	
C	PIDSTN	

Totalizer (Continued)

PVEULO	PVROCPFL
PVEXEUHI	PVROCPPR (F)
PVEXEULO	PVROCPTP (F)
PVEXHIFL	PVSGCHTP (F)
PVEXLOFL	PVSOURCE (F)
PVFORMAT	PVSRCOPT (F)
PVHHFL	PVSTS
PVHHPR (F)	PVTV (F)
PVHHTP (F)	PVTVP (F)
PVHIFL	RESETFL
PVHIPR (F)	RESETVAL
PVHITP (F)	SLOTNUM
PVINIT	STARTFL
PVLLFL	STATE
PVLLPR (F)	STOPFL
PVLLTP (F)	TF
PVLOFL	TIMEBASE
PVLOPR (F)	UNIT
PVLOTP (F)	
PVP	
PVROCNFL	
PVROCNPR (F)	
PVROCNTP (F)	

Variable Dead Time With Lead/Lag

The parameters of the Variable Dead Time With Lead/Lag PV algorithm are listed below in Alphabetical order. (F) indicates that the parameter is applicable when the PNTFORM = Full.

\$ALDLOPT (F)	EUDESC (F)	PNTSTATE
\$CDETAIL	HIGHAL (F)	PNTTYPE
\$DLBADAL	HIGHALPR (F)	PRIMMOD (F)
\$HHSELECT (F)	KEYWORD (F)	PTDESC (F)
\$HISELECT (F)	LASTPV	PTEXCST
\$LSELECT (F)	MODNUM	PTINAL
\$LOSELECT (F)	NAME	PV
\$REALARM (F)	NLOC	PVALDB (F)
\$RSELECT (F)	NODENUM	PVALDBEU (F)
\$RPSELECT (F)	NODETYP	PVALGID
ALENBST (F)	NOPINPTS	PVAUTO
ASSOCDSP	NTWKNUM	PVAUTOST
BADPVFL (F)	OVERVAL (F)	PVCLC
BADPVPR (F)	P1	PVCLAMP
C	P1STS	PVEQN
C1	P2	PVEUHI
C2	P2STS	PVEULO
CONTCUT (F)	PERIOD	PVEXEUHI
CUTOFFLM	PIDSTN	
D	PISRC	(Continued)
D1	PNTFORM	
D2	PNTMODTY	
DLYTIME	PNTNODTY	

Variable Dead Time With Lead/Lag (Continued)

PVEXEULO	PVSOURCE (F)
PVEXHIFL	PVSRCOPT (F)
PVEXLOFL	PVSTS
PVFORMAT	PVTV (F)
PVHHFL	PVTVP (F)
PVHHPR (F)	SLOTNUM
PVHHTP (F)	TD
PVHIFL	TF
PVHIPR (F)	TLD
PVHITP (F)	TLG1
PVINIT	TLG2
PVLLFL	UNIT
PVLLPR (F)	
PVLLTP (F)	
PVLOFL	
PVLOPR (F)	
PVLOTP (F)	
PVP	
PVROCNFL	
PVROCNPR (F)	
PVROCNP (F)	
PVROCPFL	
PVROCPR (F)	
PVROCPTP (F)	

Parameter	Description	Type	Lock	(Default) and Range
\$ALDLOPT	Alarm Delay Option (R620 & later)	e:	Eng	(None); OffDlyLo, OffDlyHi, OffDlyEm, OnDlyLo, OnDlyHi, OnDlyEm
\$CDETAIL	Custom Schematic Name (R620 & later)	S	Eng	(8 space characters); Any 8 character string valid for a schematic name
\$DBVALID	PM Database Valid	e:	Eng	(DBInvalid); DB_Valid, DBInvalid
\$DLBADAL	Delay for BADPV (R681 & later)	e:	Eng	(None); None, Offdelay
\$DHSELECT	Deviation High Selective Cutout (R681 & later)	e:	Eng	(Cutout); Cutout, Allow
\$DLSELECT	Deviation Low Selective Cutout (R681 & later)	e:	Eng	(Cutout); Cutout, Allow
\$DLYOPT	Digital Input Alarm Delay Option (R660 & later)	e:	Eng	(None); PmOffDly, NmOffDly, NmOnDly If you migrate to R660, the default is PmOffDly
\$EVNTREC	Number of Event Receivers	I	View	(N/A); N/A
\$HHSELECT	PV High High Selective Cutout (R681 & later)	e:	Eng	(Cutout); Cutout, Allow
\$HISELECT	PV High Selective Cutout (R681 & later)	e:	Eng	(Cutout); Cutout, Allow
\$IOBSFm(n)	Box Soft Failure Status (m = 1-64), (n = 1-168)	I	View	(); 0-FF
\$IOFSLm(n)	Slot with Failures (m = 1-32), (n = 1-168)	I	View	(); 0-FF
\$IOMPADD(n)	OP Address (n = 1 - 168)	I	View	(); 0, 129-255

Parameter	Description	Type	Lock	(Default) and Range
\$IOSSFm (n)	Slot Soft Failures (m = 1-64), (n = 1-168)	I	View	(); 0-FF
\$LLSELECT	PV Low Low Selective Cutout (R681 & later)	e:	Eng	(Cutout); Cutout, Allow
\$LOSELECT	PV Low Selective Cutout (R681 & later)	e:	Eng	(Cutout); Cutout, Allow
\$MODESEL	Mode Selection List (R630 & later) Refer PM Family Parameter Reference Dictionary for more information.	L	Eng	All the modes and mode attributes applicable for a point type that can be changed from a display.
\$OFSELECT	Off Normal Selective Cutout (R681 & later)	e:	Eng	(Cutout); Cutout, Allow
\$OLDEVDS	Open-Line Detect Event Disable (AnalogIn) (R640 & later)	e:	Eng	(Enable); Enable, Disable (for the LLAI / LLMUX AI points having sensor type of Thermocouple or RTD). (NoOTDetc) for all other AI points. (Enable); Enable, Disable
	Open-Line Detect Event Disable (AnalogOut) (R640 & later)	e:	Eng	
\$PMDLYTM	Value of IOP DLYTIME parameter for Digital Input points that have been configured as STATUS points (R660 & later)	I	View	(5); 0 - 60 Seconds
\$REALARM	Re-arming Interval (R660 & later)	I	Eng	(0) No alarm; 0 through 9999 minutes (if configured, value ranges from one minute to approximately 167 hours)
\$RNSELECT	PV Negative Rate of Change Selective Cutout (R681 & later)	e:	Eng	(Cutout); Cutout, Allow

Parameter	Description	Type	Lock	(Default) and Range
\$RPSELECT	PV Positive Rate of Change Selective Cutout (R681 & later)	e:	Eng	(Cutout); Cutout, Allow
\$UCNLSBn	Local UCN Communications Statistics	R	View	(N/A); N/A
ABHEMSD	Abnormal Handler Emergency Shutdown Enable Flag	L	View	(Off); On – Off
ABHHOLD	Abnormal Handler Hold Enable Flag	L	View	(Off); On – Off
ABHRSTR	Abnormal Handler Restart Enable Flag	L	View	(Off); On – Off
ABHSHDN	Abnormal Handler Shtdn Enable Flag	L	View	(Off); On – Off
ACCTYPE	Accumulator Operation Mode	e:	Eng/PB	(Analog); Pulse, Analog
ACP	Advanced Control Data Point	E	PB	(Null); A-Z, 0-9, _
ACTPRIM(n)	Acting Primary I/O Module (n = 1 - 40)	e:	View	(); IOM_A, IOM_B
ADVDEVFL	Advisory Deviation Alarm Flag	L	View	(Off); On – Off
ADVDEVPR	Advisory Deviation Alarm Priority	e:	Eng/PB	(NoAction – R670); Low, Emergency, High, Journal, NoAction, Printer, JnlPrint
ADVDEVTP	Advisory Deviation Alarm Trip Point	R	Supr	(NaN); ≥ 0.0, NaN
ADVSP	Advisory Setpoint in Engineering Units	R	Supr	(N/A); SPLOLM – SPHILM
ADVSPPP	Advisory Setpoint in Percent	R	View	(N/A); N/A
ALNBST	Alarm Enable Status	e:	Oper	(Enable); Enable, Disable, Inhibit
ALMOPT	Alarming Option (DigIn)	e:	Eng/PB	(None); Offnorml, Cmddis, None (None); Offnorml, None
ALPRIOR	Alarm Priority	e:	Eng/PB	(Low); Low, Emergency, High, Journal, NoAction, Printer, JnlPrint

Parameter	Description	Type	Lock	(Default) and Range
AOCALIB(n)	AO Calibration in Prog. Flag (n = 1 - 168)	L	Eng/PB	(); Off, - On
ARWNET	Windup Status of the Input	e:	View	(Normal); Normal, Hi, Lo, HiLo
ARWOP	Windup Status of the Output	e:	View	(Normal); Normal, Hi, Lo, HiLo
ASPPROC	Advisory SP Processor State	e:	Supr	(Disable); Disable, Enable
ASSOCDSP	Associated Display	S	Eng	(Blank); N/A
ASTEP(n)	Abnormal Step Name (n = 1 - 3)	S	View	(Blank); N/A
ASTEPIDX(n)	Abnormal Step Name Index (n = 1 - 3)	I	View	(Blank); 0 - 3000
ASTMT(n)	Abnormal Statement Number (n = 1 - 3)	I	View	(Blank); 0 - 255
AUTMODFL	Automatic Mode Flag	L	View	(N/A); Off - On
AV	Accumulated Value in Engineering Units	I	View	(0); 0 - 32767
AVDELTHS	The Last Half-Second's AV	I	View	(0); ≥ 0
AVDEV1TP	Accumulated Value - 1st Deviation Trip Point	R	Supr	(NaN); ≥ 0.0 , NaN
AVDEV2FL	Accumulated Value - 2nd Deviation Flag	L	View	(N/A); Off - On
AVDEV2TP	Accumulated Value - 2nd Dev. Trip Point	R	Supr/PB	(NaN); ≥ 0.0 , NaN
AVGTF	Avg. Statistics Single Lag Filter	R	View	(1 minute); N/A
AVSTS	Value Status of AV	e:	View	(Bad); Bad, Normal
AVTV	Accumulator Target Value (Dign)	I	Oper	(0); 0 - 32767
	Accumulator Target Value (Totalizr)	R	Oper/PB	(NaN); N/A, NaN
AVTVFL	Accumulated Value Target Reached Flag	L	View	(N/A); Off - On
B	Overall Bias	R	Oper/PB	(0.0); N/A
B0	Last Operator Entered Output Bias	R	View	(0.0); N/A

Parameter	Description	Type	Lock	(Default) and Range
B1	Output Bias Constant	R	Supr/PB	(0.0); N/A
B2	Bias for Input X2	R	Supr/PB	(0.0); N/A
BADCTLFL	Bad Control Alarm Flag	L	View	(Off); Off – On
BADCTLPR	Bad Control Alarm Priority	e:	Eng/PB	(NoAction – R670); Low, Emergency, High, Journal, NoAction, Printer, JnlPrint
BADOCFL	Bad Output Connection Alarm Flag	L	View	(Off); Off – On
BADOCnFL	Bad Output Connection Flag n. (n = 1 - 4)	L	View	(Off); Off – On
BADOCPR	Bad Output Conn. Alarm Priority	e:	Eng/PB	(NoAction – R670); Low, Emergency, High, Journal, NoAction, Printer, JnlPrint
BADOCPT	Bad Output Conn. Alarm Option	L	Eng/PB	(Off); Off – On
BADPVFL	Bad PV Alarm Flag	L	View	(Off); Off – On
BADPVPR	Bad PV Alarm Priority	e:	Eng/PB	(NoAction – R670); Low, Emergency, High, Journal, NoAction, Printer, JnlPrint
BADPVTXT	Bad PV Text Descriptor	S	PB	(BAD); A-Z, 0-9, _
BATCHID	Batch Identifier	S	PB	(Blank); A-Z, 0-9, _
BFF	Feed Forward Input Bias	R	Supr	(0.0); N/A
BHALMF(n)	Alarm Flags (n = 1 - 7)	S	View	(); 0 0-FF
BIAS	Bias	R	Oper/PB	(0.0); BSLOLM – BSHILM; 0 0-FF
BNDRESET	Bounds Statistics Reset Flag	L	Oper	(Off); Off - On
BNDRSTIM	Last Bounds Statistics Reset	T	View	(PM Startup Time); N/A

Parameter	Description	Type	Lock	(Default) and Range
BOXCLR(n)	Box Color for Digital Displays (DigComp)	e:	Eng/PB	(Green – Upper Box Default, State 1); (Red – Lower Box Default, State 2); (Yellow – Middle Box Default, State 0); Red, Green, White, Black, Cyan, Yellow, Blue, Magenta
	Box Color for Digital Displays (DigIn, Flag)	e:	Eng/PB	(Green – Upper Box Default, State 1); (Yellow – Lower Box Default, State 0); Red, Green, White, Black, Cyan, Yellow, Blue
BSHILM	Bias High Limit	R	Supr	(50.0); $\geq$ BSLOLM, NaN
BSLOLM	Bias Low Limit	R	Supr	(-50.0); $\leq$ BSHILM, NaN
BYPASS	Interlock Bypass	L	Oper	(Off); Off - On
BYPASSX1-4	Bypass ORSel's X1 - X4 Input	L	Oper	(BYPASSX1 = Off); Off-On (BYPASSX2-X4 = On);
C	Scaling Factor	R	Supr	(1.0); Anything except NaN
C1-C2	Correction Constant (FlowComp)	R	Supr	(1.0); $C1 \geq 0.1$, $C2 \geq 0.1$
	Scaling Constant for Input P1-P2 (VdtLdLag)	R	Supr	(1.0); ≥ 0.0
	Scaling Constants Used to Calculate PVCALC (PI)	R	Supr	(1.0); $C1 \geq 0$, $C2 > 0$
C1-C4	Intermediate Results of Calculations (CaICuLtr)	R	Supr	(N/A); N/A

Parameter	Description	Type	Lock	(Default) and Range
C1-C6	Scaling Constants 1-6 (Summer)	R	Supr	(1.0); N/A
CABLESTS	Overall Cable Status for UCN Node	I	View	(N/A); 0, 1, 2 or 3
CALCEXP	Calculator Expression	S	Eng/PB	(Blank); N/A
CALIBALL(n)	Full Calibration Enable Flag (n = 1 - 4)	L	Eng/PB	(Off); Off – On
CALIBRJ(n)	Reference Junction Calibration Enable Flag (n = 1 - 40)	L	Eng/PB	(Off); Off – On
CASREQ	Remote Cascade Request	e:	Prog	(NotReq); NotReq, Request
CHPINHWY	Automatic Checkpoint Inhibit	e:	Supr	(Enable); Enable, Inhibit
CHPINOPR	Automatic Checkpoint Inhibit Operation	e:	Supr	(Enable); Enable, Inhibit
CIDSTN(n)	Control Input Connection Destination (n = 1 - 40)	P	PB	(Varies by Algo Type, Equation, N); N/A
CISRC(n)	Control Input Connection Source (n = 1 - 40)	E	PB	(Null.Null); "TagName.Parameter"
CJTACTION	Internal Cold Junction Temperature	L	Eng/PB	(Off); On – Off
CLPZMXC	Overall Cable Status for UCN Cable A	L	View	(N/A); Off – On
CLPZMXP	Overall Cable Status for UCN Cable B	L	View	(N/A); Off – On
CMDDISFL	Command Disagree Alarm Flag	L	View	(Off); Off – On
CMDDISPR	Command Disagree Alarm Priority	e:	Eng	(NoAction – R670); Low, Emergency, High, Journal, NoAction, Printer, JnlPrint
CMDFALFL	Command Fail Alarm Flag	L	View	(Off); Off – On
CNTLLOCK	Control Lock	e:	Eng	(Operator); Operator, Supervis, Engineer, Program
CODSTN(n)	Control Output Connection Destination (n = 1 - 4)	E	PB	(Null.Null); "TagName.Parameter" or "IMTmmSss.Parameter"

Parameter	Description	Type	Lock	(Default) and Range
COMCFAVG	Avg. PM Comm. CPU Free %	R	View	(NaN); 0 – 100
COMCFMAX	Max. PM Comm. CPU Free %	R	View	(NaN); 0 – 100
COMCFMIN	Min. PM Comm. CPU Free %	R	View	(NaN); 0 – 100
COMMAND	Accumulator Commands (DigIn, Totalizr) Timer Commands (Timer) STI Point/Database Transfer; STI Calibration	e: e: e:	Oper Oper Oper	(None); None, Start, Stop, Reset (None); None, Start, Stop, Reset, RestStrt (None); None, DnLoadDb, UpLoadDb, Set_LRV, Set_URV, Cor_LRV, Cor_URV, Cor_Inpt, RstCor
COMPILM	Compensation Term High Limit	R	Supr	(1.25); COMPLOLM - 10.0, NaN
COMPLOLM	Compensation Term Low Limit	R	Supr	(0.8); 0.0 - COMPILM, NaN
COMPTERM	Compensation Term	R	View	(1.0); COMPLOLM – COMPILM
CONTCUT	Contact Cutout	L	Prog	(Off); Off – On
COUNTDWN	Accumulator Count Down Flag	L	Eng/PB	(Off); Off – On
CRIOLORN	Current Hour I/O LinkFetch/Store Overrun Counter	I	View	(0); ≥ 0
CRPPXORN(n)	Current Hr Pt. Processing Overrun Counter (n = 1 - 8)	I	View	(0); ≥ 0
CRUCNORN	Current Hour UCN Fetch/Store Overrun Counter	I	View	(0); ≥ 0
CTLACTN	Control Action	e:	Eng/PB	(Reverse); Direct, Reverse

Parameter	Description	Type	Lock	(Default) and Range
CTLALGID	Control Algorithm Identifier	e:	PB	(Null); Null, Pid, PidErfb, PidFF, RatioCtl, IncrSum, Switch, PosProp, AutoMan, RampSoak, ORSel
CTLCFAVG	Avg. PM Ctl. Processor Free %	R	View	(NaN); 0 – 100
CTLCFMAX	Max. PM Ctl. Processor Free %	R	View	(NaN); 0 – 100
CTLCFMIN	Min. PM Ctl. Processor Free %	R	View	(NaN); 0 – 100
CTLEQN	Control Equation Type (AutoMan, ORSel, Switch)	e:	Eng/PB	(EqA); EqA, EqB
	Control Equation Type (Pid algos)	e:	Eng/PB	(EqA); EqA, EqB, EqC, EqD
CTLOPT	PMM Control Processor Option	L	PB	(On); Off – On
CTLREDUN	PMM Control Redundancy Present Flag	e:	View	(); Off- On
CTRLINIT	Control Initialization Request Flag	L	Prog	(Off); Off- On
CURSEGID	Current Segment ID	L	Oper	(Ramp1); Ramp1/Soak1 to Ramp12/Soak12
CUTOFFLM	Zero-Flow/Belt-Speed Cut-Off Limit	R	Supr	(0.0); ≥ 0.0, NaN
CV	Calculated Variable	R	Prog	(NaN); N/A
CVEUHI	CV's High Limit in Engineering Units	R	Eng	(100.0); ≥ CVEULO
CVEULO	CV's Low Limit in Engineering Units	R	Eng	(0.0); ≤ CVEUHI
CYCLOPT	Ramp Soak Cycle Option	e:	Oper	(Cyclic); Single, Cyclic
CYCLETIM	PosProp Output Cycle Time in Seconds	R	Supr	(10.0); 0.25 - 1000.0 Seconds
D	Overall Bias	R	Supr	(0.0); N/A
D1	Fixed Dearthime in Minutes (VdtLdLag)	R	Supr	(0.0); 0.0 - 400.0 Minutes

Parameter	Description	Type	Lock	(Default) and Range
D1_0	Digital Input 1 Equal to a PV State of 0 (DigComp)	e:	View	(PVState0); PVState0, PVState1
D1_1	Digital Input 1 Equal to a PV State of 1 (DigComp)	e:	Eng/PB	(PVState0); PVState0, PVState1 (Off); Off – On
D1, D2	Status of Digital Inputs 1 & 2 (DigComp)	L	View	(0.0); ≥ 0.0
D2	Bias for Input D2 (VdtLdLag)	R	Supr	(MovPV); MovPV, PVState0,
D2D1_00	D2_D1 Zero_Zero PV State	e:	Eng/PB	PVState1, PVState2, BadPV (PVState0); PVState0, MovPV
D2D1_01	D2D1 Zero_One PV State	e:	Eng/PB	PVState1, PVState2, BadPV (PVState1); PVState1, MovPV
D2D1_10	D2D1 One_Zero PV State	e:	Eng/PB	PVState0, PVState2, BadPV (BadPV); BadPV, PVState0,
D2D1_11	D2D1 One_One PV State	e:	Eng/PB	PVState1, PVState2, MovPV
DAMPING	First Order PV Filtering Option for the Smart Transmitter	R	Supr/View	(0.0); 0.0 – 102.3, NaN
DB_VALID	Database Valid, (n = 1 - 40)	e:	Engr	(Invalid); Valid, Invalid
DEADBAND	Deadband Value (Logic)	R	Supr	(1.0); ≥ 0.0
	Deadband in % of Full Scale (PosProp)	R	Supr	(5.0%); 0.0 - 100.0%
DEADTIME	Deadtime Value for Raise Pulse	R	Supr	(0.0); 0.0 - 60.0 Seconds
DECONF	Digitally Enhanced Configuration Mode	e:	Eng/View	(Pv_Sv_Db); PV, PV_Sv, PV_Db, Pv_Sv_Db
DEL CV	Delta CV in Eng Units (IncrSum)	R	View	(N/A); N/A
	Delta CV in Percent (Pid)	R	View	(N/A); N/A
DEV	Deviation	R	View	(N/A); N/A

Parameter	Description	Type	Lock	(Default) and Range
DEVHIFL	Deviation High Alarm Flag	L	View	(Off); Off – On
DEVHIPR	Deviation High Alarm Priority	e:	Eng/PB	(NoAction – R670); Low, Emergncy, High, Journal, NoAction, Printer, JnlPrint
DEVHITP	Deviation High Alarm Trip Point	R	Supr	(NaN); ≥0.0, NaN
DEVLOFL	Deviation Low Alarm Flag	L	View	(Off); Off – On
DEVLOPR	Deviation Low Alarm Priority	e:	Eng/PB	(NoAction – R670); JnlPrint, Printer, Emergncy, High, Low, Journal, NoAction
DEVLOTP	Deviation Low Alarm Trip Point	R	Supr	(NaN); ≥0.0, NaN
DISRC(n)	DigComp Input-Connection Source	U	PB	(Null.Null); "TagName.Parameter" or "!MTmmSss.Parameter" or "\$NMhhBxx.Parameter"
DITYPE	Digital Input Type	e:	PB	(Status); Status, Latched, Accum
DLYTIME	Alarm Delay in Seconds (DigIn)	I	Supr	(5); 0 - 60 Seconds
	Alarm Delay in Seconds for Logic Blocks (Logic)	R	Supr	(1); 1 - 8000 Seconds
	Alarm Delay in Seconds (AI, RegCtl, RegPV) (R620 & later)	e:	Eng	(0); 0 – 9999 Seconds
DODSTN(n)	DigComp Output Connection Destination (n = 1 - 3)	U	PB	(Null.Null); "TagName.Parameter" or "!MTmmSss.Parameter" or "\$NMhhBxx.Parameter"
DOTYPE	Digital Output Type	e:	PB	(Status); PWM, Status
EIPPCODE	Event-Initiated Point Identifier	E	PB	(Null); A-Z, 0-9, _
ESWAUTO	External Switching Flag for Auto Mode	L	Prog	(Off); Off – On

Parameter	Description	Type	Lock	(Default) and Range
ESWCAS	External Switching Flag for Cascade Mode	L	Prog	(Off); Off – On
ESWENBST	External Mode Switching Enable State	e:	Oper	(Disable); Disable, Enable
ESWMAN	External Switching Flag for Manual Mode	L	Prog	(Off); Off – On
EUDESC	Engineering Units Descriptor	S	PB	(Blank); A-Z 0-9 space ! % & ' () * + - / : ; > < = ? _ , . \$
EUNDESC	IOP Generic Descriptor, n = 1 – 168	S	View	(N/A); N/A
EVTOPT	Event Reporting Option (DigComp)	e:	PB	(None); None, Eip
	Event Reporting Option (DigIn)	e:	PB	(None); None, Eip, Soe, Eip_Soe
EXTSWOPT	External Mode Switching Option	e:	Eng/PB	(None); None, Ems, Emp
F	Flow Input	R	View	(NaN); N/A
FAILOPT	Failure Option for Outputs	e:	Eng/PB	(Unpower); Unpower, Hold
FBTIME	Feedback Time	I	Eng/PB	(1000); 1-1000 Seconds
FF	Feed Forward Algorithm Input	R	View	(N/A); N/A
FFOPT	Feed Forward Type	e:	Eng/PB	(Multiply); Multiply, Add
FL(n)	Box Flags FL(1) - FL(1023)	L	Oper	(Off); Off – On
	Process Module Flags FL(1) - FL(127)	L	Oper	(Off); Off – On
	Logic Slot Flags FL(1) - FL(12)	L	Special	(FL2 = On, rest = Off) (Off); Off-On
FORCE	Forced Input Request Flag	L	Oper	(Off); Off - On
FRCPERM	Forced Input Permissive	L	Eng/PB	(Off); Off - On
FREQ6050	Frequency 60/50 Hz for LLMUX or STT	e:	PB	(60Hz); 0 - 60 Hz, 1 - 50 Hz
FRQUTAVG	Average UCN Fetch Request Trip Time	R	View	(NAN); N/A
FRQUTMAX	Maximum UCN Fetch Request Trip Time	R	View	(NAN); N/A
FRSPTAVG	Average UCN Fetch Response Trip Time	R	View	(NAN); N/A

Parameter	Description	Type	Lock	(Default) and Range
FRSPTMAX	Max. UCN Fetch Response Trip Time	R	View	(NAN); N/A
FSELIN	Force Selected Input	e:	PB	(SelectP1); SelectP1 - SelectP6,
FSTS	Flow Input Value Status	e:	View	(Bad); Bad, Normal, Uncertn
FTACONN	FTA Connection to I/O Module This File	e:	View	(Conn_A); Conn_A, Conn_B
G	Specific Gravity Input	R	View	(1.0); N/A
GAINOPT	Gain (K) Option	e:	Eng/PB	(Lin); Lin, Gap, NonLin, Ext
GAPHI	Gap High Limit	R	Supr	(0.0); ≥ 0.0
GAPLO	Gap Low Limit	R	Supr	(0.0); ≥ 0.0
GENDESC(n)	Generic Descriptor (n = 1 - 12)	S	PB	(Blanks); A-Z 0-9 Space ! % & ' () * + - . : ; > < = ? _ , . \$
GENDESC(n)	Generic Descriptor (n = 1 - 40 or 129 - 168)	S	View	(Blanks); 1 - 40 = Acting Primary, 129 - 168 = Acting Secondary
GSTS	Gravity Input Value Status	e:	View	(Normal); Normal, Uncertn, Bad
HIGHAL	Highest Analog Alarm Detected (AnalogIn, PI, RegCtl, RegPV)	e:	View	(NoAlarm); NoAlarm, AvDev, DevHi, DevLo, PVROcN, PVROcP, PVHi, PVHH, PVLO, PVLL, BadCtl, BadPV, BOC
	Highest Digital Alarm Detected (Digital)	e:	View	(NoAlarm); NoAlarm, OffNorm, UnCEvt, CmdDis
HIGHALPR	Highest Level Alarm's Priority	e:	View	(Low); NoAction, Journal, Printer, JnlPrint, Low, High, Emergency
HOLDCMD	Hold Command Flag	L	Prog	(Off); Off - On
HWYCTLST	UCN Network Functional State	e:	Supr	(Basic); Basic, Full
I0 - I2	Override Interlocks for Output States 0-2	L	Eng	(Off); Off - On

Parameter	Description	Type	Lock	(Default) and Range
IN0 - IN12	Input Coordinates 0-12	R	Supr	(NaN); > Previous INn but ≤ Next INn. IN0 < IN1 < IN2 < IN12
INITMAN	Initialization Manual Flag	L	View	(On); Off – On
INITREQ	Initialization Request Flag	L	View	(Off); Off – On
	Initialization Request Flags (DO)	L	View	(On); Off – On
INITREQ(i)	Initialization Request Flags (DigComp) (i = 0 - 2)	L	View	(On); Off – On
INITVAL	Initialization Value	R	View	(N/A); N/A
INPTDIR	Input Direction	e:	Eng/PB	(Direct); Direct, Reverse
IOLASTS	I/O Link Cable A Status	L	View	(Off); Off – On
IOLBSTS	I/O Link Cable B Status	L	View	(Off); Off – On
IOLCHAER	I/O Link Channel A Error Count	I	View	(0); ≥ 0
IOLCHASL	I/O Link Channel A Silence Count	I	View	(0); ≥ 0
IOLCHBER	I/O Link Channel B Error Count	I	View	(0); ≥ 0
IOLCHBSL	I/O Link Channel B Silence Count	I	View	(0); ≥ 0
IOLCHERT	I/O Link Channel Error Threshold	I	EgOnly	(10); ≥ 0
IOLCMD	I/O Link Command	e:	EgOnly	(None); None, SelChnA, SelChnB, EnbPerSw, DisPerSw, RslolCom
IOLPERSW	I/O Link Periodic Cable Swap	e:	View	(N/A); Enable, Disable
IOMCARD(n)	I/O Module Card Position for the Acting Primary/Secondary n = 1-40 for Acting Primaries; n = 129-168 for Act. Secondaries	I	View	(N/A); 0 - 15

Parameter	Description	Type	Lock	(Default) and Range
IOMCARDA(n)	I/O Module A Card Position (n = 1 – 40)	I	PtBldr	(0); 0 – 15
IOMCARDB(n)	I/O Module B Card Position (n = 1 - 40)	I	PtBldr	(0); 0 – 15
IOMFILE(n)	I/O Module File Position for the Acting Primary/Sec. (n = 1 - 40, 129 - 168)	I	View	(0); 0 – 8
IOMFILEA(n)	I/O Module File A Position for the Acting Primary/Secondary (n = 1 - 40)	I	View	(0); 0 – 8
IOMFILEB(n)	I/O Module File B Position for the Acting Primary/Secondary (n = 1 - 40)	I	View	(0); 0 – 8
IOMFWREV	IOP Card Firmware Revision Status	A	View	(N/A); X.Y (X=Range, Y=Revision)
IOMHWREV	IOP Card Hardware Revision Status	A	View	(N/A); Hexadecimal "00" to "FF"
IOMLFHST	IOP Card Last Hard Fail Status	e:	View	(N/A); Unknown, PowerDwn, AdCincmp, AdOutOvf, AdOutUdf, BadDcLtc, Dmt_Tmot, MLtOutFI, BadDaRng, MstrTmot, InvPrgEx, EpromErr, RamCntEr, RamAdrEr, DpaError, DsaError, RxBufOfL, IOLJaber, BadPgJmp, AdCCalEr
IOMNUM	IOP Card Number	I	PB	(N/A); 1 – 40
IOMOPER(n)	IOP in Operation (n = 1 -168)	e:	View	(N/A); Primary, Secndry
IOMREALT	Actual IOP Type	e:	View	(None); None, LLAI, HLAI, DI, DO, AO, LLMUX, STIM, PI
IOMSEVER(n)	Error Severity Based on IOP State (n = 1 -40; 129 - 168)	e:	View	(N/A); OK, Fail, Warning, Inform

Parameter	Description	Type	Lock	(Default) and Range
IOMSTS(n)	IOP Status (n = 1 - 40; 129 - 168)	e:	View	(N/A); CommErr, ConfigMis, Idle, IdleSF, NonExist, NoResp, NotConfig, OK, PowerOn, SoftFail, UnAvail, ConfErr
IOMTYPE(n)	IOP Type (IOP) (n = 1 - 168)	e:	View	(None); None, HLAI, LLAI, AO, DI, DO; LLMUX STIM, PI
IOMTYPE	IOP Type (IOP) (PM Box)	e:	PB	(NotConfig); NotConfig, HLAI, LLAI, AO, DI, DO, LLMUX STIM, PI, FBUS
IOPDESC(n)	IOP Description	S	View	(Spaces); 8 characters
IOREDOPT	I/O Module Redundancy Option	e:	PB	(Nonredun); Redun, Nonredun
IOSTKNDR	IO Data Scan Period in seconds	I	View	(N/A); 0 - 32767
K	IOP Token Drop Count Gain Constant for X2 Input (AutoMan) Overall Gain in % Per % (Pid) Gain Constant (PosProp)	R R R	Supr Supr Supr	(1.0); N/A (1.0); 0.0 - 240.0 (1.0); 0.0 - 10.0
K1	External Reset Feedback Gain (PidErfb)	R	Supr	(0.0); 0.0 - 1.0
K1-K2	K1=Ratio Scale Factor; K2= Gain for X2 Input (RatioCtl)	R	Supr	(1.0); ≥0
K1-K4	Gain Constant for X1-X4 Inputs (IncrSum)	R	Supr	(1.0); ≥ 0.0
KEXT	External Gain Modifier	R	Prog	(1.0); 0.0 - 240.0
KEYWORD	Keyword Descriptor	S	PB	(Blank); A-Z, 0-9, _
KFF	Gain for Feed Forward Input	R	Supr	(1.0); ≥ 0.0 to ≤ 1.0
KGAP	Gap Gain Factor	R	Supr	(1.0); 0.0 - 1.0
KLIN	Linear Gain Factor	R	PB	(1.0); 0.0 - 240.0

Parameter	Description	Type	Lock	(Default) and Range
KNL	Non-linear Gain Factor	R	View	(N/A); N/A
L(n)	Value of the External Input (n = 1 – 12)	L	View	(N/A); Off - On
LASTPV	Last PV Value	R	View	(NaN); N/A
LCNRECHN	LCN Channel That NIM is Listening to	e:	View	(ChannelA); ChannelA, ChannelB
LIBADOPT	Logic Bad Input Handling Option	e:	PB	(Hold); Off, On, Hold
LIBRYNUM	NIM Library Number	I	PB	(N/A); 1 – 3
LIBRYTXT	NIM Library Text	S	PB	(N/A); N/A
LINEPERD(n)	Line Period in Microseconds (n = 1 - 168)	R	View	(N/A); 15616 - 21759 μ seconds
LISRC(n)	Logic Input Connection Source (n = 1 - 12)	U	PB	(Null.Null); "TagName.Parameter" or "IMTmmSss.Parameter" or "\$NMhhBxx.Parameter"
LOADSCOP	Load Scope	e:	PB	(NIMOnly); NimOnly, NimAndPm
LOADSTAT	Load Status	e:	View	(); Not Loaded, Loaded, Loading, Unloading
LOCALMAN	Local Manual Flag (AnalgOut, RegCtl)	L	View	(Off); Off – On
	Local Manual Flag (DigComp, DevCtl)	L	Prog	(Off); Off – On
LOCUTOFF	Low Signal Cut Off for Flow Inputs	R	Eng/PB	(NaN); PVEULO - PVEUHI, >NaN
LODSTN(n)	Logic Output-Connection Destination (n = 1 - 12)	U	PB	(Null.Null); "TagName.Parameter" or "IMTmmSss.Parameter", or "\$NMhhBxx.Parameter"
LOENBL(n)	Logic Output Enable (n = 1 - 12)	e:	PB	(FL2); FL1 - FL12, SO1 - SO16, L1 -L12

Parameter	Description	Type	Lock	(Default) and Range
LOGALGID(n)	Logic Block Algorithm Identifier (n = 1 - 12)	e:	PB	(Null); OR, NOT, NAND, NOR, XOR, AND, SWITCH, CheckBad, Pulse, Delay, OnDly, OffDly, QOR2, QOR3, EQ, NE, GT, GE, LT, LE, MinPulse, MaxPulse, WatchDog, FlipFlop, ChDetect, Null
LOGICSRC	Logic Source	E	PB	(Null); A-Z, 0-9, _
LOGMIX	Logic Mix	e:	PB	(12_0_12); 12_16_4, 12_8_8, 12_0_12
LOSRC(n)	Output - Connection Source 1 - 12	e:	Eng/PB	(FL1); L1 - L12, FL1 - FL12, NN1 - NN4, SO1 - SO16
LOWERTIM	Lower Output Pulse Time (Secs)	R	View	(N/A); N/A
LOWRDSTN	Lower OP Pulse Destination	U	PB	(Null); ONPULSE, OFFPULSE
LOWRRATE	Lower OP Stroke Rate in %/Sec	R	Supr	(100.0); >0.0% / Second
LRL	Lower Range Limit (STI)	R	View	(NaN); Na, NaN
LRV	Lower Range Value (STI)	R	Supr/ View	(NaN); Na, NaN
LSIOLORN(n)	Last Hour's I/O Link Fetch/Store Overruns. (n = 1 - 4)	I	View	(0); ≥ 0
LSPPXORN(n)	Last Hour's Point Processing Fetch/Store Overruns (n = 1 - 8)	I	View	(0); ≥ 0
LSUCNORN	Last Hour's UCN Access Overruns	I	View	(0); ≥ 0
M	Number of Inputs	I	PB	(2); 2 - 4

Parameter	Description	Type	Lock	(Default) and Range
MANMODFL	Manual Mode Flag	L	View	(Off); Off – On
MANOPCMD	Manual Output Pulse Command	e:	Oper	(None); Raise_1, Lower_1, None, Raise_10, Lower_10
MANOPTIM	Manual Output Pulse Time	R	Eng/PB	(1.0); 0.0 - 60.0 Seconds
MAXPULSE	Maximum Pulse Time Limit	R	Supr	(60.0); MINPULSE to 60.0 Seconds, NaN
MAXSLOTS	Maximum Configurable Slots in IOP	R	View	(0); 0 – 127
MINPULSE	Minimum Pulse Time Limit	R	PB	(0.0); 0.0 Seconds to MAXPULSE, NaN
MODATTR	Mode Attribute	e:	Oper	(Operator); Operator, Program, None
MODE	Mode (AnalgOut) Mode (DigComp) Mode (RegCtl)	e: e: e:	Oper Oper Oper	(Man); Man, Cas, Normal (Man); Man, Normal (Man); Man, Cas, Auto, Bcas Normal
MODEAPPL	Mode Applicability	L	View	(Man=On; Auto, Cas, & Bcas = Off, N/A
MODEPERM	Mode Permissive	e:	Eng/PB	(Permit); Permit, NotPerm
MODNUM	IOP Card Number	I	PB	(N/A); 0 –127
MOMSTATE	Momentary Output States	e:	Eng/PB	(None); Mom_0, Mom_1, Mom_2, Mom_1_2, None
MOVVFVL	Moving PV Flag	L	View	(Off); Off – On
MOVVPTXT	Moving PV Text Descriptor	S	PB	(MOVING); A-Z, 0-9, _
MSGPEND	Sequence Message Pending	L	View	(none); N/A
MXRMPDEV	Maximum Ramp Deviation Value	R	PB	(NaN); ≥ 0.0, NaN
MXSOKDEV	Maximum Soak Deviation Value	R	PB	(NaN); ≥ 0.0, NaN

Parameter	Description	Type	Lock	(Default) and Range
N	Number of Inputs (CalcuLtr)	I	PB	(1); 1 – 6
	Number of Inputs (HiloAvg & Summer)	I	PB	(2); 2 – 6
NAME	Tag Name	E	Eng/PB	(N/A); A-Z, 0-9, _
NCTLSLOT	Number of Regulatory Control Points	I	PB	(0); 0 – 160
NDCSLOT	Number of Digital Composite Points	I	PB	(0); 0 – 255
NEVTAVG	Avg. Number of Events per Second	R	View	(0); N/A
NEVTMAX	Max. Number of Events per Second	R	View	(0); N/A
NFASTCTL	Number of Fast Regulatory Control Slots	I	PB	(0); 0 - 40 but $\leq$ NCTLSLOT
NFASTLOG	Number of Fast Logic Slots	I	PB	(0); 0 – 40 but $\leq$ NLOGSLOT
NFASTDC	Number of Fast Digital Composite Points	I	PB	(0); 0 – 255 but $\leq$ NDCSLOT
NFASTPV	Number of Fast Regulatory PV Slots	I	PB	(0); 0 - 40 but $\leq$ NPVSLLOT
NFLAG	Number of Flags (Box)	I	View	(0); 0 – 1023
NLFM	Nonlinearity Form	I	Supr	(1); 0 or 1
NLGAIN	Nonlinear Gain	R	Supr	(0.0); 0.0 - 240.0
NLOC	Number of Locations in Delay Table	I	Eng	(30); 2 – 30
NLOGSLOT	Number of Logic Points	I	PB	(0); 0 – 80
NMIN	Minimum Number of Good Inputs	I	Supr	(1); 1 to Number Specified in N
NMODATTR	Normal Mode Attribute	e:	Engr/PB	(None); None, Operator, Program, Normal
NMODE	Normal Mode (AnalgOut)	e:	Engr/PB	(None); None, Man, Cas
	Normal Mode (DigComp, DevCtl)	e:	View	(Man); Man
	Normal Mode (RegCtl)	e:	Engr	(None); Man, Auto, Bcas, Cas, None
NN(n)	Numeric Value (ProcModl) (n = 1 - 80)	R	Oper	(NaN); N/A

Parameter	Description	Type	Lock	(Default) and Range
	Numeric Value (Box) (n = 1 - 2047)	R	Oper	(NaN); N/A
	Numeric Value (Logic Point) (n = 1 - 4)	R	Supr	(NaN); N/A
NNUMERIC	Number of Numerics in PM Box	I	PB	(256); 0 - 2047
NOCINPTS	Number of Control Input Connections	I	PB	(Varies by Algo Type, Equation); 0–4
NOCOPTS	Number of Control Output Conn.	I	PB	(1); 0 – 4
NODEASSN	Node Assignment	e:	PB	(ThisNIM); ThisNIM, RemotNIM,
NODECMD	Node Command	e:	OnPrc	(None); None, Run, Idle
NODENUM	Node Number	I	PB	(N/A); 0, 1 – 64
NODEOPR	Node Operating Mode	e:	View	() Primary, Secndry
NODESC	Number of Generic Descriptors	I	PB	(0); 0 – 12
NODESTAT	NIM's Node Status			(N/A); Offnet, ConfigMis, Run
NODESTS	NIM Node Summary Status	e:	View	(N/A); Offnet, ConfigMis, OK
	PM Node Summary Status	e:	View	(N/A); NotConf, PowerOn, OK, Alive, Fail, Offnet, Loading, ConfigMis, Idle, PartFail, Pf_IOldL, Pf_IDLE
NODETYP	UCN Node Type (PM)	e:	PB	(PM);PM, APM, HPM, LM
	UCN Node Type (UCN)	e:	PB	(NotConfig);NotConfig, NIM, PM, APM, HPM, LM
NODFSTAT	UCN Node's Functional Status	e:	Supr	(Basic); Basic, Full
NODINPTS	Number of Digital Input Connections	I	PB	(1); 0, 1, 2
NODOPTS	Number of Digital Output Connections	I	PB	(1); 0, 1, 2, 3
NOLINPTS	Number of Logic Inputs	I	View	(N/A); 0 – 12
NOLOGBLK	Number of Logic Blocks	I	View	(N/A); 0 – 16

Parameter	Description	Type	Lock	(Default) and Range
NOLOPTS	Number of Logic Output Connections	I	View	(N/A); 0 – 12
NOPINPTS	Number of PV Input Connections	I	View	(Varies by Algo Type, Equation,N); 0 – 6
NORQUAVG	Avg. Number Nodes to which UCN Requests are made	R	View	(0); N/A
NORQUMAX	Max. Number Nodes to which UCN Requests are made	R	View	(0); N/A
NORSPAVG	Avg. Number Nodes to which UCN Responses are made	R	View	(0); N/A
NORSPMAX	Max. Number Nodes to which UCN Responses are made	R	View	(0); N/A
NORSSEQ	Number of Ramp/Soak Pairs in the Sequence	I	Eng/PB	(2); 2 – 12
NOSTATES	Number of Digital States	I	PB	(2); 2 & 3
NOTRAAVG	Avg. Number of Nodes to which UCN Transactions are made	R	View	(0); N/A
NOTRAMAX	Max. Number of Nodes to which UCN Transactions are made	R	View	(0); N/A
NPARAVG	Avg. Number of UCN Parameter Access per Second	R	View	(0); N/A
NPARMAX	Max. Number of UCN Parameter Access per Second	R	View	(0); N/A
NPMSLOT	Number of Process Module Points	I	PB	(0); 0 – 128
NPRQUAVG(n)	Avg. Number of UCN Parameter Requests (n = 0 - 64)	R	View	(0); N/A

Parameter	Description	Type	Lock	(Default) and Range
NPRQUMAX(n)	Max. Number of UCN Parameter Requests (n = 0 - 64)	R	View	(0); N/A
NPRSPAVG(n)	Avg. Number of UCN Parameter Responses (n = 0 - 64)	R	View	(0); N/A
NPRSPMAX(n)	Max. Number of UCN Parameter Responses (n = 0 - 64)	R	View	(0); N/A
NPVSLLOT	Number of Regulatory PV Slots	I	PB	(0); 0 – 80
NSCANITM	Number of Scan Items in PM Scan Table	I	View	(0); 0 – 50
NTIMER	Number of Box Timer Points	I	View	(0); 0 – 64
NTRAAVG	Avg. Number of UCN Transactions	R	View	(0); N/A
NTRAMAX	Max. Number of UCN Transactions	R	View	(0); N/A
NTRQUAVG(n)	Avg. No. of UCN Transaction Requests	R	View	(0); N/A
NTRQUMAX(n)	Max. No. of UCN Transaction Requests	R	View	(0); N/A
NTRSPAVG(n)	Avg. No. of UCN Transaction Responses	R	View	(0); N/A
NTRSPMAX(n)	Max. No. of UCN Transaction Responses	R	View	(0); N/A
NTWKNUM	Network Number	I	PB	(N/A); 1 – 20
NXTSOAKV	Next Soak Value	R	View	(N/A); ≥0.0
OFFNRMFL	Off-Normal Alarm Flag	L	View	(Off); Off – On
OFFNRMPR	Off-Normal Alarm Priority	L	Eng	(NoAction – R670); Emergency, High, Low, JnlPrint, Printer, Journal, NoAction
OFFPULSE	Off-Pulse Command	R	Oper	(N/A); 0.0 - 60.0 seconds
OLDAV	Old Accumulated Value (Dign)	I	View	(N/A); ≥ 0
	Old Accumulated Value (Totalizr)	R	View	(N/A); ≥ 0.0
ONPULSE	On Pulse Command	R	Prog	(N/A); 0.0 - 60.0 Seconds
OP	Output in Percent (AnalogOut & RegCtl)	R	Oper	(-6.9% F/scale); -6.9 to 106.9%

Parameter	Description	Type	Lock	(Default) and Range
	Digital State Output (DigComp)	SDE	Oper	(STATETXT0); STATETXT0, STATETXT1 or STATETXT2 Descriptor
	Pulsed Digital Output (DigOut)	R	Prog	(0.0%); 0 to 100.0%
OPALDB	Output Alarm Dead Band	R	Eng/PB	(5 Units); 0 - 25 Output Units
OPCHAR	Output Characterization Option	R	PB	(Off); Off – On
OPCMD	Output Command	L	View	(N/A); Raise, Idle, Lower
OPEU	Output Value in Engineering Units	e	View	(N/A); N/A
OPFINAL	Final OP in % Sent to Control Element	R	View	(-6.9%); N/A
OPHAFL	Output High Alarm Flag	L	View	(Off); Off – On
OPHIFL	Output High Limit Flag	R	Prog	(Off); Off – On
OPHILM	Output High Limit in Percent	L	Supr	(105%); OPLOLM - 106.9%, NaN
OPHIPR	Output High Alarm Priority	e:	Eng/PB	(NoAction – R670); NoAction, Emergency, High, Low, Journal, JnlPrint, Printer
OPHITP	Output High Alarm Trip Point	R	Supr	(NaN); NaN, OPLOTP – OPHILM, NaN
OPIN0	Input Coordinate Number 0 in Percent	R	View	(-6.9%); N/A
OPIN1-4	Input Coordinates Number 1-4 in %	R	Supr	(N/A); ≥ Prev. Coordinate but ≤ Next Coordinate
OPIN5	Input Coordinate Number 5 in %	R	View	(106.9%); N/A
OPLAFL	Output Low Alarm Flag	L	View	(Off); Off – On
OPLOFL	Output Low Limit Flag	R	Prog	(Off); Off – On
OPLOLM	Output Low Limit in %	L	Supr	(-5.0%); -6.9% to OPHILM, NaN

Parameter	Description	Type	Lock	(Default) and Range
OPLOPR	Output Low Alarm Priority	e:	Eng/PB	(NoAction – R670); Emergency, High, Low, JnlPrint, Printer, Journal, NoAction
OPLOTP	Output Low Alarm Trip Point	R	Supr	(NaN); NaN, OPLOLM – OPHITP
OPMCHLM	Output Minimum Change Limit in %	R	Supr	(0.0); ≥ 0.0 , NaN
OPOUT0	Output Coordinate Number 0 in %	R	View	(-6.9%); N/A
OPOUT1-4	Output Coordinates Number 1-4 in %	R	Supr	(N/A); $\geq$ Previous Coordinate but $\leq$ Next Coordinate
OPOUT5	Output Coordinate Number 5 in %	R	View	(106.9%); N/A
OPRATRFL	Operator Mode Attribute Flag	L	View	(N/A); Off – On
OPRINPUT	Operator Input	R	Oper	(0.0); N/A
OPROCLM	OP Rate of Change Limit in %	R	Supr	(NaN); ≥ 0.0 , NaN
OPTDIR	Direct/Reverse Action	e:	Eng/PB	(Direct); Direct, Reverse
OROFFSET	Override Offset	L	Eng/PB	(On); Off – On
OROPT	Override Option	L	Eng/PB	(Off); Off – On
OUT0-12	Output Coordinates Number 0-12	R	Supr	(NaN); $>$ Anything but NaN
OUTIND	Direct/Reverse Action (R620 & later)	e:	Eng/PB	(Direct); Direct, Reverse
OVERFLOW	Accumulation Overflow Flag	L	View	(Off); Off – On
OVERPHAS	Override Current Phase	e:	OnPrc	(Blank); Forward – Backward
OVERSTAT	Override Current Statement	e:	OnPrc	(Blank); Forward – Backward
OVERSTEP	Override Current Step	e:	OnPrc	(Blank); Forward – Backward
OVERVAL	Overview Value in Percent	I	Eng/PB	(25%); 0 - 100%
P	Pressure Input	R	View	(1.0); ≥ 0.0
P0	Zero Reference for Pressure	R	Supr	(0.0); N/A, NaN

Parameter	Description	Type	Lock	(Default) and Range
P0 - P2	Permissive Interlocks for Output State 0, 1, and 2	L	Engr	(On); Off – On
P1 - P6	PV Inputs 1-6 (RegPV)	R	View	(NaN); N/A
P1STS-P6STS	P1-P6 Status	e:	View	(Bad); Bad, Uncertn, Normal
PERIOD	Period (ProcMod, Timer)	R	View	(1.0); 1 Second
	Period (DigOut)	R	Eng/PB	(10.0); 1 - 120.0 Seconds
	Period (RegPV, RegCtl, Logic, DigComp)	R	View	(1.0); 0.25, 0.5, or 1 Second
PHASE	Phase	S	View	(); N/A
PHASEAL	Phase Alarm	L	View	(Off); On – Off
PHASEIDX	Phase Index	I	View	(0); 0 - 3000
PHASETIM	Phase Time	I	View	(0); 0 - 9999 Minutes
PIDFORM	PID Controller Form	e:	Eng/PB	(Interact); Interact, Ideal
PIDSTN(n)	PV Input Connection Destination (n = 1 - 6)	P	View	(Varies by Algo Type, Equation, N); 1-8 Character Valid Parameter Name
PISRC(n)	PV Input Connection Source (n = 1 - 6)	E	PB	(Null.Null); "TagName.Parameter"
PIUOTDCF	Open Thermocouple Detection Enable (STI, LLMUX)	L	Eng/View	(On); On – Off
PIUOTDCF(n)	Open Thermocouple Detection Enable (LLAI) (n = 1 - 168)	L	Supr	(On); On – Off
PKGOPT	PMM Hardware Packaging Option	e:	PB	(Redun); Redun, Redun_2F Redun_IO, Nodefalt, Nonredun
PMEVOVFL	PMM Event Overflow Flag	L	View	(); Off, On
PMMCHAER	PMM's I/O Link Channel A Error Count	I	View	(0); ≥ 0
PMMCHASL	PMM's I/O Link Channel A Silence Count	I	View	(0); ≥ 0

Parameter	Description	Type	Lock	(Default) and Range
PMMCHBER	PMM's I/O Link Channel B Error Count	I	View	(0); ≥ 0
PMMCHBSL	PMM's I/O Link Channel B Silence Count	I	View	(0); ≥ 0
PMMCMD	PMM Command	e:	OnProc	(None); None, Run, Idle, ShutDown, SwapPri, Coldstrt, SelChnA, SelChnB, Warmstrt, RsUCNLsb, RslolCom
PMMCOMER	PMM's I/O Link Communication Error Status	e:	View	(N/A); InvAlert, InvDest, InvSourc, InvChCnt, InvCmd, Checksum, No_Resp, ChTimOut, MsgOvRun, GapError, LpBckErr, NTH_0 TknRecov, RplBufOv, None
PMMCTLST	PMM Control Processor Status	L	View	(Off); Off, On
PMMIOLST	I/O Link Status	e:	View	(); Notconfg, Confgmis, OK, Idle, Softfail, Idlesf, Nonexist, Noresp, Poweron, Commerr, Unavail
PMMOPER	PMM Operation	e:	View	(N/A); NonRedun, Primary, Secondary
PMMRECCH	PMM's I/O Link Current Receive Channel	e:	View	(N/A); ChannelA, ChannelB
PMMSFST	PMM Soft Failure	L	View	(); Off - On
PMMSTS	PMM Primary Status	e:	View	(N/A); Offnet, Alive, OK, Idle, IdleSF, Fail, Loading, ConfgMis, AliveSF SoftFail, Test, TestSF
PNTFORM	Point Form	e:	PB/View	(Full); Full, Componnt
PNTMODTY	Point's IOP Type	e:	View	(NotConf), PMM, HLAI, LLAI, AO, DI, DO, PI, LLMUX, NotConfg
PNTNODTY	Point's Node Type	e:	View	(N/A); NIM, PM, NotConfg

Parameter	Description	Type	Lock	(Default) and Range
PNTSTATE	Point's Overall State	e:	View	(N/A); OK, Fail, Idle, Config
PNTTYPE	Point Type	e:	PB	(Null); AnalIn, AnalOut, DigCom, DigIn, DigOut, ProcModl, RegPV, RegCtl, Logic, Null
POSITION	PMM File Position	e:	View	(N/A); Left, Right, File_1, File_2
PR2PREFF	Peer-To-Peer Comm Efficiency (%)	R	View	(100); 0 – 100
PRIMMOD	Primary Module Identifier	E	PB	(); A-Z, 0-9, _
PRMDESC	Parameter Descriptor Assignment.	e:	Eng/PB	(N/A); L1-12, FL1-12, NN1-4, SO1-16
PROCMOD	Process Module Operating State	e:	Special	(Off); Off, Norm, Hold, Shdn, Emsd, Strt, Stop
PSTS	Pressure Input Value Status	e:	View	(Normal); Normal, Uncertn, Bad
PTDESC	Point Descriptor	S	PB	(Blank); A-Z 0-9 Space ! % & ' () + - / : ; > < = ? _ , . \$
PTEXECST	Point Execution State	e:	Supr	(Inactive); Inactive, Active
PROCMOD	Process Module Operating State	e:	Oper	(Off); Off, Norm, Hold, Shdn, Emsd, Strt, Stop
PSTS	Pressure Input Value Status	e:	View	(Normal); Normal, Uncertn, Bad
PTDESC	Point Descriptor	S	PB	(Blank); A-Z 0-9 Space ! % & ' () * + - / : ; > < = ? _ , . \$
PTEXECST	Point Execution State	e:	Supr	(Inactive); Inactive, Active
PTINAL	Point in Alarm Indicator	L	View	(Off); Off – On
PTORST	Point Override Status	e:	Prog	(NotCon); NotCon, Sel, NotSel

Parameter	Description	Type	Lock	(Default) and Range
PTSTSIOL	Redundant Partner Status as seen from the IOL	e:	View	(); OffNet, ConfigMis, Idle, Idlesf, Poweron, Ok, Fail, SoftFail, , Alive, Alivesf, TestSF, Test, Loading, Notconfig, Nosynch, Unavail
PTSTSUCN	Redundant Partner Status as seen from the UCN	e:	View	(); Offnet, Configms, Idle, Idlesf, Ok, Softfail, Fail, Poweron, Alive, Test, Testsf, Alivesf, Loading, Notconfig, Nosynch, Unavail
PULSEWTH	Pulse Width for Point Outputs	R	Supr	(1.0); 0.0 - 60.0 Seconds
PV	Process Variable (AnalogIn, PI)	R	Oper	(NaN); PVEXEUHI - PVEXEULO, NaN
	Current State (DigComp)	e:	Oper	(BADPVTXT); PVSTATES(0)-(4)
	Current State (DigIn)	e:	Oper	(Off); STATETXT(0) or STATETXT(1)
	Current State (Flag)	e:	Oper	(Blank); STATETXT(0) or STATETXT(1)
	Process Variable (Numeric)	R	Oper	(NaN); N/A
	Process Variable (RegCtl)	R	View	(NaN); N/A
	Process Variable (RegPV)	R	Oper	(NaN); N/A
	Current Value (Timer)	I	View	(0); 0 to 32000 Seconds or Minutes
PVALDB	PV Alarm Deadband in Percent	e:	Eng/PB	(one); Half, One, Two, Three, Four, Five, EU

Parameter	Description	Type	Lock	(Default) and Range
PVAUTO	PV Auto Value (AnalogIn, PI)	R	View	(NaN); N/A (BADPVTXT for STATE2); STATETXT(0), STATETXT (1), STATETXT (2), MOVPTXT, BADPVTXT (N/A); STATETXT(0) or STATETXT(1) (NaN); N/A
	Current PV State (DigComp)	e:	View	
	Current PV State (DigIn)	e:	View	
	PV Value Fetched Using Control Input Connection (RegCtl)	R	View	
	PV Auto Value (RegPV)	R	View	(NaN); N/A
PVAUTOST	PV Auto Value Status	e:	View	(Bad); Bad, Normal, Uncertn
PVCALC	Calculated PV (AnalogIn)	R	View	(NaN); PVEXEUHI – PVEXEULO
	Calculated PV (RegPV)	R	View	(NaN); N/A, NaN
PVCHAR	PV Characterization Option	e:	PB	(Linear); Sqrroot, Btherm, Etherm, Jtherm, Ktherm, Rtherm, Stherm, Ttherm, Ntherm, RPtherm, DinRtd, NickLRtd, CopprRtd, NiNiMOTC, Linear, JisRtd, Pt100DinRtd, Pt100JisRtd, Pt200Rtd, Pt500Rtd, CU10Rtd, CU25Rtd, W3W25TC, W5W26TC, RHRAD, RTD Ohms
PVCLAMP	PV Clamping Option	e:	Eng/PB	(NoClamp); Clamp, NoClamp

Parameter	Description	Type	Lock	(Default) and Range
PVEQN	PV Equation Type (FlowComp)	e:	Eng/PB	(EqA); EqA – EqE
	PV Equation Type (HiLoAvg, MidOf3)	e:	Eng/PB	(EqA); EqA – EqC
	PV Equation Type (Summer)	e:	Eng/PB	(EqA); EqA & EqB
	PV Equation Type (Totalizr)	e:	Eng/PB	(EqA); EqA – EqF
	PV Equation Type (VdtLdLag)	e:	Eng/PB	(EqA); EqA – EqD
PVEUHI	PV High Range in Engineering Units	R	Eng	(100); PVEULO - PVEUHI
PVEULO	PV Low Range in Engineering Units	R	Eng	(0); PVEXEULO - PVEUHI
PVEUHI	PV Extended Hi Range in Engineering Units	R	Eng	(102.9); ≥ PVEUHI
PVEXEULO	PV Extended Lo Range in Engineering Units	R	Eng	(-2.9); ≤ PVEULO
PVEXHIFL	PV Extended Hi Range Violation	L	View	(Off); Off – On
PVEXLOFL	PV Extended Lo Range Violation	L	View	(Off); Off – On
PVFL(n)	PV Flag (DigComp) (n = 0 - 2)	L	View	(Off); Off, On
PVFL	PV Flag (DigIn, Flag)	L	Oper	(Off); Off, On
PVFORMAT	PV Decimal Point Format	e:	Eng	(D1 = XXX.X); D0, D1 D2, D3
PVHHFL	PV High High Alarm Flag	L	View	(Off); Off – On
PVHHPR	PV High High Alarm Priority	e:	Eng	(NoAction – R670); JnlPrint, Printer, Emergency, High, Low, Journal, NoAction
PVHITP	PV Hi Hi Alarm Trip Point (AnalogIn, RegPV)	R	Supr	(NaN); PVHITP - PVEUHI, NaN
	PV Hi Hi Alarm Trip Point (RegCtl PosProp, PIDPosPr)	R	Supr	(NaN); PVHITP - PVEUHI, NaN
PVHIFL	PV High Alarm Flag	L	View	(Off); Off – On

Parameter	Description	Type	Lock	(Default) and Range
PVHIPR	PV High Alarm Priority	e:	Eng	(NoAction – R670); JnlPrint, Printer, Emergency, High, Low, Journal, NoAction
PVHITP	PV High Alarm Trip Point	R	Supr	(NaN); PVLOTP - PVHHTP, NaN
PVINIT	PV Initialization Request Flag	L	Prog	(Off); Off – On
PVLLFL	PV Low Low Alarm Flag	L	View	(Off); Off – On
PVLLPR	PV Low Low Alarm Priority	e:	Eng	(NoAction – R670); JnlPrint, Printer, Emergency, High, Low, Journal, NoAction
PVLLTP	PV Low Low Alarm Trip Point (AnalIn, RegPV)	R	Supr	(NaN); PVEXEULO - PVLOTP, NaN
	PV Low Low Alarm Trip Point (RegCtl)	R	Supr	(NaN); PVEULO - PVLOTP, NaN
PVLOFL	PV Low Alarm Flag	L	View	(Off); Off – On
PVLOPR	PV Low Alarm Priority	e:	Eng/PB	(NoAction – R670); JnlPrint, Printer, Emergency, Low, High, Journal, NoAction
PVLOTP	PV Low Alarm Trip Point	R	Supr	(NaN); PVLLTP - PVHITP, NaN
PVNORMAL	PV Normal State	e:	Supr	(N/A); STATETXT(0) - STATETXT(2), None (requires lock = Engr)
PVNORMFL	PV Value's Normal State Flag	L	View	(Off); Off – On
PVP	PV in Percent	R	View	(NaN); N/A
PVRAW	PV Raw Value (AnalIn, PI, STI)	R	View	(NaN); N/A
	Raw State of Field Contacts (DigIn)	L	View	(Off); Off-On

Parameter	Description	Type	Lock	(Default) and Range
PVRAWHI	PV Raw High Range	R	Eng/PB	(NaN); PVRAWLO to 100 (for a 0_100_mV Input), PVRAWLO to 1 [for a Slidewire Input (ratio)]
PVRAWLO	PV Raw Low Range	R	Eng/PB	(NaN); 0.0 - PVRAWHI (0 to 100 Microvolts for a 0_100_mV Input, or 0 to 1 Ratio for a Slidewire Input)
PVROC NFL	PV Negative Rate-of-Change Alarm Flag	L	View	(Off); Off – On
PVROC NPR	PV Negative Rate-of-Change Alarm Priority	e:	Eng	(NoAction – R670); JnlPrint, Printer, Emergency, Low, High, Journal, NoAction
PVROC NTP	PV Negative Rate-of-Change Trip Point	R	Supr	(NaN); ≥ 0.0 , NaN
PVROC PFL	PV Positive Rate-of-Change Alarm Flag	L	View	(Off); Off – On
PVROC PPR	PV Positive Rate-of-Change Alarm Priority	e:	Eng	(NoAction – R670); JnlPrint, Printer, Emergency, Low, High, Journal, NoAction
PVROC PTP	PV Positive Rate-of-Change Trip Point	R	Supr	(NaN); ≥ 0.0 , NaN
PVSGCHTP	PV Significant Change Alarm Trip Point	R	Supr	(NaN); ≥ 0.0 , NaN
PVSOURCE	PV Source	e:	Oper	(Auto); Auto, Man, Sub,Track
PVSRCOPT	PV Source Option	e:	Eng/PB	(OnlyAuto); All, OnlyAuto
PVSTATES(n)	PV State Descriptors (n = 0 - 4)	S	View	(N/A); N/A
PVSTS	Status of PV Input Value	e:	View	(Bad); Bad, Normal, Uncertn
PVTEMP	PV Temperature Scale	e:	PB	Degrees(C); C, F, R, K
PVTRACK	PV Tracking Option	e:	Eng/PB	(NoTrack); Track, NoTrack
PVTV	PV Target Value in Engineering Units	R	Oper	(NaN); PVEXEULO - PVEXEUHI, NaN

Parameter	Description	Type	Lock	(Default) and Range
PVTVP	PV Target Value in Percent	R	View	(NaN); ≥ 0.0 , NaN
Q	Steam Quality Factor Input	R	View	(1.0); ≥ 0.0 , NaN
QSTS	Q Input Value Status	e:	View	(Normal); Normal, Uncertn, Bad
R1(n)-R2(n)	Real Input Number 1 - 2 (n = 1 - 24)	e:	PB	(L1); L1 - L12 & NN1 - NN4
RAISDSTN	Raise Output Pulse Destination	U	PB	(Null); ONPULSE - OFFPULSE
RAISTIM	Raise Output Pulse Time	R	View	(N/A); N/A, NaN
RAISRATE	Raise OP Stroke Rate in %/Sec	R	Supr	(100.0); > 0.0
RAMPTIME	Ramp Time in Minutes	R	Oper	(0.0); ≥ 0.0
RARWSTS	Remote Anti-Reset Windup Status	e:	View	(Normal); Normal, Hi, Lo, HiLo
RATE1	Rate at Which Bias Ramps Down (AutoMan)	R	Supr	(0.0); ≥ 0.0 , NaN
RATE1-12	Ramp Rates for Ramp Soak Segments 1-12 (RampSoak)	R	Supr	(NaN); N/A
RATIO	Ratio	R	Oper	(1.0); RTLOLM - RTHILM
RBOPT	Ratio Bias Option	e:	Eng/PB	(NoRatBi); NoRatBi, FixRatBi, AutoRat, AutoBi
RCASOPT	Remote Cascade Option (AnalgOut, AutoMan, Incrsum, ORSel, Switch)	e:	Eng/PB	(None); None, Ddc
	Remote Cascade Option (PID algos)	e:	Eng/PB	(None); None, Spc, Ddc, DdcRsp, Rsp
	Remote Cascade Option (PosProp, RatioCtl)	e:	Eng/PB	(None); None, Spc
RCASSHED	Remote Cascade Shed	L	View	(Off); Off - On
REDTAG	Red Tag State	e:	Supr	(Off); Off - On
REMSOAKT	Remaining Soak Time	R	Oper	(0.0); 0.0 - 720.0 Minutes

Parameter	Description	Type	Lock	(Default) and Range
RESETFL	Reset Flag	L	Prog	(Off); Off – On
RESETVAL	Accumulator Reset Value (DigIn)	I	Oper	(0); 0 – 32767
	Reset Value (Totalizr)	R	Oper	(0.0); N/A
RESTART	Process Module Restart State	e:	View	(None); None, Failover, Warm, Cold, PTACTVN
RFB	Reset Feedback Input in %	R	View	(N/A); $\geq 0.0\%$
RG	Reference Specific Gravity	R	Supr	(1.0); N/A
RINITREQ	Remote Initialization Request (AnalogOut)	L	View	(On); Off – On
	Remote Initialization Value (RegCtl)	L	View	(Off); Off – On
RINITVAL	Remote Initialization Value	R	View	(NaN); N/A, NaN
RJRAW	Reference Junction's Raw Count in μ Volts	R	View	(NaN); N/A
RJTEMP	Reference Junction Temperature	R	View	(N/A); N/A
RP	Minimum Pulse Ratio (PosProp)	R	Supr	(1.0); 0.01 – 100
	Reference Pressure (Flowcomp)	R	Supr	(1.0); N/A
RQ	Reference Steam Quality Factor	R	Supr	(1.0); N/A
RSPBGP\$\$	Ramp/Soak Percent Bar Graph Parameter	R	View	(N/A); ≥ 0
RSTROPT	Restart Option	e:	Eng	(Off); Off, Restart
RT	Dead Time Ratio (PosProp)	R	Supr	(1.0); 0.01 - 100.0
	Reference Temperature (Flowcomp)	R	Supr	(1.0); N/A
RTHILM	Ratio High Limit	R	Supr	(100); RTLOLM - 100, NaN
RTLOLM	Ratio Low Limit	R	Supr	(0.01); 0.01 - RTHILM, NaN
RV	Remaining Time	I	View	(0); >0
RX	Reference Steam Compressibility	R	Supr	(1.0); anything but NaN

Parameter	Description	Type	Lock	(Default) and Range
S0BOXCLR S1BOXCLR S2BOXCLR	State Box Color	e:	View	(N/A); Red, Green, White, Black, Cyan, Yellow, Blue
S1	Tracking Switch (PidErfb) Transmitter Status (STI)	L S	Prog View	(Off); On – Off (Blank); Blank, N/A
S1, S2	Mark 1 and Mark 2 Flags (RampSoak)	L	View	(Off); On – Off
S1-S4	Status Inputs 1-4 (Logic) Select X1-X4 Request Flag (Switch)	e: L	PB Oper	(L1); L1 - L12, FL1 - FL12, SO1 – SO16 (On); Off – On
S1BGNTIM, S2BGNTIM	Mark 1 and Mark 2 Begin Times	R	Supr	(0.0); 0 - 120 Minutes
S1ENDTIM, S2ENDTIM	Mark 1 and Mark 2 End Times	R	Supr	(0.0); 0 - 120 Minutes
S1REV(n) - S3REV(n)	S1, S2, S3 Inputs Reversed (n = 1 - 24)	L	PB	(Off); On – Off
S1SEGID, S2SEGID	Mark 1 and Mark 2 Segment Identifiers	e:	Supr	(Ramp1); Ramp1 - Ramp12, Soak1 - Soak12
SAFEOP	Safe Operation for Safety Shutdown	R	Engr	(N/A); -6.9 – 106.9%, NaN
SCANRATE	Scan Rate	e:	PB	(Reg1Log1); Reg1Log1, Reg1Log2, Reg1Log4, Reg2Log2, Reg2Log4, Reg4Log4, Null
SECSYNC	Secondary Synchronization Status	e:	View	(); Synched, NoSynch
SECVAR	Secondary Variable	R	View	(NaN); N/A, NaN
SEGTOT	Total Number of Segments	I	Supr	(1); 1- 12

Parameter	Description	Type	Lock	(Default) and Range
SEGTYPE	Segment Type	e:	View	(N/A); Ramp, Soak
SELINP	Selected Input (HiLoAvg)	e:	View	(SelectP1); SelectP1 - SelectP6
	Selected Input (MidOf3)	e:	View	(SelectP1); SelectP1 - SelectP3
SELXINP	Selected X Input (ORSel)	e:	View	(SelectX1); SelectX1 - SelectX4
	Selected X Input (Switch)	e:	Oper	(SelectX1); SelectX1 - SelectX4
SENSRYTP	Sensor Type (HLAI & LLAI)	e:	PB	(1_5_V); 1_5_V, 0_5_V, P4_2_V, 5_V, 0_100_MV, Thermcpl, RTD, Slidwire
SENSRYTP	Sensor Type (LLMUX)	e:	PB	(); 0_100_mV, Thermcpl, RTD
	Sensor Type (STI)	e:	PB	(Spt_Dp); Spt_Dp, Spt_Gp, Spt_Ap, Stt, Sfm
SEQERR	Sequence Error	I	View	(0); 0 - 255, as Follows: 0 - No Error 1-100 - Not Used Error Codes 101 - Not Used 102 - Array Index Error 103 - Illegal IMD Code 104 - Illegal Variable/Operator Code 105 - Interpreter Stack Overflow 106 - GOTO Destination Error 107 - Key Level Error 108 - Configuration Mismatch

Parameter	Description	Type	Lock	(Default) and Range
SEQERR	Sequence Error (Continued)	I	View	Error 109 - I/O Link Prefetch Overflow 110 - Subroutine Nesting Level Error 111 - Illegal Value Error 112 - Fail Statement 113 - 164 – Not Used 165 - Sequence Halted by Operator 166 - Sequence Jumped to an Abnormal Condition Handler That was Not Enabled 167 - Not Used Failure Codes 168 - Timeout Condition on WAIT Statement 169 - Attempt was Made to Start a Sequence that was Not Loaded 170 - Communication Error in READ/WRITE Statement 171 - Communication Error During I/O Link Access; also generated for all Post-Store problems

Parameter	Description	Type	Lock	(Default) and Range
SEQERR	Sequence Error (Continued)	I	View	172 - Range Error 173 - Attempt was Made to Write to a Point That was Not in the Proper Mode 174 - Interlock Error 175-255 - Not Used
SEQEXEC	Sequence Execution State	e:	View	(NL); NL, DLL, Loaded, Run, Pause, Error, Fail, End
SEQMODE	Sequence Execution Mode	e:	Special	(Auto); Auto, SemiAuto, SnglStep
SEQNAME	Sequence Name	S	View	(Blank); N/A
SEQPR	Sequence Priority	e:	Eng/PB	(NoAction – R670); JnlPrint, Printer, Emergency, Low, High, Journal, NoAction
SEQPRGSZ	Sequence Program Size	I	View	(N/A); N/A
SEQPROC	Sequence Processing	e:	PB	(1_PU); 1_PU, 2_PU
SEQSLTSZ	Sequence Slot Size	I	PB	(0); ≥0
SERIALNO	Serial No./PROM Number of the Smart Transmitter	S	View	(Blank); N/A
SHEDMODE	Shed Mode (RegCtl)	e:	Eng	(Man); Man, Bcas, Auto
SHEDTIME	Remote Cascade Shed Time	I	Eng/PB	(0); 0 - 1000 Seconds
SHUTDOWN	Shutdown Command Flag	L	Prog	(Off); Off – On

Parameter	Description	Type	Lock	(Default) and Range
SLOTNUM	Slot Number	I	PB	(N/A); HLA _I and ST _I = 1 - 16 LLA _I = 1 - 8 AnalogOut = 1 - 8 Box Flag = 1 - 1023 Box Numeric = 1 - 2047 Box Timer = 1 - 64 but ≤ NTIMER DigComp = 1 - 255 but ≤ NDCSLOT DigIn = 1 - 32 DigOut = 1 - 16 Logic = 1 - 80 but ≤ NLOGSLOT ProcMod = 1 - 160 but ≤ NPMSLOT RegCtl = 1 - 160 but ≤ NCTLSLOT RegPV = 1 - 80 but ≤ NPVSLLOT Flag = 1 - 1023 but ≤ NFLAG LLMUX = 1 - 32 PI = 1 - 8
SLWSRCID	Slidewire Voltage Source Identifier	I	Eng/PB	(1); 1 - 16
SO	Status Output (Digout)	L	Oper	(Off); Off - On
	Status Output (Timer)	L	View	(Off); Off - On
SO1 - SO16	Logic Block Status Output	L	View	(Off); On - Off
SO(I)	Status Output Array (I = State)	L	View	(Off); On - Off
SOAKT1-12	Soak Time for Soak Segments 1-12	R	Supr	(0.0); 0.0 - 120.0 Minutes
SOAKV1-12	Soak Value for Soak Segments 1-12	R	Supr	(NaN); N/A

Parameter	Description	Type	Lock	(Default) and Range
SOCMD(I)	Digital Composite Output Status Command (I = State)	L	Prog	(Off); Off – On
SP	Setpoint of the PV in Engineering Units (RegCtl) Preset Time (Timer)	R I	Oper Oper	(0.0); SPLOLM-SPHILM (0); 0 – 32000
SPEUHI	Setpoint Engineering Unit Range High	R	View	(N/A); $\geq$ SPEULO
SPEULO	Setpoint Engineering Unit Range Low	R	View	(N/A); $\leq$ SPEUHI
SPFORMAT	Setpoint Decimal Point Format	e:	View	(N/A); D0, D1, D2, D3
SPHIFL	Setpoint High Limit Violation Flag	L	View	(Off); Off – On
SPHILM	Setpoint High Limit	R	Supr	(NaN); SPLOLM - SPEUHI, NaN
SPLOCK	Control Lock	e:	Eng	(Operator); Operator, Supervis, Engineer, Program
SPLOFL	Setpoint Low Limit Violation Flag	L	View	(Off); Off – On
SPLOLM	Setpoint Low Limit	R	Supr	(NaN); SPEULO - SPHILM, NaN
SPOPT	Setpoint Option	e:	Eng/PB	(None); None, TV, Asp
SPP	Setpoint In Percent	R	View	(N/A); N/A
SPTV	Setpoint Target Value in Engineering Units	R	Oper	(N/A); SPLOLM - SPHILM, NaN
SPTVP	Set Point Target Value in %	R	View	(N/A); $\geq$ 0.0%
SRQUTAVG	Avg. UCN Store Request Trip Time	R	View	(0); N/A
SRQUTMAX	Max. UCN Store Request Trip Time	R	View	(0); N/A
SRSPTAVG	Avg. UCN Store Response Trip Time	R	View	(0); N/A
SRSPTMAX	Max. UCN Store Response Trip Time	R	View	(0); N/A
SSTEP(n)	Subroutine Step Name (n = 1 - 2)	S	View	(Blank); N/A
SSTEPIDX(n)	Subroutine Step Name Index (n = 1 - 2)	I	View	(Blank); 0 - 3000

Parameter	Description	Type	Lock	(Default) and Range
SSTMT(n)	Subroutine Statement Number (n = 1 - 2)	I	View	(Blank); 0 – 255
ST0_OP1 through ST2_OP3	State 0 - Output 1 Through State 2 - Output 3	L	Eng/PB	(Off); Off – On
STARTFL	Start Command Flag	L	Prog	(Off); Off – On
STATE	Timer State (Timer, DigIn, Totalizr) Current State (STI)	e: e:	View View	(Stopped); Stopped, Running (N/A); Loading, Loadcomp, Loadfail, Calib, Calcomp, Calfail, OK, DBChange
STATE0 through STATE2	Current State	S	View	(Off for DigOut, Blank for Others);N/A
STATETXT(n)	State Descriptor 0 - 3 Text	S	PB	(STATETXT(0) = Off, STATETXT(1) = On, STATETXT(2) = STATE2);A-Z, 0-9, –
STATMENT	Statement	I	View	(0); 1 – 255
STDBYMAN	Standby Manual Flag	L	View	(Off); Off – On
STEP	Step	S	View	(Blank); N/A

Parameter	Description	Type	Lock	(Default) and Range
STEPIDX	Step Index	I	View	(Blank); 0 - 3000
STI_EU	Smart Transmitter Engineering Units	e:	Eng	(InH2O); InH2O, MMHG, PSI, KPA, MBar, Bar, G_SQCM, KG_SQCM, MPA, MMH2O, INHG, Deg_C, Deg_F, Deg_K, Deg_R, MV, V, Ohms, CM_HR, Gal_HR, LIT_HR, CC_HR, CM_Min, Gal_Min, Lit_Min, CC_Min, CM_DAY, Gal_Day, kGal_Day, BRL_Day, CM_Sec, Ft_Sec, M_Sec, PRCNT, BLANK, LBS, KG, TONS, GRAMS, OZ, GAL, BRL, CUB_M, LITERS, MLITRES, FL_OZ, FEET, METERS, MM, INCHES, KG_CUM, G_CUM, LBS_CUFT, LBS_CUIN
STISWVER	Software Revision Level of the Smart Transmitter	S	View	(Blank); N/A
STITAG	Transmitter Tag Name of the Smart Transmitter	E	Eng/PB	(Spaces); A - Z and 0 - 9
STOPFL	Stop Command Flag	L	Prog	(Off); Off - On
STRTFAIL(n)	Startup/Failover Information (n = 1 - 6)	S	View	(); 00 - FF
SUMSLTSZ	Total Memory for CL	I	View	(0); >0
SUSPSTAT	Suspend State	e:	View	(None); None, ConfMsg, Wait, InputMsg, Feedback

Parameter	Description	Type	Lock	(Default) and Range
SYNCHSTS	Primary/Secondary Database Synchronization Status	e:	View	(None); OK, Warning, Fail
T	Temperature Input	R	View	(1); ≥ 0.0
T0	Zero Reference for Temperature	R	Supr	(0.0); N/A
T1	Integral Time in Minutes	R	Supr	(0.0); 0.0 - 1440.0 Minutes
T2	Derivative Time in Minutes	R	Supr	(0.0); 0.0 - 1440.0 Minutes
TCRNGOPT	Thermocouple Range Option	e:	Eng/PB	(Normal); Normal, Extended
TD	Total Dead Time in Minutes	R	Supr	(0.0); ≥ 0.0 Minutes
TF	PV Filter Lag Time in Minutes	R	Supr	(0.0); 0.0 - 60.0 Minutes
TIMEBASE	Time Base (Timer) Time Base (Totalizr, PI)	e: e:	Eng Eng/PB	(Seconds); Seconds, Minutes (Minutes); Seconds, Minutes, Hours
TLD	Lead Time Constant in Minutes	R	Supr	(0.0); -1440.0 to +1440.0 Minutes
TLG1, TLG2	Lag Time Constants 1 and 2 in Minutes	R	Supr	(0.0); 0.0 - 1440.0 Minutes
TMCMD(n)	Timer Commands for Timers 1-64	e:	Oper	(N/A); None, Start, Stop, Reset, ResetStrt
TMPV(n)	Timer PV in Seconds or Minutes for Timers 1-64	I	View	(0); > 0
TMRV(n)	Timer RV – Remaining Time for Timers 1-64	I	View	(0); > 0
TMSO(n)	Timer Status Outputs for Timers 1-64	L	View	(Off); Off – On

Parameter	Description	Type	Lock	(Default) and Range
TMSP(n)	Timer SP in Seconds/Minutes for Timers 1-64	I	Oper	(0); 0 – 32000
TMST(n)	Timer States for Timers 1-64	e:	View	(Stopped); Stopped, Running
TMTB(n)	Time Base for Timers 1-64	e:	Engr	(Seconds); Seconds, Minutes
TRACKING	Selected Input Tracking	L	Eng/PB	(Off); Off – On
TRFB	Tracking Feedback Input in %	R	View	(NaN); N/A
TRATAVG	Average UCN Transaction Trip Time	R	View	(0); N/A
TRATMAX	Maximum UCN Transaction Trip Time	R	View	(0); N/A
TSTS	Temperature Input Value Status	e:	View	(Normal); Normal, Uncertn, Bad
TVPROC	Target Value Processor State	e:	Oper	(Off); Off, Preset, Run
UCNRECHN	UCN Receive Channel	e:	View	(ChannelA); ChannelA - ChannelB
UNCMDFL	Uncommanded Change Alarm Flag	L	View	(Off); Off – On
UNIT	Unit Identifier	S	PB	(N/A); A-Z, 0-9 (Max of 100 Unit Identifiers)
UPGRADE	PM Upgrade Status	e:	Oper	(OK); OK, Upgrade
URL	Upper Range Limit	R	Eng/View	(N/A); N/A – NaN
URV	Upper Range Value	R	Supr/View	(NaN); N/A – NaN
WARMSTRT	Warm start flag	L	View	(N/A); On – Off
WITHBIASn	I/O Module Physical Bias State (n=1 - 40)	L	View	(On); On – Off
X	Steam Compressibility Input (FlowComp)	R	View	(1.0); ≥ 0.0

Parameter	Description	Type	Lock	(Default) and Range
X1	X1 Input Value to be Biased (AutoMan)	R	Prog	(NaN); N/A
X1 - X4	Inputs 1-4 (IncrSum, OrSel)	R	Prog	(NaN); ≥ 0.0 , NaN
X2	Bias Adjustment Input (AutoMan) Input Number 2 (RatioCtl)	R	View	(N/A); N/A
X2FILT	Filtered value of the X2 input	R	View	(N/A); N/A
X2TF	X2 input filter lag time in minutes	R	Supr	(0.0); 0 - 60 minutes
XEUHI	X Input High Range in Engineering Units	R	Eng	(100.0, Equivalent to 100%); >XEULO
XEULO	X Input Low Range in Engineering Units	R	Eng	(0.0, Equivalent to 0%); < XEUHI
XSTS	X Input Value Status	e:	View	(Normal); Normal, Uncertn, Bad