

NovaCart Electronics
Official User Manual
Document Name: UserManual.pdf
Version: 2.0
Published by: NovaCart Electronics
Website: www.novacartelectronics.com

About This Document

This document explains the everyday operation, maintenance, troubleshooting, software updates, battery care, safety recommendations, and best practices for NovaCart Electronics products.

It is intended for customers who have already completed the initial product setup.

Product Maintenance

How can I keep my device in good condition?

To maximize the lifespan of your NovaCart product:

- Keep the device clean and dry.
- Avoid extreme temperatures.
- Use only official NovaCart chargers and accessories.
- Install software updates regularly.
- Store devices in a cool, dry environment.
- Avoid dropping or applying excessive force.

Proper maintenance improves reliability and product lifespan.

Battery Care

How should I care for rechargeable batteries?

For battery-powered NovaCart devices:

- Keep battery levels between 20% and 80% whenever possible.
- Avoid leaving the battery connected after reaching 100%.
- Use only approved chargers.
- Avoid charging in extremely hot or cold environments.
- If storing a device for a long period, leave the battery around 50% charged.

Software Updates

Why should I install software updates?

Software and firmware updates may include:

- Security improvements
- Performance improvements
- Stability improvements
- Bug fixes
- New features

Install updates whenever they become available.

Cleaning Instructions

How should I clean my device?

Before cleaning:

- Turn off the device.
- Disconnect power.
- Remove connected accessories.

Cleaning recommendations:

- Use a microfiber cloth.

- Do not use abrasive cleaners.
- Avoid spraying liquids directly onto electronics.
- Never immerse products in water unless specifically designed for water resistance.

Laptop Troubleshooting

Applicable Products

- NovaBook Air 14
- NovaBook Pro 15

My laptop won't turn on.

Try the following:

1. Connect the official charger.
2. Charge the battery for at least 30 minutes.
3. Hold the power button for 10 seconds.
4. Verify the charging indicator is illuminated.

My laptop is running slowly.

Possible solutions:

- Restart the laptop.
- Install pending updates.
- Close unnecessary applications.
- Free available storage space.

My laptop won't connect to Wi-Fi.

Try the following:

- Restart the router.
- Toggle Wi-Fi off and back on.
- Forget and reconnect to the network.
- Install the latest network drivers.

Smartphone Troubleshooting

Applicable Products

- NovaPhone X
- NovaPhone Lite

My phone is not charging.

Try the following:

- Inspect the charging cable.
- Use the supplied charger.
- Clean the charging port.
- Restart the phone.

My fingerprint sensor is not working.

Possible solutions:

- Clean the fingerprint sensor.
- Dry your finger.
- Register the fingerprint again.

Bluetooth cannot find nearby devices.

Try the following:

- Restart Bluetooth.

- Place nearby devices into pairing mode.
- Move closer to the device.
- Restart the phone.

Tablet Troubleshooting

Applicable Product

- NovaTab 11

My stylus is not working.

Possible solutions:

- Recharge the stylus.
- Restart the tablet.
- Install firmware updates.
- Pair the stylus again.

Smartwatch Troubleshooting

Applicable Product

- NovaWatch S

My smartwatch won't pair.

Try the following:

- Enable Bluetooth.
- Restart both devices.
- Reset Bluetooth pairing.
- Update the Companion App.

Heart rate readings appear inaccurate.

Try the following:

- Wear the watch snugly.
- Clean the heart-rate sensor.
- Ensure proper skin contact.

NovaBuds Pro Troubleshooting

My earbuds won't pair.

Try the following:

- Return both earbuds to the charging case.
- Hold the pairing button for five seconds.
- Delete previous Bluetooth pairings.
- Pair again.

One earbud has no sound.

Possible solutions:

- Recharge both earbuds.
- Clean the speaker mesh.
- Reset the earbuds.

NovaSound Mini Troubleshooting

My speaker has no audio.

Try the following:

- Increase the volume.
- Verify the Bluetooth connection.

- Restart the speaker.
- Recharge the battery.

NovaVision 55 Troubleshooting

My TV won't connect to Wi-Fi.

Possible solutions:

- Restart the television.
- Restart the router.
- Enter the Wi-Fi password again.
- Install the latest software updates.

My TV remote is not responding.

Try the following:

- Replace the batteries.
- Remove obstacles between the remote and television.
- Pair the remote again if necessary.

NovaCam Home Troubleshooting

My camera is offline.

Possible solutions:

- Verify the Wi-Fi connection.
- Restart the camera.
- Check your internet connection.
- Install firmware updates.

Motion detection is not working.

Try the following:

- Verify motion detection is enabled.
- Check notification permissions.
- Restart the camera.
- Update the firmware.

NovaBulb Smart Troubleshooting

My smart bulb cannot connect to Wi-Fi.

Possible solutions:

- Reset the bulb.
- Use a 2.4 GHz Wi-Fi network.
- Restart the Companion App.
- Pair the bulb again.

My smart bulb is not detected.

Try the following:

- Verify the bulb has power.
- Reset the bulb.
- Add the device again from the Companion App.

Factory Reset

When should I perform a factory reset?

Factory reset restores the product to its original settings.

Perform a factory reset only after other troubleshooting steps have failed.

Back up important data before performing a reset.

Long-Term Storage

How should I store my device?

If storing your device for an extended period:

- Keep it in a cool, dry location.
- Avoid direct sunlight.
- Recharge batteries every three months.
- Disconnect external accessories.

Safety Recommendations

How can I safely use my device?

- Do not disassemble the product.
- Keep electronics away from water unless designed for water resistance.
- Keep ventilation openings unobstructed.
- Use only approved accessories.
- Keep products away from small children where appropriate.

Data Protection

What should I do before sending my device for service?

Before sending any device for repair or servicing:

- Back up important data.
- Remove personal accounts.
- Disable device locks where possible.

NovaCart Electronics is not responsible for customer data remaining on serviced devices.

Technical Support

How can I get technical support?

Customers can contact NovaCart Electronics through:

- AI-powered Chat Support
- Email Support
- Phone Support

Technical support is available during normal business hours.