






black: the waveguide's mouth, where its lip meets the roof
grey: the insert's seam

Notes


1. Cabinet: 18 mm Baltic birch, glued. The vertical corners and the gable's hips are rounded 6 mm, the fin's edges 3 mm. 3 x 3 mm shadow lines at z 110 and z 857.
2. The drivers sit flush: each frame in a rebate, a 3 mm trim ring over its flange and screws, level with the finish.
3. The tweeter is at the throat of a waveguide insert in the roof (sheet 3): axis z 935, 176 behind the front face. The shape is set by simulation (fab/out/acoustics/waveguide).
4. The back (port, amplifier, label) is drawn on sheet 4 with the wiring.
5. Finish: colour coat and 2K clear; the Facts printed between them.

earmilk floorstander | General arrangement


Front, left side and top at 1:5. Heights from the floor; depths from the front face.

mm | first issue 2026-10-08 | from fab/sheets.py (the CAD)

Check every bought part against its own drawing before cutting.



red dashed: the cables' runs to the amplifier (sheet 4)



The roof


1. The waveguide insert (light blue) sits in a pocket in the gable block, 0.3 mm clear all round. It slides out forward, level, with the tweeter on it.
2. The tweeter is rear-mounted: its flange in a counterbore behind the throat, its dome and surround filling the 30 mm throat, so the wall runs on from the surround with no step.
3. Its cable leaves through the boss's open back into a 14 mm channel down through the block and the top panel, to a connector in the woofer chamber with slack for the insert's travel.
4. Four magnets and two pins in the insert's back face meet their partners in the pocket's back wall (sheet 3).

earmilk floorstander | Section on the centreline


Section A-A on the centre plane (x 195) seen from the left at 1:5, and the roof at 1:2. Cut wood hatched; the insert hatched the other way.

mm | first issue 2026-10-08 | from fab/sheets.py (the CAD)


Check every bought part against its own drawing before cutting.



FRONT



SECTION ON THE AXIS (WITH THE GABLE)



BACK (THE FACE THAT MEETS THE POCKET)

Fitting the tweeter and the insert

1. Solder the tweeter's lead (2 x 1.5 mm², 450 mm) to its tabs and fit the plug half of the connector. Feed the lead through the boss from the front.
2. Seat the tweeter in the counterbore from behind, dome toward the throat, on a 0.5 mm foam gasket. Fix its 3 screws into the insert (heat-set brass inserts, M3).
3. Glue the magnets into the insert's back with epoxy, polarity marked, and their partners into the pocket's back wall, opposite poles out. Fit the two pins in the insert.
4. From the front, feed the lead into the pocket's channel, plug it into the socket on the cabinet's lead (pulled up through the channel from the woofer chamber), push the slack back down.
5. Slide the insert in, level, until the pins seat and the magnets pull it home: its face flush with the roof, the seam even.
6. Service: lift it out with a suction lifter on its flat border (or a pull loop under its lower edge), unplug, and the tweeter comes out with it.

earmilk floorstander | Waveguide insert and tweeter mount

The insert at 1:2: front, section on the axis, back; the pocket; fitting and service.

mm | first issue 2026-10-08 | from fab/sheets.py (the CAD)

Check every bought part against its own drawing before cutting.