

```
1  list  F=inhx8m, P=16F88, R=hex, N=0
2
3 #include p16f88.inc
4
5  __config __CONFIG1, _FOSC_INTOSCIO & _WDT_OFF & _LVP_OFF & _CCP1_RB0
6  __config __CONFIG2, _IESO_OFF & _FCMEN_OFF
7
8  Errorlevel -302 ; switches off Message [302]: Register in operand not in bank 2
9
10 ; Definitions -----
11
12 ; RAM preserved -----
13
14 ; Constants -----
15
16 ; Program Memory -----
17     ORG    0x0000
18     GOTO   Init
19
20 ; Interrupt Service Routine (ISR) -----
21     ORG    0x0004 ; Interrupt vector location
22
23 ; Microcontroller initialization -----
24 Init    ORG    0x0008
25
26 ; Main program -----
27 Start
28 ; ***** YOUR CODE GOES HERE *****
29     MOVLW  b'00001111'
30     MOVWF  H'20'
31     CLRF   H'21'
32     MOVLW  b'11001100'
33     MOVWF  H'21'
34 LoopPoint RRF  H'20',F
35     INCF   H'21',F
36     GOTO   LoopPoint
37 Finish
38     END    ; End of program
39
40
41
42
```