ZAPI code (dec)	Emergency Code	ZAPI string	MDI Code	Colonne1	LogBook	Warning	Block	Stop
0	209	PARAM RESTORE	14	0	X	X		
0	249	CHECK UP NEEDED	0	0				
0	247	DATA ACQUISITION	0	0				
0	224	WAITING FOR NODE	0	0		X		
0	228	TILLER OPEN	51	0				
0	224	WAITING FOR NODE	0	0		X		
0	224	WAITING FOR NODE	0	0		X		
8784	223	COIL SHOR. MC	76	0	X		X	
8977	53	STBY I HIGH	53	0	X		X	
8978	52	PUMP I=0 EVER	52	0	X	X		
12544	251	WRONG SET BAT.	41	0	X		X	
12545	170	WRONG KEY VOLT.	41	0	X		X	
12560	31	VMN HIGH	31	0	X		X	
12561	206	INIT VMN HIGH	31	0	X		X	
12576	30	VMN LOW	30	0	X		X	
12577	207	INIT VMN LOW	30	0	X		X	
12592	60	CAPACITOR CHARGE	60	0	X		X	
12801	252	WRONG ZERO	58	0	X			X
12817	74	DRIVER SHORTED	74	0	X		X	
12833	75	CONTACTOR DRIVER	75	0	X		X	
12834	254	EB. DRIV.SHRT.	40	0	X			X
12835	195	POS. EB. SHORTED	84	0	X		X	
12836	246	EB. DRIV.OPEN	42	0	X			X
13058	193	SMARTDRIVER KO	69	0	X		X	
13840	208	EEPROM KO	13	0	X			X
16656	65	MOTOR TEMPERAT.	65	0	X			
16912	62	TH. PROTECTION	62	0	X	X		
16913	250	THERMIC SENS. KO	61	0	X	X		
17169	218	SENS MOT TEMP KO	68	0	X	X		
20481	194	AUX BATT. SHORT.	27	0	X		X	
20482	214	EVP COIL OPEN	9	0	X			X
20483	215	EVP DRIV. SHORT.	9	0	X		X	
20737	220	VKEY OFF SHORTED	20	0	X		X	
20756	19	LOGIC FAILURE #1	19	0	X		X	
21569	38	CONTACTOR OPEN	38	0	X		X	
21570	37	CONTACTOR CLOSED	37	0	X		X	
24592	8	WATCHDOG	8	0	X		X	
25346	236	CURRENT GAIN	92	0	X			
33072	248	NO CAN MSG.	67	0	X		X	
65281	244	WARNING SLAVE	1	0		X		
65297	17	LOGIC FAILURE #3	17	0	X		X	
65298	18	LOGIC FAILURE #2	18	0	X		X	
65308	28	PUMP VMN LOW	28	0	X		X	
65309	29	PUMP VMN HIGH	29	0	X		X	
65346	66	BATTERY LOW	0	0		X		
65358	78	VACC NOT OK	78	0				X
65359	79	INCORRECT START	79	0				X
65360	80	FORW + BACK	80	0				X
65361	181	WRONG ENC SET	83	0	X		X	
65362	82	ENCODER ERROR	82	0	X		X	
65366	86	PEDAL WIRE KO	86	0	X			X
65433	153	OFFSET SPD.SENS.	3	0		X		
65434	154	SIXSTEP ERROR	3	0	X		X	
65435	155	WAIT MOTOR STILL	45	0		X		
65437	157	FAULT DRV.POWER	4	0	X		X	
65438	158	NOT RDY DRV.POW.	4	0	X		X	
65439	159	HVIL FAIL	5	0	X		X	
65440	160	SENS BAT TEMP KO	0	0				X
65441	161	RPM HIGH	0	0				X
65442	162	BUMPER STOP	0	0				X
65443	163	ED SLIP MISMATCH	7	0	X		X	
65444	164	PWM ACQ. ERROR	6	0	X		X	
65448	168	SIN/COS D.ERR XX	3	0	X		X	
65449	169	ENCODER D.ERR XX	3	0	X			X
65451	171	ACQUIRING A.S.	2	0		X		
65452	172	ACQUIRE ABORT	2	0		X		
65453	173	ACQUIRE END	2	0		X		
65455	175	SPEED FB. ERROR	81	0	X		X	
65456	176	HOME SENS.ERR XX	3	0	X		X	
65457	177	COIL SHOR. EB.	76	0	X			X
65458	178	MOTOR TEMP. STOP	65	0	X			X
65459	179	STEER SENSOR KO	95	0	X			
65460	180	OVERLOAD	57	0	X		X	
65465	185	TILLER ERROR	64	0	X		X	
65466	186	WAIT MOT.P STILL	45	0		X		
65467	187	LIFT+LOWER	49	0				X
65468	188	PUMP VACC NOT OK	50	0				X
65469	189	PUMP INC START	79	0				X
65470	190	PUMP VMN NOT OK	33	0	X		X	
65471	191	PUMP I NO ZERO	56	0	X	X		
65472	192	PUMP VACC RANGE	90	0	X			X
65476	196	MOT.PHASE SH.	47	0	X		X	
65477	197	WRONG SLAVE VER.	91	0	X			X
65478	198	M/S PAR CHK MISM	97	0	X			X
65479	199	PARAM TRANSFER	93	0	X			X
65480	200	VDC OFF SHORTED	88	0	X		X	
65481	201	TORQUE PROFILE	98	0	X			X
65482	202	VDC LINK OVERV.	77	0	X		X	
65484	204	BRAKE RUN OUT	63	0		X		
65485	205	EPS RELAY OPEN	70	0	X			X
65490	210	WRONG RAM MEM.	71	0	X		X	
65491	211	STALL ROTOR	11	0	X			X
65492	212	POWER MISMATCH	39	0	X		X	
65493	213	POSITIVE LC OPEN	35	0	X		X	
65496	216	EB. COIL OPEN	43	0	X			X
65499	217	PEV NOT OK	25	0	X			X
65499	219	PEB-PEVP NOT OK	73	0	X			X
65501	221	HANDBRAKE	46	0				X
65502	222	SEAT MISMATCH	15	0	X		X	
65506	226	VACC OUT RANGE	85	0	X			X
65507	227	HW FAULT	32	0	X		X	
65509	229	HW FAULT EB.	34	0	X	X		
65510	230	LC COIL OPEN	22	0	X		X	
65512	232	CONT. DRV. EV	21	0	X			X
65513	233	POWERMOS SHORTED	89	0	X		X	
65518	238	HW FAULT EV.	16	0	X	X		
65519	239	CONTROLLER MISM.	12	0	X		X	
65522	242	OPEN COIL EV.	21	0	X			X
65523	243	THROTTLE PROG.	48	0		X		
65525	245	IQ MISMATCHED	24	0	X		X	
65528	240	EVP DRIVER OPEN	9	0	X			X
65529	234	DRV. SHOR. EV	21	0	X			X
65530	237	ANALOG INPUT	96	0	X		X	
65533	253	FIELD ORIENT. KO	36	0	X		X	