Title:	#26062 - MD4-10 (Screen)
Part Number:	#26062
Description:	----

rapidHARNESS

From	To	Conductor	Conductor PN	Twist With	Gauge	Length	From Contact PN	Notes
Button_OFF.X1	Supply_12V	W31.Red	1mm² Red		1 mm²			
Button_OFF.X2	MD4_C2_Black.5	W42.Black	1mm² Black		1 mm²			
Button_ON.X1	Supply_12V	W30.Red	1mm² Red		1 mm²			
Button_ON.X2	MD4_C2_Black.4	W43.Black	1mm² Black		1 mm²			
Cabine_Button.A	Supply_12V	W28.Red	1mm² Red		1 mm²			
Cabine_Button.C	Supply_12V	W29.Red	1mm² Red		1 mm²			
CanBus_KeyBox.A	CanHigh_Wifi_Key	W12.White	1mm² - White		1 mm²			
CanBus_KeyBox.B	CanLow_Wifi_Key	W5.Blue	1mm² - Blue		1 mm²			
CanHigh_Main	CanBus_MC42.A	W10.White	1mm² - White		1 mm²			
CanHigh_Main	MD4_C1_Grey.11	W8.White	1mm² - White		1 mm²			
CanLow_Main	CanBus_MC42.B	W2.Blue	1mm² - Blue		1 mm²			
CanLow_Main	MD4_C1_Grey.2	W3.Blue	1mm² - Blue		1 mm²			
Joystick_Left.1	Supply_0V	W41.Black	1mm² Black		1 mm²			
Joystick_Left.2	Supply_VREF	W53.Violet	1 mm² Purple		1 mm²			
Joystick_Left.3	MD4_C2_Black.1	W19.Orange	1 mm² - Orange		1 mm²			
Joystick_Right.1	Supply_0V	W37.Black	1mm² Black		1 mm²			
Joystick_Right.2	Supply_VREF	W54.Violet	1 mm² Purple		1 mm²			
Joystick_Right.3	MD4_C2_Black.2	W20.Orange	1 mm² - Orange		1 mm²			
MD4_C1_Grey.1	Supply_0V	W39.Black	1mm² Black		1 mm²		Contact deutsch DTMO6	
MD4_C1_Grey.3	CanLow_Wifi_Key	W6.Blue	1mm² - Blue		1 mm²		Contact deutsch DTMO6	
MD4_C1_Grey.4	CanBus_Garmin.B	W7.Blue	1mm² - Blue		1 mm²		Contact deutsch DTMO6	
MD4_C1_Grey.5	CanBus_Spare.B	W59.Blue	1mm² - Blue		1 mm²		Contact deutsch DTMO6	
MD4_C1_Grey.6	Cabine_Button.B	W17.Orange	1 mm² - Orange		1 mm²		Contact deutsch DTMO6	
MD4_C1_Grey.7	Cabine_Button.D	W18.Orange	1 mm² - Orange		1 mm²		Contact deutsch DTMO6	
MD4_C1_Grey.8	CanBus_Spare.A	W15.White	1mm² - White		1 mm²		Contact deutsch DTMO6	
MD4_C1_Grey.9	CanBus_Garmin.A	W14.White	1mm² - White		1 mm²		Contact deutsch DTMO6	
MD4_C1_Grey.10	CanHigh_Wifi_Key	W13.White	1mm² - White		1 mm²		Contact deutsch DTMO6	
MD4_C1_Grey.12	Supply_12V	W32.Red	1mm² Red		1 mm²		Contact deutsch DTMO6	
MD4_C2_Black.3	Buzzer.B	W40.Black	1mm² Black		1 mm²		Contact deutsch DTMO6	
MD4_C2_Black.11	Supply_VREF	W55.Violet	1 mm² Purple		1 mm²		Contact deutsch DTMO6	
MD4_C2_Black.12	1_5_kOhm	W51.Red	1mm² Red		1 mm²		Contact deutsch DTMO6	
Modem_G11.1	Supply_0V	W36.Black	1mm² Black		1 mm²			
Modem_G11.2	Supply_12V	W47.Red	1mm² Red		1 mm²			
Modem_G11.3	CanLow_Main	W1.Blue	1mm² - Blue		1 mm²			
Modem_G11.4	CanHigh_Main	W9.White	1mm² - White		1 mm²			
Power_Button_To_Power_Box.A	Button_ON.3	W21.Orange	1 mm² - Orange		1 mm²			
Power_Button_To_Power_Box.B	Button_ON.4	W22.Orange	1 mm² - Orange		1 mm²			
Power_Button_To_Power_Box.C	Button_OFF.1	W56.Violet	1 mm² Purple		1 mm²			
Power_Button_To_Power_Box.D	Button_OFF.2	W57.Violet	1 mm² Purple		1 mm²			
RTC.A	1_5_kOhm	W50.Red	1mm² Red		1 mm²			
RTC.B	1_5_kOhm1	W45.Black	1mm² Black		1 mm²			

Title:	#26062 - MD4-10 (Screen)
Part Number:	#26062
Description:	----

From	To	Conductor	Conductor PN	Twist With	Gauge	Length	From Contact PN	Notes
Supply.A	Supply_12V	W26.Red	1mm² Red		1 mm²	120 cm		
Supply.B	Supply_0V	W35.Black	1mm² Black		1 mm²	120 cm		
Supply_0V	1_5_kOhm1	W44.Black	1mm² Black		1 mm²			
Supply_12V	Buzzer.A	W34.Red	1mm² Red		1 mm²			
Wifi_Supply_CanBus.A	Supply_12V	W27.Red	1mm² Red		1 mm²			
Wifi_Supply_CanBus.B	Supply_0V	W38.Black	1mm² Black		1 mm²			
Wifi_Supply_CanBus.C	CanHigh_Wifi_Key	W11.White	1mm² - White		1 mm²			
Wifi_Supply_CanBus.D	CanLow_Wifi_Key	W4.Blue	1mm² - Blue		1 mm²			