Page Name : Q-BOM
Sku management adding new sku improvements and functional changes.
Feature name : adding new sku



1. Field Renaming

- Replace **“DOVE_SH_6ml”** with **“Barcode No.”**
- Replace **“Material Type”** with **“Layer Material”**
- Replace **“Thickness”** with **“Layer Thickness”**



2. Column Reordering

- Swap the position of the following columns:
  - **Layer Material** → should appear first
  - **Layer Thickness** → should appear after Layer Material

3. Material Dropdown

- In the **Material** field, add a dropdown with the following options:
  - PET
  - MVPET
  - PE
  - LLDPE

4. Supplier Dropdown

- Add a **Supplier** dropdown field with options:
  - Scygnus
  - Flexo
  - Flexible



5. Add Volume Number Field

- Add a new input field labeled **"Volume No."**
- This should be a **free-text / numeric input** where users can enter values manually.

Sku management



6. Status Column Update

- Rename **"Status"** column to **"Select"**

Functionality:

- Provide two options:
  - **Apply**
  - **Active**
- Behavior:
  - When the user clicks **Apply**, it should change to **Active**
  - When clicked again (Active), it should revert back to **Apply**
  - This should behave similar to an **Active/Deactivate toggle**

Activation Condition

At any given time:

Only **one condition** and **one SKU** should be **Active**

Activating a new SKU/condition should automatically deactivate the previous one

Q-BOM = while creating changes

1. Machine Setpoint – Field Updates

{Remove the stroke and puller speed}



a. Field Renaming

- Replace **"Seal Temp"** with **"Vertical Sealer Temperature"**
  - *Note: This setting should be applied to all 26 machines.*

b. New Fields / Input Boxes

Sealer Temperature

- Add a new tab/section for **Horizontal Sealer Temperature**
  - Applicable for:
    - Front + Back

Vertical Stroke

- Add input fields:
  - **Vertical Stroke 1**
  - **Vertical Stroke 2**
- Unit: **Degree**

Horizontal Stroke

- Add input fields:
  - **Horizontal Stroke 1**
  - **Horizontal Stroke 2**

Filling & Nozzle Controls

- Add input fields:
  - **Right Filling Piston Stroke**
  - **Left Filling Piston Stroke**
  - **Shut Off Nozzle**
  - **Shut On Nozzle**

2. SQI_THRESHOLD Tab Enhancements

a. Limit Configuration

- For each category: **Green ,Amber ,Red**

Add:

- **Upper Limit**
- **Lower Limit**

b. Validation Logic

- Ensure logical continuity between ranges:
  - Lower limit of **Green** = Upper limit of **Amber**
  - Lower limit of **Amber** = Upper limit of **Red**
- The ranges should be:
  - Continuous (no gaps)
  - Non-overlapping

These tabs should be completely removed from the UI.

Hardware Config

Alert Config

Reason

SQI WEIGHTS



Page Name : Q-BOM
Feature name :

Page Name: Q-BOM

Feature Name: Q-BOM Management



Required Changes:

1. **Terminology Update**
   - Replace the word **“ver”** with **“version”** across the page.
2. **Remove Filters**
   - Remove the following filters:
     - Active
     - Draft
     - Pending
3. **Remove Page**
   - Remove the **Audit Trail** page completely.
4. **Column Changes**
   - Remove existing columns:
     - Seal Temp
     - Stroke
     - Speed
     - SQI Green
     - SQI Amber
   - Add new columns:
     - Horizontal Sealer Temperature
     - Vertical Sealer Temperature
     - Vertical Stroke 1
     - Vertical Stroke 2
     - Horizontal Stroke 1
     - Horizontal Stroke 2

Page Name: History

Feature Name: SQI, PQI, TQI



Required Changes:

1. **Grade Column Update**
    - Keep only the following values:
        - Bad
        - Okay
    - Remove:
        - Good
        - Cycle Result (apply this change for all: SQI, PQI, TQI)
2. **Filter Table Update**
    - In grade filter options, keep only:
        - Okay
        - Bad
    - Remove all other grade options

Page Name: settings

Feature Name: settings



Add new columns:

Horizontal Sealer Temperature

Vertical Sealer Temperature

Vertical Stroke 1

Vertical Stroke 2

Horizontal Stroke 1

Horizontal Stroke 2

Filling & Nozzle Controls

Right Filling Piston Stroke

Left Filling Piston Stroke

Shut Off Nozzle

Shut On Nozzle

Features:

1. **Default View**

    - The Settings page should display the **current settings by default** when the page loads.
2. **Machine Functionality**
    - The **machine functionality in the Settings page** should be the **same as the Hardware Settings**.