

REFILLING THE WASH FLUID RESERVOIR

Refill the wash fluid reservoir with zc10 wash fluid when alerted by the software, or refill if the wick on the service station has dried out. One bottle of wash fluid will fill up the entire reservoir. The software will alert you when it is time to refill the wash fluid if the maintenance reminder feature is enabled.



1. Select the 'Unpark' option in the software under the Service menu.







- 3. Lift the top cover of the printer.
- 4. Manually move the gantry to expose the service station.




5. Remove the red wash fluid reservoir cover.

80 service@zcorp.com



- 6. Refill the reservoir using the wash fluid supplied in the toolbox. One bottle will fill up the reservoir. Remember to reorder zc10 wash fluid.
- 7. Close the top cover of the printer.







9. Press 'OK' on the software to re-park the gantry.

www.zcorp-users.com 81