

NAND Flash Memory

MT29F64G08CBAB[A/B], MT29F128G08CFABA, MT29F128G08CFABB, MT29F256G08CJABA, MT29F256G08CJABB, MT29F64G08CBCBB, MT29F128G08CECBB, MT29F256G08C[K/M]CBB

Features

- Open NAND Flash Interface (ONFI) 2.3-compliant¹
- JEDEC NAND Flash Interface Interoperability (JESD230) compliant
- Multiple-level cell (MLC) technology
- Organization
 - Page size x8: 8936 bytes (8192 + 744 bytes)
 - Block size: 256 pages (2048K + 186K bytes)
 - Plane size: 2 planes x 2048 blocks per plane
 - Device size: 64Gb: 4096 blocks: 128Gb: 8192 blocks: 256Gb: 16,384 blocks
- Synchronous I/O performance
 - Up to synchronous timing mode 5²
 - Clock rate: 10ns (DDR)
 - Read/write throughput per pin: 200MT/s
- Asynchronous I/O performance
 - Up to asynchronous timing mode 5
 - tRC/tWC: 20ns (MIN)
 - Read/write throughput per pin: 50MT/s
- Array performance
 - Read page: 100µs (MAX)
 - Program page: 1300µs (TYP)
 - Erase block: 3ms (TYP)
- Operating Voltage Range
 - V_{CC}: 2.7–3.6V
 - V_{CCO}: 1.7–1.95V, 2.7–3.6V
- Command set: ONFI NAND Flash Protocol
- Advanced Command Set
 - Program cache
 - Read cache sequential
 - Read cache random
 - One-time programmable (OTP) mode
 - Multi-plane commands
 - Multi-LUN operations
 - Read unique ID
 - Copyback
 - Read Retry
- · First block (block address 00h) is valid when shipped from factory. For minimum required ECC, see Error Management (page 119).³

- RESET (FFh) required as first command after power-on
- Operation status byte provides software method for detecting
 - Operation completion
 - Pass/fail condition
 - Write-protect status
- Data strobe (DQS) signals provide a hardware method for synchronizing data DQ in the synchronous interface
- Copyback operations supported within the plane from which data is read
- Quality and reliability³
 - Data retention: JESD47 compliant; see qualification report
 - Endurance: 3000 PROGRAM/ERASE cycles
- Operating temperature:
 - Commercial: 0°C to +70°C
 - Industrial (IT): -40°C to +85°C
- Package
 - 48-pin TSOP
 - 100-ball BGA

Notes: 1. The ONFI 2.3 specification is available at www.onfi.org.


- 2. BGA devices up to Synchronous timing mode 5. TSOP devices up to Synchronous timing mode 4.
- 3. Read Retry operations are required to achieve specified endurance and for general array data integrity



Part Numbering Information

Micron NAND Flash devices are available in different configurations and densities. Verify valid part numbers by using Micron's part catalog search at www.micron.com. To compare features and specifications by device type, visit www.micron.com/products. Contact the factory for devices not found.

Figure 1: Part Numbering



Note: 1. Pb-free package.



Contents

General Description	
Asynchronous and Synchronous Signal Descriptions	10
Signal Assignments	
Package Dimensions	15
Architecture	18
Device and Array Organization	19
Bus Operation – Asynchronous Interface	25
Asynchronous Enable/Standby	25
Asynchronous Bus Idle	25
Asynchronous Pausing Data Input/Output	26
Asynchronous Commands	
Asynchronous Addresses	27
Asynchronous Data Input	28
Asynchronous Data Output	29
Write Protect	30
Ready/Busy#	
Bus Operation – Synchronous Interface	35
Synchronous Enable/Standby	
Synchronous Bus Idle/Driving	
Synchronous Pausing Data Input/Output	
Synchronous Commands	
Synchronous Addresses	38
Synchronous DDR Data Input	39
Synchronous DDR Data Output	40
Write Protect	
Ready/Busy#	42
Device Initialization	43
Activating Interfaces	45
Activating the Asynchronous Interface	
Activating the Synchronous Interface	45
Command Definitions	
Reset Operations	49
RESET (FFh)	49
SYNCHRONOUS RESET (FCh)	50
RESET LUN (FAh)	51
Identification Operations	52
READ ID (90h)	
READ ID Parameter Tables	53
READ PARAMETER PAGE (ECh)	54
Parameter Page Data Structure Tables	56
READ UNIQUE ID (EDh)	
Configuration Operations	74
SET FEATURES (EFh)	
GET FEATURES (EEh)	
Status Operations	
READ STATUS (70h)	
READ STATUS ENHANCED (78h)	
Column Address Operations	
CHANGE READ COLUMN (05h-E0h)	
CHANGE READ COLUMN ENHANCED (06h-E0h)	



CHANGE READ COLUMN ENHANCED (00h-05h-E0h) Operation	85
CHANGE WRITE COLUMN (85h)	86
CHANGE ROW ADDRESS (85h)	87
Read Operations	89
READ MODE (00h)	91
READ PAGE (00h-30h)	92
READ PAGE CACHE SEQUENTIAL (31h)	93
READ PAGE CACHE RANDOM (00h-31h)	94
READ PAGE CACHE LAST (3Fh)	96
READ PAGE MULTI-PLANE (00h-32h)	97
Read Retry Operations	99
Program Operations	
PROGRAM PAGE (80h-10h)	101
PROGRAM PAGE CACHE (80h-15h)	103
PROGRAM PAGE MULTI-PLANE (80h-11h)	105
Erase Operations	107
ERASE BLOCK (60h-D0h)	
ERASE BLOCK MULTI-PLANE (60h-D1h)	108
ERASE BLOCK MULTI-PLANE (60h-60h-D0h)	108
Copyback Operations	109
COPYBACK READ (00h-35h)	
COPYBACK PROGRAM (85h–10h)	
COPYBACK READ MULTI-PLANE (00h-32h)	
COPYBACK PROGRAM MULTI-PLANE (85h-11h)	
One-Time Programmable (OTP) Operations	
PROGRAM OTP PAGE (80h-10h)	
PROTECT OTP AREA (80h-10h)	
READ OTP PAGE (00h-30h)	
Multi-Plane Operations	117
Multi-Plane Addressing	
Interleaved Die (Multi-LÜN) Operations	
Error Management	
Shared Pages	120
Output Drive Impedance	
AC Overshoot/Undershoot Specifications	125
Synchronous Input Slew Rate	
Output Slew Rate	
Power Cycle Requirements	128
Electrical Specifications	
Electrical Specifications – DC Characteristics and Operating Conditions (Asynchronous)	131
Electrical Specifications – DC Characteristics and Operating Conditions (Synchronous)	
Electrical Specifications – DC Characteristics and Operating Conditions (V _{CCO})	
Electrical Specifications – AC Characteristics and Operating Conditions (Asynchronous)	
Electrical Specifications – AC Characteristics and Operating Conditions (Synchronous)	
Electrical Specifications – Array Characteristics	
Asynchronous Interface Timing Diagrams	141
Synchronous Interface Timing Diagrams	
Revision History	
Rev. H Production – 12/13	174
Rev. G – 1/13	
Rev. F - 6/12	
Rev. E – 11/11	

Micron Confidential and Proprietary



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Features

Rev. D – 9/11	
Rev. C – 4/11	
Rev. B – 2/11	
Rev. A – 8/10	



List of Figures

	9	
Figure 1:	Part Numbering	. 2
	48-Pin TSOP Type 1 (Top View)	
Figure 3:	100-Ball BGA (Ball-Down, Top View)	13
	48-Pin TSOP – Type 1 CPL (Package Code: WP)	
	100-Ball VBGA – 12mm x 18mm (Package Code: H1)	
Figure 6:	100-Ball TBGA – 12mm x 18mm (Package Code: H2)	17
	NAND Flash Die (LUN) Functional Block Diagram	
Figure 8:	Device Organization for Single-Die Package (TSOP/BGA)	19
	Device Organization for Two-Die Package (TSOP)	
	Device Organization for Two-Die Package (BGA)	
Figure 11:	Device Organization for Four-Die Package (TSOP)	21
Figure 12:	Device Organization for Four-Die Package with two CE# (BGA)	22
Figure 13:	Device Organization for Four-Die Package with four CE# (BGA)	23
Figure 14:	Array Organization per Logical Unit (LUN)	24
Figure 15:	Asynchronous Command Latch Cycle	26
Figure 16:	Asynchronous Address Latch Cycle	27
Figure 17:	Asynchronous Data Input Cycles	28
Figure 18:	Asynchronous Data Output Cycles	29
Figure 19:	Asynchronous Data Output Cycles (EDO Mode)	30
Figure 20:	READ/BUSY# Open Drain	31
Figure 21:	t Fall and t Rise ($V_{CCO} = 2.7-3.6V$)	32
Figure 22:	^t Fall and ^t Rise (V _{CCO} = 1.7-1.95V)	32
Figure 23:	IOL vs Rp ($V_{CCO} = 2.7-3.6V$)	33
Figure 24:	IOL vs Rp ($V_{CCO} = 1.7-1.95V$)	33
Figure 25:	TC vs Rp	34
Figure 26:	Synchronous Bus Idle/Driving Behavior	37
Figure 27:	Synchronous Command Cycle	38
Figure 28:	Synchronous Address Cycle	39
Figure 29:	Synchronous DDR Data Input Cycles	40
Figure 30:	Synchronous DDR Data Output Cycles	42
Figure 31:	R/B# Power-On Behavior	43
Figure 32:	Activating the Synchronous Interface	46
	RESET (FFh) Operation	
Figure 34:	SYNCHRONOUS RESET (FCh) Operation	50
	RESET LUN (FAh) Operation	
Figure 36:	READ ID (90h) with 00h Address Operation	52
Figure 37:	READ ID (90h) with 20h Address Operation	52
Figure 38:	READ ID (90h) with 40h Address Operation	52
Figure 39:	READ PARAMETER (ECh) with 00h Address Operation for ONFI	54
Figure 40:	READ PARAMETER (ECh) with 40h Address Operation for JEDEC	55
Figure 41:	READ UNIQUE ID (EDh) Operation	73
Figure 42:	SET FEATURES (EFh) Operation	75
Figure 43:	GET FEATURES (EEh) Operation	75
Figure 44:	READ STATUS (70h) Operation	82
Figure 45:	READ STATUS ENHANCED (78h) Operation	82
	CHANGE READ COLUMN (05h-E0h) Operation	
	CHANGE READ COLUMN ENHANCED (06h-E0h) Operation	
	CHANGE READ COLUMN ENHANCED (00h-05h-E0h) Operation	
	CHANGE WRITE COLUMN (85h) Operation	
	CHANGE ROW ADDRESS (85h) Operation	

Micron Confidential and Proprietary



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Features

Figure 51:	READ PAGE (00h-30h) Operation	92
	READ PAGE CACHE SEQUENTIAL (31h) Operation	
	READ PAGE CACHE RANDOM (00h-31h) Operation	
	READ PAGE CACHE LAST (3Fh) Operation	
	READ PAGE MULTI-PLANE (00h-32h) Operation	
	Read Retry Flow Chart	
	PROGRAM PAGE (80h-10h) Operation	
	PROGRAM PAGE CACHE (80h–15h) Operation (Start)	
	PROGRAM PAGE CACHE (80h–15h) Operation (End)	
	PROGRAM PAGE MULTI-PLANE (80h–11h) Operation	
	ERASE BLOCK (60h-D0h) Operation	
	ERASE BLOCK MULTI-PLANE (60h–D1h) Operation	
	ERASE BLOCK MULTI-PLANE (60h-60h-D0h) Operation	
	COPYBACK READ (00h-35h) Operation	
	COPYBACK READ (00h–35h) with CHANGE READ COLUMN (05h–E0h) Operation	
	COPYBACK PROGRAM (85h–10h) Operation	
	COPYBACK PROGRAM (85h-10h) with CHANGE WRITE COLUMN (85h) Operation	
0	COPYBACK PROGRAM MULTI-PLANE (85h-11h) Operation	
	PROGRAM OTP PAGE (80h-10h) Operation	
	PROGRAM OTP PAGE (80h-10h) with CHANGE WRITE COLUMN (85h) Operation	
	PROTECT OTP AREA (80h-10h) Operation	
	READ OTP PAGE (00h-30h) Operation	
	Overshoot	
	Undershoot	
	RESET Operation	
	RESET LUN Operation	
	READ STATUS Cycle	
	READ STATUS ENHANCED Cycle	
	READ PARAMETER PAGE	
	READ PAGE	
Figure 81:	READ PAGE Operation with CE# "Don't Care"	. 144
Figure 82:	CHANGE READ COLUMN	. 145
	READ PAGE CACHE SEQUENTIAL	
	READ PAGE CACHE RANDOM	
Figure 85:	READ ID Operation	. 148
Figure 86:	PROGRAM PAGE Operation	. 148
Figure 87:	PROGRAM PAGE Operation with CE# "Don't Care"	. 149
Figure 88:	PROGRAM PAGE Operation with CHANGE WRITE COLUMN	. 149
Figure 89:	PROGRAM PAGE CACHE	. 150
Figure 90:	PROGRAM PAGE CACHE Ending on 15h	. 150
	COPYBACK	
Figure 92:	ERASE BLOCK Operation	. 151
	SET FEATURES Operation	
	READ ID Operation	
Figure 95:	GET FEATURES Operation	. 154
	RESET (FCh) Operation	
	READ STATUS Cycle	
	READ STATUS ENHANCED Operation	
	READ PARAMETER PAGE Operation	
	READ PAGE Operation	
	CHANGE READ COLUMN	
Figure 102:	READ PAGE CACHE SEQUENTIAL (1 of 2)	. 161

Micron Confidential and Proprietary



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Features

Figure 103:	READ PAGE CACHE SEQUENTIAL (2 of 2)	162
Figure 104:	READ PAGE CACHE RANDOM (1 of 2)	163
Figure 105:	READ PAGE CACHE RANDOM (2 of 2)	163
Figure 106:	Multi-Plane Read Page (1 of 2)	164
Figure 107:	Multi-Plane Read Page (2 of 2)	165
Figure 108:	PROGRAM PAGE Operation (1 of 2)	166
Figure 109:	PROGRAM PAGE Operation (2 of 2)	166
Figure 110:	CHANGE WRITE COLUMN	167
Figure 111:	Multi-Plane Program Page	168
	ERASE BLOCK	
Figure 113:	COPYBACK (1 of 3)	169
Figure 114:	COPYBACK (2 of 3)	170
Figure 115:	COPYBACK (3 of 3)	170
Figure 116:	READ OTP PAGE	171
Figure 117:	PROGRAM OTP PAGE (1 of 2)	172
Figure 118:	PROGRAM OTP PAGE (2 of 2)	172
Figure 119:	PROTECT OTP AREA	173

8



List of Tables

Table 1: A	Asynchronous and Synchronous Signal Definitions	10
Table 2: A	Array Addressing for Logical Unit (LUN)	24
	Asynchronous Interface Mode Selection	
	Synchronous Interface Mode Selection	
	Command Set	
	Read ID Parameters for Address 00h	
Table 7: 1	Read ID Parameters for Address 20h	53
Table 8: 1	Read ID Parameters for Address 40h	53
Table 9: (ONFI Parameter Page Definiton	56
	JEDEC Parameter Page Defintion	
	Feature Address Definitions	
	Feature Address 01h: Timing Mode	
	Feature Addresses 10h and 80h: Programmable Output Drive Strength	
Table 14:	Feature Address 81h: Programmable R/B# Pull-Down Strength	77
	Feature Address 89h: Read Retry	
	Feature Address 90h: Array Operation Mode	
	Status Register Definition	
	OTP Area Details	
	Error Management Details	
	Shared Pages	
	Output Drive Strength Conditions (V _{CCQ} = 1.7–1.95V)	
Table 22:	Output Drive Strength Impedance Values (V _{CCQ} = 1.7–1.95V)	122
Table 23:	Output Drive Strength Conditions (V _{CCQ} = 2.7–3.6V)	123
Table 24:	Output Drive Strength Impedance Values (V _{CCQ} = 2.7–3.6V)	123
	Pull-Up and Pull-Down Output Impedance Mismatch	
	Asynchronous Overshoot/Undershoot Parameters	
	Synchronous Overshoot/Undershoot Parameters	
	Test Conditions for Input Slew Rate	
Table 29:	Input Slew Rate ($V_{CCQ} = 1.7-1.95V$)	126
	Input Slew Rate (V _{CCQ} = 2.7–3.6V)	
	Test Conditions for Output Slew Rate	
	Output Slew Rate ($V_{CCQ} = 1.7-1.95V$)	
	Output Slew Rate ($V_{CCQ} = 2.7-3.6V$)	
	Power Cycle Requirements	
	Absolute Maximum Ratings by Device	
	Recommended Operating Conditions	
Table 37:	Valid Blocks per LUN	129
Table 38:	Capacitance: 100-Ball BGA Package	130
	Capacitance: 48-Pin TSOP Package	
	Test Conditions	
	DC Characteristics and Operating Conditions (Asynchronous Interface)	
	DC Characteristics and Operating Conditions (Synchronous Interface) for $3.3 \mathrm{VV}_{\mathrm{CCQ}}$	
	DC Characteristics and Operating Conditions (Synchronous Interface) for 1.8V V_{CCQ}	
	DC Characteristics and Operating Conditions (3.3VV _{CCQ})	
Table 45:	DC Characteristics and Operating Conditions (1.8VV _{CCQ})	134
	AC Characteristics: Asynchronous Command, Address, and Data	
	AC Characteristics: Synchronous Command, Address, and Data	
Table 48:	Array Characteristics	140



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND General Description

General Description

Micron NAND Flash devices include an asynchronous data interface for high-performance I/O operations. These devices use a highly multiplexed 8-bit bus (DQx) to transfer commands, address, and data. There are five control signals used to implement the asynchronous data interface: CE#, CLE, ALE, WE#, and RE#. Additional signals control hardware write protection (WP#) and monitor device status (R/B#).

This Micron NAND Flash device additionally includes a synchronous data interface for high-performance I/O operations. When the synchronous interface is active, WE# becomes CLK and RE# becomes W/R#. Data transfers include a bidirectional data strobe (DQS).

This hardware interface creates a low pin-count device with a standard pinout that remains the same from one density to another, enabling future upgrades to higher densities with no board redesign.

A target is the unit of memory accessed by a chip enable signal. A target contains one or more NAND Flash die. A NAND Flash die is the minimum unit that can independently execute commands and report status. A NAND Flash die, in the ONFI specification, is referred to as a logical unit (LUN). For further details, see Device and Array Organization

Asynchronous and Synchronous Signal Descriptions

Table 1: Asynchronous and Synchronous Signal Definitions

Asynchronous Signal ¹	Synchronous Signal ¹	Туре	Description ²
ALE	ALE	Input	Address latch enable: Loads an address from DQx into the address register.
CE#	CE#	Input	Chip enable: Enables or disables one or more die (LUNs) in a target ¹ .
CLE	CLE	Input	Command latch enable: Loads a command from DQx into the command register.
DQx	DQx	I/O	Data inputs/outputs: The bidirectional I/Os transfer address, data, and command information.
-	DQS	I/O	Data strobe: Provides a synchronous reference for data input and output.
RE#	W/R#	Input	Read enable and write/read: RE# transfers serial data from the NAND Flash to the host system when the asynchronous interface is active. When the synchronous interface is active, W/R# controls the direction of DQx and DQS.
WE#	CLK	Input	Write enable and clock: WE# transfers commands, addresses, and serial data from the host system to the NAND Flash when the asynchronous interface is active. When the synchronous interface is active, CLK latches command and address cycles.
WP#	WP#	Input	Write protect: Enables or disables array PROGRAM and ERASE operations.
R/B#	R/B#	Output	Ready/busy: An open-drain, active-low output that requires an external pull-up resistor. This signal indicates target array activity.



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND **Asynchronous and Synchronous Signal Descriptions**

Table 1: Asynchronous and Synchronous Signal Definitions (Continued)

Asynchronous Signal ¹	Synchronous Signal ¹	Туре	Description ²
V _{CC}	V_{CC}	Supply	V _{CC} : Core power supply
V _{CCQ}	V_{CCQ}	Supply	V _{CCQ} : I/O power supply
V _{SS}	V_{SS}	Supply	V _{SS} : Core ground connection
V_{SSQ}	V_{SSQ}	Supply	V _{SSQ} : I/O ground connection
NC	NC	_	No connect: NCs are not internally connected. They can be driven or left unconnected.
DNU	DNU	_	Do not use: DNUs must be left unconnected.
RFU	RFU	_	Reserved for future use: RFUs must be left unconnected.


- Notes: 1. See Device and Array Organization for detailed signal connections.
 - 2. See Bus Operation Asynchronous Interface (page 25) and Bus Operation Synchronous Interface (page 35) for detailed asynchronous and synchronous interface signal descriptions.



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Signal Assignments

Signal Assignments

Figure 2: 48-Pin TSOP Type 1 (Top View)




Notes:

- 1. CE1# and R/B1# are available on dual die and quad die packages. They are NC for other configurations.
- 2. These V_{CCQ} and V_{SSQ} pins are for compatibility with ONFI 2.3. If not supplying V_{CCQ} or V_{SSO} to these pins, do not use them.



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Signal Assignments

Figure 3: 100-Ball BGA (Ball-Down, Top View)



Notes:

- 1. N/A: This signal is tri-stated when the asynchronous interface is active.
- 2. Signal names in parentheses are the signal names when the synchronous interface is active.
- 3. These signals are available on dual, and quad die packages. They are NC for other configurations.

Micron Confidential and Proprietary



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Signal Assignments


4. These signals are available on quad die four CE# die packages. They are NC for other configurations.



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Package Dimensions

Package Dimensions

Figure 4: 48-Pin TSOP - Type 1 CPL (Package Code: WP)




Note: 1. All dimensions are in millimeters.



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Package Dimensions

Figure 5: 100-Ball VBGA - 12mm x 18mm (Package Code: H1)



Notes: 1. All dimensions are in millimeters.


2. Solder ball material: SAC305 (96.5% Sn, 3% Ag, 0.5% Cu)

16



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Package Dimensions

Figure 6: 100-Ball TBGA - 12mm x 18mm (Package Code: H2)



Notes: 1. All dimensions are in millimeters.

2. Solder ball material: SAC305 (96.5% Sn, 3% Ag, 0.5% Cu)



Architecture


These devices use NAND Flash electrical and command interfaces. Data, commands, and addresses are multiplexed onto the same pins and received by I/O control circuits. The commands received at the I/O control circuits are latched by a command register and are transferred to control logic circuits for generating internal signals to control device operations. The addresses are latched by an address register and sent to a row decoder to select a row address, or to a column decoder to select a column address.

Data is transferred to or from the NAND Flash memory array, byte by byte, through a data register and a cache register.

The NAND Flash memory array is programmed and read using page-based operations and is erased using block-based operations. During normal page operations, the data and cache registers act as a single register. During cache operations, the data and cache registers operate independently to increase data throughput.

The status register reports the status of die (LUN) operations.

Figure 7: NAND Flash Die (LUN) Functional Block Diagram



Notes: 1. N/A: This signal is tri-stated when the asynchronous interface is active.

2. Some devices do not include the synchronous interface.



Device and Array Organization

Figure 8: Device Organization for Single-Die Package (TSOP/BGA)




Figure 9: Device Organization for Two-Die Package (TSOP)






Figure 10: Device Organization for Two-Die Package (BGA)






Figure 11: Device Organization for Four-Die Package (TSOP)






Figure 12: Device Organization for Four-Die Package with two CE# (BGA)






Figure 13: Device Organization for Four-Die Package with four CE# (BGA)






Figure 14: Array Organization per Logical Unit (LUN)




Table 2: Array Addressing for Logical Unit (LUN)

Cycle	DQ7	DQ6	DQ5	DQ4	DQ3	DQ2	DQ1	DQ0
First	CA7	CA6	CA5	CA4	CA3	CA2	CA1	CA0 ²
Second	LOW	LOW	CA13 ³	CA12	CA11	CA10	CA9	CA8
Third	PA7	PA6	PA5	PA4	PA3	PA2	PA1	PA0
Fourth	BA15	BA14	BA13	BA12	BA11	BA10	BA9	BA8 ⁴
Fifth	LOW	LOW	LOW	LA0 ⁵	BA19	BA18	BA17	BA16

Notes:

- 1. CAx = column address, PAx = page address, BAx = block address, LAx = LUN address; the page address, block address, and LUN address are collectively called the row address.
- 2. When using the synchronous interface, CA0 is forced to 0 internally; one data cycle always returns one even byte and one odd byte.
- 3. Column addresses 8936 (22E8h) through 16,383 (3FFFh) are invalid, out of bounds, do not exist in the device, and cannot be addressed.
- 4. BA[8] is the plane-select bit:

Plane 0: BA[8] = 0

Plane 1: BA[8] = 1

5. LA0 is the LUN-select bit. It is present only when two LUNs are shared on the target; otherwise, it should be held LOW.

LUN 0: LA0 = 0 LUN 1: LA0 = 1



Bus Operation – Asynchronous Interface

The asynchronous interface is active when the NAND Flash device powers on. The I/O bus, DQ[7:0], is multiplexed sharing data I/O, addresses, and commands. The DQS signal, if present, is tri-stated when the asynchronous interface is active.

Asynchronous interface bus modes are summarized below.

Table 3: Asynchronous Interface Mode Selection

Mode	CE#	CLE	ALE	WE#	RE#	DQS	DQx	WP#	Notes
Standby	Н	Х	Х	Х	Х	Х	Х	0V/V _{CCQ} ²	2
Bus idle	L	Х	Х	Н	Н	Х	Х	Х	
Command input	L	Н	L	LF	Н	Х	input	Н	
Address input	L	L	Н	L	Н	Х	input	Н	
Data input	L	L	L	L	Н	Х	input	Н	
Data output	L	L	L	Н	 €	Х	output	Х	
Write protect	Х	Х	Х	Х	Х	Х	Х	L	

- Notes: 1. DQS is tri-stated when the asynchronous interface is active.
 - 2. WP# should be biased to CMOS LOW or HIGH for standby.
 - 3. Mode selection settings for this table: H = Logic level HIGH; L = Logic level LOW; $X = V_{IH}$ or V_{II} .

Asynchronous Enable/Standby

A chip enable (CE#) signal is used to enable or disable a target. When CE# is driven LOW, all of the signals for that target are enabled. With CE# LOW, the target can accept commands, addresses, and data I/O. There may be more than one target in a NAND Flash package. Each target is controlled by its own chip enable; the first target (Target 0) is controlled by CE#; the second target (if present) is controlled by CE2#, etc.

A target is disabled when CE# is driven HIGH, even when the target is busy. When disabled, all of the target's signals are disabled except CE#, WP#, and R/B#. This functionality is also known as CE# "Don't Care". While the target is disabled, other devices can utilize the disabled NAND signals that are shared with the NAND Flash.

A target enters low-power standby when it is disabled and is not busy. If the target is busy when it is disabled, the target enters standby after all of the die (LUNs) complete their operations. Standby helps reduce power consumption.

Asynchronous Bus Idle

A target's bus is idle when CE# is LOW, WE# is HIGH, and RE# is HIGH.

During bus idle, all of the signals are enabled except DQS, which is not used when the asynchronous interface is active. No commands, addresses, and data are latched into the target; no data is output.



Asynchronous Pausing Data Input/Output


Pausing data input or data output is done by keeping WE# or RE# HIGH, respectively.

Asynchronous Commands

An asynchronous command is written from DQ[7:0] to the command register on the rising edge of WE# when CE# is LOW, ALE is LOW, CLE is HIGH, and RE# is HIGH.

Commands are typically ignored by die (LUNs) that are busy (RDY = 0); however, some commands, including READ STATUS (70h) and READ STATUS ENHANCED (78h), are accepted by die (LUNs) even when they are busy.

Figure 15: Asynchronous Command Latch Cycle






Asynchronous Addresses

An asynchronous address is written from DQ[7:0] to the address register on the rising edge of WE# when CE# is LOW, ALE is HIGH, CLE is LOW, and RE# is HIGH.

Bits that are not part of the address space must be LOW (see Device and Array Organization). The number of cycles required for each command varies. Refer to the command descriptions to determine addressing requirements (see Command Definitions).

Addresses are typically ignored by die (LUNs) that are busy (RDY = 0); however, some addresses are accepted by die (LUNs) even when they are busy; for example, address cycles that follow the READ STATUS ENHANCED (78h) command.

Figure 16: Asynchronous Address Latch Cycle






Asynchronous Data Input

Data is written from DQ[7:0] to the cache register of the selected die (LUN) on the rising edge of WE# when CE# is LOW, ALE is LOW, CLE is LOW, and RE# is HIGH.

Data input is ignored by die (LUNs) that are not selected or are busy (RDY = 0).

Figure 17: Asynchronous Data Input Cycles





Asynchronous Data Output

Data can be output from a die (LUN) if it is in a READY state. Data output is supported following a READ operation from the NAND Flash array. Data is output from the cache register of the selected die (LUN) to DQ[7:0] on the falling edge of RE# when CE# is LOW, ALE is LOW, CLE is LOW, and WE# is HIGH.

If the host controller is using a ^tRC of 30ns or greater, the host can latch the data on the rising edge of RE# (see Figure 18 for proper timing). If the host controller is using a ^tRC of less than 30ns, the host can latch the data on the next falling edge of RE# (see Figure 19 (page 30) for extended data output (EDO) timing).

Using the READ STATUS ENHANCED (78h) command prevents data contention following an interleaved die (multi-LUN) operation. After issuing the READ STATUS ENHANCED (78h) command, to enable data output, issue the READ MODE (00h) command.

Data output requests are typically ignored by a die (LUN) that is busy (RDY = 0); however, it is possible to output data from the status register even when a die (LUN) is busy by first issuing the READ STATUS (70h) or READ STATUS ENHANCED (78h) command.

Figure 18: Asynchronous Data Output Cycles







Figure 19: Asynchronous Data Output Cycles (EDO Mode)



Write Protect

The write protect# (WP#) signal enables or disables PROGRAM and ERASE operations to a target. When WP# is LOW, PROGRAM and ERASE operations are disabled. When WP# is HIGH, PROGRAM and ERASE operations are enabled.

It is recommended that the host drive WP# LOW during power-on until Vcc and Vccq are stable to prevent inadvertent PROGRAM and ERASE operations (see Device Initialization for additional details).

WP# must be transitioned only when the target is not busy and prior to beginning a command sequence. After a command sequence is complete and the target is ready, WP# can be transitioned. After WP# is transitioned, the host must wait ^tWW before issuing a new command.

The WP# signal is always an active input, even when CE# is HIGH. This signal should not be multiplexed with other signals.

Ready/Busy#

The ready/busy# (R/B#) signal provides a hardware method of indicating whether a target is ready or busy. A target is busy when one or more of its die (LUNs) are busy (RDY = 0). A target is ready when all of its die (LUNs) are ready (RDY = 1). Because each die (LUN) contains a status register, it is possible to determine the independent status of each die (LUN) by polling its status register instead of using the R/B# signal (see Status Operations for details regarding die (LUN) status).

This signal requires a pull-up resistor, Rp, for proper operation. R/B# is HIGH when the target is ready, and transitions LOW when the target is busy. The signal's open-drain



driver enables multiple R/B# outputs to be OR-tied. Typically, R/B# is connected to an interrupt pin on the system controller (see Figure 20 (page 31)).

The combination of Rp and capacitive loading of the R/B# circuit determines the rise time of the R/B# signal. The actual value used for Rp depends on the system timing requirements. Large values of Rp cause R/B# to be delayed significantly. Between the 10-to 90-percent points on the R/B# waveform, the rise time is approximately two time constants (TC).

$$TC = R \times C$$

Where R = Rp (resistance of pull-up resistor), and C = total capacitive load.

The fall time of the R/B# signal is determined mainly by the output impedance of the R/B# signal and the total load capacitance. Approximate Rp values using a circuit load of 100pF are provided in Figure 25 (page 34).

The minimum value for Rp is determined by the output drive capability of the R/B# signal, the output voltage swing, and Vccq.

$$Rp = \frac{Vcc (MAX) - Vol (MAX)}{IOL + \Sigma iI}$$

Where Σ il is the sum of the input currents of all devices tied to the R/B# pin.

Figure 20: READ/BUSY# Open Drain








Figure 21: ^tFall and ^tRise (V_{CCQ} = 2.7-3.6V)



- Notes: 1. ${}^{t}FALL$ is $V_{OH(DC)}$ to $V_{OL(AC)}$ and ${}^{t}RISE$ is $V_{OL(DC)}$ to $V_{OH(AC)}$.
 - 2. ^tRise dependent on external capacitance and resistive loading and output transistor impedance.
 - 3. ^tRise primarily dependent on external pull-up resistor and external capacitive loading.
 - 4. ^tFall = 10ns at 3.3V
 - 5. See TC values in Figure 25 (page 34) for approximate Rp value and TC.

Figure 22: ^tFall and ^tRise (V_{CCQ} = 1.7-1.95V)



- Notes: 1. ${}^{t}FALL$ is $V_{OH(DC)}$ to $V_{OL(AC)}$ and ${}^{t}RISE$ is $V_{OL(DC)}$ to $V_{OH(AC)}$.
 - 2. ^tRise is primarily dependent on external pull-up resistor and external capacitive loading.
 - 3. ${}^{t}Fall \approx 7 \text{ ns at } 1.8 \text{ V}.$
 - 4. See TC values in Figure 25 (page 34) for TC and approximate Rp value.



Figure 23: IOL vs Rp ($V_{CCQ} = 2.7-3.6V$)




Figure 24: IOL vs Rp (V_{CCQ} = 1.7-1.95V)







Figure 25: TC vs Rp





Bus Operation – Synchronous Interface

These NAND Flash devices have two interfaces—a synchronous interface for fast data I/O transfer and an asynchronous interface that is backward compatible with existing NAND Flash devices.

The NAND Flash command protocol for both the asynchronous and synchronous interfaces is identical. However, there are some differences between the asynchronous and synchronous interfaces when issuing command, address, and data I/O cycles using the NAND Flash signals.

When the synchronous interface is activated on a target (see Activating Interfaces), the target is capable of high-speed DDR data transfers. Existing signals are redefined for high-speed DDR I/O. The WE# signal becomes CLK. DQS is enabled. The RE# signal becomes W/R#. CLK provides a clock reference to the NAND Flash device.

DQS is a bidirectional data strobe. During data output, DQS is driven by the NAND Flash device. During data input, DQS is controlled by the host controller while inputting data on DQ[7:0].

The direction of DQS and DQ[7:0] is controlled by the W/R# signal. When the W/R# signal is latched HIGH, the controller is driving the DQ bus and DQS. When the W/R# is latched LOW, the NAND Flash is driving the DQ bus and DQS.

The synchronous interface bus modes are summarized below.

Table 4: Synchronous Interface Mode Selection

Mode	CE#	CLE	ALE	CLK	W/R#	DQS	DQ[7:0]	WP#	Notes
Standby	Н	Х	Х	Х	Х	Х	Х	0V/V _{CCQ}	1, 2
Bus idle	L	L	L	L F	Н	Х	Х	Х	
Bus driv- ing	L	L	L	L F	L	output	output	Х	
Command input	L	Н	L	I ■	Н	Х	input	Н	3
Address input	L	L	Н	I ■	Н	Х	input	Н	3
Data in- put	L	Н	Н	₽ ₹	Н	₽₹	input	Н	4
Data out- put	L	Н	Н	₽ ₹	L	See Note 5	output	Х	5
Write pro- tect	Х	Х	Х	Х	Х	Х	Х	L	
Undefined	L	L	Н	I	L	output	output	х	
Undefined	L	Н	L	□	L	output	output	Х	

Notes

- 1. CLK can be stopped when the target is disabled, even when R/B# is LOW.
- 2. WP# should be biased to CMOS LOW or HIGH for standby.
- 3. Commands and addresses are latched on the rising edge of CLK.



- 4. During data input to the device, DQS is the "clock" that latches the data in the cache register.
- During data output from the NAND Flash device, DQS is an output generated from CLK after [†]DOSCK delay.
- 6. Mode selection settings for this table: H = Logic level HIGH; L = Logic level LOW; $X = V_{IH}$ or V_{II} .

Synchronous Enable/Standby

In addition to the description found in Asynchronous Enable/Standby (page 25), the following requirements also apply when the synchronous interface is active.

Before enabling a target, CLK must be running and ALE and CLE must be LOW. When CE# is driven LOW, all of the signals for the selected target are enabled. The target is not enabled until ^tCS completes; the target's bus is then idle.

Prior to disabling a target, the target's bus must be idle. A target is disabled when CE# is driven HIGH, even when it is busy. All of the target's signals are disabled except CE#, WP#, and R/B#. After the target is disabled, CLK can be stopped.

A target enters low-power standby when it is disabled and is not busy. If the target is busy when it is disabled, the target enters standby after all of the die (LUNs) complete their operations.

Synchronous Bus Idle/Driving


A target's bus is idle or driving when CLK is running, CE# is LOW, ALE is LOW, and CLE is LOW.

The bus is idle when W/R# transitions HIGH and is latched by CLK. During the bus idle mode, all signals are enabled; DQS and DQ[7:0] are inputs. No commands, addresses, or data are latched into the target; no data is output. When entering the bus idle mode, the host must wait a minimum of ^tCAD before changing the bus mode. In the bus idle mode, the only valid bus modes supported are: bus driving, command, address, and DDR data input.

The bus is driving when W/R# transitions LOW and is latched by CLK. During the bus driving mode, all signals are enabled; DQS is LOW and DQ[7:0] is driven LOW or HIGH, but no valid data is output. Following the bus driving mode, the only valid bus modes supported are bus idle and DDR data output.



Figure 26: Synchronous Bus Idle/Driving Behavior



Note: 1. Only the selected die (LUN) drives DQS and DQ[7:0]. During an interleaved die (multi-LUN) operation, the host must use the READ STATUS ENHANCED (78h) to prevent data output contention.

Synchronous Pausing Data Input/Output

Pausing data input or data output is done by setting ALE and CLE to LOW. The host may continue data transfer by setting ALE and CLE to HIGH after the applicable ^tCAD time has passed.

Synchronous Commands


A command is written from DQ[7:0] to the command register on the rising edge of CLK when CE# is LOW, ALE is LOW, CLE is HIGH, and W/R# is HIGH.

After a command is latched—and prior to issuing the next command, address, or data I/O—the bus must go to bus idle mode on the next rising edge of CLK, except when the clock period, ^tCK, is greater than ^tCAD.

Commands are typically ignored by die (LUNs) that are busy (RDY = 0); however, some commands, such as READ STATUS (70h) and READ STATUS ENHANCED (78h), are accepted by die (LUNs), even when they are busy.



Figure 27: Synchronous Command Cycle



Note: 1. When CE# remains LOW, ^tCAD begins at the rising edge of the clock from which the command cycle is latched for subsequent command, address, data input, or data output cycle(s).

Synchronous Addresses

A synchronous address is written from DQ[7:0] to the address register on the rising edge of CLK when CE# is LOW, ALE is HIGH, CLE is LOW, and W/R# is HIGH.


After an address is latched—and prior to issuing the next command, address, or data I/O—the bus must go to bus idle mode on the next rising edge of CLK, except when the clock period, ^tCK, is greater than ^tCAD.

Bits not part of the address space must be LOW (see Device and Array Organization). The number of address cycles required for each command varies. Refer to the command descriptions to determine addressing requirements.

Addresses are typically ignored by die (LUNs) that are busy (RDY = 0); however, some addresses such as address cycles that follow the READ STATUS ENHANCED (78h) command, are accepted by die (LUNs), even when they are busy.



Figure 28: Synchronous Address Cycle



Note: 1. When CE# remains LOW, ^tCAD begins at the rising edge of the clock from which the command cycle is latched for subsequent command, address, data input, or data output cycle(s).

Synchronous DDR Data Input

To enter the DDR data input mode, the following conditions must be met:

- · CLK is running
- CE# is LOW
- W/R# is HIGH
- tCAD is met
- DQS is LOW
- ALE and CLE are HIGH on the rising edge of CLK

Upon entering the DDR data input mode after ^tDQSS, data is written from DQ[7:0] to the cache register on each and every rising and falling edge of DQS (center-aligned) when CLK is running and the DQS to CLK skew meets ^tDSH and ^tDSS, CE# is LOW, W/R# is HIGH, and ALE and CLE are HIGH on the rising edge of CLK.

To exit DDR data input mode, the following conditions must be met:

- CLK is running and the DQS to CLK skew meets ^tDSH and ^tDSS
- CE# is LOW
- W/R# is HIGH
- ALE and CLE are latched LOW on the rising edge of CLK




- The final two data bytes of the data input sequence are written to DQ[7:0] to the cache register on the rising and falling edges of DQS after the last cycle in the data input sequence in which ALE and CLE are latched HIGH.
- DQS is held LOW for tWPST (after the final falling edge of DQS)

Following ^tWPST, the bus enters bus idle mode and ^tCAD begins on the next rising edge of CLK. After ^tCAD starts, the host can disable the target if desired.

Data input is ignored by die (LUNs) that are not selected or are busy.

Figure 29: Synchronous DDR Data Input Cycles



Notes:

- When CE# remains LOW, ^tCAD begins at the first rising edge of the clock after ^tWPST completes.
- 2. ^tDSH (MIN) generally occurs during ^tDQSS (MIN).
- 3. ^tDSS (MIN) generally occurs during ^tDQSS (MAX).

Synchronous DDR Data Output

Data can be output from a die (LUN) if it is ready. Data output is supported following a READ operation from the NAND Flash array.

To enter the DDR data output mode, the following conditions must be met:

- CLK is running
- CE# is LOW
- The host has released the DQ[7:0] bus and DQS
- W/R# is latched LOW on the rising edge of CLK to enable the selected die (LUN) to take ownership of the DQ[7:0] bus and DQS within ^tWRCK
- tCAD is met
- ALE and CLE are HIGH on the rising edge of CLK



Upon entering the DDR data output mode, DQS will toggle HIGH and LOW with a delay of ^tDQSCK from the respective rising and falling edges of CLK. DQ[7:0] will output data edge-aligned to the rising and falling edges of DQS, with the first transition delayed by no more than ^tAC.

DDR data output mode continues as long as CLK is running, CE# is LOW, W/R# is LOW, and ALE and CLE are HIGH on the rising edge of CLK.

To exit DDR data output mode, the following conditions must be met:


- CLK is running
- CE# is LOW
- W/R# is LOW
- ALE and CLE are latched LOW on the rising edge of CLK

The final two data bytes are output on DQ[7:0] on the final rising and falling edges of DQS. The final rising and falling edges of DQS occur ^tDQSCK after the last cycle in the data output sequence in which ALE and CLE are latched HIGH. After ^tCKWR, the bus enters bus idle mode and ^tCAD begins on the next rising edge of CLK. Once ^tCAD starts the host can disable the target if desired.

Data output requests are typically ignored by a die (LUN) that is busy (RDY = 0); however, it is possible to output data from the status register even when a die (LUN) is busy by issuing the READ STATUS (70h) or READ STATUS ENHANCED (78h) command.



Figure 30: Synchronous DDR Data Output Cycles



Notes:

- 1. When CE# remains LOW, ^tCAD begins at the rising edge of the clock after ^tCKWR for subsequent command or data output cycle(s).
- 2. See Figure 27 (page 38) for details of W/R# behavior.
- 3. ^tAC is the DQ output window relative to CLK and is the long-term component of DQ skew.
- 4. For W/R# transitioning HIGH, DQ[7:0] and DQS go to tri-state.
- 5. For W/R# transitioning LOW, DQ[7:0] drives current state and DQS goes LOW.
- 6. After final data output, DQ[7:0] is driven until W/R# goes HIGH, but is not valid.

Write Protect

See Write Protect (page 30).

Ready/Busy#

See Ready/Busy# (page 30).



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Device Initialization

Device Initialization


Some NAND Flash devices do not support V_{CCQ} . For these devices all references to V_{CCQ} are replaced with V_{CC} .

Micron NAND Flash devices are designed to prevent data corruption during power transitions. V_{CC} is internally monitored. (The WP# signal supports additional hardware protection during power transitions.) When ramping V_{CC} and V_{CCQ} , use the following procedure to initialize the device:

- 1. Ramp V_{CC} .
- 2. Ramp V_{CCO} . V_{CCO} must not exceed V_{CC} .
- 3. The host must wait for R/B# to be valid and HIGH before issuing RESET (FFh) to any target (see Figure 31). The R/B# signal becomes valid when 50µs has elapsed since the beginning the V_{CC} ramp, and 10µs has elapsed since V_{CCQ} reaches V_{CCQ} (MIN) and V_{CC} reaches V_{CC} (MIN).
- 4. If not monitoring R/B#, the host must wait at least 100 μ s after V_{CCQ} reaches V_{CCQ} (MIN) and V_{CC} reaches V_{CC} (MIN). If monitoring R/B#, the host must wait until R/B# is HIGH.
- 5. The asynchronous interface is active by default for each target. Each LUN draws less than an average of I_{ST} measured over intervals of 1ms until the RESET (FFh) command is issued.
- 6. The RESET (FFh) command must be the first command issued to all targets (CE#s) after the NAND Flash device is powered on. Each target will be busy for ^tPOR after a RESET command is issued. The RESET busy time can be monitored by polling R/B# or issuing the READ STATUS (70h) command to poll the status register. The host must not issue an additional RESET (FFh) command during ^tPOR.
- 7. The device is now initialized and ready for normal operation.

At power-down, V_{CCQ} must go LOW, either before, or simultaneously with, V_{CC} going LOW.

Figure 31: R/B# Power-On Behavior



Note: 1. Disregard V_{CCQ} for devices that use only V_{CC}.

To initialize a discovered target, the following steps shall be taken. The initialization process should be followed for each connected CE# signal, including performing the READ PARAMETER PAGE (ECh) command for each target. Each chip enable corre-



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Device Initialization

sponds to a unique target with its own independent properties that the host shall observe and subsequently use.

The host should issue the READ PARAMETET PAGE (ECh) command. This command returns information that includes the capabilities, features, and operating parameters of the device. When the information is read from the device, the host shall check the CRC to ensure that the data was received correctly and without error prior to taking action on that data.

If the CRC of the first parameter page read is not valid, the host should read redundant parameter page copies. The host can determine whether a redundant parameter page is present or not by checking if the first four bytes contain at least two bytes of the parameter page signature. If the parameter page signature is present, then the host should read the entirety of that redundant parameter page. The host should then check the CRC of that redundant parameter page. If the CRC is correct, the host may take action based on the contents of that redundant parameter page. If the CRC is incorrect, then the host should attempt to read the next redundant parameter page by the same procedure.

The host should continue reading redundant parameter pages until the host is able to accurately reconstruct the parameter page contents. The host may use bit-wise majority or other ECC techniques to recover the contents of the parameter page from the parameter page copies present. When the host determines that a parameter page signature is not present, then all parameter pages have been read.

After successfully retrieving the parameter page, the host has all information necessary to successfully communicate with that target. If the host has not previously mapped defective block information for this target, the host should next map out all defective blocks in the target. The host may then proceed to utilize the target, including erase and program operations.



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Activating Interfaces

Activating Interfaces

After performing the steps under (page $\,0\,$), the asynchronous interface is active for all targets on the device.

Each target's interface is independent of other targets, so the host is responsible for changing the interface for each target.

If the host and NAND Flash device, through error, are no longer using the same interface, then steps under Activating the Asynchronous Interface are performed to resynchronize the interfaces.

Activating the Asynchronous Interface

To activate the asynchronous NAND interface, once the synchronous interface is active, the following steps are repeated for each target:

- 1. The host pulls CE# HIGH, disables its input to CLK, and enables its asynchronous interface.
- The host pulls CE# LOW and issues the RESET (FFh) command, using an asynchronous command cycle.
- 3. R/B# goes LOW for ^tRST.
- 4. After ^tITC, and during ^tRST, the device enters the asynchronous NAND interface. READ STATUS (70h) and READ STATUS ENHANCED (78h) are the only commands that can be issued.
- 5. After ^tRST, R/B# goes HIGH. Timing mode feature address (01h), subfeature parameter P1 is set to 00h, indicating that the asynchronous NAND interface is active and that the device is set to timing mode 0.

For further details, see Reset Operations.

Activating the Synchronous Interface


To activate the synchronous NAND Flash interface, the following steps are repeated for each target:

- 1. Issue the SET FEATURES (EFh) command.
- 2. Write address 01h, which selects the timing mode.
- 3. Write P1 with 1Xh, where "X" is the timing mode used in the synchronous interface (see Configuration Operations).
- 4. Write P2-P4 as 00h-00h-00h.
- 5. R/B# goes LOW for ^tITC. The host should pull CE# HIGH. During ^tITC, the host should not issue any type of command, including status commands, to the NAND Flash device.
- 6. After ^tITC, R/B# goes HIGH and the synchronous interface is enabled. Before pulling CE# LOW, the host should enable the clock.



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Activating Interfaces

Figure 32: Activating the Synchronous Interface



Note: 1. TM = Timing mode.



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Command Definitions

Command Definitions

Table 5: Command Set

	Com-	Number of Valid	Data	Com-	Number of Valid	Com-	Valid While Se-	Valid While Oth-	
	mand	Address	Input	mand	Address	mand	lected LUN	er LUNs	Note
Command	Cycle #1	Cycles	Cycles	Cycle #2	Cycles #2	Cycle #3	is Busy ¹	are Busy ²	S
Reset Operations									
RESET	FFh	0	_	-	-	_	Yes	Yes	
SYNCHRONOUS RE- SET	FCh	0	_	_	-	_	Yes	Yes	
RESET LUN	FAh	3	1	_	_	-	Yes	Yes	
Identification Oper	rations								
READ ID	90h	1	_	_	_	_			3
READ PARAMETER PAGE	ECh	1	-	-	-	-			
READ UNIQUE ID	EDh	1	_	_	_	_			
Configuration Ope	rations								
GET FEATURES	EEh	1	_	_	_	_			3
SET FEATURES	EFh	1	4	_	_	-			4
Status Operations									
READ STATUS	70h	0	_	_	_	_	Yes		
READ STATUS EN- HANCED	78h	3	-	-	-	-	Yes	Yes	
Column Address O	perations								
CHANGE READ COL- UMN	05h	2	-	E0h	-	-		Yes	
CHANGE READ COL- UMN ENHANCED (ONFI)	06h	5	-	E0h	-	-		Yes	
CHANGE READ COL- UMN ENHANCED (JEDEC)	00h	5	-	05h	2	E0h		Yes	
CHANGE WRITE COLUMN	85h	2	Optional	_	-	_		Yes	
CHANGE ROW AD- DRESS	85h	5	Optional	11h (Op- tional)	-	1		Yes	5
Read Operations									
READ MODE	00h	0	-	_	_	-		Yes	
READ PAGE	00h	5	-	30h	_	_		Yes	6
READ PAGE MULTI- PLANE	00h	5	_	32h	-	_		Yes	
READ PAGE CACHE SEQUENTIAL	31h	0	ı	-	-	I		Yes	7



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND **Command Definitions**

Table 5: Command Set (Continued)

Command	Com- mand Cycle #1	Number of Valid Address Cycles	Data Input Cycles	Com- mand Cycle #2	Number of Valid Address Cycles #2	Com- mand Cycle #3	Valid While Se- lected LUN is Busy ¹	Valid While Oth- er LUNs are Busy ²	Note s
READ PAGE CACHE RANDOM	00h	5	-	31h	-	-		Yes	6,7
READ PAGE CACHE LAST	3Fh	0	_	_	-	_		Yes	7
Program Operation	ns								
PROGRAM PAGE	80h	5	Yes	10h	_	_		Yes	
PROGRAM PAGE MULTI-PLANE	80h or 81h	5	Yes	11h	_	_		Yes	
PROGRAM PAGE CACHE	80h	5	Yes	15h	-	_		Yes	8
Erase Operations	'							1	
ERASE BLOCK	60h	3	_	D0h	_	_		Yes	
ERASE BLOCK MULTI-PLANE (ON- FI)	60h	3	_	D1h	-	_		Yes	
ERASE BLOCK MUL- TI-PLANE (JEDEC)	60h	3	-	60h	3	D0h		Yes	
Copyback Operation	ons								
COPYBACK READ	00h	5	1	35h	-	_		Yes	6
COPYBACK PRO- GRAM	85h	5	Optional	10h	_	_		Yes	
COPYBACK PRO- GRAM MULTI- PLANE	85h	5	Optional	11h	-	_		Yes	

- Notes: 1. Busy means RDY = 0.
 - 2. These commands can be used for interleaved die (multi-LUN) operations.
 - 3. The READ ID (90h) and GET FEATURES (EEh) output identical data on rising and falling DQS edges.
 - 4. The SET FEATURES (EFh) command requires data transition prior to the rising edge of CLK, with identical data for the rising and falling edges.
 - 5. Command cycle #2 of 11h is conditional. See CHANGE ROW ADDRESS (85h) (page 87) for more details.
 - 6. This command can be preceded by READ PAGE MULTI-PLANE (00h-32h) command to accommodate a maximum simultaneous multi-plane array operation.
 - 7. Issuing a READ PAGE CACHE-series (31h, 00h-31h, 00h-32h, 3Fh) command when the array is busy (RDY = 1, ARDY = 0) is supported if the previous command was a READ PAGE (00h-30h) or READ PAGE CACHE-series command; otherwise, it is prohibited.
 - 8. Issuing a PROGRAM PAGE CACHE (80h-15h) command when the array is busy (RDY = 1, ARDY = 0) is supported if the previous command was a PROGRAM PAGE CACHE (80h-15h) command; otherwise, it is prohibited.

48



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Reset Operations

Reset Operations

RESET (FFh)

The RESET (FFh) command is used to put a target into a known condition and to abort command sequences in progress. This command is accepted by all die (LUNs), even when they are busy.


When FFh is written to the command register, the target goes busy for ^tRST. During ^tRST, the selected target (CE#) discontinues all array operations on all die (LUNs). All pending single- and multi-plane operations are cancelled. If this command is issued while a PROGRAM or ERASE operation is occurring on one or more die (LUNs), the data may be partially programmed or erased and is invalid. The command register is cleared and ready for the next command. The data register and cache register contents are invalid.

RESET must be issued as the first command to each target following power-up (see Device Initialization). Use of the READ STATUS ENHANCED (78h) command is prohibited during the power-on RESET. To determine when the target is ready, use READ STATUS (70h).

If the RESET (FFh) command is issued when the synchronous interface is enabled, the target's interface is changed to the asynchronous interface and the timing mode is set to 0. The RESET (FFh) command can be issued asynchronously when the synchronous interface is active, meaning that CLK does not need to be continuously running when CE# is transitioned LOW and FFh is latched on the rising edge of CLK. After this command is latched, the host should not issue any commands during ^tTC. After ^tTC, and during or after ^tRST, the host can poll each LUN's status register.

If the RESET (FFh) command is issued when the asynchronous interface is active, the target's asynchronous timing mode remains unchanged. During or after ^tRST, the host can poll each LUN's status register.

Figure 33: RESET (FFh) Operation





64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Reset Operations

SYNCHRONOUS RESET (FCh)


When the synchronous interface is active, the SYNCHRONOUS RESET (FCh) command is used to put a target into a known condition and to abort command sequences in progress. This command is accepted by all die (LUNs), even when they are BUSY.

When FCh is written to the command register, the target goes busy for ^tRST. During ^tRST, the selected target (CE#) discontinues all array operations on all die (LUNs). All pending single- and multi-plane operations are cancelled. If this command is issued while a PROGRAM or ERASE operation is occurring on one or more die (LUNs), the data may be partially programmed or erased and is invalid. The command register is cleared and ready for the next command. The data register and cache register contents are invalid and the synchronous interface remains active.

During or after ^tRST, the host can poll each LUN's status register.

SYNCHRONOUS RESET is only accepted while the synchronous interface is active. Its use is prohibited when the asynchronous interface is active.

Figure 34: SYNCHRONOUS RESET (FCh) Operation





64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Reset Operations

RESET LUN (FAh)

The RESET LUN (FAh) command is used to put a particular LUN on a target into a known condition and to abort command sequences in progress. This command is accepted by only the LUN addressed by the RESET LUN (FAh) command, even when that LUN is busy.

When FAh is written to the command register, the addressed LUN goes busy for ^tRST. During ^tRST, the selected LUN discontinues all array operations. All pending single- and multi-plane operations are canceled. If this command is issued while a PROGRAM or ERASE operation is occurring on the addressed LUN, the data may be partially programmed or erased and is invalid. The command register is cleared and ready for the next command. The data register and cache register contents are invalid.

If the RESET LUN (FAh) command is issued when the synchronous interface is enabled, the targets's interface remains in synchronous mode.


If the RESET LUN (FAh) command is issued when the asynchronous interface is enabled, the target's interface remains in asynchronous mode.

During or after ^tRST, the host can poll each LUN's status register.

The RESET LUN (FAh) command is prohibited when not in the default array operation mode.

The RESET LUN (FAh) command can only be issued to a target (CE#) after the RESET (FFh) command has been issued as the first command to a target following power-up.

Figure 35: RESET LUN (FAh) Operation





Identification Operations

READ ID (90h)

The READ ID (90h) command is used to read identifier codes programmed into the target. This command is accepted by the target only when all die (LUNs) on the target are idle.

Writing 90h to the command register puts the target in read ID mode. The target stays in this mode until another valid command is issued.


When the 90h command is followed by a 00h address cycle, the target returns a 5-byte identifier code that includes the manufacturer ID, device configuration, and part-specific information.

When the 90h command is followed by a 20h address cycle, the target returns the 4-byte ONFI identifier code.

When the 90h command is followed by a 40h address cycle, the target returns the 5-byte IEDEC identifier code.


After the 90h and address cycle are written to the target, the host enables data output mode to read the identifier information. When the asynchronous interface is active, one data byte is output per RE# toggle. When the synchronous interface is active, one data byte is output per rising edge of DQS when ALE and CLE are HIGH; the data byte on the falling edge of DQS is identical to the data byte output on the previous rising edge of DQS.

Figure 36: READ ID (90h) with 00h Address Operation




Note: 1. See the READ ID Parameter tables for byte definitions.

Figure 37: READ ID (90h) with 20h Address Operation



Note: 1. See the READ ID Parameter tables for byte definitions.

Figure 38: READ ID (90h) with 40h Address Operation



Note: 1. See the READ ID Parameter tables for byte definitions.



READ ID Parameter Tables

Table 6: Read ID Parameters for Address 00h

Device	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
MT29F64G08CBABA	2Ch	64h	44h	4Bh	A9h	00h	00h	00h
MT29F64G08CBABB	2Ch	64h	44h	4Bh	A9h	00h	00h	00h
MT29F64G08CBCBB	2Ch	64h	44h	4Bh	A9h	00h	00h	00h
MT29F128G08CECBB	2Ch	64h	44h	4Bh	A9h	00h	00h	00h
MT29F128G08CFABA	2Ch	64h	44h	4Bh	A9h	00h	00h	00h
MT29F128G08CFABB	2Ch	64h	44h	4Bh	A9h	00h	00h	00h
MT29F256G08CJABA	2Ch	84h	C5h	4Bh	A9h	00h	00h	00h
MT29F256G08CJABB	2Ch	84h	C5h	4Bh	A9h	00h	00h	00h
MT29F256G08CKCBB	2Ch	84h	C5h	4Bh	A9h	00h	00h	00h
MT29F256G08CMCBB	2Ch	64h	44h	4Bh	A9h	00h	00h	00h

Note: 1. h = hexadecimal.

Table 7: Read ID Parameters for Address 20h

Device	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4
All	4Fh	4Eh	46h	49h	XXh

Notes: 1. h = hexadecimal.

2. XXh = Undefined.

Table 8: Read ID Parameters for Address 40h

Device	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5
Asynchronous only	4Ah	45h	44h	45h	43h	01h
Asynchronous or Synchronous	4Ah	45h	44h	45h	43h	05h

Note: 1. h = hexadecimal.



READ PARAMETER PAGE (ECh)

The READ PARAMETER PAGE (ECh) command is used to read the ONFI or JEDEC parameter page programmed into the target. This command is accepted by the target only when all die (LUNs) on the target are idle.

Writing ECh to the command register puts the target in read parameter page mode. The target stays in this mode until another valid command is issued.

When the ECh command is followed by an 00h or 40h address cycle, the target goes busy for ^tR. If the READ STATUS (70h) command is used to monitor for command completion, the READ MODE (00h) command must be used to re-enable data output mode. Use of the READ STATUS ENHANCED (78h) command is prohibited while the target is busy and during data output.

After ^tR completes, the host enables data output mode to read the parameter page. When the asynchronous interface is active, one data byte is output per RE# toggle. When the synchronous interface is active, one data byte is output for each rising or falling edge of DQS.

A minimum of three copies of the parameter page are stored in the device. Each parameter page is 256 bytes. If desired, the CHANGE READ COLUMN (05h-E0h) command can be used to change the location of data output. Use of the CHANGE READ COLUMN ENHANCED (06h-E0h or 00h-05h-E0h) command is prohibited.

The READ PARAMETER PAGE (ECh) output data can be used by the host to configure its internal settings to properly use the NAND Flash device. Parameter page data is static per part, however the value can be changed through the product cycle of NAND Flash. The host should interpret the data and configure itself accordingly.

The host should continue reading redundant parameter pages until the host is able to accurately reconstruct the parameter page contents. Parameter pages returned by the target may have invalid CRC values; however, bit-wise majority may be used to recover the contents of the parameter page. The host may use bit-wise majority or other techniques to recover the contents of the parameter page from the parameter page copies present.

Figure 39: READ PARAMETER (ECh) with 00h Address Operation for ONFI







Figure 40: READ PARAMETER (ECh) with 40h Address Operation for JEDEC





Parameter Page Data Structure Tables

Table 9: ONFI Parameter Page Definiton

Byte	Description	Device	Values
Revision	information and features block		
0–3	Parameter page signature Byte 0: 4Fh, "O" Byte 1: 4Eh, "N" Byte 2: 46h, "F" Byte 3: 49h, "I"	-	4Fh, 4Eh, 46h, 49h
4–5	Revision number Bit[15:6]: Reserved (0) Bit 5: 1 = supports ONFI version 2.3 Bit 4: 1 = supports ONFI version 2.2 Bit 3: 1 = supports ONFI version 2.1 Bit 2: 1 = supports ONFI version 2.0 Bit 1: 1 = supports ONFI version 1.0 Bit 0: Reserved (0)	-	3Eh, 00h
6–7	Features supported	MT29F64G08CBABA	D8h, 01h
	Bit[15:9]: Reserved (0)	MT29F128G08CFABA	
	Bit 8: 1 = supports program page register clear enhancement	MT29F256G08CJABA	DAh, 01h
	Bit 7: 1 = supports extended parameter page	MT29F64G08CBABB	F8h, 01h
	Bit 6: 1 = supports multi-plane read operations	MT29F64G08CBCBB	
	Bit 5: 1 = supports synchronous interface	MT29F128G08CECBB	
	Bit 4: 1 = supports odd-to-even page copyback Bit 3: 1 = supports multi-plane program and erase oper-	MT29F128G08CFABB	
	ations	MT29F256G08CMCBB	
	Bit 2: 1 = supports non-sequential page programming	MT29F256G08CJABB	FAh, 01h
	Bit 1: 1 = supports multiple LUN operations Bit 0: 1 = supports 16-bit data bus width	MT29F256G08CKCBB	
8–9	Optional commands supported Bit[15:10]: Reserved (0) Bit 9: 1 = supports Reset LUN command Bit 8: 1 = supports small data move Bit 7: 1 = supports CHANGE ROW ADDRESS Bit 6: 1 = supports CHANGE READ COLUMN ENHANCED Bit 5: 1 = supports READ UNIQUE ID Bit 4: 1 = supports COPYBACK Bit 3: 1 = supports READ STATUS ENHANCED Bit 2: 1 = supports GET FEATURES and SET FEATURES Bit 1: 1 = supports read cache commands Bit 0: 1 = supports PROGRAM PAGE CACHE	_	FFh, 03h
10–11	Reserved (0)	_	All 00h
12–13	Extended parameter page length	-	03h, 00h
14	Number of parameter pages	-	1Dh
15–31	Reserved (0)	-	All 00h
Vlanufact	curer information block		



Byte	Description	Device	Values
32–43	Device manufacturer (12 ASCII characters) Micron	-	4Dh, 49h, 43h, 52h, 4Fh, 4Eh, 20h, 20h, 20h, 20h, 20h
44–63	Device model (20 ASCII characters)	MT29F64G08CBABAWP	4Dh, 54h, 32h, 39h, 46h, 36h, 34h, 47h, 30h, 38h, 43h, 42h, 41h, 42h, 41h, 57h, 50h, 20h, 20h, 20h
		MT29F64G08CBABBWP	4Dh, 54h, 32h, 39h, 46h, 36h, 34h, 47h, 30h, 38h, 43h, 42h, 41h, 42h, 42h, 57h, 50h, 20h, 20h, 20h
		MT29F128G08CFABAWP	4Dh, 54h, 32h, 39h, 46h, 31h, 32h, 38h, 47h, 30h, 38h, 43h, 46h, 41h, 42h, 41h, 57h, 50h, 20h, 20h
		MT29F128G08CFABBWP	4Dh, 54h, 32h, 39h, 46h, 31h, 32h, 38h, 47h, 30h, 38h, 43h, 46h, 41h, 42h, 42h, 57h, 50h, 20h, 20h
		MT29F256G08CJABAWP	4Dh, 54h, 32h, 39h, 46h, 32h, 35h, 36h, 47h, 30h, 38h, 43h, 4Ah, 41h, 42h, 41h, 57h, 50h, 20h, 20h
		MT29F256G08CJABBWP	4Dh, 54h, 32h, 39h, 46h, 32h, 35h, 36h, 47h, 30h, 38h, 43h, 4Ah, 41h, 42h, 42h, 57h, 50h, 20h, 20h



Byte	Description	Device	Values
44–63	Device model (20 ASCII characters)	MT29F64G08CBCBBH1	4Dh, 54h, 32h, 39h, 46h, 36h, 34h, 47h, 30h, 38h, 43h, 42h, 43h, 42h, 42h, 48h, 31h, 20h, 20h, 20h
		MT29F128G08CECBBH1	4Dh, 54h, 32h, 39h, 46h, 31h, 32h, 38h, 47h, 30h, 38h, 43h, 45h, 43h, 42h, 42h, 48h, 31h, 20h, 20h
		MT29F256G08CKCBBH2	4Dh, 54h, 32h, 39h, 46h, 32h, 35h, 36h, 47h, 30h, 38h, 43h, 4Bh, 43h, 42h, 42h, 48h, 32h, 20h, 20h
		MT29F256G08CMCBBH2	4Dh, 54h, 32h, 39h, 46h, 32h, 35h, 36h, 47h, 30h, 38h, 43h, 4Dh, 43h, 42h, 42h, 48h, 32h, 20h, 20h
64	JEDEC manufacturer ID	_	2Ch
65–66	Date code	_	00h, 00h
67–79	Reserved (0)	_	All 00h
Memory o	organization block		
80–83	Number of data bytes per page	_	00h, 20h, 00h, 00h
84–85	Number of spare bytes per page	_	E8h, 02h
86–91	Reserved (0)	_	All 00h
92–95	Number of pages per block	_	00h, 01h, 00h, 00h
96–99	Number of blocks per LUN	_	00h, 10h, 00h, 00h
100	Number of LUNs per chip enable	MT29F64G08CBABA	01h
		MT29F64G08CBABB	
		MT29F64G08CBCBB	
		MT29F128G08CECBB	
		MT29F128G08CFABA	
		MT29F128G08CFABB	
		MT29F256G08CMCBB	
		MT29F256G08CJABA	02h
		MT29F256G08CJABB	
		MT29F256G08CKCBB	
101	Number of address cycles Bit[7:4]: Column address cycles Bit[3:0]: Row address cycles	-	23h



Byte	Description	Device	Values
102	Number of bits per cell	-	02h
103–104	Bad blocks maximum per LUN	-	55h, 00h
105–106	Block endurance	-	03h, 03h
107	Guaranteed valid blocks at beginning of target	-	01h
108–109	Block endurance for guaranteed valid blocks	-	00h, 00h
110	Number of programs per page	-	01h
111	Reserved (0)	_	00h
112	Number of bits ECC correctability	_	FFh
113	Number of plane address bits Bit[7:4]: Reserved (0) Bit[3:0]: Number of interleaved address bits	-	01h
114	Multi-plane operation attributes Bit[7:6]: Reserved (0) Bit 5: Reserved Bit 4: 1 = supports read cache Bit 3: Address restrictions for cache operations Bit 2: 1 = supports program cache Bit 1: 1 = no block address restrictions Bit 0: Overlapped/concurrent interleaving support	_	1Eh
115–127	Reserved (0)	_	All 00h
Electrical	parameters block		
128	I/O pin capacitance per chip enable	MT29F64G08CBABAWP	06h
		MT29F64G08CBABBWP	
		MT29F128G08CFABAWP	05h
		MT29F128G08CFABBWP	
		MT29F256G08CJABAWP	08h
		MT29F256G08CJABBWP	
		MT29F64G08CBCBBH1	06h
		MT29F128G08CECBBH1	06h
		MT29F256G08CKCBBH2	0Ah
		MT29F256G08CMCBBH2	05h
129–130	Timing mode support Bit[15:6]: Reserved (0) Bit 5: 1 = supports timing mode 5 Bit 4: 1 = supports timing mode 4 Bit 3: 1 = supports timing mode 3 Bit 2: 1 = supports timing mode 2 Bit 1: 1 = supports timing mode 1 Bit 0: 1 = supports timing mode 0, shall be 1	_	3Fh, 00h
131–132	Reserved (0)	_	All 00h
133–134	^t PROG Maximum PROGRAM PAGE time (μs)	_	C4h, 09h



Byte	Description	Device	Values
135–136	^t BERS Maximum BLOCK ERASE time (μs)	-	E0h, 2Eh
137–138	^t R Maximum PAGE READ time (μs)	_	64h, 00h
139–140	^t CCS Minimum change column setup time (ns)	_	C8h, 00h
141–142	Source synchronous timing mode support	MT29F64G08CBABAWP	00h, 00h
	Bit [15:6]: Reserved (0) Bit 5: 1 = supports timing mode 5 Bit 4: 1 = supports timing mode 4	MT29F128G08CFABAWP	
		MT29F256G08CJABAWP	
	Bit 3: 1 = supports timing mode 3	MT29F64G08CBABBWP	1Fh, 00h
	Bit 2: 1 = supports timing mode 2	MT29F128G08CFABBWP	
	Bit 1: 1 = supports timing mode 1	MT29F256G08CJABBWP	
	Bit 0: 1 = supports timing mode 0	MT29F64G08CBCBBH1	3Fh, 00h
		MT29F128G08CECBBH1	
		MT29F256G08CKCBBH2	
		MT29F256G08CMCBBH2	
143	Source synchronous features	MT29F64G08CBABAWP	00h
	Bit[7:3]: Reserved (0)	MT29F128G08CFABAWP	
	Bit 2: 1 = devices support CLK stopped for data input Bit 1: 1 = typical capacitance values present Bit 0: 0 = use [†] CAD MIN value	MT29F256G08CJABAWP	
		MT29F64G08CBABBWP	02h
		MT29F128G08CFABBWP	
		MT29F256G08CJABBWP	
		MT29F64G08CBCBBH1	
		MT29F128G08CECBBH1	
		MT29F256G08CKCBBH2	
		MT29F256G08CMCBBH2	
144–145	CLK input pin capacitance, typical	MT29F64G08CBABAWP	00h, 00h
		MT29F128G08CFABAWP	
		MT29F256G08CJABAWP	
		MT29F64G08CBABBWP	2Eh, 00h
		MT29F128G08CFABBWP	28h, 00h
		MT29F256G08CJABBWP	43h, 00h
		MT29F64G08CBCBBH1	33h, 00h
		MT29F128G08CECBBH1	
		MT29F256G08CKCBBH2	40h, 00h
		MT29F256G08CMCBBH2	26h, 00h



Byte	Description	Device	Values
146–147	I/O pin capacitance, typical	MT29F64G08CBABAWP	00h, 00h
		MT29F128G08CFABAWP	
		MT29F256G08CJABAWP	
		MT29F64G08CBABBWP	2Fh, 00h
		MT29F128G08CFABBWP	28h, 00h
		MT29F256G08CJABBWP	41h, 00h
		MT29F64G08CBCBBH1	2Fh, 00h
		MT29F128G08CECBBH1	
		MT29F256G08CKCBBH2	48h, 00h
		MT29F256G08CMCBBH2	24h, 00h
148–149	Input capacitance, typical	MT29F64G08CBABAWP	00h, 00h
		MT29F128G08CFABAWP	
		MT29F256G08CJABAWP	
		MT29F64G08CBABBWP	34h, 00h
		MT29F128G08CFABBWP	2Dh, 00h
		MT29F256G08CJABBWP	48h, 00h
		MT29F64G08CBCBBH1	2Bh, 00h
		MT29F128G08CECBBH1	
		MT29F256G08CKCBBH2	44h, 00h
		MT29F256G08CMCBBH2	22h, 00h
150	Input pin capacitance, maximum	MT29F64G08CBABAWP	07h
		MT29F64G08CBABBWP	
		MT29F128G08CFABAWP	06h
		MT29F128G08CFABBWP	
		MT29F256G08CJABAWP	08h
		MT29F256G08CJABBWP	
		MT29F64G08CBCBBH1	06h
		MT29F128G08CECBBH1	
		MT29F256G08CKCBBH2	09h
		MT29F256G08CMCBBH2	05h
151	Driver strength support Bit[7:3]: Reserved (0) Bit 2: 1 = Supports 18 Ohm drive strength Bit 1: 1 = Supports 25 Ohm drive strength Bit 0: 1 = Supports driver strength settings	-	07h
152–153	^t R maximum multi-plane page read time (µs)	_	64h, 00h
154–155	^t ADL program page register clear enhancement value (ns)	-	46h, 00h
156–163	Reserved (0)	_	All 00h



Byte	Description	Device	Values
Vendor bl	ock		
164–165	Vendor-specific revision number	_	03h, 00h
166	TWO-PLANE PAGE READ support Bit[7:1]: Reserved (0) Bit 0: 1 = Support for TWO-PLANE PAGE READ	-	01h
167	Read cache support Bit[7:1]: Reserved (0) Bit 0: 0 = Does not support Micron-specific read cache function	-	00h
168	READ UNIQUE ID support Bit[7:1]: Reserved (0) Bit 0: 0 = Does not support Micron-specific READ UNIQUE ID	-	00h
169	Programmable DQ output impedance support Bit[7:1]: Reserved (0) Bit 0: 0 = No support for programmable DQ output impedance by B8h command	-	00h
170	Number of programmable DQ output impedance settings Bit[7:3]: Reserved (0) Bit [2:0] = Number of programmable DQ output impedance settings	-	04h
171	Programmable DQ output impedance feature address Bit[7:0] = Programmable DQ output impedance feature address	-	10h
172	Programmable R/B# pull-down strength support Bit[7:1]: Reserved (0) Bit 0: 1 = Support programmable R/B# pull-down strength	_	01h
173	Programmable R/B# pull-down strength feature address Bit[7:0] = Feature address used with programmable R/B# pull-down strength	-	81h
174	Number of programmable R/B# pull-down strength settings Bit[7:3]: Reserved (0) Bit[2:0] = Number of programmable R/B# pull-down strength settings	-	04h
175	OTP mode support Bit[7:2]: Reserved (0) Bit 1: 1 = Supports Get/Set Features command set Bit 0: 0 = Does not support A5h/A0h/AFh OTP command set	_	02h
176	OTP page start Bit[7:0] = Page where OTP page space begins	-	02h



Byte	Description	Device	Values
177	OTP DATA PROTECT address Bit[7:0] = Page address to use when issuing OTP DATA PROTECT command	-	01h
178	Number of OTP pages Bit[7:5]: Reserved (0) Bit[4:0] = Number of OTP pages	_	1Eh
179	OTP Feature Address	_	90h
180	Read Retry options Bit[7:4]: Reserved (0) Bit[3:0] = Number of Read Retry options supported	_	08h
181–184	Read Retry Options available. A value of '1' in a bit position shows that Read Retry option is available for use. A value of '0' in a bit position shows that Read Retry option is not available for use.	_	FFh, 00h, 00h, 00h
	For example, the binary value of '37h, 00h, 00h, 00h' would represent that Read Retry options 0, 1, 2, 4, and 5 are available which would correspond to Read Retry input option selections of 00h, 01h, 02h, 04h, and 05h. It furthermore would show that Read Retry options 3, 6, and 7 to 32 which would correspond to Read Retry input option selections 03h, 06h, 07h to 20h, are not available.		
185–252	Reserved (0)	_	All 00h
185–252	Reserved (0)	_	All 00h
253	Parameter page revision	MT29F64G08CBABAWP	06h
		MT29F64G08CBABBWP	
		MT29F128G08CFABAWP	
		MT29F128G08CFABBWP	
		MT29F256G08CJABAWP	
		MT29F256G08CJABBWP	
		MT29F64G08CBCBBH1	
		MT29F128G08CECBBH1	
		MT29F256G08CKCBBH2	
		MT29F256G08CMCBBH2	



Byte	Description	Device	Values
254–255	Integrity CRC	MT29F64G08CBABAWP	04h, 8Fh
		MT29F64G08CBABBWP	95h, 19h
		MT29F128G08CFABAWP	B9h, ACh
		MT29F128G08CFABBWP	2Fh, 5Eh
		MT29F256G08CJABAWP	BEh, 28h
		MT29F256G08CJABBWP	E9h, EFh
		MT29F64G08CBCBBH1	21h, AEh
		MT29F128G08CECBBH1	83h, F0h
		MT29F256G08CKCBBH2	8Dh, 5Ch
		MT29F256G08CMCBBH2	EDh, 2Bh
Redundan	t ONFI parameter pages	,	
256–511	Value of bytes 0–255	_	See bytes 0–255
512–767	Value of bytes 0–255	_	See bytes 0–255
		-	
6912–7167	Value of bytes 0–255	-	See bytes 0–255
7168–7423	Value of bytes 0–255	-	See bytes 0–255
Extended	parameter pages		
7424–7425	Extended parameter page Integrity CRC	-	2Eh, 60h
7426–7429	Extended parameter page signature Byte 0: 45h, "E" Byte 1: 50h, "P" Byte 2: 50h, "P" Byte 3: 53h, "S"	_	45h, 50h, 50h, 53h
7430–7439	Reserved (0)	_	All 00h
7440	Section 0 type	_	02h
7441	Section 0 length	_	01h
7442–7455	-	_	All 00h
7456	Number of bits ECC correctability	_	28h
7457	ECC codeword size	_	0Ah
7458–7459	Bad blocks maximum per LUN	_	55h, 00h
7460–7461	Block endurance	_	03h, 03h
7462–7471	Reserved (0)	_	All 00h
	t Extended parameter pages	I	ı
7472–7519	Value of bytes 7424-7471	_	See bytes 7424-7471
7520–7567	Value of bytes 7424-7471	-	See bytes 7424-7471
		-	
8720–8767	Value of bytes 7424-7471	-	See bytes 7424-7471
8768–8815	Value of bytes 7424-7471	-	See bytes 7424-7471
8816–8935	Reserved (FFh)	_	All FFh



Table 10: JEDEC Parameter Page Defintion

Byte	Description	Device	Values
Revision l	nformation and Features Block		
0–3	Parameter page signature Byte 0: 4Ah, "J" Byte 1: 45h, "E" Byte 2: 53h, "S" Byte 3: 44h, "D"	-	4Ah, 45h, 53h, 44h
4–5	Revision number Bit[15:3]: Reserved (0) Bit 2: 1 = supports JEDEC version 1.0 Bit 1: 1 = supports vendor specific parameter page Bit 0: Reserved (0)	-	06h, 00h
6–7	Features supported	MT29F64G08CBABA	18h, 01h
	Bit[15:9]: Reserved (0) Bit 8: 1 = supports program page register clear enhancement	MT29F128G08CFABA	
		MT29F256G08CJABA	1Ah, 01h
	Bit 7: 1 = supports external V _{PP}	MT29F64G08CBABB	38h, 01h
	Bit 6: 1 = supports Toggle Mode DDR Bit 5: 1 = supports Synchronous DDR Bit 4: 1 = supports multi-plane read operations Bit 3: 1 = supports multi-plane program and erase operations	MT29F64G08CBCBB	
		MT29F128G08CECBB	
		MT29F128G08CFABB	
		MT29F256G08CMCBB	
	Bit 2: 1 = supports non-sequential page programming	MT29F256G08CJABB	3Ah, 01h
	Bit 1: 1 = supports multiple LUN operations Bit 0: 1 = supports 16-bit data bus width	MT29F256G08CKCBB	
8–10	Features supported Bit[23:11]: Reserved (0) Bit 10: 1 = supports Synchronous Reset Bit 9: 1 = supports Reset LUN (Primary) Bit 8: 1 = supports Small Data Move Bit 7: 1 = supports Multi-plane Copyback Program (Primary) Bit 6: 1 = supports Random Data Out (Primary) Bit 5: 1 = supports Read Unique ID Bit 4: 1 = supports Copyback Bit 3: 1 = supports Read Status Enhanced (Primary) Bit 2: 1 = supports Get Features and Set Features Bit 1: 1 = supports Read Cache commands	_	FFh, 07h, 00h
	Bit 0: 1 = supports Read Cache Commands Bit 0: 1 = supports Page Cache Program command		



Byte	Description	Device	Values
11–12	Secondary commands supported	_	58h, 00h
	Bit[15:8]: Reserved (0)		
	Bit 7: 1 = supports secondary Read Status Enhanced		
	Bit 6: 1 = supports secondary Multi-plane Block Erase		
	Bit 5: 1 = supports secondary Multi-plane Copyback Pro-		
	gram		
	Bit 4: 1 = supports secondary Multi-plane Program		
	Bit 3: 1 = supports secondary Random Data Out		
	Bit 2: 1 = supports secondary Multi-plane Copyback		
	Read		
	Bit 1: 1 = supports secondary Multi-plane Read Cache		
	Random		
	Bit 0: 1 = supports secondary Multi-plane Read		
13	Number of Parameter Pages	-	11h
14–31	Reserved (0)	-	All 00h
Manufact	urer information block		
32–43	Device manufacturer (12 ASCII characters)	_	4Dh, 49h, 43h, 52h, 4Fh,
	Micron		4Eh, 20h, 20h, 20h, 20h,
			20h, 20h



Byte	Description	Device	Values
44–63	Device model (20 ASCII characters)	MT29F64G08CBABAWP	4Dh, 54h, 32h, 39h, 46h, 36h, 34h, 47h, 30h, 38h, 43h, 42h, 41h, 42h, 41h, 57h, 50h, 20h, 20h, 20h
		MT29F64G08CBABBWP	4Dh, 54h, 32h, 39h, 46h, 36h, 34h, 47h, 30h, 38h, 43h, 42h, 41h, 42h, 42h, 57h, 50h, 20h, 20h, 20h
		MT29F128G08CFABAWP	4Dh, 54h, 32h, 39h, 46h, 31h, 32h, 38h, 47h, 30h, 38h, 43h, 46h, 41h, 42h, 41h, 57h, 50h, 20h, 20h
		MT29F128G08CFABBWP	4Dh, 54h, 32h, 39h, 46h, 31h, 32h, 38h, 47h, 30h, 38h, 43h, 46h, 41h, 42h, 42h, 57h, 50h, 20h, 20h
		MT29F256G08CJABAWP	4Dh, 54h, 32h, 39h, 46h, 32h, 35h, 36h, 47h, 30h, 38h, 43h, 4Ah, 41h, 42h, 41h, 57h, 50h, 20h, 20h
		MT29F256G08CJABBWP	4Dh, 54h, 32h, 39h, 46h, 32h, 35h, 36h, 47h, 30h, 38h, 43h, 4Ah, 41h, 42h, 42h, 57h, 50h, 20h, 20h
		MT29F64G08CBCBBH1	4Dh, 54h, 32h, 39h, 46h, 36h, 34h, 47h, 30h, 38h, 43h, 42h, 43h, 42h, 42h, 48h, 31h, 20h, 20h, 20h
		MT29F128G08CECBBH1	4Dh, 54h, 32h, 39h, 46h, 31h, 32h, 38h, 47h, 30h, 38h, 43h, 45h, 43h, 42h, 42h, 48h, 31h, 20h, 20h
		MT29F256G08CKCBBH2	4Dh, 54h, 32h, 39h, 46h, 32h, 35h, 36h, 47h, 30h, 38h, 43h, 48h, 43h, 42h, 42h, 48h, 32h, 20h, 20h
		MT29F256G08CMCBBH2	4Dh, 54h, 32h, 39h, 46h, 32h, 35h, 36h, 47h, 30h, 38h, 43h, 4Dh, 43h, 42h, 42h, 48h, 32h, 20h, 20h
64–69	JEDEC manufacturer ID	-	2Ch, 00h, 00h, 00h
70–79	Reserved (0)	_	All 00h
	organization block	T	
80–83	Number of data bytes per page	_	00h, 20h, 00h, 00h



Description	Device	Values
Number of spare bytes per page	_	E8h, 02h
Number of data bytes per parital page	_	All 00h
Number of pages per block	_	00h, 01h, 00h, 00h
Number of blocks per LUN	_	00h, 10h, 00h, 00h
Number of LUNs per chip enable	MT29F64G08CBABA	01h
	MT29F64G08CBABB	
	MT29F64G08CBCBB	
	MT29F128G08CECBB	
	MT29F128G08CFABA	
	MT29F128G08CFABB	
	MT29F256G08CMCBB	
	MT29F256G08CJABA	02h
	MT29F256G08CJABB	
	MT29F256G08CKCBB	
Number of address cycles Bit[7:4]: Column address cycles Bit[3:0]: Row address cycles	-	23h
	_	02h
-	_	01h
Multi-plane operation addressing Bit[7:4]: Reserved (0) Bit[3:0]: Number of plane address bits	-	01h
Multi-plane operation attributes Bit[7:3]: Reserved (0) Bit 2: 1 = Address restrictions for cache operations Bit 1: 1 = Read cache operations supported Bit 0: 1 = Program cache operations supported	-	07h
Reserved (0)	_	All 00h
parameters block		
Asynchronous SDR speed grade support Bit[15:6]: Reserved (0) Bit 5: 1 = supports timing mode 5 Bit 4: 1 = supports timing mode 4 Bit 3: 1 = supports timing mode 3 Bit 2: 1 = supports timing mode 2 Bit 1: 1 = supports timing mode 1	-	3Fh, 00h
	Number of data bytes per page Number of pages per block Number of blocks per LUN Number of LUNs per chip enable Number of LUNs per chip enable Number of blocks per LUN Number of LUNs per chip enable Number of bits per cell Number of bits per cell Number of programs per page Multi-plane operation addressing Bit[7:4]: Reserved (0) Bit[3:0]: Number of plane address bits Multi-plane operation attributes Bit[7:3]: Reserved (0) Bit 2: 1 = Address restrictions for cache operations Bit 1: 1 = Read cache operations supported Bit 0: 1 = Program cache operations supported Bit 0: 1 = Program cache operations supported Reserved (0) parameters block Asynchronous SDR speed grade support Bit[15:6]: Reserved (0) Bit 5: 1 = supports timing mode 5 Bit 4: 1 = supports timing mode 4 Bit 3: 1 = supports timing mode 3 Bit 2: 1 = supports timing mode 2	Number of spare bytes per page



Byte	Description	Device	Values
146–147	Toggle Mode DDR and NV-DDR2 speed grade support Bit[15:8]: Reserved (0) Bit 7: 1 = supports timing mode 7 Bit 6: 1 = supports timing mode 6 Bit 5: 1 = supports timing mode 5 Bit 4: 1 = supports timing mode 4 Bit 3: 1 = supports timing mode 3 Bit 2: 1 = supports timing mode 2 Bit 1: 1 = supports timing mode 1 Bit 0: 1 = supports timing mode 0, shall be 1	-	00h, 00h
148–149	Synchronous DDR speed grade support	MT29F64G08CBABAWP	00h, 00h
	Bit[15:6]: Reserved (0)	MT29F128G08CFABAWP	
	Bit 5: 1 = supports timing mode 5 Bit 4: 1 = supports timing mode 4 Bit 3: 1 = supports timing mode 3 Bit 2: 1 = supports timing mode 2 Bit 1: 1 = supports timing mode 1 Bit 0: 1 = supports timing mode 0, shall be 1	MT29F256G08CJABAWP	
		MT29F64G08CBABBWP	1Fh, 00h
		MT29F128G08CFABBWP	
		MT29F256G08CJABBWP	
		MT29F64G08CBCBBH1	3Fh, 00h
		MT29F128G08CECBBH1	
		MT29F256G08CKCBBH2	
		MT29F256G08CMCBBH2	
150	Asynchronous SDR features Bit[7:0]: Reserved (0)	-	00h
151	Toggle-mode DDR features (0)	_	00h
152	Synchronous DDR features Bit[7:2]: Reserved (0) Bit 1: 1 = devices support CLK stopped for data input Bit 0: 0 = use ^t CAD MIN value	-	00h
153–154	^t PROG Maximum PROGRAM PAGE time (μs)	_	C4h, 09h
155–156	^t BERS Maximum BLOCK ERASE time (μs)	_	E0h, 2Eh
157–158	^t R Maximum PAGE READ time (μs)	_	64h, 00h
159–160	^t R Maximum Multi-PLANE PAGE READ time (µs)	_	64h, 00h
161–162	^t CCS Minimum change column setup time (ns)	_	C8h, 00h



Byte	Description	Device	Values
163–164	I/O pin capacitance, typical	MT29F64G08CBABAWP	2Fh, 00h
		MT29F128G08CFABAWP	28h, 00h
		MT29F256G08CJABAWP	41h, 00h
		MT29F64G08CBABBWP	2Fh, 00h
		MT29F128G08CFABBWP	28h, 00h
		MT29F256G08CJABBWP	41h, 00h
		MT29F64G08CBCBBH1	2Fh, 00h
		MT29F128G08CECBBH1	2Fh, 00h
		MT29F256G08CKCBBH2	48h, 00h
		MT29F256G08CMCBBH2	24h, 00h
165–166	Input capacitance, typical	MT29F64G08CBABAWP	34h, 00h
		MT29F128G08CFABAWP	2Dh, 00h
		MT29F256G08CJABAWP	48h, 00h
		MT29F64G08CBABBWP	34h, 00h
		MT29F128G08CFABBWP	2Dh, 00h
		MT29F256G08CJABBWP	48h, 00h
		MT29F64G08CBCBBH1	2Bh, 00h
		MT29F128G08CECBBH1	2Bh, 00h
		MT29F256G08CKCBBH2	44h, 00h
		MT29F256G08CMCBBH2	22h, 00h
167–168	CLK input pin capacitance, typical	MT29F64G08CBABAWP	2Eh, 00h
		MT29F128G08CFABAWP	28h, 00h
		MT29F256G08CJABAWP	43h, 00h
		MT29F64G08CBABBWP	2Eh, 00h
		MT29F128G08CFABBWP	28h, 00h
		MT29F256G08CJABBWP	43h, 00h
		MT29F64G08CBCBBH1	33h, 00h
		MT29F128G08CECBBH1	33h, 00h
		MT29F256G08CKCBBH2	4Dh, 00h
		MT29F256G08CMCBBH2	26h, 00h
169	Driver strength support Bit[7:3]: Reserved (0) Bit 2: 1 = Supports 18 Ohm drive strength Bit 1: 1 = Supports 25 Ohm drive strength Bit 0: 1 = Supports driver strength settings	-	07h
170–171	^t ADL program page register clear enhancement value (ns)	-	46h, 00h
172–207	Reserved (0)	-	00h
ECC and e	ndurance block		



Byte	Description	Device	Values
208	Guaranteed valid blocks at beginning of target	-	01h
209–210	Block endurance for guaranteed valid blocks	-	00h, 00h
211	Number of bits ECC correctability	-	28h
212	ECC codeword size		0Ah
213–214	Bad blocks maximum per LUN	-	55h, 00h
215–216	Block endurance	-	03h, 03h
217–218	Reserved (0)	-	00h
219–271	Reserved (0)	-	00h
Reserved			
272–419	Reserved (0)	-	00h
Vendor sp	ecific block		
420-421	Vendor-specific revision number	_	04h, 00h
422	Read Retry options Bit[7:4]: Reserved (0) Bit[3:0] = Number of Read Retry options supported	-	08h
423–426	Read Retry Options available. A value of '1' in a bit position shows that Read Retry option is available for use. A value of '0' in a bit position shows that Read Retry option is not available for use. For example, the binary value of '37h, 00h, 00h, 00h' would represent that Read Retry options 0, 1, 2, 4, and 5 are available which would correspond to Read Retry input option selections of 00h, 01h, 02h, 04h, and 05h. It furthermore would show that Read Retry options 3, 6, and 7 to 32 which would correspond to Read Retry input option selections 03h, 06h, 07h to 20h, are not available.	_	FFh, 00h, 00h, 00h
427–509	Reserved (0)	-	All 00h
CRC for Pa	rameter Page		
510–511	Integrity CRC	MT29F64G08CBABAWP	4Bh, F4h
		MT29F64G08CBABBWP	D3h, 7Bh
		MT29F128G08CFABAWP	36h, 29h
		MT29F128G08CFABBWP	4Bh, C2h
		MT29F256G08CJABAWP	88h, 25h
		MT29F256G08CJABBWP	F5h, CEh
		MT29F64G08CBCBBH1	FCh, FCh
		MT29F128G08CECBBH1	88h, CFh
		MT29F256G08CKCBBH2	80h, 05h
	1		3Ch, 5Bh



Table 10: JEDEC Parameter Page Defintion (Continued)

Byte	Description	Device	Values
512–1023	Value of bytes 0-511	_	See bytes 0-511
1024–1535	Value of bytes 0-511	_	See bytes 0-511
		_	
7680–8191	Value of bytes 0-511	_	See bytes 0-511
8192–8703	Value of bytes 0-511	_	See bytes 0-511
8704–8935	Reserved (FFh)	-	All FFh

Note: 1. h = hexadecimal.



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Identification Operations

READ UNIQUE ID (EDh)

The READ UNIQUE ID (EDh) command is used to read a unique identifier programmed into the target. This command is accepted by the target only when all die (LUNs) on the target are idle.


Writing EDh to the command register puts the target in read unique ID mode. The target stays in this mode until another valid command is issued.

When the EDh command is followed by a 00h address cycle, the target goes busy for ^tR. If the READ STATUS (70h) command is used to monitor for command completion, the READ MODE (00h) command must be used to re-enable data output mode.

After ^tR completes, the host enables data output mode to read the unique ID. When the asynchronous interface is active, one data byte is output per RE# toggle. When the synchronous interface is active, two data bytes are output, one byte for each rising or falling edge of DQS.

Sixteen copies of the unique ID data are stored in the device. Each copy is 32 bytes. The first 16 bytes of a 32-byte copy are unique data, and the second 16 bytes are the complement of the first 16 bytes. The host should XOR the first 16 bytes with the second 16 bytes. If the result is 16 bytes of FFh, then that copy of the unique ID data is correct. In the event that a non-FFh result is returned, the host can repeat the XOR operation on a subsequent copy of the unique ID data. If desired, the CHANGE READ COLUMN (05h-E0h) command can be used to change the data output location. Use of the CHANGE READ COLUMN ENHANCED (06h-E0h) command is prohibited.

Figure 41: READ UNIQUE ID (EDh) Operation





Configuration Operations

The SET FEATURES (EFh) and GET FEATURES (EEh) commands are used to modify the target's default power-on behavior. These commands use a one-byte feature address to determine which subfeature parameters will be read or modified. Each feature address (in the 00h to FFh range) is defined in . The SET FEATURES (EFh) command writes subfeature parameters (P1-P4) to the specified feature address. The GET FEATURES command reads the subfeature parameters (P1-P4) at the specified feature address.

Unless otherwise specified, the values of the feature addresses do not change when RE-SET (FFh, FCh, FAh) is issued by the host.

Table 11: Feature Address Definitions

Feature Address	Definition
00h	Reserved
01h	Timing mode
02h-0Fh	Reserved
10h	Programmable output drive strength
11h–7Fh	Reserved
80h	Programmable output drive strength
81h	Programmable RB# pull-down strength
82h–88h	Reserved
89h	Read Retry
8Ah-8Fh	Reserved
90h	Array operation mode
91h–FFh	Reserved

SET FEATURES (EFh)

The SET FEATURES (EFh) command writes the subfeature parameters (P1-P4) to the specified feature address to enable or disable target-specific features. This command is accepted by the target only when all die (LUNs) on the target are idle.

Writing EFh to the command register puts the target in the set features mode. The target stays in this mode until another command is issued.


The EFh command is followed by a valid feature address as specified in . The host waits for $^t\mathrm{ADL}$ before the subfeature parameters are input. When the asynchronous interface is active, one subfeature parameter is latched per rising edge of WE#. When the synchronous interface is active, one subfeature parameter is latched per rising edge of DQS. The data on the falling edge of DQS should be identical to the subfeature parameter input on the previous rising edge of DQS. The device is not required to wait for the repeated data byte before beginning internal actions.

After all four subfeature parameters are input, the target goes busy for ^tFEAT. The READ STATUS (70h) command can be used to monitor for command completion.

Feature address 01h (timing mode) operation is unique. If SET FEATURES is used to modify the interface type, the target will be busy for ^tITC. See Activating Interfaces (page 45) for details.



Figure 42: SET FEATURES (EFh) Operation



GET FEATURES (EEh)

The GET FEATURES (EEh) command reads the subfeature parameters (P1-P4) from the specified feature address. This command is accepted by the target only when all die (LUNs) on the target are idle.

Writing EEh to the command register puts the target in get features mode. The target stays in this mode until another valid command is issued.

When the EEh command is followed by a feature address, the target goes busy for ^tFEAT. If the READ STATUS (70h) command is used to monitor for command completion, the READ MODE (00h) command must be used to re-enable data output mode. During and prior to data output, use of the READ STATUS ENHANCED (78h) command is prohibited.

After ^tFEAT completes, the host enables data output mode to read the subfeature parameters. When the asynchronous interface is active, one data byte is output per RE# toggle. When the synchronous interface is active, one subfeature parameter is output per DQS toggle on rising or falling edge of DQS.

Figure 43: GET FEATURES (EEh) Operation






Table 12: Feature Address 01h: Timing Mode

Subfeature											
Parameter Options		DQ7	DQ6	DQ5	DQ4	DQ3	DQ2	DQ1	DQ0	Value	Notes
P1											
Timing mode	Mode 0 (default)					0	0	0	0	x0h	1, 2
	Mode 1					0	0	0	1	x1h	
	Mode 2					0	0	1	0	x2h	
	Mode 3					0	0	1	1	x3h	
	Mode 4					0	1	0	0	x4h	
	Mode 5					0	1	0	1	x5h	
Data interface	Asynchronous (default)			0	0					0xh	1
	Synchronous DDR			0	1					1xh	
	Reserved			1	х					2xh	
Program clear	Program com- mand clears all cache registers on a target (default)		0							0b	
	Program com- mand clears only addressed LUN cache register on a target		1							1b	
Reserved		0								0b	
P2											
Reserved		0	0	0	0	0	0	0	0	00h	
Р3			-							•	
Reserved		0	0	0	0	0	0	0	0	00h	
P4	-		-								
Reserved		0	0	0	0	0	0	0	0	00h	

- Notes: 1. Asynchronous timing mode 0 is the default, power-on value.
 - 2. If the synchronous interface is active, a RESET (FFh) command will change the timing mode and data interface bits of feature address 01h to their default values. If the asynchronous interface is active, a RESET (FFh) command will not change the values of the timing mode or data interface bits to their default valued.



Table 13: Feature Addresses 10h and 80h: Programmable Output Drive Strength

Subfeature Pa- rameter	Options	DQ7	DQ6	DQ5	DQ4	DQ3	DQ2	DQ1	DQ0	Value	Notes
P1	Options	DQ7	DQ8	DQ5	DQ4	DQ3	DQZ	DQ1	DQU	value	Notes
	1	1				<u> </u>		_	_	T	_
Output drive	Overdrive 2							0	0	00h	1
strength	Overdrive 1							0	1	01h	
	Nominal (de- fault)							1	0	02h	
	Underdrive							1	1	03h	
Reserved		0	0	0	0	0	0			00h	
P2										•	
Reserved		0	0	0	0	0	0	0	0	00h	
Р3										•	
Reserved		0	0	0	0	0	0	0	0	00h	
P4			•	•		•			•	•	
Reserved		0	0	0	0	0	0	0	0	00h	

Note: 1. See Output Drive Impedance section for details.

Table 14: Feature Address 81h: Programmable R/B# Pull-Down Strength

Subfeature Pa- rameter	Options	DQ7	DQ6	DQ5	DQ4	DQ3	DQ2	DQ1	DQ0	Value	Notes
P1	Оразоно			- 40		- 40				10.00	
R/B# pull-down	Full (default)							0	0	00h	1
strength	Three-quarter							0	1	01h	
	One-half							1	0	02h	
	One-quarter							1	1	03h	
Reserved		0	0	0	0	0	0			00h	
P2				<u>'</u>	l	<u>'</u>	<u> </u>		<u>'</u>		
Reserved		0	0	0	0	0	0	0	0	00h	
Р3											
Reserved		0	0	0	0	0	0	0	0	00h	
P4				•			•				
Reserved		0	0	0	0	0	0	0	0	00h	

Note: 1. This feature address is used to change the default R/B# pull-down strength. Its strength should be selected based on the expected loading of R/B#. Full strength is the default, power-on value.



Table 15: Feature Address 89h: Read Retry

Subfeature Pa-											
rameter	Options	DQ7	DQ6	DQ5	DQ4	DQ3	DQ2	DQ1	DQ0	Value	Notes
P1											
Read Retry	Disable (de-						0	0	0	00h	
	fault)										
	Option 1						0	0	1	01h	
	Option 2						0	1	0	02h	
	Option 3						0	1	1	03h	
	Option 4						1	0	0	04h	2
	Option 5						1	0	1	05h	
	Option 6						1	1	0	06h	
	Option 7						1	1	1	07h	
Reserved		0	0	0	0	0				00h	
P2	•										
Reserved		0	0	0	0	0	0	0	0	00h	
Р3		·								•	
Reserved		0	0	0	0	0	0	0	0	00h	
P4	·										
Reserved		0	0	0	0	0	0	0	0	00h	

- Notes: 1. See Read Retry Operation for details.
 - 2. ^tR will be longer with selected option. See Electrical Specifications Array Characteristics section for details.



Table 16: Feature Address 90h: Array Operation Mode

Subfeature Pa- rameter	Options	DQ7	DQ6	DQ5	DQ4	DQ3	DQ2	DQ1	DQ0	Value	Notes
P1	- -									1	
Array Operation Mode	Normal (de- fault)								0	00h	
	OTP Block								1	01h	1
Reserved		0	0	0	0	0	0	0		00h	
P2					'				'	•	
Reserved		0	0	0	0	0	0	0	0	00h	
Р3					'				'	•	
Reserved		0	0	0	0	0	0	0	0	00h	
P4	•	•								•	
Reserved		0	0	0	0	0	0	0	0	00h	

- Notes: 1. See One-Time Programmable (OTP) Operations for details.
 - 2. A RESET (FFh) command will cause the bits of the array operation mode to change to their default values.



Status Operations

Each die (LUN) provides its status independently of other die (LUNs) on the same target through its 8-bit status register.

After the READ STATUS (70h) or READ STATUS ENHANCED (78h) command is issued, status register output is enabled. The contents of the status register are returned on DQ[7:0] for each data output request.

When the asynchronous interface is active and status register output is enabled, changes in the status register are seen on DQ[7:0] as long as CE# and RE# are LOW; it is not necessary to toggle RE# to see the status register update.

When the synchronous interface is active and status register output is enabled, changes in the status register are seen on DQ[7:0] as long as CE# and W/R# are LOW and ALE and CLE are HIGH. DQS also toggles while ALE and CLE are HIGH.

While monitoring the status register to determine when a data transfer from the Flash array to the data register (^tR) is complete, the host must issue the READ MODE (00h) command to disable the status register and enable data output (see READ MODE (00h) (page 91)).

The READ STATUS (70h) command returns the status of the most recently selected die (LUN). To prevent data contention during or following an interleaved die (multi-LUN) operation, the host must enable only one die (LUN) for status output by using the READ STATUS ENHANCED (78h) command (see Interleaved Die (Multi-LUN) Operations (page 118)).

Table 17: Status Register Definition

SR Bit	Definition	Independent per Plane ¹	Description
7	WP#	-	Write Protect: 0 = Protected 1 = Not protected In the normal array mode, this bit indicates the value of the WP# signal. In OTP mode this bit is set to 0 if a PROGRAM OTP PAGE operation is attempted and the OTP area is protected.
6	RDY	-	Ready/Busy I/O: 0 = Busy 1 = Ready This bit indicates that the selected die (LUN) is not available to accept new commands, address, or data I/O cycles with the exception of RESET (FFh), SYNCHRONOUS RESET (FCh), READ STATUS (70h), and READ STATUS ENHANCED (78h). This bit applies only to the selected die (LUN).
5	ARDY	-	Ready/Busy Array: 0 = Busy 1 = Ready This bit goes LOW (busy) when an array operation is occurring on any plane of the selected die (LUN). It goes HIGH when all array operations on the selected die (LUN) finish. This bit applies only to the selected die (LUN).
4	-	_	Reserved (0)
3	_	_	Reserved (0)



Table 17: Status Register Definition (Continued)

SR Bit	Definition	Independent per Plane ¹	Description
2	-	_	Reserved (0)
1	FAILC	Yes	Pass/Fail (N-1): 0 = Pass 1 = Fail This bit is set if the previous operation on the selected die (LUN) failed. This bit is valid only when RDY (SR bit 6) is 1. It applies to PROGRAM-, and COPYBACK PROGRAM-series operations (80h-10h, 80h-15h, 85h-10h). This bit is not valid following an ERASE-series or READ-series operation.
0	FAIL	Yes	Pass/Fail (N): 0 = Pass 1 = Fail This bit is set if the most recently finished operation on the selected die (LUN) failed. This bit is valid only when ARDY (SR bit 5) is 1. It applies to PROGRAM-, ERASE-, and COPYBACK PROGRAM-series operations (80h-10h, 80h-15h, 60h-D0h, 85h-10h). This bit is not valid following a READ-series operation.

Note

After a multi-plane operation begins, the FAILC and FAIL bits are ORed together for the
active planes when the READ STATUS (70h) command is issued. After the READ STATUS
ENHANCED (78h) command is issued, the FAILC and FAIL bits reflect the status of the
plane selected.

READ STATUS (70h)

The READ STATUS (70h) command returns the status of the last-selected die (LUN) on a target. This command is accepted by the last-selected die (LUN) even when it is busy (RDY = 0).


If there is only one die (LUN) per target, the READ STATUS (70h) command can be used to return status following any NAND command.

In devices that have more than one die (LUN) per target, during and following interleaved die (multi-LUN) operations, the READ STATUS ENHANCED (78h) command must be used to select the die (LUN) that should report status. In this situation, using the READ STATUS (70h) command will result in bus contention, as two or more die (LUNs) could respond until the next operation is issued. The READ STATUS (70h) command can be used following all single die (LUN) operations.

If following a multi-plane operation, regardless of the number of LUNs per target, the READ STATUS (70h) command indicates an error occurred (FAIL = 1), use the READ STATUS ENHANCED (78h) command—once for each plane—to determine which plane operation failed.



Figure 44: READ STATUS (70h) Operation



READ STATUS ENHANCED (78h)

The READ STATUS ENHANCED (78h) command returns the status of the addressed die (LUN) on a target even when it is busy (RDY = 0). This command is accepted by all die (LUNs), even when they are BUSY (RDY = 0).


Writing 78h to the command register, followed by three row address cycles containing the page, block, and LUN addresses, puts the selected die (LUN) into read status mode. The selected die (LUN) stays in this mode until another valid command is issued. Die (LUNs) that are not addressed are deselected to avoid bus contention.

The selected LUN's status is returned when the host requests data output. The RDY and ARDY bits of the status register are shared for all of the planes of the selected die (LUN). The FAILC and FAIL bits are specific to the plane specified in the row address.

The READ STATUS ENHANCED (78h) command also enables the selected die (LUN) for data output. To begin data output following a READ-series operation after the selected die (LUN) is ready (RDY = 1), issue the READ MODE (00h) command, then begin data output. If the host needs to change the cache register that will output data, use the CHANGE READ COLUMN ENHANCED (06h-E0h) command after the die (LUN) is ready (see CHANGE READ COLUMN ENHANCED (06h-E0h)).

Use of the READ STATUS ENHANCED (78h) command is prohibited during the poweron RESET (FFh) command and when OTP mode is enabled. It is also prohibited following some of the other reset, identification, and configuration operations. See individual operations for specific details.

Figure 45: READ STATUS ENHANCED (78h) Operation





Column Address Operations

The column address operations affect how data is input to and output from the cache registers within the selected die (LUNs). These features provide host flexibility for managing data, especially when the host internal buffer is smaller than the number of data bytes or words in the cache register.

When the asynchronous interface is active, column address operations can address any byte in the selected cache register.

When the synchronous interface is active, column address operations are aligned to word boundaries (CA0 is forced to 0), because as data is transferred on DQ[7:0] in two-byte units.


CHANGE READ COLUMN (05h-E0h)

The CHANGE READ COLUMN (05h-E0h) command changes the column address of the selected cache register and enables data output from the last selected die (LUN). This command is accepted by the selected die (LUN) when it is ready (RDY = 1; ARDY = 1). It is also accepted by the selected die (LUN) during CACHE READ operations (RDY = 1; ARDY = 0).

Writing 05h to the command register, followed by two column address cycles containing the column address, followed by the E0h command, puts the selected die (LUN) into data output mode. After the E0h command cycle is issued, the host must wait at least ^tCCS before requesting data output. The selected die (LUN) stays in data output mode until another valid command is issued.

In devices with more than one die (LUN) per target, during and following interleaved die (multi-LUN) operations, the READ STATUS ENHANCED (78h) command must be issued prior to issuing the CHANGE READ COLUMN (05h-E0h). In this situation, using the CHANGE READ COLUMN (05h-E0h) command without the READ STATUS ENHANCED (78h) command will result in bus contention, as two or more die (LUNs) could output data.

Figure 46: CHANGE READ COLUMN (05h-E0h) Operation





CHANGE READ COLUMN ENHANCED (06h-E0h)

The CHANGE READ COLUMN ENHANCED (06h-E0h) command enables data output on the addressed die's (LUN's) cache register at the specified column address. This command is accepted by a die (LUN) when it is ready (RDY = 1; ARDY = 1).

Writing 06h to the command register, followed by two column address cycles and three row address cycles, followed by E0h, enables data output mode on the address LUN's cache register at the specified column address. After the E0h command cycle is issued, the host must wait at least ^tCCS before requesting data output. The selected die (LUN) stays in data output mode until another valid command is issued.


Following a multi-plane read page operation, the CHANGE READ COLUMN EN-HANCED (06h-E0h) command is used to select the cache register to be enabled for data output. After data output is complete on the selected plane, the command can be issued again to begin data output on another plane.

In devices with more than one die (LUN) per target, after all of the die (LUNs) on the target are ready (RDY = 1), the CHANGE READ COLUMN ENHANCED (06h-E0h) command can be used following an interleaved die (multi-LUN) read operation. Die (LUNs) that are not addressed are deselected to avoid bus contention.

In devices with more than one die (LUN) per target, during interleaved die (multi-LUN) operations where more than one or more die (LUNs) are busy (RDY = 1; ARDY = 0 or RDY = 0; ARDY = 0), the READ STATUS ENHANCED (78h) command must be issued to the die (LUN) to be selected prior to issuing the CHANGE READ COLUMN ENHANCED (06h-E0h). In this situation, using the CHANGE READ COLUMN ENHANCED (06h-E0h) command without the READ STATUS ENHANCED (78h) command will result in bus contention, as two or more die (LUNs) could output data.

If there is a need to update the column address without selecting a new cache register or LUN, the CHANGE READ COLUMN (05h-E0h) command can be used instead.

Figure 47: CHANGE READ COLUMN ENHANCED (06h-E0h) Operation





CHANGE READ COLUMN ENHANCED (00h-05h-E0h) Operation

This operation behaves the same as the CHANGE READ COLUMN ENHANCED (06h-E0h) command.

Figure 48: CHANGE READ COLUMN ENHANCED (00h-05h-E0h) Operation





CHANGE WRITE COLUMN (85h)


The CHANGE WRITE COLUMN (85h) command changes the column address of the selected cache register and enables data input on the last-selected die (LUN). This command is accepted by the selected die (LUN) when it is ready (RDY = 1; ARDY = 1). It is also accepted by the selected die (LUN) during cache program operations (RDY = 1; ARDY = 0).

Writing 85h to the command register, followed by two column address cycles containing the column address, puts the selected die (LUN) into data input mode. After the second address cycle is issued, the host must wait at least ^tCCS before inputting data. The selected die (LUN) stays in data input mode until another valid command is issued. Though data input mode is enabled, data input from the host is optional. Data input begins at the column address specified.

The CHANGE WRITE COLUMN (85h) command is allowed after the required address cycles are specified, but prior to the final command cycle (10h, 11h, 15h) of the following commands while data input is permitted: PROGRAM PAGE (80h-10h), PROGRAM PAGE MULTI-PLANE (80h-11h), PROGRAM PAGE CACHE (80h-15h), COPYBACK PROGRAM (85h-10h), and COPYBACK PROGRAM MULTI-PLANE (85h-11h).

In devices that have more than one die (LUN) per target, the CHANGE WRITE COLUMN (85h) command can be used with other commands that support interleaved die (multi-LUN) operations.

Figure 49: CHANGE WRITE COLUMN (85h) Operation





CHANGE ROW ADDRESS (85h)

The CHANGE ROW ADDRESS (85h) command changes the row address (block and page) where the cache register contents will be programmed in the NAND Flash array. It also changes the column address of the selected cache register and enables data input on the specified die (LUN). This command is accepted by the selected die (LUN) when it is ready (RDY = 1; ARDY = 1). It is also accepted by the selected die (LUN) during cache programming operations (RDY = 1; ARDY = 0).

Write 85h to the command register. Then write two column address cycles and three row address cycles. This updates the page and block destination of the selected plane for the addressed LUN and puts the cache register into data input mode. After the fifth address cycle is issued the host must wait at least ^tCCS before inputting data. The selected LUN stays in data input mode until another valid command is issued. Though data input mode is enabled, data input from the host is optional. Data input begins at the column address specified.

The CHANGE ROW ADDRESS (85h) command is allowed after the required address cycles are specified, but prior to the final command cycle (10h, 11h, 15h) of the following commands while data input is permitted: PROGRAM PAGE (80h-10h), PROGRAM PAGE MULTI-PLANE (80h-11h), PROGRAM PAGE CACHE (80h-15h), COPYBACK PROGRAM (85h-10h), and COPYBACK PROGRAM MULTI-PLANE (85h-11h). When used with these commands, the LUN address and plane select bits are required to be identical to the LUN address and plane select bits originally specified.

The CHANGE ROW ADDRESS (85h) command enables the host to modify the original page and block address for the data in the cache register to a new page and block address.


In devices that have more than one die (LUN) per target, the CHANGE ROW ADDRESS (85h) command can be used with other commands that support interleaved die (multi-LUN) operations.

The CHANGE ROW ADDRESS (85h) command can be used with the CHANGE READ COLUMN (05h-E0h) or CHANGE READ COLUMN ENHANCED (06h-E0h) commands to read and modify cache register contents in small sections prior to programming cache register contents to the NAND Flash array. This capability can reduce the amount of buffer memory used in the host controller.

To modify the cache register contents in small sections, first issue a PAGE READ (00h-30h) or COPYBACK READ (00h-35h) operation. When data output is enabled, the host can output a portion of the cache register contents. To modify the cache register contents, issue the 85h command, the column and row addresses, and input the new data. The host can re-enable data output by issuing the 11h command, waiting ^tDBSY, and then issuing the CHANGE READ COLUMN (05h-E0h) or CHANGE READ COLUMN ENHANCED (06h-E0h) command. It is possible toggle between data output and data input multiple times. After the final CHANGE ROW ADDRESS (85h) operation is complete, issue the 10h command to program the cache register to the NAND Flash array.



Figure 50: CHANGE ROW ADDRESS (85h) Operation





Read Operations

Read operations are used to copy data from the NAND Flash array of one or more of the planes to their respective cache registers and to enable data output from the cache registers to the host through the DQ bus.

Read Operations

The READ PAGE (00h-30h) command, when issued by itself, reads one page from the NAND Flash array to its cache register and enables data output for that cache register.

During data output the following commands can be used to read and modify the data in the cache registers: CHANGE READ COLUMN (05h-E0h) and CHANGE ROW ADDRESS (85h).

Read Cache Operations

To increase data throughput, the READ PAGE CACHE-series (31h, 00h-31h) commands can be used to output data from the cache register while concurrently copying a page from the NAND Flash array to the data register.

To begin a read page cache sequence, begin by reading a page from the NAND Flash array to its corresponding cache register using the READ PAGE (00h-30h) command. R/B# goes LOW during tR and the selected die (LUN) is busy (RDY = 0, ARDY = 0). After tR (R/B# is HIGH and RDY = 1, ARDY = 1), issue either of these commands:

- READ PAGE CACHE SEQUENTIAL (31h)—copies the next sequential page from the NAND Flash array to the data register
- READ PAGE CACHE RANDOM (00h-31h)—copies the page specified in this command from the NAND Flash array (any plane) to its corresponding data register

After the READ PAGE CACHE-series (31h, 00h-31h) command has been issued, R/B# goes LOW on the target, and RDY = 0 and ARDY = 0 on the die (LUN) for t RCBSY while the next page begins copying data from the array to the data register. After t RCBSY, R/B# goes HIGH and the die's (LUN's) status register bits indicate the device is busy with a cache operation (RDY = 1, ARDY = 0). The cache register becomes available and the page requested in the READ PAGE CACHE operation is transferred to the data register. At this point, data can be output from the cache register, beginning at column address 0. The CHANGE READ COLUMN (05h-E0h) command can be used to change the column address of the data output by the die (LUN).

After outputting the desired number of bytes from the cache register, either an additional READ PAGE CACHE-series (31h, 00h-31h) operation can be started or the READ PAGE CACHE LAST (3Fh) command can be issued.

If the READ PAGE CACHE LAST (3Fh) command is issued, R/B# goes LOW on the target, and RDY = 0 and ARDY = 0 on the die (LUN) for $^{\rm t}$ RCBSY while the data register is copied into the cache register. After $^{\rm t}$ RCBSY, R/B# goes HIGH and RDY = 1 and ARDY = 1, indicating that the cache register is available and that the die (LUN) is ready. Data can then be output from the cache register, beginning at column address 0. The CHANGE READ COLUMN (05h-E0h) command can be used to change the column address of the data being output.

For READ PAGE CACHE-series (31h, 00h-31h, 3Fh), during the die (LUN) busy time, ^tRCBSY, when RDY = 0 and ARDY = 0, the only valid commands are status operations (70h, 78h) and RESET (FFh, FCh). When RDY = 1 and ARDY = 0, the only valid commands during READ PAGE CACHE-series (31h, 00h-31h) operations are status opera-



tions (70h, 78h), READ MODE (00h), READ PAGE CACHE-series (31h, 00h-31h), CHANGE READ COLUMN (05h-E0h), and RESET (FFh, FCh).

Multi-Plane Read Operations

Multi-plane read page operations improve data throughput by copying data from more than one plane simultaneously to the specified cache registers. This is done by prepending one or more READ PAGE MULTI-PLANE (00h-32h) commands in front of the READ PAGE (00h-30h) command.

When the die (LUN) is ready, the CHANGE READ COLUMN ENHANCED (06h-E0h) command determines which plane outputs data. During data output, the following commands can be used to read and modify the data in the cache registers: CHANGE READ COLUMN (05h-E0h) and CHANGE ROW ADDRESS (85h). See Multi-Plane Operations for details.

Multi-Plane Read Cache Operations

Multi-plane read cache operations can be used to output data from more than one cache register while concurrently copying one or more pages from the NAND Flash array to the data register. This is done by prepending READ PAGE MULTI-PLANE (00h-32h) commands in front of the PAGE READ CACHE RANDOM (00h-31h) command.

To begin a multi-plane read page cache sequence, begin by issuing a MULTI-PLANE READ PAGE operation using the READ PAGE MULTI-PLANE (00h-32h) and READ PAGE (00h-30h) commands. R/B# goes LOW during tR and the selected die (LUN) is busy (RDY = 0, ARDY = 0). After tR (R/B# is HIGH and RDY = 1, ARDY = 1), issue either of these commands:

- READ PAGE CACHE SEQUENTIAL (31h)—copies the next sequential page from the previously addressed planes from the NAND Flash array to the data registers.
- READ PAGE MULTI-PLANE (00h-32h) commands, if desired, followed by the READ PAGE CACHE RANDOM (00h-31h) command—copies the pages specified from the NAND Flash array to the corresponding data registers.

After the READ PAGE CACHE-series (31h, 00h-31h) command has been issued, R/B# goes LOW on the target, and RDY = 0 and ARDY = 0 on the die (LUN) for ^tRCBSY while the next pages begin copying data from the array to the data registers. After ^tRCBSY, R/B# goes HIGH and the LUN's status register bits indicate the device is busy with a cache operation (RDY = 1, ARDY = 0). The cache registers become available and the pages requested in the READ PAGE CACHE operation are transferred to the data registers. Issue the CHANGE READ COLUMN ENHANCED (06h-E0h) command to determine which cache register will output data. After data is output, the CHANGE READ COLUMN ENHANCED (06h-E0h) command can be used to output data from other cache registers. After a cache register has been selected, the CHANGE READ COLUMN (05h-E0h) command can be used to change the column address of the data output.

After outputting data from the cache registers, either an additional MULTI-PLANE READ CACHE-series (31h, 00h-31h) operation can be started or the READ PAGE CACHE LAST (3Fh) command can be issued.

If the READ PAGE CACHE LAST (3Fh) command is issued, R/B# goes LOW on the target, and RDY = 0 and ARDY = 0 on the die (LUN) for t RCBSY while the data registers are copied into the cache registers. After t RCBSY, R/B# goes HIGH and RDY = 1 and ARDY = 1, indicating that the cache registers are available and that the die (LUN) is ready. Issue the



CHANGE READ COLUMN ENHANCED (06h-E0h) command to determine which cache register will output data. After data is output, the CHANGE READ COLUMN ENHANCED (06h-E0h) command can be used to output data from other cache registers. After a cache register has been selected, the CHANGE READ COLUMN (05h-E0h) command can be used to change the column address of the data output.

For READ PAGE CACHE-series (31h, 00h-31h, 3Fh), during the die (LUN) busy time, ^tRCBSY, when RDY = 0 and ARDY = 0, the only valid commands are status operations (70h, 78h) and RESET (FFh, FCh). When RDY = 1 and ARDY = 0, the only valid commands during READ PAGE CACHE-series (31h, 00h-31h) operations are status operations (70h, 78h), READ MODE (00h), multi-plane read cache-series (31h, 00h-32h, 00h-31h), CHANGE READ COLUMN (05h-E0h, 06h-E0h), and RESET (FFh, FCh).

See Multi-Plane Operations for additional multi-plane addressing requirements.

READ MODE (00h)

The READ MODE (00h) command disables status output and enables data output for the last-selected die (LUN) and cache register after a READ operation (00h-30h, 00h-35h) has been monitored with a status operation (70h, 78h). This command is accepted by the die (LUN) when it is ready (RDY = 1, ARDY = 1). It is also accepted by the die (LUN) during READ PAGE CACHE (31h, 3Fh, 00h-31h) operations (RDY = 1 and ARDY = 0).

In devices that have more than one die (LUN) per target, during and following interleaved die (multi-LUN) operations, the READ STATUS ENHANCED (78h) command must be used to select only one die (LUN) prior to issuing the READ MODE (00h) command. This prevents bus contention.



READ PAGE (00h-30h)

The READ PAGE (00h–30h) command copies a page from the NAND Flash array to its respective cache register and enables data output. This command is accepted by the die (LUN) when it is ready (RDY = 1, ARDY = 1).

To read a page from the NAND Flash array, write the 00h command to the command register, the write five address cycles to the address registers, and conclude with the 30h command. The selected die (LUN) will go busy (RDY = 0, ARDY = 0) for ${}^{t}R$ as data is transferred.


To determine the progress of the data transfer, the host can monitor the target's R/B# signal or, alternatively, the status operations (70h, 78h) can be used. If the status operations are used to monitor the LUN's status, when the die (LUN) is ready (RDY = 1, ARDY = 1), the host disables status output and enables data output by issuing the READ MODE (00h) command. When the host requests data output, output begins at the column address specified.

During data output the CHANGE READ COLUMN (05h-E0h) command can be issued.

In devices that have more than one die (LUN) per target, during and following interleaved die (multi-LUN) operations the READ STATUS ENHANCED (78h) command must be used to select only one die (LUN) prior to the issue of the READ MODE (00h) command. This prevents bus contention.

The READ PAGE (00h-30h) command is used as the final command of a multi-plane read operation. It is preceded by one or more READ PAGE MULTI-PLANE (00h-32h) commands. Data is transferred from the NAND Flash array for all of the addressed planes to their respective cache registers. When the die (LUN) is ready (RDY = 1, ARDY = 1), data output is enabled for the cache register linked to the last even plane addressed. When the host requests data output, output begins at the column address last specified in the READ PAGE (00h-30h) command. The CHANGE READ COLUMN ENHANCED (06h-E0h) command is used to enable data output in the other cache registers. See Multi-Plane Operations for additional multi-plane addressing requirements.

Figure 51: READ PAGE (00h-30h) Operation





READ PAGE CACHE SEQUENTIAL (31h)


The READ PAGE CACHE SEQUENTIAL (31h) command reads the next sequential page within a block into the data register while the previous page is output from the cache register. This command is accepted by the die (LUN) when it is ready (RDY = 1, ARDY = 1). It is also accepted by the die (LUN) during READ PAGE CACHE (31h, 00h-31h) operations (RDY = 1 and ARDY = 0).

To issue this command, write 31h to the command register. After this command is issued, R/B# goes LOW and the die (LUN) is busy (RDY = 0, ARDY = 0) for ^tRCBSY. After ^tRCBSY, R/B# goes HIGH and the die (LUN) is busy with a cache operation (RDY = 1, ARDY = 0), indicating that the cache register is available and that the specified page is copying from the NAND Flash array to the data register. At this point, data can be output from the cache register beginning at column address 0. The CHANGE READ COLUMN (05h-E0h) command can be used to change the column address of the data being output from the cache register.

The READ PAGE CACHE SEQUENTIAL (31h) command can be used to cross block boundaries. If the READ PAGE CACHE SEQUENTIAL (31h) command is issued after the last page of a block is read into the data register, the next page read will be the next logical block in the plane which the 31h command was issued. Do not issue the READ PAGE CACHE SEQUENTIAL (31h) to cross die (LUN) boundaries. Instead, issue the READ PAGE CACHE LAST (3Fh) command.

If the READ PAGE CACHE SEQUENTIAL (31h) command is issued after a MULTI-PLANE READ PAGE operation (00h-32h, 00h-30h), the next sequential pages are read into the data registers while the previous pages can be output from the cache registers. After the die (LUN) is ready (RDY = 1, ARDY = 0), the CHANGE READ COLUMN ENHANCED (06h-E0h) command is used to select which cache register outputs data.

Figure 52: READ PAGE CACHE SEQUENTIAL (31h) Operation





READ PAGE CACHE RANDOM (00h-31h)

The READ PAGE CACHE RANDOM (00h-31h) command reads the specified block and page into the data register while the previous page is output from the cache register. This command is accepted by the die (LUN) when it is ready (RDY = 1, ARDY = 1). It is also accepted by the die (LUN) during READ PAGE CACHE (31h, 00h-31h) operations (RDY = 1 and ARDY = 0).

To issue this command, write 00h to the command register, then write five address cycles to the address register, and conclude by writing 31h to the command register. The column address in the address specified is ignored. The die (LUN) address must match the same die (LUN) address as the previous READ PAGE (00h-30h) command or, if applicable, the previous READ PAGE CACHE RANDOM (00h-31h) command. There is no restriction on the plane address.


After this command is issued, R/B# goes LOW and the die (LUN) is busy (RDY = 0, ARDY = 0) for t RCBSY. After t RCBSY, R/B# goes HIGH and the die (LUN) is busy with a cache operation (RDY = 1, ARDY = 0), indicating that the cache register is available and that the specified page is copying from the NAND Flash array to the data register. At this point, data can be output from the cache register beginning at column address 0. The CHANGE READ COLUMN (05h-E0h) command can be used to change the column address of the data being output from the cache register.

In devices that have more than one die (LUN) per target, during and following interleaved die (multi-LUN) operations the READ STATUS ENHANCED (78h) command followed by the READ MODE (00h) command must be used to select only one die (LUN) and prevent bus contention.

If a MULTI-PLANE CACHE RANDOM (00h-32h, 00h-31h) command is issued after a MULTI-PLANE READ PAGE operation (00h-32h, 00h-30h), then the addressed pages are read into the data registers while the previous pages can be output from the cache registers. After the die (LUN) is ready (RDY = 1, ARDY = 0), the CHANGE READ COLUMN ENHANCED (06h-E0h) command is used to select which cache register outputs data.



Figure 53: READ PAGE CACHE RANDOM (00h-31h) Operation



95



READ PAGE CACHE LAST (3Fh)


The READ PAGE CACHE LAST (3Fh) command ends the read page cache sequence and copies a page from the data register to the cache register. This command is accepted by the die (LUN) when it is ready (RDY = 1, ARDY = 1). It is also accepted by the die (LUN) during READ PAGE CACHE (31h, 00h-31h) operations (RDY = 1 and ARDY = 0).

To issue the READ PAGE CACHE LAST (3Fh) command, write 3Fh to the command register. After this command is issued, R/B# goes LOW and the die (LUN) is busy (RDY = 0, ARDY = 0) for t RCBSY. After t RCBSY, R/B# goes HIGH and the die (LUN) is ready (RDY = 1, ARDY = 1). At this point, data can be output from the cache register, beginning at column address 0. The CHANGE READ COLUMN (05h-E0h) command can be used to change the column address of the data being output from the cache register.

In devices that have more than one LUN per target, during and following interleaved die (multi-LUN) operations the READ STATUS ENHANCED (78h) command followed by the READ MODE (00h) command must be used to select only one die (LUN) and prevent bus contention.

If the READ PAGE CACHE LAST (3Fh) command is issued after a MULTI-PLANE READ PAGE CACHE operation (31h; 00h-32h, 00h-30h), the die (LUN) goes busy until the pages are copied from the data registers to the cache registers. After the die (LUN) is ready (RDY = 1, ARDY = 1), the CHANGE READ COLUMN ENHANCED (06h-E0h) command is used to select which cache register outputs data.

Figure 54: READ PAGE CACHE LAST (3Fh) Operation





READ PAGE MULTI-PLANE (00h-32h)

The READ PAGE MULTI-PLANE (00h-32h) command queues a plane to transfer data from the NAND flash array to its cache register. This command can be issued one or more times. Each time a new plane address is specified, that plane is also queued for data transfer. The READ PAGE (00h-30h) command is issued to select the final plane and to begin the read operation for all previously queued planes. All queued planes will transfer data from the NAND Flash array to their cache registers.

To issue the READ PAGE MULTI-PLANE (00h-32h) command, write 00h to the command register, then write five address cycles to the address register, and conclude by writing 32h to the command register. The column address in the address specified is ignored.

After this command is issued, R/B# goes LOW and the die (LUN) is busy (RDY = 0, ARDY = 0) for ^tDBSY. After ^tDBSY, R/B# goes HIGH and the die (LUN) is ready (RDY = 1, ARDY = 1). At this point, the die (LUN) and block are queued for data transfer from the array to the cache register for the addressed plane. During ^tDBSY, the only valid commands are status operations (70h, 78h) and reset commands (FFh, FCh). Following ^tDBSY, to continue the MULTI-PLANE READ operation, the only valid commands are status operations (70h, 78h), READ PAGE MULTI-PLANE (00h-32h), READ PAGE (00h-30h), and READ PAGE CACHE RANDOM (00h-31h).

Additional READ PAGE MULTI-PLANE (00h-32h) commands can be issued to queue additional planes for data transfer.

If the READ PAGE (00h-30h) command is used as the final command of a MULTI-PLANE READ operation, data is transferred from the NAND Flash array for all of the addressed planes to their respective cache registers. When the die (LUN) is ready (RDY = 1, ARDY = 1), data output is enabled for the cache register linked to the last even plane addressed. When the host requests data output, it begins at the column address specified in the READ PAGE (00h-30h) command. To enable data output in the other cache registers, use the CHANGE READ COLUMN ENHANCED (06h-E0h) command. Additionally, the CHANGE READ COLUMN (05h-E0h) command can be used to change the column address within the currently selected plane.

If the READ PAGE CACHE SEQUENTIAL (31h) is used as the final command of a MULTI-PLANE READ CACHE operation, data is copied from the previously read operation from each plane to each cache register and then data is transferred from the NAND Flash array for all previously addressed planes to their respective data registers. When the die (LUN) is ready (RDY = 1, ARDY = 0), data output is enabled. The CHANGE READ COLUMN ENHANCED (06h-E0h) command is used to determine which cache register outputs data first. To enable data output in the other cache registers, use the CHANGE READ COLUMN ENHANCED (06h-E0h) command. Additionally, the CHANGE READ COLUMN (05h-E0h) command can be used to change the column address within the currently selected plane.


If the READ PAGE CACHE RANDOM (00h-31h) command is used as the final command of a MULTI-PLANE READ CACHE operation, data is copied from the previously read operation from the data register to the cache register and then data is transferred from the NAND Flash array for all of the addressed planes to their respective data registers. When the die (LUN) is ready (RDY = 1, ARDY = 0), data output is enabled. The CHANGE READ COLUMN ENHANCED (06h-E0h) command is used to determine which cache register outputs data first. To enable data output in the other cache registers, use the CHANGE READ COLUMN ENHANCED (06h-E0h) command. Additionally, the CHANGE READ



COLUMN (05h-E0h) command can be used to change the column address within the currently selected plane.

See Multi-Plane Operations for additional multi-plane addressing requirements.

Figure 55: READ PAGE MULTI-PLANE (00h-32h) Operation



98



Read Retry Operations

Read retry operations are used as an additional method to recover from bit errors beyond the ECC correction threshold.

Read Retry Operations


The read retry operations are a coordination of read operations and SET FEATURES (EFh) with feature address 89h, selecting different internal read settings in attempt to recover data that is beyond the ECC correction threshold. Using the read retry operations with any array read operation commands is allowed. See Configuration Operations and Feature Address 89h: Read Retry for details.

If reading a page has failed for bit errors beyond the ECC correction threshold, the host issues the SET FEATURE (EFh) command to feature address 89h with P1 subfeature set to a read retry option, as defined in that feature address. A new NAND array READ operation can now be performed. If the read still fails for bit errors beyond the ECC correction threshold, issue the SET FEATURES (EFh) command with the read retry (89h) feature address to select the next consecutive read retry option and repeat read retry operations until the data is correctable or the last option has been attempted. If the re-read is now correctable within the ECC threshold limits, the next read retry option should be set to its default value before the next NAND array READ operation. See Figure 56 (page 100) for flow diagram of read retry operations.

When the user writes to the read retry feature address, all subsequent reads use the internal NAND settings associated with that value until either the read retry feature address is rewritten or the device is powered down. This feature should not be used with the following commands: READ PARAMETER PAGE (ECh), READ UNIQUE ID (EDh), READ OTP PAGE (00h-30h).



Figure 56: Read Retry Flow Chart



Note: 1. There may be more read retry options than are shown in the figure for this NAND device. See Configuration Operations and Read Retry (89h) feature address for details.



Program Operations

Program operations are used to move data from the cache or data registers to the NAND array of one or more planes. During a program operation the contents of the cache and/or data registers are modified by the internal control logic.

Within a block, pages must be programmed sequentially from the least significant page address to the most significant page address (i.e. 0, 1, 2, 3, ...). Programming pages out of order within a block is prohibited.

Program Operations

The PROGRAM PAGE (80h-10h) command, when not preceded by the PROGRAM PAGE MULTI-PLANE (80h-11h) command, programs one page from the cache register to the NAND Flash array. When the die (LUN) is ready (RDY = 1, ARDY = 1), the host should check the FAIL bit to verify that the operation has completed successfully.

Program Cache Operations

The PROGRAM PAGE CACHE (80h-15h) command can be used to improve program operation system performance. When this command is issued, the die (LUN) goes busy (RDY = 0, ARDY = 0) while the cache register contents are copied to the data register, and the die (LUN) is busy with a program cache operation (RDY = 1, ARDY = 0. While the contents of the data register are moved to the NAND Flash array, the cache register is available for an additional PROGRAM PAGE CACHE (80h-15h) or PROGRAM PAGE (80h-10h) command.

For PROGRAM PAGE CACHE-series (80h-15h) operations, during the die (LUN) busy times, ^tCBSY and ^tLPROG, when RDY = 0 and ARDY = 0, the only valid commands are status operations (70h, 78h) and reset (FFh, FCh). When RDY = 1 and ARDY = 0, the only valid commands during PROGRAM PAGE CACHE-series (80h-15h) operations are status operations (70h, 78h), PROGRAM PAGE CACHE (80h-15h), PROGRAM PAGE (80h-10h), CHANGE WRITE COLUMN (85h), CHANGE ROW ADDRESS (85h), and reset (FFh, FCh).

Multi-Plane Program Operations

The PROGRAM PAGE MULTI-PLANE (80h-11h) command can be used to improve program operation system performance by enabling multiple pages to be moved from the cache registers to different planes of the NAND Flash array. This is done by prepending one or more PROGRAM PAGE MULTI-PLANE (80h-11h) commands in front of the PROGRAM PAGE (80h-10h) command. See Multi-Plane Operations for details.

Multi-Plane Program Cache Operations

The PROGRAM PAGE MULTI-PLANE (80h-11h) command can be used to improve program cache operation system performance by enabling multiple pages to be moved from the cache registers to the data registers and, while the pages are being transferred from the data registers to different planes of the NAND Flash array, free the cache registers to receive data input from the host. This is done by prepending one or more PROGRAM PAGE MULTI-PLANE (80h-11h) commands in front of the PROGRAM PAGE CACHE (80h-15h) command. See Multi-Plane Operations for details.

PROGRAM PAGE (80h-10h)

The PROGRAM PAGE (80h-10h) command enables the host to input data to a cache register, and moves the data from the cache register to the specified block and page address in the array of the selected die (LUN). This command is accepted by the die (LUN)



when it is ready (RDY = 1, ARDY = 1). It is also accepted by the die (LUN) when it is busy with a PROGRAM PAGE CACHE (80h-15h) operation (RDY = 1, ARDY = 0).


To input a page to the cache register and move it to the NAND array at the block and page address specified, write 80h to the command register. Unless this command has been preceded by a PROGRAM PAGE MULTI-PLANE (80h-11h) command, issuing the 80h to the command register clears all of the cache registers' contents on the selected target. Then write five address cycles containing the column address and row address. Data input cycles follow. Serial data is input beginning at the column address specified. At any time during the data input cycle the CHANGE WRITE COLUMN (85h) and CHANGE ROW ADDRESS (85h) commands may be issued. When data input is complete, write 10h to the command register. The selected LUN will go busy (RDY = 0, ARDY = 0) for ^tPROG as data is transferred.

To determine the progress of the data transfer, the host can monitor the target's R/B# signal or, alternatively, the status operations (70h, 78h) may be used. When the die (LUN) is ready (RDY = 1, ARDY = 1), the host should check the status of the FAIL bit.

In devices that have more than one die (LUN) per target, during and following interleaved die (multi-LUN) operations, the READ STATUS ENHANCED (78h) command must be used to select only one die (LUN) for status output. Use of the READ STATUS (70h) command could cause more than one die (LUN) to respond, resulting in bus contention.

The PROGRAM PAGE (80h-10h) command is used as the final command of a multiplane program operation. It is preceded by one or more PROGRAM PAGE MULTI-PLANE (80h-11h) commands. Data is transferred from the cache registers for all of the addressed planes to the NAND array. The host should check the status of the operation by using the status operations (70h, 78h). See Multi-Plane Operations for multi-plane addressing requirements.

Figure 57: PROGRAM PAGE (80h-10h) Operation





PROGRAM PAGE CACHE (80h-15h)

The PROGRAM PAGE CACHE (80h-15h) command enables the host to input data to a cache register; copies the data from the cache register to the data register; then moves the data register contents to the specified block and page address in the array of the selected die (LUN). After the data is copied to the data register, the cache register is available for additional PROGRAM PAGE CACHE (80h-15h) or PROGRAM PAGE (80h-10h) commands. The PROGRAM PAGE CACHE (80h-15h) command is accepted by the die (LUN) when it is ready (RDY =1, ARDY = 1). It is also accepted by the die (LUN) when busy with a PROGRAM PAGE CACHE (80h-15h) operation (RDY = 1, ARDY = 0).

To input a page to the cache register to move it to the NAND array at the block and page address specified, write 80h to the command register. Unless this command has been preceded by a PROGRAM PAGE MULTI-PLANE (80h-11h) command, issuing the 80h to the command register clears all of the cache registers' contents on the selected target. Then write five address cycles containing the column address and row address. Data input cycles follow. Serial data is input beginning at the column address specified. At any time during the data input cycle the CHANGE WRITE COLUMN (85h) and CHANGE ROW ADDRESS (85h) commands may be issued. When data input is complete, write 15h to the command register. The selected LUN will go busy (RDY = 0, ARDY = 0) for ^tCBSY to allow the data register to become available from a previous program cache operation, to copy data from the cache register to the data register, and then to begin moving the data register contents to the specified page and block address.

To determine the progress of ^tCBSY, the host can monitor the target's R/B# signal or, alternatively, the status operations (70h, 78h) can be used. When the LUN's status shows that it is busy with a PROGRAM CACHE operation (RDY = 1, ARDY = 0), the host should check the status of the FAILC bit to see if a previous cache operation was successful.

If, after ^tCBSY, the host wants to wait for the program cache operation to complete, without issuing the PROGRAM PAGE (80h-10h) command, the host should monitor ARDY until it is 1. The host should then check the status of the FAIL and FAILC bits.

In devices with more than one die (LUN) per target, during and following interleaved die (multi-LUN) operations, the READ STATUS ENHANCED (78h) command must be used to select only one die (LUN) for status output. Use of the READ STATUS (70h) command could cause more than one die (LUN) to respond, resulting in bus contention.

The PROGRAM PAGE CACHE (80h-15h) command is used as the final command of a multi-plane program cache operation. It is preceded by one or more PROGRAM PAGE MULTI-PLANE (80h-11h) commands. Data for all of the addressed planes is transferred from the cache registers to the corresponding data registers, then moved to the NAND Flash array. The host should check the status of the operation by using the status operations (70h, 78h). See Multi-Plane Operations for multi-plane addressing requirements.



Figure 58: PROGRAM PAGE CACHE (80h-15h) Operation (Start)





Figure 59: PROGRAM PAGE CACHE (80h-15h) Operation (End)



104



PROGRAM PAGE MULTI-PLANE (80h-11h)

The PROGRAM PAGE MULTI-PLANE (80h-11h) command enables the host to input data to the addressed plane's cache register and queue the cache register to ultimately be moved to the NAND Flash array. This command can be issued one or more times. Each time a new plane address is specified that plane is also queued for data transfer. To input data for the final plane and to begin the program operation for all previously queued planes, issue either the PROGRAM PAGE (80h-10h) command or the PROGRAM PAGE CACHE (80h-15h) command. All of the queued planes will move the data to the NAND Flash array. This command is accepted by the die (LUN) when it is ready (RDY = 1).

To input a page to the cache register and queue it to be moved to the NAND Flash array at the block and page address specified, write 80h to the command register. Unless this command has been preceded by an 11h command, issuing the 80h to the command register clears all of the cache registers' contents on the selected target. Write five address cycles containing the column address and row address; data input cycles follow. Serial data is input beginning at the column address specified. At any time during the data input cycle, the CHANGE WRITE COLUMN (85h) and CHANGE ROW ADDRESS (85h) commands can be issued. When data input is complete, write 11h to the command register. The selected die (LUN) will go busy (RDY = 0, ARDY = 0) for ^tDBSY.

To determine the progress of tDBSY , the host can monitor the target's R/B# signal or, alternatively, the status operations (70h, 78h) can be used. When the LUN's status shows that it is ready (RDY = 1), additional PROGRAM PAGE MULTI-PLANE (80h-11h) commands can be issued to queue additional planes for data transfer. Alternatively, the PROGRAM PAGE (80h-10h) or PROGRAM PAGE CACHE (80h-15h) commands can be issued.


When the PROGRAM PAGE (80h-10h) command is used as the final command of a multi-plane program operation, data is transferred from the cache registers to the NAND Flash array for all of the addressed planes during ${}^{t}PROG$. When the die (LUN) is ready (RDY = 1, ARDY = 1), the host should check the status of the FAIL bit for each of the planes to verify that programming completed successfully.

When the PROGRAM PAGE CACHE (80h-15h) command is used as the final command of a MULTI-PLANE PROGRAM CACHE operation, data is transferred from the cache registers to the data registers after the previous array operations finish. The data is then moved from the data registers to the NAND Flash array for all of the addressed planes. This occurs during ^tCBSY. After ^tCBSY, the host should check the status of the FAILC bit for each of the planes from the previous program cache operation, if any, to verify that programming completed successfully.

For the PROGRAM PAGE MULTI-PLANE (80h-11h), PROGRAM PAGE (80h-10h), and PROGRAM PAGE CACHE (80h-15h) commands, see Multi-Plane Operations for multiplane addressing requirements.



Figure 60: PROGRAM PAGE MULTI-PLANE (80h-11h) Operation



For JEDEC compliance the PROGRAM PAGE MULTI-PLANE (81h-11h) command is also supported. This would also include the last command 81h-10h to conclude a PRO-GRAM PAGE MULTI-PLANE sequence and 81h-15h to conclude a PROGRAM PAGE CACHE MULTI-PLANE sequence.



Erase Operations

Erase operations are used to clear the contents of a block in the NAND Flash array to prepare its pages for program operations.

Erase Operations

The ERASE BLOCK (60h-D0h) command, when not preceded by the ERASE BLOCK MULTI-PLANE (60h-D1h) command, erases one block in the NAND Flash array. When the die (LUN) is ready (RDY = 1, ARDY = 1), the host should check the FAIL bit to verify that this operation completed successfully.

MULTI-PLANE ERASE Operations

The ERASE BLOCK MULTI-PLANE (60h-D1h) command can be used to further system performance of erase operations by allowing more than one block to be erased in the NAND array. This is done by prepending one or more ERASE BLOCK MULTI-PLANE (60h-D1h) commands in front of the ERASE BLOCK (60h-D0h) command. See Multi-Plane Operations for details.

ERASE BLOCK (60h-D0h)

The ERASE BLOCK (60h-D0h) command erases the specified block in the NAND Flash array. This command is accepted by the die (LUN) when it is ready (RDY = 1, ARDY = 1).


To erase a block, write 60h to the command register. Then write three address cycles containing the row address; the page address is ignored. Conclude by writing D0h to the command register. The selected die (LUN) will go busy (RDY = 0, ARDY = 0) for ^tBERS while the block is erased.

To determine the progress of an ERASE operation, the host can monitor the target's R/B# signal, or alternatively, the status operations (70h, 78h) can be used. When the die (LUN) is ready (RDY = 1, ARDY = 1) the host should check the status of the FAIL bit.

In devices that have more than one die (LUN) per target, during and following interleaved die (multi-LUN) operations, the READ STATUS ENHANCED (78h) command must be used to select only one die (LUN) for status output. Use of the READ STATUS (70h) command could cause more than one die (LUN) to respond, resulting in bus contention.

The ERASE BLOCK (60h-D0h) command is used as the final command of a MULTI-PLANE ERASE operation. It is preceded by one or more ERASE BLOCK MULTI-PLANE (60h-D1h) commands. All of blocks in the addressed planes are erased. The host should check the status of the operation by using the status operations (70h, 78h). See Multi-Plane Operations for multi-plane addressing requirements.

Figure 61: ERASE BLOCK (60h-D0h) Operation





ERASE BLOCK MULTI-PLANE (60h-D1h)


The ERASE BLOCK MULTI-PLANE (60h-D1h) command queues a block in the specified plane to be erased in the NAND Flash array. This command can be issued one or more times. Each time a new plane address is specified, that plane is also queued for a block to be erased. To specify the final block to be erased and to begin the ERASE operation for all previously queued planes, issue the ERASE BLOCK (60h-D0h) command. This command is accepted by the die (LUN) when it is ready (RDY = 1, ARDY = 1).

To queue a block to be erased, write 60h to the command register, then write three address cycles containing the row address; the page address is ignored. Conclude by writing D1h to the command register. The selected die (LUN) will go busy (RDY = 0, ARDY = 0) for t DBSY.

To determine the progress of ^tDBSY, the host can monitor the target's R/B# signal, or alternatively, the status operations (70h, 78h) can be used. When the LUN's status shows that it is ready (RDY = 1, ARDY = 1), additional ERASE BLOCK MULTI-PLANE (60h-D1h) commands can be issued to queue additional planes for erase. Alternatively, the ERASE BLOCK (60h-D0h) command can be issued to erase all of the queued blocks.

For multi-plane addressing requirements for the ERASE BLOCK MULTI-PLANE (60h-D1h) and ERASE BLOCK (60h-D0h) commands, see Multi-Plane Operations.


Figure 62: ERASE BLOCK MULTI-PLANE (60h-D1h) Operation



ERASE BLOCK MULTI-PLANE (60h-60h-D0h)

This operation behaves the same as the ERASE BLOCK MULTI-PLANE (60h-D1h) command followed by a ERASE BLOCK (60h-D0h) command.

Figure 63: ERASE BLOCK MULTI-PLANE (60h-60h-D0h) Operation





Copyback Operations

COPYBACK operations make it possible to transfer data within a plane from one page to another using the cache register. This is particularly useful for block management and wear leveling.

The COPYBACK operation is a two-step process consisting of a COPYBACK READ (00h-35h) and a COPYBACK PROGRAM (85h-10h) command. To move data from one page to another on the same plane, first issue the COPYBACK READ (00h-35h) command. When the die (LUN) is ready (RDY = 1, ARDY = 1), the host can transfer the data to a new page by issuing the COPYBACK PROGRAM (85h-10h) command. When the die (LUN) is again ready (RDY = 1, ARDY = 1), the host should check the FAIL bit to verify that this operation completed successfully.

To prevent bit errors from accumulating over multiple COPYBACK operations, it is recommended that the host read the data out of the cache register after the COPYBACK READ (00h-35h) completes prior to issuing the COPYBACK PROGRAM (85h-10h) command. The CHANGE READ COLUMN (05h-E0h) command can be used to change the column address. The host should check the data for ECC errors and correct them. When the COPYBACK PROGRAM (85h-10h) command is issued, any corrected data can be input. The CHANGE ROW ADDRESS (85h) command can be used to change the column address.

It is not possible to use the COPYBACK operation to move data from one plane to another or from one die (LUN) to another. Instead, use a READ PAGE (00h-30h) or COPYBACK READ (00h-35h) command to read the data out of the NAND, and then use a PROGRAM PAGE (80h-10h) command with data input to program the data to a new plane or die (LUN).

Between the COPYBACK READ (00h-35h) and COPYBACK PROGRAM (85h-10h) commands, the following commands are supported: status operations (70h, 78h), and column address operations (05h-E0h, 06h-E0h, 85h). Reset operations (FFh, FCh) can be issued after COPYBACK READ (00h-35h), but the contents of the cache registers on the target are not valid.

In devices which have more than one die (LUN) per target, once the COPYBACK READ (00h-35h) is issued, interleaved die (multi-LUN) operations are prohibited until after the COPYBACK PROGRAM (85h-10h) command is issued.

Multi-Plane Copyback Operations

Multi-plane copyback read operations improve read data throughput by copying data simultaneously from more than one plane to the specified cache registers. This is done by prepending one or more READ PAGE MULTI-PLANE (00h-32h) commands in front of the COPYBACK READ (00h-35h) command.

The COPYBACK PROGRAM MULTI-PLANE (85h-11h) command can be used to further system performance of COPYBACK PROGRAM operations by enabling movement of multiple pages from the cache registers to different planes of the NAND Flash array. This is done by prepending one or more COPYBACK PROGRAM (85h-11h) commands in front of the COPYBACK PROGRAM (85h-10h) command. See Multi-Plane Operations for details.



COPYBACK READ (00h-35h)

The COPYBACK READ (00h-35h) command is functionally identical to the READ PAGE (00h-30h) command, except that 35h is written to the command register instead of 30h. See READ PAGE (00h-30h) (page 92) for further details.

Though it is not required, it is recommended that the host read the data out of the device to verify the data prior to issuing the COPYBACK PROGRAM (85h-10h) command to prevent the propagation of data errors.

Figure 64: COPYBACK READ (00h-35h) Operation





Figure 65: COPYBACK READ (00h-35h) with CHANGE READ COLUMN (05h-E0h) Operation



110



COPYBACK PROGRAM (85h-10h)

The COPYBACK PROGRAM (85h-10h) command is functionally identical to the PRO-GRAM PAGE (80h-10h) command, except that when 85h is written to the command register, cache register contents are not cleared. See PROGRAM PAGE (80h-10h) for further details.

Figure 66: COPYBACK PROGRAM (85h-10h) Operation





Figure 67: COPYBACK PROGRAM (85h-10h) with CHANGE WRITE COLUMN (85h) Operation



COPYBACK READ MULTI-PLANE (00h-32h)


The COPYBACK READ MULTI-PLANE (00h-32h) command is functionally identical to the READ PAGE MULTI-PLANE (00h-32h) command, except that the 35h command is written as the final command. The complete command sequence for the COPYBACK READ PAGE MULTI-PLANE is 00h-32h-00h-35h. See READ PAGE MULTI-PLANE (00h-32h) (page 97) for further details.



COPYBACK PROGRAM MULTI-PLANE (85h-11h)

The COPYBACK PROGRAM MULTI-PLANE (85h-11h) command is functionally identical to the PROGRAM PAGE MULTI-PLANE (80h-11h) command, except that when 85h is written to the command register, cache register contents are not cleared. See PROGRAM PAGE MULTI-PLANE (80h-11h) for further details.

Figure 68: COPYBACK PROGRAM MULTI-PLANE (85h-11h) Operation





One-Time Programmable (OTP) Operations

This Micron NAND Flash device offers a protected, one-time programmable NAND Flash memory area. Each target has a an OTP area with a range of OTP pages (see Table 18 (page 114)); the entire range is guaranteed to be good. Customers can use the OTP area in any way they desire; typical uses include programming serial numbers or other data for permanent storage.

The OTP area leaves the factory in an erased state (all bits are 1). Programming an OTP page changes bits that are 1 to 0, but cannot change bits that are 0 to 1. The OTP area cannot be erased, even if it is not protected. Protecting the OTP area prevents further programming of the pages in the OTP area.

Enabling the OTP Operation Mode

The OTP area is accessible while the OTP operation mode is enabled. To enable OTP operation mode, issue the SET FEATURES (EFh) command to feature address 90h and write 01h to P1, followed by three cycles of 00h to P2 through P4.

When the target is in OTP operation mode, all subsequent PAGE READ (00h-30h) and PROGRAM PAGE (80h-10h) commands are applied to the OTP area.

ERASE commands are not valid while the target is in OTP operation mode.

Programming OTP Pages

Each page in the OTP area is programming using the PROGRAM OTP PAGE (80h-10h) command. Each page can be programmed more than once, in sections, up to the maximum number allowed (see NOP in Table 18 (page 114)). The pages in the OTP area must be programmed in ascending order.

If the host issues a PAGE PROGRAM (80h-10h) command to an address beyond the maximum page-address range, the target will be busy for ^tOBSY and the WP# status register bit will be 0, meaning that the page is write-protected.

Protecting the OTP Area

To protect the OTP area, issue the OTP PROTECT (80h-10h) command to the OTP Protect Page. When the OTP area is protected it cannot be programmed further. It is not possible to unprotect the OTP area after it has been protected.

Reading OTP Pages

To read pages in the OTP area, whether the OTP area is protected or not, issue the PAGE READ (00h-30h) command.

If the host issues the PAGE READ (00h-30h) command to an address beyond the maximum page-address range, the data output will not be valid. To determine whether the target is busy during an OTP operation, either monitor R/B# or use the READ STATUS (70h) command. Use of the READ STATUS ENHANCED (78h) command is prohibited while the OTP operation is in progress.

Returning to Normal Array Operation Mode

To exit OTP operation mode and return to normal array operation mode, issue the SET FEATURES (EFh) command to feature address 90h and write 00h to P1 through P4.

If the RESET (FFh) command is issued while in OTP operation mode, the target will exit OTP operation mode and enter normal operating mode. If the synchronous interface is active, the target will exit OTP operation and enable the asynchronous interface.



If the SYNCHRONOUS RESET (FCh) command is issued while in the OTP operation mode, the target will exit OTP operation mode and the synchronous interface remains active.

Table 18: OTP Area Details

Description	Value
Number of OTP pages	30
OTP protect page address	01h
OTP start page address	02h
Number of partial page programs (NOP) to each OTP page	2

PROGRAM OTP PAGE (80h-10h)

The PROGRAM OTP PAGE (80h-10h) command is used to write data to the pages within the OTP area. To program data in the OTP area, the target must be in OTP operation mode.

To use the PROGRAM OTP PAGE (80h-10h) command, issue the 80h command. Issue five address cycles including the column address, the page address within the OTP page range, and a block address of 0. Next, write the data to the cache register using data input cycles. After data input is complete, issue the 10h command.

R/B# goes LOW for the duration of the array programming time, ^tPROG. The READ STATUS (70h) command is the only valid command for reading status in OTP operation mode. The RDY bit of the status register will reflect the state of R/B#. Use of the READ STATUS ENHANCED (78h) command is prohibited.

When the target is ready, read the FAIL bit of the status register to determine whether the operation passed or failed (see Status Operations).

The PROGRAM OTP PAGE (80h-10h) command also accepts the CHANGE WRITE COL-UMN (85h) command during data input.

If a PROGRAM PAGE command is issued to the OTP area after the area has been protected, then R/B# goes LOW for ^tOBSY. After ^tOBSY, the status register is set to 60h.

Figure 69: PROGRAM OTP PAGE (80h-10h) Operation







Figure 70: PROGRAM OTP PAGE (80h-10h) with CHANGE WRITE COLUMN (85h) Operation



PROTECT OTP AREA (80h-10h)

The PROTECT OTP AREA (80h-10h) command is used to prevent further programming of the pages in the OTP area. The protect the OTP area, the target must be in OTP operation mode.

To protect all data in the OTP area, issue the 80h command. Issue five address cycles including the column address, OTP protect page address and block address; the column and block addresses are fixed to 0. Next, write 00h data for the first byte location and issue the 10h command.


R/B# goes LOW for the duration of the array programming time, ^tPROG. The READ STATUS (70h) command is the only valid command for reading status in OTP operation mode. The RDY bit of the status register will reflect the state of R/B#. Use of the READ STATUS ENHANCED (78h) command is prohibited.

When the target is ready, read the FAIL bit of the status register to determine if the operation passed or failed (see Status Operations).

If the PROTECT OTP AREA (80h-10h) command is issued after the OTP area has already been protected, R/B# goes LOW for ^tOBSY. After ^tOBSY, the status register is set to 60h.



Figure 71: PROTECT OTP AREA (80h-10h) Operation



Note: 1. OTP data is protected following a status confirmation.

READ OTP PAGE (00h-30h)

The READ OTP PAGE (00h-30h) command is used to read data from the pages in the OTP area. To read data in the OTP area, the target must be in OTP operation mode.


To use the READ OTP PAGE (00h-30h) command, issue the 00h command. Issue five address cycles including the column address, the page address within the OTP page range, and a block address of 0. Next, issue the 30h command. The selected die (LUN) will go busy (RDY = 0, ARDY = 0) for ${}^{\rm t}{\rm R}$ as data is transferred.

To determine the progress of the data transfer, the host can monitor the target's R/B# signal, or alternatively the READ STATUS (70h) command can be used. If the status operations are used to monitor the die's (LUN's) status, when the die (LUN) is ready (RDY = 1, ARDY = 1) the host disables status output and enables data output by issuing the READ MODE (00h) command. When the host requests data output, it begins at the column address specified.

Additional pages within the OTP area can be read by repeating the READ OTP PAGE (00h-30h) command.

The READ OTP PAGE (00h-30h) command is compatible with the CHANGE READ COL-UMN (05h-E0h) command. Use of the READ STATUS ENHANCED (78h) and CHANGE READ COLUMN ENHANCED (06h-E0h) commands are prohibited.

Figure 72: READ OTP PAGE (00h-30h) Operation





64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Multi-Plane Operations

Multi-Plane Operations

Each NAND Flash logical unit (LUN) is divided into multiple physical planes. Each plane contains a cache register and a data register independent of the other planes. The planes are addressed via the low-order block address bits. Specific details are provided in Device and Array Organization.

Multi-plane operations make better use of the NAND Flash arrays on these physical planes by performing concurrent READ, PROGRAM, or ERASE operations on multiple planes, significantly improving system performance. Multi-plane operations must be of the same type across the planes; for example, it is not possible to perform a PROGRAM operation on one plane with an ERASE operation on another.

When issuing MULTI-PLANE PROGRAM or ERASE operations, use the READ STATUS (70h) command and check whether the previous operation(s) failed. If the READ STATUS (70h) command indicates that an error occurred (FAIL = 1 and/or FAILC = 1), use the READ STATUS ENHANCED (78h) command—time for each plane—to determine which plane operation failed.

Multi-Plane Addressing

Multi-plane commands require an address per operational plane. For a given multiplane operation, these addresses are subject to the following requirements:

- The LUN address bit(s) must be identical for all of the issued addresses.
- The plane select bit, BA[8], must be different for each issued address.
- The page address bits, PA[7:0], must be identical for each issued address.

The READ STATUS (70h) command should be used following MULTI-PLANE PROGRAM PAGE and ERASE BLOCK operations on a single die (LUN).



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Interleaved Die (Multi-LUN) Operations

Interleaved Die (Multi-LUN) Operations

In devices that have more than one die (LUN) per target, it is possible to improve performance by interleaving operations between the die (LUNs). An interleaved die (multi-LUN) operation is one that individual die (LUNs) involved may be in any combination of busy or ready status during operations.

Interleaved die (multi-LUN) operations are prohibited following RESET (FFh, FCh), identification (90h, ECh, EDh), and configuration (EEh, EFh) operations until ARDY =1 for all of the die (LUNs) on the target.

During an interleaved die (multi-LUN) operation, there are two methods to determine operation completion. The R/B# signal indicates when all of the die (LUNs) have finished their operations. R/B# remains LOW while any die (LUN) is busy. When R/B# goes HIGH, all of the die (LUNs) are idle and the operations are complete. Alternatively, the READ STATUS ENHANCED (78h) command can report the status of each die (LUN) individually.

If a die (LUN) is performing a cache operation, like PROGRAM PAGE CACHE (80h-15h), then the die (LUN) is able to accept the data for another cache operation when status register bit 6 is 1. All operations, including cache operations, are complete on a die when status register bit 5 is 1.

Use the READ STATUS ENHANCED (78h) command to monitor status for the addressed die (LUN). When multi-plane commands are used with interleaved die (multi-LUN) operations, the multi-plane commands must also meet the requirements, see Multi-Plane Operations for details. After the READ STATUS ENHANCED (78h) command has been issued, the READ STATUS (70h) command may be issued for the previously addressed die (LUN).

See Command Definitions for the list of commands that can be issued while other die (LUNs) are busy.

During an interleaved die (multi-LUN) operation that involves a PROGRAM-series (80h-10h, 80h-15h, 80h-11h) operation and a READ operation, the PROGRAM-series operation must be issued before the READ-series operation. The data from the READ-series operation must be output to the host before the next PROGRAM-series operation is issued. This is because the 80h command clears the cache register contents of all cache registers on all planes.

When issuing combinations of commands to multiple die (LUNs) (e.g. Reads to one die (LUN) and Programs to another die (LUN)) or Reads to one die (LUN) and Reads to another die (LUN)), the host shall issue the READ STATUS ENHANCED (78h) command before reading data from any LUN. This ensures that only the LUN selected by the READ STATUS ENHANCED (78h) command responds to a data output cycle after being put into data output mode, and thus avoiding bus contention. After the READ STATUS ENHANCED (78h) command is issued to the selected die (LUN) a CHANGE READ COL-UMN (05h-E0h) or CHANGE READ COLUMN ENHANCED (06h-E0h) command shall be issued prior to any data output from the selected die (LUN).

118



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Error Management

Error Management

Each NAND Flash die (LUN) is specified to have a minimum number of valid blocks (NVB) of the total available blocks. This means the die (LUNs) could have blocks that are invalid when shipped from the factory. An invalid block is one that contains at least one page that has more bad bits than can be corrected by the minimum required ECC. Additional blocks can develop with use. However, the total number of available blocks per die (LUN) will not fall below NVB during the endurance life of the product.

Although NAND Flash memory devices could contain bad blocks, they can be used quite reliably in systems that provide bad-block management and error-correction algorithms. This type of software environment ensures data integrity.

Internal circuitry isolates each block from other blocks, so the presence of a bad block does not affect the operation of the rest of the NAND Flash array.

NAND Flash devices are shipped from the factory erased. The factory identifies invalid blocks before shipping by attempting to program the bad-block mark into every location in the first page of each invalid block. It may not be possible to program every location with the bad-block mark. However, the first spare area location in each bad block is guaranteed to contain the bad-block mark. This method is compliant with ONFI Factory Defect Mapping requirements. See the following table for the first spare area location and the bad-block mark.

System software should check the first spare area location on the first page of each block prior to performing any PROGRAM or ERASE operations on the NAND Flash device. A bad block table can then be created, enabling system software to map around these areas. Factory testing is performed under worst-case conditions. Because invalid blocks could be marginal, it may not be possible to recover this information if the block is erased.

Over time, some memory locations may fail to program or erase properly. In order to ensure that data is stored properly over the life of the NAND Flash device, the following precautions are required:

- Always check status after a PROGRAM or ERASE operation
- Under typical conditions, use the minimum required ECC (see table below)
- Use bad-block management and wear-leveling algorithms

The first block (physical block address 00h) for each CE# is guaranteed to be valid with ECC when shipped from the factory.

Table 19: Error Management Details

Description	Requirement
Minimum number of valid blocks (NVB) per LUN	4011
Total available blocks per LUN	4096
First spare area location	Byte 8192
Bad-block mark	00h
Minimum required ECC	40-bit ECC per 1117 bytes of data



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Shared Pages

Shared Pages

In MLC NAND Flash devices, each memory cell contains two bits of data. These bits are distributed across two NAND pages. Pages within a NAND block that share the same NAND memory cells are referred to as shared pages. If any program operation is interrupted (for example, power loss or reset), data in previously programmed shared pages can also be corrupted.

The least significant numbered shared page must be programmed before the most significant numbered page of that pair can be programmed.

Table 20: Shared Pages

Share	Shared Pages		d Pages
0	6	1	7
2	-	3	-
4	10	5	11
8	14	9	15
12	18	13	19
16	22	17	23
20	26	21	27
24	30	25	31
28	34	29	35
32	38	33	39
36	42	37	43
40	46	41	47
44	50	45	51
48	54	49	55
52	58	53	59
56	62	57	63
60	66	61	67
64	70	65	71
68	74	69	75
72	78	73	79
76	82	77	83
80	86	81	87
84	90	85	91
88	94	89	95
92	98	93	99
96	102	97	103
100	106	101	107
104	110	105	111
108	114	109	115
112	118	113	119



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Shared Pages

Table 20: Shared Pages (Continued)

Shared Pages		Shared Pages		
116	122	117	123	
120	126	121	127	
124	130	125	131	
128	134	129	135	
132	138	133	139	
136	142	137	143	
140	146	141	147	
144	150	145	151	
148	154	149	155	
152	158	153	159	
156	162	157	163	
160	166	161	167	
164	170	165	171	
168	174	169	175	
172	178	173	179	
176	182	177	183	
180	186	181	187	
184	190	185	191	
188	194	189	195	
192	198	193	199	
196	202	197	203	
200	206	201	207	
204	210	205	211	
208	214	209	215	
212	218	213	219	
216	222	217	223	
220	226	221	227	
224	230	225	231	
228	234	229	235	
232	238	233	239	
236	242	237	243	
240	246	241	247	
244	250	245	251	
248	-	249	-	
252	-	253	-	
254	-	255	-	



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Output Drive Impedance

Output Drive Impedance

Because NAND Flash is designed for use in systems that are typically point-to-point connections, an option to control the drive strength of the output buffers is provided. Drive strength should be selected based on the expected loading of the memory bus. There are four supported settings for the output drivers: overdrive 2, overdrive 1, nominal, and underdrive.

The nominal output drive strength setting is the power-on default value. The host can select a different drive strength setting using the SET FEATURES (EFh) command.

The output impedance range from minimum to maximum covers process, voltage, and temperature variations. Devices are not guaranteed to be at the nominal line.

Table 21: Output Drive Strength Conditions (V_{CCQ} = 1.7–1.95V)

Range	Process	Voltage	Temperature
Minimum	Fast-Fast	1.95V	T _A (MIN)
Nominal	Typical-Typical	1.8V	+25°C
Maximum	Slow-Slow	1.7V	T _A (MAX)

Table 22: Output Drive Strength Impedance Values (V_{CCQ} = 1.7–1.95V)

Output Strength	Rpd/Rpu	V _{OUT} to V _{SSQ}	Minimum	Nominal	Maximum	Unit
Overdrive 2	Rpd	V _{CCQ} × 0.2	7.5	13.5	34	ohms
		V _{CCQ} × 0.5	9	18	31	ohms
		V _{CCQ} × 0.8	11	23.5	44	ohms
	Rpu	V _{CCQ} × 0.2	11	23.5	44	ohms
		V _{CCQ} × 0.5	9	18	31	ohms
		V _{CCQ} × 0.8	7.5	13.5	34	ohms
Overdrive 1	Rpd	V _{CCQ} × 0.2	10.5	19	47	ohms
		V _{CCQ} × 0.5	13	25	44	ohms
		V _{CCQ} × 0.8	16	32.5	61.5	ohms
	Rpu	V _{CCQ} × 0.2	16	32.5	61.5	ohms
		V _{CCQ} × 0.5	13	25	44	ohms
		V _{CCQ} × 0.8	10.5	19	47	ohms
Nominal	Rpd	V _{CCQ} × 0.2	15	27	66.5	ohms
		V _{CCQ} × 0.5	18	35	62.5	ohms
		V _{CCQ} × 0.8	22	52	88	ohms
	Rpu	V _{CCQ} × 0.2	22	52	88	ohms
		V _{CCQ} × 0.5	18	35	62.5	ohms
		V _{CCQ} × 0.8	15	27	66.5	ohms



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Output Drive Impedance

Table 22: Output Drive Strength Impedance Values ($V_{CCQ} = 1.7-1.95V$) (Continued)

Output Strength	Rpd/Rpu	V _{OUT} to V _{SSQ}	Minimum	Nominal	Maximum	Unit
Underdrive	Rpd	$V_{CCQ} \times 0.2$	21.5	39	95	ohms
		V _{CCQ} × 0.5	26	50	90	ohms
		V _{CCQ} × 0.8	31.5	66.5	126.5	ohms
	Rpu	V _{CCQ} × 0.2	31.5	66.5	126.5	ohms
		V _{CCQ} × 0.5	26	50	90	ohms
		V _{CCQ} × 0.8	21.5	39	95	ohms

Table 23: Output Drive Strength Conditions ($V_{CCQ} = 2.7-3.6V$)

Range	Process	Voltage	Temperature
Minimum	Fast-Fast	3.6V	T _A (MIN)
Nominal	Typical-Typical	3.3V	+25°C
Maximum	Slow-Slow	2.7V	T _A (MAX)

Table 24: Output Drive Strength Impedance Values (V_{CCQ} = 2.7–3.6V)

Output Strength	Rpd/Rpu	V _{OUT} to V _{SSQ}	Minimum	Nominal	Maximum	Unit
Overdrive 2	Rpd	V _{CCQ} X 0.2	7.0	16.2	28.7	ohms
		V _{CCQ} X 0.5	9.0	18.0	36.0	ohms
		V _{CCQ} X 0.8	11.8	21.0	50.0	ohms
	Rpu	V _{CCQ} X 0.2	11.8	21.0	50.0	ohms
		V _{CCQ} X 0.5	9.0	18.0	36.0	ohms
		V _{CCQ} X 0.8	7.0	14.0	28.7	ohms
Overdrive 1	Rpd	V _{CCQ} X 0.2	9.3	22.3	40.0	ohms
		V _{CCQ} X 0.5	12.6	25.0	50.0	ohms
		V _{CCQ} X 0.8	16.3	29.0	68.0	ohms
	Rpu	V _{CCQ} X 0.2	16.3	29.0	68.0	ohms
		V _{CCQ} X 0.5	12.6	25.0	50.0	ohms
		V _{CCQ} X 0.8	9.3	19.0	40.0	ohms
Nominal	Rpd	V _{CCQ} X 0.2	12.8	32.0	58.0	ohms
		V _{CCQ} X 0.5	18.0	35.0	70.0	ohms
		V _{CCQ} X 0.8	23.0	40.0	95.0	ohms
	Rpu	V _{CCQ} X 0.2	23.0	40.0	95.0	ohms
		V _{CCQ} X 0.5	18.0	35.0	70.0	ohms
		V _{CCQ} X 0.8	12.8	32.0	58.0	ohms



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND **Output Drive Impedance**

Table 24: Output Drive Strength Impedance Values (V_{CCQ} = 2.7–3.6V) (Continued)

Output Strength	Rpd/Rpu	V _{OUT} to V _{SSQ}	Minimum	Nominal	Maximum	Unit
Underdrive	Rpd	V _{CCQ} X 0.2	18.4	45.0	80.0	ohms
		V _{CCQ} X 0.5	25.0	50.0	100.0	ohms
		V _{CCQ} X 0.8	32.0	57.0	136.0	ohms
	Rpu	V _{CCQ} X 0.2	32.0	57.0	136.0	ohms
		V _{CCQ} X 0.5	25.0	50.0	100.0	ohms
		V _{CCQ} X 0.8	18.4	45.0	80.0	ohms

Table 25: Pull-Up and Pull-Down Output Impedance Mismatch

Drive Strength	Minimum	Maximum	Unit	Notes
Overdrive 2	0	6.3	ohms	1, 2
Overdrive 1	0	8.8	ohms	1, 2
Nominal	0	12.3	ohms	1, 2
Underdrive	0	17.5	ohms	1, 2

- Notes: 1. Mismatch is the absolute value between pull-up and pull-down impedances. Both are measured at the same temperature and voltage.
 - 2. Test conditions: $V_{CCQ} = V_{CCQ}$ (MIN), $V_{OUT} = V_{CCQ} \times 0.5$, $T_A = T_{OPER}$.



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND AC Overshoot/Undershoot Specifications

AC Overshoot/Undershoot Specifications

The supported AC overshoot and undershoot area depends on the timing mode selected by the host.

Table 26: Asynchronous Overshoot/Undershoot Parameters

		Timing Mode					
Parameter	0	1	2	3	4	5	Unit
Maximum peak amplitude provided for overshoot area	1	1	1	1	1	1	V
Maximum peak amplitude provided for undershoot area	1	1	1	1	1	1	V
Maximum overshoot area above V _{CCQ}	3	3	3	3	3	3	V-ns
Maximum undershoot area below V _{SSQ}	3	3	3	3	3	3	V-ns

Table 27: Synchronous Overshoot/Undershoot Parameters

		Timing Mode							
Parameter	0	1	2	3	4	5	Unit		
Maximum peak amplitude provided for overshoot area	1	1	1	1	1	1	V		
Maximum peak amplitude provided for undershoot area	1	1	1	1	1	1	V		
Maximum overshoot area above V _{CCQ}	3	3	3	2.25	1.8	1.5	V-ns		
Maximum undershoot area below V _{SSQ}	3	3	3	2.25	1.8	1.5	V-ns		

Figure 73: Overshoot





Figure 74: Undershoot





64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Synchronous Input Slew Rate

Synchronous Input Slew Rate

Though all AC timing parameters are tested with a nominal input slew rate of 1 V/ns, it is possible to run the device at a slower slew rate. The input slew rates shown below are sampled, and not 100% tested. When using slew rates slower than the minimum values, timing must be derated by the host.

Table 28: Test Conditions for Input Slew Rate

Parameter	Value
Rising edge	V _{IL(DC)} To V _{IH(AC)}
Falling edge	V _{IH(DC)} To V _{IL(AC)}
Temperature range	T _A

Table 29: Input Slew Rate (V_{CCQ} = 1.7-1.95V)

Command/		CLK/DQS Slew Rate Derating V _{IH(AC)} /V _{IL(AC)} = 540mV, V _{IH(DC)} /V _{IL(DC)} = 360mV															
Address and DQ	,	1	0	.9 0.8		0.7		0.6		0.5		0.4		0.3			
V/ns	set	hold	set	hold	set	hold	set	hold	set	hold	set	hold	set	hold	set	hold	Unit
1	0	0	0	0	-	-	-	-	-	-	-	-	-	-	-	-	ps
0.9	0	0	0	0	0	0	-	-	-	-	-	-	-	-	-	-	ps
0.8	-	-	0	0	0	0	0	0	-	-	-	-	-	-	-	-	ps
0.7	-	-	-	-	0	0	0	0	0	0	-	-	-	-	-	-	ps
0.6	-	-	-	-	-	-	0	0	0	0	0	0	-	-	-	-	ps
0.5	-	-	-	-	-	-	-	-	0	0	0	0	180	180	-	-	ps
0.4	-	-	-	-	-	-	-	-	•	-	180	180	360	360	660	660	ps
0.3	-	-	-	-	-	-	-	-	-	-	-	-	660	660	920	920	ps

Table 30: Input Slew Rate (V_{CCQ}= 2.7-3.6V)

Command/		CL	K/DQ	S Slew	Rate	Derat	ing V	IH(AC) ^{/\}	/ _{IL(AC)}	= 990r	nV, V _I	H(DC)/\	IL(DC)	= 660n	ηV		
Address	•	1	0.9		0.8		0.7		0.6		0	.5	0	.4	0.3		
and DQ V/ns	set	hold	set	hold	set	hold	set	hold	set	hold	set	hold	set	hold	set	hold	Unit
1	0	0	0	0	-	-	-	-	•	-	-	-	-	-	-	-	ps
0.9	0	0	0	0	0	0	-	-	-	-	-	-	-	-	-	-	ps
0.8	-	-	0	0	0	0	0	0	-	-	-	-	-	-	-	-	ps
0.7	-	-	-	-	0	0	0	0	0	0	-	-	-	-	-	-	ps
0.6	-	-	-	-	-	-	0	0	0	0	0	0	-	-	-	-	ps
0.5	-	-	-	-	-	-	-	-	0	0	0	0	330	330	-	-	ps
0.4	-	-	-	-	-	-	-	-	-	-	330	330	660	660	1210	1210	ps
0.3	-	-	-	-	-	-	-	-	ı	-	ı	-	1210	1210	1760	1760	ps



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Output Slew Rate

Output Slew Rate

The output slew rate is tested using the following setup with only one die per DQ channel.

Table 31: Test Conditions for Output Slew Rate

Parameter	Value
V _{OL(DC)}	0.3 × V _{CCQ}
V _{OH(DC)}	0.7 × V _{CCQ}
V _{OL(AC)}	0.2 × V _{CCQ}
V _{OH(AC)}	0.8 × V _{CCQ}
Rising edge (^t RISE)	V _{OL(DC)} to V _{OH(AC)}
Falling edge (tFALL)	V _{OH(DC)} to V _{OL(AC)}
Output capacitive load (C _{LOAD})	5pF
Temperature range	T _A

Table 32: Output Slew Rate (V_{CCQ} = 1.7–1.95V)

Output Drive Strength	Min	Мах	Unit
Overdrive 2	1	5.5	V/ns
Overdrive 1	0.85	5	V/ns
Nominal	0.75	4	V/ns
Underdrive	0.6	4	V/ns

Table 33: Output Slew Rate (V_{CCQ} = 2.7–3.6V)

Output Drive Strength	Min	Мах	Unit
Overdrive 2	1.5	10.0	V/ns
Overdrive 1	1.5	9.0	V/ns
Nominal	1.2	7.0	V/ns
Underdrive	1.0	5.5	V/ns



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Power Cycle Requirements

Power Cycle Requirements

Upon power-down the NAND device requires a maximum voltage and minimum time that the host must hold V_{CC} and V_{CCQ} below the voltage prior to power-on.

Table 34: Power Cycle Requirements

Parameter	Value	Unit
Maximum V _{CC} /V _{CCQ}	100	mV
Minimum time below maximum voltage	100	ns



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Electrical Specifications

Electrical Specifications

Stresses greater than those listed can cause permanent damage to the device. This is a stress rating only, and functional operation of the device at these or any other conditions above those indicated in the operational sections of this specification is not guaranteed. Exposure to absolute maximum rating conditions for extended periods can affect reliability.

Table 35: Absolute Maximum Ratings by Device

Parameter	Symbol	Min ¹	Max ¹	Unit
Voltage input	V _{IN}	-0.6	4.6	V
V _{CC} supply voltage	V _{CC}	-0.6	4.6	V
V _{CCQ} supply voltage	V _{CCQ}	-0.6	4.6	V
Storage temperature	T _{STG}	-65	+150	°C

Note: 1. Voltage on any pin relative to V_{SS}.

Table 36: Recommended Operating Conditions

Parameter	Symbol	Min	Тур	Max	Unit	
Operating temperature	Commercial	T _A	0	_	+70	°C
	Industrial		-40	_	+85	
V _{CC} supply voltage	•	V _{CC}	2.7	3.3	3.6	V
V _{CCQ} supply voltage (1.8V)		V _{CCQ}	1.7	1.8	1.95	V
V _{CCQ} supply voltage (3.3V)			2.7	3.3	3.6	V
V _{SS} ground voltage		V _{SS}	0	0	0	V

Table 37: Valid Blocks per LUN

Parameter	Symbol	Min	Мах	Unit	Notes
Valid block number	NVB	4011	4096	Blocks	1

129

Note: 1. Invalid blocks are blocks that contain one or more bad bits beyond ECC. The device may contain bad blocks upon shipment. Additional bad blocks may develop over time; however, the total number of available blocks will not drop below NVB during the endurance life of the device. Do not erase or program blocks marked invalid from the factory.



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Electrical Specifications

Table 38: Capacitance: 100-Ball BGA Package

		Single Die/Dual Die Package Quad Die Package							
Description	Symbol	Min	Тур	Max	Min	Тур	Max	Unit	Notes
Input capacitance (CLK / WE#)	C _{CK}	4.1	5.1	6.1	6.2	7.7	9.2	pF	3
Input capacitance (ALE, CLE, RE# / W/R#)	C _{IN}	3.3	4.3	5.3	5.3	6.8	8.3	pF	3
Input/output capacitance (DQ[7:0], DQS)	C _{IO}	3.7	4.7	5.7	5.7	7.2	8.7	pF	3
Input capacitance (CE#, WP#)	C _{OTHER}	-	_	5	-	-	10	pF	
Delta clock capacitance	DC _{CK}	-	-	0.5	_	_	1.0	pF	
Delta input capacitance	DC _{IN}	-	-	1.4	_	_	1.7	pF	
Delta input/output capacitance	DC _{IO}	_	_	1.4	_	_	1.7	pF	

Notes:

- 1. Verified in device characterization; not 100% tested.
- 2. Test conditions: $T_A = 25$ °C, f = 100 MHz, $V_{IN} = 0$ V.
- 3. Values for C_{CK}, C_{IN}, and C_{IO} (TYP) are estimates.

Table 39: Capacitance: 48-Pin TSOP Package

Description	Symbol	Device	Мах	Unit	Notes
Input capacitance – ALE, CE#, CLE, RE# /	C _{IN}	Single die package	7	pF	1
W/R#, CLK / WE#, WP#		Dual die package	11		
		Quad die package	16		
Input/output capacitance – DQ[7:0], DQS	C _{IO}	Single die package	6	pF	1
		Dual die package	10		
		Quad die package	16		

Note: 1. These parameters are verified in device characterization and are not 100% tested. Test conditions: T_C = 25°C; f = 1 MHz; Vin = 0V.

Table 40: Test Conditions

Parameter	Value	Notes
Rising input transition	V _{IL(DC)} to V _{IH(AC)}	1
Falling input transition	$V_{IH(DC)}$ to $V_{IL(AC)}$	1
Input rise and fall slew rates	1 V/ns	_
Input and output timing levels	V _{CCQ} /2	_
Output load: Nominal output drive strength	C _L = 5pF	2, 3

Notes: 1. The receiver will effectively switch as a result of the signal crossing the AC input level; it will remain in that status as long as the signal does not ring back above (below) the DC input LOW (HIGH) level.



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Electrical Specifications – DC Characteristics and Operating Conditions (Asynchronous)

- 2. Transmission line delay is assumed to be very small.
- 3. This test setup applies to all package configurations.

Electrical Specifications – DC Characteristics and Operating Conditions (Asynchronous)

Table 41: DC Characteristics and Operating Conditions (Asynchronous Interface)

Parameter	Conditions	Symbol	Min ¹	Typ ¹	Max ¹	Unit
Array read current (active)	-	I _{CC1_A}	-	25	50	mA
Array program current (active)	-	I _{CC2_A}	-	29	50	mA
Erase current (active)	_	I _{CC3_A}	_	25	50	mA
I/O burst read current	${}^{t}RC = {}^{t}RC \text{ (MIN); } I_{OUT} = 0mA$	I _{CC4R_A}	_	8	12	mA
		I _{CCQ4R_A}	_	6	10	mA
I/O burst write current	tWC = tWC (MIN)	I _{CC4W_A}	_	10	14	mA
		I _{CCQ4W_A}	_	1	3	mA
Bus idle current	-	I _{CC5_A}	_	3	5	mA
Current during first RESET command after power-on	-	I _{CC6}	-	_	10	mA
Standby current - V _{CC}	$CE# = V_{CCQ} - 0.2V;$ $WP# = 0V/V_{CCQ}$	I _{SB}	_	10	50	μΑ
Standby current - V _{CCQ}	$CE# = V_{CCQ} - 0.2V;$ $WP# = 0V/V_{CCQ}$	I _{SBQ}	-	3	10	μΑ
Staggered power-up current	^t RISE = 1ms; C _{LINE} = 0.1uF	I _{ST}	_	_	10	mA

Note: 1. All values are per die (LUN) unless otherwise specified.

Electrical Specifications – DC Characteristics and Operating Conditions (Synchronous)

Table 42: DC Characteristics and Operating Conditions (Synchronous Interface) for 3.3V V_{CCO}

Parameter	Conditions	Symbol	Min ¹	Typ ¹	Max ¹	Unit
Array read current (active)	$CE# = V_{IL}$; ${}^{t}CK = {}^{t}CK$ (MIN)	I _{CC1_S}	_	25	50	mA
Array program current (active)	$^{t}CK = {}^{t}CK \text{ (MIN)}$	I _{CC2_S}	_	29	50	mA
Erase current (active)	${}^{t}CK = {}^{t}CK $ (MIN)	I _{CC3_S}	_	25	50	mA
I/O burst read current	${}^{t}CK = {}^{t}CK \text{ (MIN); I}_{OUT} = 0\text{mA}$	I _{CC4R_S}	_	20 ²	25 ²	mA
		I _{CCQ4R_S}	_	28 ²	35 ²	mA
I/O burst write current	^t CK = ^t CK (MIN)	I _{CC4W_S}	_	18 ²	25 ²	mA
		I _{CCQ4W_S}	_	1	3	mA
Bus idle current	${}^{t}CK = {}^{t}CK \text{ (MIN)}$	I _{CC5_S}	_	5	10	mA



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Electrical Specifications – DC Characteristics and Operating Conditions (V_{CCO})

Table 42: DC Characteristics and Operating Conditions (Synchronous Interface) for 3.3V V_{CCQ} (Continued)

Parameter	Conditions	Symbol	Min ¹	Typ ¹	Max ¹	Unit
Standby current - V _{CC}	$CE# = V_{CCQ} - 0.2V;$ $WP# = 0V/V_{CCQ}$	I _{SB}	_	10	50	μΑ
Standby Current - V _{CCQ}	$CE# = V_{CCQ} - 0.2V;$ $WP# = 0V/V_{CCQ}$	I _{SBQ}	_	3	10	μΑ

Notes: 1. All values are per die (LUN) unless otherwise specified.

2. For 3.3V V_{CCO} up to 166MT/s

Table 43: DC Characteristics and Operating Conditions (Synchronous Interface) for 1.8V V_{CCO}

Parameter	Conditions	Symbol	Min ¹	Typ ¹	Max ¹	Unit
Array read current (active)	$CE# = V_{IL}$; ${}^{t}CK = {}^{t}CK$ (MIN)	I _{CC1_S}	-	25	50	mA
Array program current (active)	^t CK = ^t CK (MIN)	I _{CC2_S}	_	29	50	mA
Erase current (active)	^t CK = ^t CK (MIN)	I _{CC3_S}	-	25	50	mA
I/O burst read current	^t CK = ^t CK (MIN); I _{OUT} = 0mA	I _{CC4R_S}	-	24 ²	30 ²	mA
		I _{CCQ4R_S}	-	16 ²	20 ²	mA
I/O burst write current	^t CK = ^t CK (MIN)	I _{CC4W_S}	-	22 ²	28 ²	mA
		I _{CCQ4W_S}	-	1	3	mA
Bus idle current	^t CK = ^t CK (MIN)	I _{CC5_S}	-	5	10	mA
Standby current - V _{CC}	$CE# = V_{CCQ} - 0.2V;$ $WP# = 0V/V_{CCQ}$	I _{SB}	_	10	50	μА
Standby Current - V _{CCQ}	$CE# = V_{CCQ} - 0.2V;$ $WP# = 0V/V_{CCQ}$	I _{SBQ}	_	3	10	μА

Notes: 1. All values are per die (LUN) unless otherwise specified.

2. For 1.8V V_{CCO} up to 200MT/s

Electrical Specifications – DC Characteristics and Operating Conditions (V_{CCQ})

Table 44: DC Characteristics and Operating Conditions (3.3V V_{CCO})

Parameter	Condition	Symbol	Min	Тур	Max	Unit	Notes
AC input high voltage	CE#, DQ[7:0], DQS, ALE, CLE, CLK	V _{IH(AC)}	$0.8 \times V_{CCQ}$	_	V _{CCQ} + 0.3	V	
AC input low voltage	(WE#), W/R# (RE#), WP#	V _{IL(AC)}	-0.3	_	$0.2 \times V_{CCQ}$	V	
DC input high voltage	DQ[7:0], DQS, ALE, CLE, CLK	V _{IH(DC)}	$0.7 \times V_{CCQ}$	_	V _{CCQ} + 0.3	V	
DC input low voltage	(WE#), W/R# (RE#)	$V_{IL(DC)}$	-0.3	_	0.3 × V _{CCQ}	V	
Input leakage current	Any input $V_{IN} = 0V$ to V_{CCQ} (all other pins under test = $0V$)	I _{LI}	-	_	±10	μΑ	1
Output leakage cur- rent	DQ are disabled; $V_{OUT} = 0V$ to V_{CCQ}	I _{LO}	_	-	±10	μΑ	1



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Electrical Specifications – DC Characteristics and Operating Conditions (V_{CCQ})

Table 44: DC Characteristics and Operating Conditions (3.3V V_{CCQ}) (Continued)

Parameter	Condition	Symbol	Min	Тур	Max	Unit	Notes
Output low current (R/B#)	V _{OL} = 0.4V	I _{OL} (R/B#)	8	10	-	mA	2

Notes:

- 1. All leakage currents are per die (LUN). Two die (LUNs) have a maximum leakage current of $\pm 20\mu A$ and four die (LUNs) have a maximum leakage current of $\pm 40\mu A$.
- 2. DC characteristics may need to be relaxed if R/B# pull-down strength is not set to full strength. See Table 14 (page 77) for additional details.



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Electrical Specifications – DC Characteristics and Operating Conditions (V_{CCO})

Table 45: DC Characteristics and Operating Conditions (1.8V V_{CCQ})

Parameter	Condition	Symbol	Min	Тур	Max	Unit	Notes
AC input high voltage	CE#, DQ[7:0], DQS, ALE, CLE, CLK	V _{IH(AC)}	$0.8 \times V_{CCQ}$	-	V _{CCQ} + 0.3	V	
AC input low voltage	(WE#), W/R# (R/E#), WP#	V _{IL(AC)}	-0.3	-	$0.2 \times V_{CCQ}$	V	
DC input high voltage	DQ[7:0], DQS, ALE, CLE, CLK	V _{IH(DC)}	$0.7 \times V_{CCQ}$	_	V _{CCQ} + 0.3	V	
DC input low voltage	(WE#), W/R# (R/E#)	V _{IL(DC)}	-0.3	-	$0.3 \times V_{CCQ}$	V	
Input leakage current	Any input $V_{IN} = 0V$ to V_{CCQ} (all other pins under test = 0V)	I _{LI}	_	-	±10	μΑ	1
Output leakage current	DQ are disabled; Vout = 0V to V_{CCQ}	I _{LO}	_	_	±10	μΑ	1
Output low current (R/B#)	V _{OL} = 0.2V	I _{OL} (R/B#)	3	4	_	mA	2

Notes:

- 1. All leakage currents are per die (LUN). Two die (LUNs) have a maximum leakage current of ±20μA and four die (LUNs) have a maximum leakage current of ±40μA.
- 2. DC characteristics may need to be relaxed if R/B# pull-down strength is not set to full strength. See Table 14 (page 77) for additional details.



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Electrical Specifications – AC Characteristics and Operating Conditions (Asynchronous)

Electrical Specifications – AC Characteristics and Operating Conditions (Asynchronous)

Table 46: AC Characteristics: Asynchronous Command, Address, and Data

		Мо	de 0	Мо	de 1	Мо	de 2	Мо	de 3	Мо	de 4	Мо	de 5						
Parameter	Symbol	Min	Max	Min	Мах	Min	Max	Min	Max	Min	Мах	Min	Мах	Unit	Notes				
Clock period		10	00	5	0	3	5	3	0	2	5	2	20	ns					
Frequency		≈	10	≈2	20	≈:	28	≈:	≈33		≈40		≈40		≈40		50	MHz	
ALE to data start	^t ADL	200	_	100	_	100	_	100	_	70	_	70	_	ns	1				
ALE hold time	^t ALH	20	-	10	_	10	_	5	_	5	_	5	-	ns					
ALE setup time	^t ALS	50	-	25	_	15	_	10	_	10	_	10	-	ns					
ALE to RE# delay	^t AR	25	-	10	_	10	_	10	_	10	_	10	-	ns					
CE# access time	^t CEA	_	100	_	45	_	30	_	25	_	25	_	25	ns					
CE# hold time	^t CH	20	_	10	_	10	_	5	_	5	_	5	-	ns					
CE# HIGH to output High-Z	^t CHZ	-	100	-	50	-	50	_	50	-	30	-	30	ns	2				
CLE hold time	^t CLH	20	-	10	_	10	_	5	_	5	_	5	_	ns					
CLE to RE# delay	^t CLR	20	_	10	_	10	_	10	_	10	_	10	_	ns					
CLE setup time	^t CLS	50	-	25	_	15	_	10	_	10	_	10	_	ns					
CE# HIGH to output hold	^t COH	0	_	15	_	15	_	15	_	15	_	15	_	ns					
CE# setup time	tCS	70	-	35	_	25	_	25	_	20	_	15	_	ns					
Data hold time	^t DH	20	-	10	_	5	_	5	-	5	-	5	-	ns					
Data setup time	^t DS	40	_	20	_	15	_	10	_	10	_	7	_	ns					
Output High-Z to RE# LOW	^t IR	10	_	0	_	0	_	0	_	0	_	0	_	ns					
RE# cycle time	^t RC	100	-	50	_	35	_	30	-	25	-	20	-	ns					
RE# access time	^t REA	_	40	-	30	_	25	_	20	_	20	_	16	ns	3				
RE# HIGH hold time	^t REH	30	_	15	_	15	_	10	_	10	_	7	_	ns	3				
RE# HIGH to output hold	^t RHOH	0	_	15	_	15	_	15	_	15	_	15	_	ns	3				
RE# HIGH to WE# LOW	^t RHW	200	_	100	_	100	_	100	_	100	-	100	_	ns					
RE# HIGH to output High-Z	^t RHZ	-	200	-	100	-	100	_	100	-	100	-	100	ns	2, 3				
RE# LOW to output hold	tRLOH	0	-	0	-	0	-	0	-	5	-	5	_	ns	3				
RE# pulse width	^t RP	50	_	25	_	17	_	15	_	12	_	10	_	ns					
Ready to RE# LOW	^t RR	40	_	20	_	20	_	20	_	20	_	20	_	ns					
WE# HIGH to R/B# LOW	tWB	-	200	-	100	-	100	-	100	-	100	-	100	ns	4				
WE# cycle time	tWC	100	_	45	_	35	_	30	_	25	_	20	_	ns					



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Electrical Specifications – AC Characteristics and Operating Conditions (Asynchronous)

Table 46: AC Characteristics: Asynchronous Command, Address, and Data (Continued)

		Мо	Mode 0		Mode 0 Mode 1		Mode 2		Mode 3		Mode 4		Mode 5			
Parameter	Symbol	Min	Max	Min	Max	Min	Max	Min	Max	Min	Max	Min	Max	Unit	Notes	
WE# HIGH hold time	tWH	30	_	15	_	15	_	10	_	10	_	7	_	ns		
WE# HIGH to RE# LOW	tWHR	120	-	80	_	80	-	60	-	60	-	60	_	ns		
WE# pulse width	tWP	50	_	25	_	17	_	15	_	12	_	10	_	ns		
WP# transition to WE# LOW	tWW	100	_	100	_	100	_	100	_	100	_	100	-	ns		

Notes:

- 1. Timing for ^tADL begins in the address cycle, on the final rising edge of WE# and ends with the first rising edge of WE# for data input.
- 2. Data transition is measured ±200mV from steady-steady voltage with load. This parameter is sampled and not 100 percent tested.
- 3. AC characteristics may need to be relaxed if output drive strength is not set to at least nominal.
- 4. Do not issue a new command during ^tWB, even if R/B# or RDY is ready.



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Electrical Specifications – AC Characteristics and Operating Conditions (Synchronous)

Electrical Specifications – AC Characteristics and Operating Conditions (Synchronous)

Table 47: AC Characteristics: Synchronous Command, Address, and Data

		Мо	de 0	Мо	de 1	Мо	de 2	Мо	de 3	Мо	de 4	Мо	de 5		
Parameter	Symbol	Min	Max	Min	Max	Min	Max	Min	Max	Min	Max	Min	Max	Unit	Notes
Clock period		5	0	3	80	2	:0	1	5	1	2	1	0	ns	
Frequency		≈;	20	≈.	33	≈	50	≈67		≈83		≈100		MHz	
Access window of DQ[7:0] from CLK	^t AC	3	20	3	20	3	20	3	20	3	20	3	20	ns	
ALE to data loading time	^t ADL	100	_	100	_	70	_	70	_	70	_	70	_	ns	
Command, address data delay	^t CAD	25	_	25	_	25	_	25	_	25	_	25	_	ns	1
ALE, CLE, W/R# hold	^t CALH	10	-	5	_	4	-	3	-	2.5	-	2	-	ns	
ALE, CLE, W/R# setup	^t CALS	10	-	5	_	4	_	3	_	2.5	_	2	_	ns	
DQ hold – com- mand, address	^t CAH	10	_	5	_	4	_	3	_	2.5	_	2	_	ns	
DQ setup – command, ad- dress	^t CAS	10	_	5	_	4	-	3	-	2.5	-	2	_	ns	
CE# hold	^t CH	10	_	5	_	4	_	3	_	2.5	_	2	_	ns	
Average CLK cy- cle time	^t CK (avg)	50	100	30	50	20	30	15	20	12	15	10	12	ns	3
Absolute CLK cycle time, from rising edge to rising edge	^t CK (abs)								tJIT (pe					ns	
CLK cycle HIGH	^t CKH (abs)	0.43	0.57	0.43	0.57	0.43	0.57	0.43	0.57	0.43	0.57	0.43	0.57	^t CK	4
CLK cycle LOW	^t CKL (abs)	0.43	0.57	0.43	0.57	0.43	0.57	0.43	0.57	0.43	0.57	0.43	0.57	^t CK	4
Data output end to W/R# HIGH	^t CKWR	$^{t}CKWR(MIN) = RoundUp[(^{t}DQSCK(MAX) + {^{t}CK})/{^{t}CK}]$								^t CK					
CE# setup	tCS	35	_	25	_	15	_	15	_	15	_	15	_	ns	
Data In hold	^t DH	5	-	2.5	_	1.7	-	1.3	_	1.1	-	0.8	_	ns	
Access window of DQS from CLK	^t DQSCK	_	20	_	20	_	20	_	20	_	20	_	20	ns	



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Electrical Specifications – AC Characteristics and Operating Conditions (Synchronous)

Table 47: AC Characteristics: Synchronous Command, Address, and Data (Continued)

	Mode 0 Mode 1		de 1	Mode 2		Mode 3		Mode 4		Mode 5					
Parameter	Symbol	Min	Max	Min	Max	Min	Max	Min	Мах	Min	Max	Min	Max	Unit	Notes
DQS, DQ[7:0] Driven by NAND	^t DQSD	-	18	-	18	-	18	-	18	-	18	-	18	ns	
DQS, DQ[7:0] to tri-state	^t DQSHZ	_	20	_	20	_	20	_	20	_	20	_	20	ns	5
DQS input high pulse width	^t DQSH	0.4	0.6	0.4	0.6	0.4	0.6	0.4	0.6	0.4	0.6	0.4	0.6	^t CK	
DQS input low pulse width	^t DQSL	0.4	0.6	0.4	0.6	0.4	0.6	0.4	0.6	0.4	0.6	0.4	0.6	^t CK	
DQS-DQ skew	^t DQSQ	_	5	_	2.5	_	1.7	-	1.3	_	1.0	_	0.85	ns	
Data input	^t DQSS	0.75	1.25	0.75	1.25	0.75	1.25	0.75	1.25	0.75	1.25	0.75	1.25	^t CK	
Data In setup	^t DS	5	_	3	_	2	_	1.5	_	1.1	_	0.8	_	ns	
DQS falling edge from CLK rising – hold	^t DSH	0.2	_	0.2	_	0.2	_	0.2	_	0.2	_	0.2	_	^t CK	
DQS falling to CLK rising – set- up	^t DSS	0.2	_	0.2	_	0.2	_	0.2	_	0.2	_	0.2	_	^t CK	
Data valid win- dow	^t DVW		$^{t}DVW = {}^{t}QH - {}^{t}DQSQ$									ns			
Half clock peri- od	tHP					^t HP	= Min(tCKH, t	CKL)					ns	
The deviation of a given ^t CK (abs) from a ^t CK (avg)	^t JIT (per)	-0.7	0.7	-0.7	0.7	-0.7	0.7	-0.6	0.6	-0.6	0.6	-0.5	0.5	ns	
DQ-DQS hold, DQS to first DQ to go nonvalid, per access	^t QH		^t QH = ^t HP - ^t QHS								ns				
Data hold skew factor	tQHS	_	6	-	3	_	2	_	1.5	_	1.2	_	1	ns	
Data output to command, address, or data input	^t RHW	100	_	100	_	100	_	100	_	100	_	100		ns	
Ready to data output	^t RR	20	-	20	_	20	_	20	_	20	_	20	_	ns	
CLK HIGH to R/B# LOW	tWB	-	100	-	100	-	100	-	100	-	100	-	100	ns	
Command cycle to data output	tWHR	80	-	80	_	80	_	80	_	80	_	80	_	ns	



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Electrical Specifications – AC Characteristics and Operating Conditions (Synchronous)

Table 47: AC Characteristics: Synchronous Command, Address, and Data (Continued)

		Mode 0		Mode 1		Mode 2		Mode 3		Mode 4		Mode 5			
Parameter	Symbol	Min	Max	Unit	Notes										
DQS write pre- amble	tWPRE	1.5	_	1.5	-	1.5	_	1.5	-	1.5	_	1.5	-	^t CK	
DQS write post- amble	tWPST	1.5	_	1.5	_	1.5	_	1.5	_	1.5	_	1.5	_	^t CK	
W/R# LOW to data output cy- cle	^t WRCK	20	_	20	_	20	-	20	_	20	-	20	_	ns	
WP# transition to command cy- cle	tWW	100	_	100	_	100	ı	100	-	100	ı	100	ı	ns	

Notes:

- 1. Delay is from start of command to next command, address, or data cycle; start of address to next command, address, or data cycle; and end of data to start of next command, address, or data cycle.
- 2. This value is specified in the parameter page.
- 3. ^tCK(avg) is the average clock period over any consecutive 200-cycle window.
- 4. ^tCKH(abs) and ^tCKL(abs) include static offset and duty cycle jitter.
- 5. ^tDQSHZ begins when W/R# is latched HIGH by CLK. This parameter is not referenced to a specific voltage level; it specifies when the device outputs are no longer driving.



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND **Electrical Specifications – Array Characteristics**

Electrical Specifications – Array Characteristics

Table 48: Array Characteristics

Parameter	Symbol	Тур	Max	Unit	Notes
Number of partial page programs	NOP	_	1	Cycles	1
ERASE BLOCK operation time	^t BERS	3	12	ms	
Cache busy	tCBSY	900	2500	μs	3
Change column setup time to data in/out or next command	tCCS	_	200	ns	
Dummy busy time	tDBSY	0.5	1	μs	
Cache read busy time	tRCBSY	26	100	μs	5
Busy time for SET FEATURES and GET FEATURES operations	tFEAT	_	1	μs	
Busy time for interface change	^t ITC	_	1	μs	2
LAST PAGE PROGRAM operation time	tLPROG	_	_	μs	3
Busy time for OTP DATA PROGRAM operation if OTP is protected	tOBSY	_	50	μs	
Power-on reset time	^t POR	_	1	ms	
PROGRAM PAGE operation time	tPROG	1300	2500	μs	
READ PAGE operation time	^t R	_	100	μs	5
Device reset time (Read/Program/Erase)	^t RST	_	5/10/500	μs	4

- Notes: 1. The pages in the OTP Block have an NOP of 2.
 - 2. tITC (MAX) is the busy time when the interface changes from asynchronous to synchronous using the SET FEATURES (EFh) command or synchronous to asynchronous using the RESET (FFh) command. During the ^tITC time, any command, including READ STATUS (70h) and READ STATUS ENHANCED (78h), is prohibited.
 - 3. tCBSY and tLPROG = tPROG (last page) + tPROG (last page 1) command load time (last page) - address load time (last page) - data load time (last page).
 - 4. If RESET command is issued when the target is READY, the target goes busy for a maximum of 5µs.
 - 5. For Read Retry options 4 to 7, ^tRCBSY and ^tR Max may be up to 285µs.



Asynchronous Interface Timing Diagrams

Figure 75: RESET Operation





Figure 76: RESET LUN Operation



141



Figure 77: READ STATUS Cycle




Figure 78: READ STATUS ENHANCED Cycle






Figure 79: READ PARAMETER PAGE




Figure 80: READ PAGE






Figure 81: READ PAGE Operation with CE# "Don't Care"






Figure 82: CHANGE READ COLUMN






Figure 83: READ PAGE CACHE SEQUENTIAL






Figure 84: READ PAGE CACHE RANDOM






Figure 85: READ ID Operation




Figure 86: PROGRAM PAGE Operation






Figure 87: PROGRAM PAGE Operation with CE# "Don't Care"




Figure 88: PROGRAM PAGE Operation with CHANGE WRITE COLUMN






Figure 89: PROGRAM PAGE CACHE




Figure 90: PROGRAM PAGE CACHE Ending on 15h






Figure 91: COPYBACK






Figure 92: ERASE BLOCK Operation





Synchronous Interface Timing Diagrams

Figure 93: SET FEATURES Operation



Notes:

- 1. When CE# remains LOW, ^tCAD begins at the rising edge of the clock from which the last data byte is input for the subsequent command or data input cycle(s).
- 2. ^tDSH (MIN) generally occurs during ^tDQSS (MIN).
- 3. ^tDSS (MIN) generally occurs during ^tDQSS (MAX).
- The cycle that ^tCAD is measured from may be an idle cycle (as shown), another command cycle, an address cycle, or a data cycle. The idle cycle is shown in this diagram for simplicity.



Figure 94: READ ID Operation






Figure 95: GET FEATURES Operation






Figure 96: RESET (FCh) Operation






Figure 97: READ STATUS Cycle






Figure 98: READ STATUS ENHANCED Operation






Figure 99: READ PARAMETER PAGE Operation






Figure 100: READ PAGE Operation






Figure 101: CHANGE READ COLUMN






Figure 102: READ PAGE CACHE SEQUENTIAL (1 of 2)






Figure 103: READ PAGE CACHE SEQUENTIAL (2 of 2)






Figure 104: READ PAGE CACHE RANDOM (1 of 2)




Figure 105: READ PAGE CACHE RANDOM (2 of 2)






Figure 106: Multi-Plane Read Page (1 of 2)






Figure 107: Multi-Plane Read Page (2 of 2)






Figure 108: PROGRAM PAGE Operation (1 of 2)




Figure 109: PROGRAM PAGE Operation (2 of 2)






Figure 110: CHANGE WRITE COLUMN






Figure 111: Multi-Plane Program Page






Figure 112: ERASE BLOCK




Figure 113: COPYBACK (1 of 3)






Figure 114: COPYBACK (2 of 3)




Figure 115: COPYBACK (3 of 3)






Figure 116: READ OTP PAGE






Figure 117: PROGRAM OTP PAGE (1 of 2)




Figure 118: PROGRAM OTP PAGE (2 of 2)







Figure 119: PROTECT OTP AREA





64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Revision History

Revision History

Rev. H Production - 12/13

- Updated Features section with note on clarification of Read Retry operation and addition of Read Retry under Advance Command Set
- Changes to ONFI/JEDEC Read Parameter Pages for:
 - Updated bytes 103 and 7458 in ONFI and 213 in JEDEC Read Parameter Pages for number of maximum bad blocks per LUN to 85 blocks
 - Updated bytes 253 in ONFI and 420 in JEDEC Read Parameter Pages for revision
 - Updated all CRC bytes in ONFI and JEDEC Read Parameter Pages
- · Updated Error Management section NVB value to 4011 blocks
- Updates to Electrical Specifications:
 - Updated NVB value to 4011 blocks
 - Updated I_{CC2} A, I_{CC2} S TYP to 29mA
 - Updated I_{CC4R A} TYP to 8mA and Max 12mA
 - Updated I_{CC4W A} Max to 14mA
 - Updated I_{CC4R S} TYP to 20mA and Max to 25mA for 3.3V V_{CCO} up to 166MT/s
 - Updated $I_{CC4R\ S}$ TYP to 24mA and Max to 30mA for 1.8V V_{CCO} up to 200MT/s
 - Updated $I_{CC4W\ S}$ TYP to 18mA for 3.3V V_{CCO} up to 166MT/s
 - Updated $I_{CC4W\ S}$ TYP to 22mA and Max to 28mA for 1.8V V_{CCO} up to 200MT/s
 - Added new parameters I_{CCQ4R_A}, I_{CCQ4W_A}, I_{CCQ4R_S}, and I_{CCQ4W_S}
- Added ^tCBSY to note 3 of table Array Characteristics

Rev. G - 1/13

- · Removed 512Gb BGA device and related content
- Added Features section comment on JEDEC NAND Flash Interface Interoperability (JESD230) compliance
- Updated Capacitance: 100-Ball BGA Package table values
- Updated Read Parameter Page values for BGA package capacitance, JEDEC additional byte definitions, and Vendor Specific block information
- Changed ^tCBSY TYP to 900µs
- Changes to Electrical Characteristics:
 - Changed I_{CC4R A} TYP to 7mA
 - Changed I_{CC4W A} TYP to 10mA and Max to 12mA
 - Changed I_{CC4W S} TYP to 15mA and Max to 25mA

Rev. F - 6/12

- Updated 100-ball BGA package drawings package codes H1, H2, and H3
- Added statement in Device Initialization section that during the first RESET (FFh) ^tPOR time an additional RESET (FFh) command shall not be issued by the host
- Added MT29F128G08CJABA part number to Read ID Parameters for Address 00h table
- Updated Capacitance: 48-Pin TSOP Package values
- Updated Read Parameter Page values for TSOP package capacitance and ^tR



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Revision History

- Changes to Array Characteristics:
 - Changed tOBSY Max to 50μs
 - Changed ^tR and ^tRCBSY Max to 100µs
 - Changed ^tRCBSY Typ to 26µs

Rev. E - 11/11

- Corrected BGA part numbers in heading of title page
- Added 4 new options (Options 4 to 7) to Feature Address 89h: Read Retry
- Added statement on bit-wise majority recovery of parameter pages under Read Parameter Page (ECh)
- Changes to ONFI/JEDEC Read Parameter Pages for:
 - Bytes 135-136 in ONFI and 155-156 in JEDEC Read Parameter Pages for ^tBERS Max to 12ms
 - Added byte definition to byte 180 of the ONFI Read Parameter Page and byte 422 of the JEDEC Read Parameter Page for number of Read Retry settings supported
- Changes to Array Characteristics:
 - Changed note for NOP for OTP operations to 2
 - Changed ^tBERS Max to 12ms
 - Added note for ^tR Max for options 4 to 7 of Read Retry

Rev. D - 9/11

- Updated Read Parameter Page tables to show additional redundant copies of parameter pages beyond the first three and added in JEDEC Read Parameter Page information
- Updated Share Pages section in regards to paired page combinations

Rev. C - 4/11

- · Added Read Retry functionality
- Added description to Share Pages section that the least significant numbered shared page must be programmed before the most significant numbered page of that pair can be programmed
- Added Asynchronous Overshoot/Undershoot Parameters table

Rev. B - 2/11

- Noted Synchronous TSOP support to Synchronous timing mode 4
- Added JEDEC NAND commands
- Updated Read ID Parameters for Address 00h table
- Updated Output Drive Strength Impedance Values (V_{CCO} = 2.7-3.6V) table

Rev. A - 8/10

· Initial release



64Gb, 128Gb, 256Gb Asynchronous/Synchronous NAND Revision History

8000 S. Federal Way, P.O. Box 6, Boise, ID 83707-0006, Tel: 208-368-3900 www.micron.com/productsupport Customer Comment Line: 800-932-4992 Micron and the Micron logo are trademarks of Micron Technology, Inc. All other trademarks are the property of their respective owners.

This data sheet contains minimum and maximum limits specified over the power supply and temperature range set forth herein. Although considered final, these specifications are subject to change, as further product development and data characterization sometimes occur.