



# **CHDR(G) Porch Board Emulator Product Manual**

Revision 3.2

This is the back cover. Reverse grip on manual  
to continue.



Copyright ©1962 Connortone Industries Inc.

## **PRODUCT MANUAL**

Congratulations on your acquisition of a fine **CONNORTONE** product, now with innovative HYPERCUSSION technology, new for 1962! Your **CONNORTONE** instrument is a precision tool which should give you many years of service, precisely emulating a rotten and loose front porch floorboard. We at **CONNORTONE** pride ourselves on our commitment to the concept that musical instrument development came to a permanent end last year, and promise to continue manufacturing products that harness the awesome power of American industry in 1934.

Your new **CONNORTONE** CHDR(G) CHOWDINATOR porch board emulator includes a number of features that will contribute to your prowess as an indicator of stage levelness. The amplifier pickup cavity is lined with copper foil to eliminate electronic interference, rather than aluminum, as we have found that aluminum foil is not sufficient shielding against amplifiers, electric instruments, messages from the Devil, or the influence of Allen Dulles.


Your CHOWDINATOR is equipped with both TONE and VOLUME control knobs on the rear of the instrument. They may or may not do anything useful.

### **HINTS ON PLAYING YOUR CHOWDINATOR**

Like every other musical instrument, your CHOWDINATOR requires a small amount of study if the best results are to be obtained. Therefore, a little application will greatly increase the pleasure to be derived from this charming instrument.

Place either foot on the 12" x 6" embossed percussion surface and begin thumping. The CHDR(G) is fully ambidextrous.

The tone of the instrument improves with use.



### **PARTS OF THE CHORDINATOR**

- 1 Embossed percussion surface**
- 2 Premium badging**
- 3 1/4" monophonic output jack**
- 4 TONE control**
- 5 VOL control**
- 6 Premium TONE badging**
- 7 Premium VOL badging**

The embossed percussion surface can be easily replaced in the event of wear or finding a better one at a flea market or on eBay by detaching the four (4) brass screws and substituting the new plate. Do not omit the four (4) brass washers during reinstallation.



# CONNORTONE

## historical highlights

