Table of Contents

xample OFDM
arameters
ommunication system
Iodulator
hannel
emodulator
lotting

Example OFDM

Full communication system with CP-OFDM, with an AWGN channel.

```
clc; clear; close all;
```

Parameters

Communication system

Symbols to transmit. Each row corresponds to an OFDM symbol of Nsc length.

```
d = randi([0, M-1], symbol_qtty/Nsc, Nsc);
error_qtty = zeros(size(EsNo_dB));
```

Modulator

```
for i=1:1:height(d)
    % For each OFDM symbol...
    [u, constellation] = Modulator.modulate(d(i,:), mod_type, M);
    U = ifft(u, Nsc);
    s = [U(end - Ncp + 1 : end) U]; % Add cyclic prefix
```

Channel

Demodulator


```
U_r = r(Ncp+1 : Nsc + Ncp); % Remove cyclic prefix
```

```
u_r = fft(U_r, Nsc);
d_r = Demodulator.demodulate(u_r, mod_type, M, constellation);
error_qtty(j) = error_qtty(j) + sum(d(i,:)~=d_r);
end
end
ser = error_qtty / symbol_qtty;
ser_theory = Theory.ser_AWGN(mod_type, M, EsNo_dB);
```

Plotting

```
semilogy(EsNo_dB, ser, LineStyle="-"); hold on;
semilogy(EsNo_dB, ser_theory, LineStyle="--"); hold on;

grid on;
legend( strcat(num2str(M), "-", mod_type, " Simulated"), ...
    strcat(num2str(M), "-", mod_type, " Theoretical") );
xlabel("Es/NO [dB]");
ylabel("SER");
title("Symbol Error Rate");
ylim([le-6, 1]);
```



Published with MATLAB® R2022b