AE333

Mechanics of Materials

Lecture 19 - Transverse Shear
Dr. Nicholas Smith
Wichita State University, Department of Aerospace Engineering
22 Mar, 2019

schedule

- 22 Mar Transverse Shear
- 25 Mar Combined Loading, HW6 Due
- 27 Mar Combined Loading
- 29 Mar Combined Loading

outline


- shear flow in built-up members
- thin-walled pressure vessels

shear flow in built-up members

built-up members

- Often in practice, structural members are "built-up"
- This refers to parts that are comprised of several other parts to have greater strength in certain areas
- We need to analyze the shear between these members to choose appropriate adhesives or fasteners

equilibrium



equilibrium

• From equilibrium we see that

$$dF=rac{ar{dM}}{I}\int_{A'}ydA'$$

• We recall that this integral represents Q, we can also define the shear flow as q=dF/dx and recall that dM/dx=V to find


$$q=rac{VQ}{I}$$

fastener spacing

- We can use shear flow to determine fastener spacing
- Say a fastener can support a shear force of F_0 before failure
- The shear flow (force/distance) times the spacing (distance) will give the shear force per fastener F=qs

3/20/2019 Lecture 19 - transverse shear


multiple fasteners



multiple fasteners


- When multiple arms are connecting the same area (as shown in the previous slide)
- The shear flow "seen" by each fastener is q/n where n is the number of fastners per area

example 7.4



Determine the shear flow at B and B' that must be resisted by glue to bond the boards together.


example 7.5



If each nail can support a maximum shear force of 30 lb, determine the maximum spacing of the nails at B and at C so that the beam can support the force of 80 lb.

3/20/2019 Lecture 19 - transverse shear

example 7.6




Nails with a shear strength of 40 lb are used in a beam that can be constructed as shown in Case I or Case II. If the nails are spaced at 9 in determine the largest vertical shear that can be supported.

thin-walled pressure vessels

thin-walled pressure vessels

- If the radius to wall thickness ratio is 10 or more, we can treet a pressure vessule as "thin-walled"
- Cylindrical pressure vessels will have two primary sources of stress, and serve as an introduction to more general states of combined loading

cylindrical vessels




cylindrical vessels

• From equilibrium of a section of a cylindrical vessel, we see that

$$egin{aligned} \sum F_x &= 0 \ &= 2(\sigma_1 t dy) - p(2r) dy \ \sigma_1 &= rac{pr}{t} \end{aligned}$$

3/20/2019 Lecture 19 - transverse shear

cylindrical vessels



cylindrical vessels

• Considering another section we can find the longitudinal stress

$$egin{aligned} \sum F_y &= 0 \ &= \sigma_2(2\pi r t) - p(\pi r^2) \ \sigma_2 &= rac{p r}{2t} \end{aligned}$$

spherical vessels

- We can find the stress in spherical vessels using an identical section to the longitudinal section for a cylindrical vessel, and we find that $\sigma=\frac{pr}{2t}$
- Which is valid everywhere in a cylindrical vessel

example 8.1

- A cylindrical pressure vessel has an inner diameter of 4 ft. and a thickness of 1/2 in.
- Determine the maximum internal pressure it can sustain if the maximum stress it can support is 20 ksi.
- What is the maximum internal pressure a spherical pressure vessel could sustain under identical conditions?