### AE 737: Mechanics of Damage Tolerance

Lecture 8 - Fracture Toughness

Dr. Nicholas Smith

Wichita State University, Department of Aerospace Engineering

February 24, 2021

1

#### schedule

- 24 Feb Fracture Toughness, HW3 Due, HW 2 Self-grade due
- 1 Mar Residual Strength
- 3 Mar Residual Strength, HW4 Due, HW 3 Self-grade due
- 8 Mar Multiple Site Damage

### outline

- fracture toughness
- R-curve
- thickness effects
- fracture toughness review
- residual strength

# fracture toughness

2

### fracture toughness

- The critical load at which a cracked specimen fails produces a critical stress intensity factor
- The "critical stress intensity factor" is known as Kc
- For Mode I, this is called KIc
- The critical stress intensity factor is also known as fracture toughness

$$K_{IC} = \sigma_c \sqrt{\pi a} \beta$$


 Note: "Fracture Toughness" can also refer to Glc, which is analogous to Klc, but not the same

4

### fracture toughness

- Fracture toughness is a material property, but it is only well-defined in certain conditions
- Brittle materials
- Plane strain (smaller plastic zone)
- In these cases ASTM E399-12 is used.

### fracture toughness



6

#### unstable cracks

- Stable crack growth means the crack extends only with increased load
- Unstable crack growth means the crack will continue to extend indefinitely under the same load
- For a perfectly brittle material, there is no stable crack growth, as soon as a critical load is reached, the crack will extend indefinitely

#### stable cracks


- For an elastic-plastic material, once the load is large enough to extend the crack, it will extend slightly
- The load must be continually increased until a critical value causes unstable crack growth

8

### fracture toughness

- During an experiment, we will record the crack length and applied load (Pi, ai) each time we increase the load
- We can calculate a unique stress intensity factor Kli at each of these points
- These are then used to create a "K-curve", plotting KI vs. a

#### K-curve



10

#### K-curve

- Materials will generally not be as flat as the perfectly brittle example
- Plane strain conditions and brittle materials will tend towards a "flat" K-curve
- KIC for brittle/plane strain is very well defined
- KC for plane stress can refer to two things
- Either the maximum KC during a test, or tangent point on KR-curve (R-curve)

- In composites, and adhesives, some work is needed to ensure stable crack growth
- The Double-Cantilever
  Beam (DCB) experiment
  to find GIC illustrates this

$$C = \frac{\delta}{P}$$

$$C = \frac{2a^3}{3EI}$$

$$G = \frac{P^2}{2b} \frac{dC}{da}$$

$$G = \frac{P^2a^2}{bEI}$$

. .

### example

• For crack growth to be stable we need

$$\frac{dG}{da} \leq 0$$

• Under fixed-load conditions, we find

$$\frac{dG}{da} = \frac{2P^2a}{bEI}$$

 This is always positive, and thus results in unstable crack growth

- Under fixed-displacement conditions, we substitute for P
- We find

$$\frac{dG}{da} = -\frac{9\delta^2 EI}{ba^3}$$

 Which is always stable, so for DCB tests, displacement control is generally used

14

### R-curve

#### R-curve

- For materials with some plasticity, the KR Curve, or R Curve, is very important
- Sometimes called a "resistance curve" it is generally dependent on
  - Thickness
  - Temperature
  - Strain rate

15

#### R-curve

- When done correctly, *KR* curves are not dependent on initial crack size or the specimen type used
- ASTM E561 describes a general procedure

- While we can look up plane stress Kc for various materials, it is best if we have a KR curve
- We may not know if the table uses Kc using the tangent intersection method, or maximum stress intensity
- Even if tangent intersection method is used, Kc will different somewhat based on initial crack length

17

#### R-curve

- There are two main methods for plotting the R-curve
- Crack size is measured directly (possibly with a drawn-on scale and camera)
- Effective crack size is calculated from the load-displacement data

### physical crack

- When the physical crack size is measured, we need to calculate the effective crack length (and effective stress intensity factor) at each data point
- The effective crack length calculated from the load-displacement data already has the plastic zone effect built in

19

### plane stress fracture toughness

- For a plane stress (or any thickness that is not plane strain) we can find Kc two ways
- One way is simply the maximum value of the KR curve, but this does not account for unstable crack growth
- The more reliable way is to use the tangent intersection method

### tangent intersection method

- Construct curves for KI based on our specimen geometry with constant applied load and varying crack length
- Plot these curves on the same graph as KR
- NOTE: KR curve should be plotted vs. aeff, not  $\Delta a$  or  $\Delta a_{eff}$
- Kc is the point at which one of the KI curves is the tangent intersection with the KR curve

21

## **R-Curve** examples

- example<sup>1</sup>
- Excel Solver

<sup>1../</sup>examples/Tangent\_R-curve.html

### thickness effects

#### thickness effects

- We already know there is a difference between plane strain and plane stress fracture toughness
- As a material gets thicker and thicker, it converges to the plane strain solution
- Thinner specimens tend towards the plane stress solution
- When a specimen is thinner than some critical thickness, the material behavior is somewhat unknown

#### thickness effects

- There is also a difference in the fracture surface between thin and thick specimens
- Thin specimens (in plane stress region) fail due to slant fracture
- This actually indicates some mixed-mode conditions at failure
- Thick specimens fail due to square fracture (with a small shear tip near the edges)
- This is more consistent with pure Mode I

24

#### slant fracture




Figure 1: A slant fracture, where the failure plane rotates 45 degrees from the crack plane, considered a shear mode

## shear lip




Figure 2: In this shear lip, there is a long crack that near the end rotates away by 45 degrees creating a shear lip near the surface

## fracture toughness review

26

### group review

- Group 1 Sketch KR-curve (for ductile material), explain what it means, how to find Kc
- Group 2 Sketch Kc vs. crack length, explain what's happening
- Group 3 How can we determine whether a panel is in plane strain or plane stress?
- Group 4 Sketch KR-curves for ductile and brittle materials, what is the difference?

27

## residual strength


### residual strength

- As the crack grows, the area of the sample decreases, increasing the net section stress
- The residual strength, σ<sub>R</sub> is given in terms of the gross area, so as the crack grows the residual strength due to yield decreases
- We can relate the net-section stress to  $\sigma_R$  by

$$\sigma_R = \sigma_{YS} \frac{A_{net}}{A_{gross}}$$

28

### residual strength




## residual strength

For brittle fracture to occur, we need to satisfy the condition

$$\sigma_R = \sigma_C = \frac{K_C}{\sqrt{\pi \, \mathsf{a}} \beta}$$

30

## residual strength



## residual strength

- Within the same family of materials (i.e. Aluminum), there
  is generally a trade-off between yield stress and fracture
  toughness
- As we increase the yield strength, we decrease the fracture toughness (and vice versa)
- Consider a comparison of the following aluminum alloys
  - 1. 7178-T6,  $K_C = 43 \text{ ksi} \sqrt{\text{in.}}$ ,  $\sigma_{YS} = 74 \text{ ksi}$
  - 2. 7075-T6,  $K_C = 68 \text{ ksi} \sqrt{\text{in.}}$ ,  $\sigma_{YS} = 63 \text{ ksi}$
  - 3. 2024-T3,  $K_C = 144 \text{ ksi} \sqrt{\text{in.}}$ ,  $\sigma_{YS} = 42 \text{ ksi}$

32

## residual strength

- As an example let us consider an edge-cracked panel with W = 6 and t = 0.1 inches
- The net section yield condition will be given by

$$\sigma_C = \sigma_{YS} \frac{W - a}{W} = \sigma_{YS} \frac{6 - a}{6}$$

And the fracture condition by

$$\sigma_{C} = \frac{K_{C}}{\sqrt{\pi a}\beta}$$

With

$$\{\beta = 1.12 - 0.231 \left(\frac{a}{a}\right) + 10.55 \left(\frac{a}{a}\right)^2 - 21.72 \left(\frac{a}{a}\right)^3 + 30.39 \left(\frac{a^{33}}{a^{33}}\right)^4 \}$$

## 7178-T6

:::

34

## 7075-T6

...

## 2024-T3

:::

36

# comparison

. . .

### using MIL-handbook

• Uses a different grain nomenclature



- A-Basis vs. B-Basis values are reported (A = 99% of population will meet/exceed value, B = 90% of population)
- S-Basis no statistical information available, standard value to be used

38

## using MIL-handbook

- Ftu ultimate tensile strength
- Fty tensile yield strength
- Fcy compressive yield strength
- Fsu ultimate shear strength
- Fbru ultimate bearing strength
- Fbry bearing yield strength
- *E* tensile Young's Modulus
- Ec compressive Young's Modulus
- G shear modulus
- μ- Poisson's ratio

#### data

- Fracture data is on pp. 111-121
- Tensile data is on pp. 138-143
- Kc charts are also available in interactive versions here<sup>2</sup>

<sup>&</sup>lt;sup>2</sup>../examples/Fracture%20Toughness%20Figures.html