### AE 737: Mechanics of Damage Tolerance

Lecture 13 - Project Discussion

Dr. Nicholas Smith

Wichita State University, Department of Aerospace Engineering

8 March 2022

1

#### schedule

- 8 Mar Stress-based Fatigue
- 10 Mar Stress-based Fatigue, HW6 Due, HW5 Self-grade due
- 15 Mar (Spring Break)
- 17 Mar (Spring Break)

# outline

- exam
- final project
- fatigue
- nominal and local stress
- fatigue tests

exam

\_

4

# final project

# general description

- This is in place of a final exam
- Should demonstrate your understanding of the course as a whole
- Choose any real object
- Needs to undergo some cyclic loading (for fatigue)
- Materials, loads, and any other "given" data can be made up

5

#### overview

- Estimate stress intensity factor at some critical location
- Estimate residual strength (use a "typical" crack length)
- Estimate fatigue life
- Estimate crack propagation
- Suggest reasonable inspection cycle for safe use
- Suggest an improvement to make part more damage tolerant

# grade breakdown

- Per course syllabus, project will be worth 25% of final grade
- 5% Project abstract submission and approval
- 15% for each major component
  - stress intensity factor
  - · residual strength
  - fatigue
  - crack propagation
  - inspection cycle

7

### grade breakdown

- 10% for damage tolerant improvement
- 10% general presentation, organization, and grammar

# project abstract

- Main purpose of abstract is for you to make sure your idea fits with project purpose
- I will give you feedback on how to tweak your proposed idea to better meet project purpose
- Abstract submission should be 1-2 pages
- Briefly describe your chosen part, how it undergoes cyclic loading, what location you intend to consider for the stress intensity factor.
- This is like a proposal: convince me that your idea has what it takes to be a great final project

9

## justify assumptions

- You will need to make many assumptions in order to complete this project
- Clearly state your assumptions and justify them (i.e. if you assume plane strain conditions, justify that by showing how thick your part is)
- Although will not have experimental or FE analysis specific to your part, use concepts from other data in the text (stiffeners, multiple site damage) in a qualitative manner

#### figures

- Figures can greatly enhance your project report, if you use them well
- Many readers will jump to figures in a report, include sufficient information in caption and axis labels so a reader with general damage tolerance understanding can understand your figure
- This will interest them in the rest of your paper

11

#### examples

- Last year I did not curve final project grades
- Some examples of a couple of good project reports have been posted to blackboard (and here<sup>1</sup>)
- You should not use their projects, but they have very good use of figures, as well as an appropriate balance of both depth and breadth in the their analysis

<sup>&</sup>lt;sup>1</sup>https://ndaman.github.io/damagetolerance/#/2/2

# fatigue

# fatigue

- We refer to damage from repeated, or cyclic loads as fatigue damage
- Some of the earliest work on fatigue began in the 1800's
- Chains, railway axles, etc.
- An estimated 80% of failure expenses are due to fatigue

### fatigue


- There are three main approaches to fatigue analysis
  - Stress based fatigue analysis
  - Strain based fatigue analysis
  - Fracture mechanics fatigue analysis

14

## stress based fatigue

- One of the simplest assumptions we can make is that a load cycles between a constant maximum and minimum stress value
- This is a good approximation for many cases (axles, for example) and can also be easily replicated experimentally
- This is referred to as constant amplitude stressing

# constant amplitude stressing



16

### constant amplitude stressing

- $\Delta \sigma$  is known as the stress range, and is the difference between max and min stress
- σ<sub>m</sub> is the mean stress, and can sometimes be zero, but this
  is not always the case
- $\sigma_a$  is the stress amplitude, and is the variation about the mean

# constant amplitude stressing

 We can express all of these in terms of the maximum and minimum stress

$$\Delta \sigma = \sigma_{max} - \sigma_{min}$$

$$\sigma_{m} = \frac{\sigma_{max} + \sigma_{min}}{2}$$

$$\sigma_{a} = \frac{\sigma_{max} - \sigma_{min}}{2}$$

18

# constant amplitude stressing

- It is also common to describe some ratios
- The stress ratio, R is defined as

$$R = \frac{\sigma_{min}}{\sigma_{max}}$$

• And the amplitude ratio, A is defined as

$$A = \frac{\sigma_a}{\sigma_m}$$

#### useful relations

There are some useful relationships between the above equations

$$\Delta\sigma = 2\sigma_a = \sigma_{max}(1 - R)$$

$$\sigma_m = \frac{\sigma_{max}}{2}(1 + R)$$

$$R = \frac{1 - A}{1 + A}$$

$$A = \frac{1 - R}{1 + R}$$

20

# nominal and local stress

#### definition and notation


- It is important to distinguish between the nominal (global) stress and the local stress at some point of interest
- We use  $\sigma$  for the stress at a point (local stress)
- We use S as the nominal (global) stress
- In simple tension,  $\sigma = S$

21

#### notation


- For many cases (bending, notches),  $\sigma \neq S$  in general
- We must also be careful to note  $\sigma_y$ , in some cases  $S<\sigma_y$  but at some locations  $\sigma>\sigma_y$

# simple tension




23

# bending



# notches



25

# fatigue tests

### rotating cantilever beam




Figure 1: Stress variation through a cantilever beam

26

## rotating four-point bend





Figure 2: Four-point bend test gives uniform stress along the top and bottom surfaces

### fatigue tests

- The above rotating methods are very common, but in their current configurations can only be used for zero mean stress
- a reciprocating bend test can be used for non-zero mean stress

28

# reciprocating bend test



# axial fatigue test



30

# fatigue tests

- The length of a fatigue test is determined by two factors
  - How many cycles it takes for the specified load to cause failure
  - 2. The speed of the motor controlling the test

### fatigue tests

- Servohydraulic machines generally have a speed of 10 -100 Hz
- At a speed of 100 Hz, it would take 28 hours for 107 cycles,
   12 days for 108 cycles, and nearly 4 months for 109 cycles
- While some machines can test at very high speeds, the inertia of the sample can interfere with results