AE 737 - MECHANICS OF DAMAGE TOLERANCE

LECTURE 20

Dr. Nicholas Smith

Last Updated: April 7, 2016 at 11:21am

Wichita State University, Department of Aerospace Engineering

SCHEDULE

- · 7 Apr Crack Growth, Stress Spectrum
- · 12 Apr Retardation, Boeing Commercial Method
- · 14 Apr Exam Review, Homework 8 Due
- 19 Apr Damage Tolerance
- 21 Apr Exam 2
- · 26 Apr Exam Solutions, Damage Tolerance

OFFICE HOURS

- I have a meeting this Friday afternoon (4/8)
- Office hours will be Monday 4/11 from 3:00 5:00
- As always you can e-mail me to schedule another time, or ask your questions via e-mail


OUTLINE

- 1. crack growth rate
- 2. factors affecting crack propagation
- 3. numerical algorithm

FRACTURE SURFACE



FRACTURE SURFACE




· Crack growth rate can be measured experimentally

- · Crack growth rate can be measured experimentally
- $\boldsymbol{\cdot}$ Using a center-crack specimen, a fatigue load is applied

- · Crack growth rate can be measured experimentally
- · Using a center-crack specimen, a fatigue load is applied
- The crack length is measured and plotted vs. the number of cycles

- · Crack growth rate can be measured experimentally
- · Using a center-crack specimen, a fatigue load is applied
- The crack length is measured and plotted vs. the number of cycles
- The slope of this curve $(\frac{da}{dN})$ is then plotted vs. either $K_{I,max}$ or ΔK_I on a log-log scale

- · Crack growth rate can be measured experimentally
- · Using a center-crack specimen, a fatigue load is applied
- The crack length is measured and plotted vs. the number of cycles
- The slope of this curve $(\frac{da}{dN})$ is then plotted vs. either $K_{I,max}$ or ΔK_I on a log-log scale
- This chart is then commonly divided into three regions



 $\boldsymbol{\cdot}$ In Region I crack growth is very slow and/or difficult to measure

- In Region I crack growth is very slow and/or difficult to measure
- In many cases, da/dN corresponds to the spacing between atoms!

- In Region I crack growth is very slow and/or difficult to measure
- In many cases, da/dN corresponds to the spacing between atoms!
- The point at which the da/dN curve intersects the x-axis is known as the fatigue threshold, Kth

- In Region I crack growth is very slow and/or difficult to measure
- In many cases, da/dN corresponds to the spacing between atoms!
- The point at which the da/dN curve intersects the x-axis is known as the fatigue threshold, Kth
- Typically 3-15 ksi√in for steel

- In Region I crack growth is very slow and/or difficult to measure
- In many cases, da/dN corresponds to the spacing between atoms!
- The point at which the da/dN curve intersects the x-axis is known as the fatigue threshold, Kth
- Typically 3-15 ksi√in for steel
- · 3-6 ksi√in for aluminum

• Most important region for general engineering analysis

- Most important region for general engineering analysis
- Once a crack is present, most of the growth and life occurs in Region II

- Most important region for general engineering analysis
- Once a crack is present, most of the growth and life occurs in Region II
- · Generally linear in the log-log scale

REGION III

Unstable crack growth

REGION III

- Unstable crack growth
- Usually neglected (we expect failure before Region III fully develops in actual parts)

REGION III

- Unstable crack growth
- Usually neglected (we expect failure before Region III fully develops in actual parts)
- Can be significant for parts where we expect high stress and relatively short life

CRACK GROWTH RATE CURVE

 $\boldsymbol{\cdot}$ The crack growth rate curve is considered a material property

CRACK GROWTH RATE CURVE

- The crack growth rate curve is considered a material property
- The same considerations for thickness apply as with fracture toughness (K_c vs. K_{lc})

CRACK GROWTH RATE CURVE

- The crack growth rate curve is considered a material property
- The same considerations for thickness apply as with fracture toughness (K_c vs. K_{lc})
- \cdot Is also a function of the load ratio, $R=\sigma_{min}/\sigma_{max}$

• While the x-axis can be either ΔK or K_{max} , the shape of the data is the same

- While the x-axis can be either ΔK or K_{max} , the shape of the data is the same
- When we look at the effects of load ratio, *R*, the axis causes some differences on the plot

- While the x-axis can be either ΔK or K_{max} , the shape of the data is the same
- When we look at the effects of load ratio, *R*, the axis causes some differences on the plot
- With ΔK on the x-axis, increasing R will shift the curve up and to the left, shifting the fatigue threshold and fracture toughness on the graph as well

- While the x-axis can be either ΔK or K_{max} , the shape of the data is the same
- When we look at the effects of load ratio, *R*, the axis causes some differences on the plot
- With ΔK on the x-axis, increasing R will shift the curve up and to the left, shifting the fatigue threshold and fracture toughness on the graph as well
- With K_{max} on the x-axis, increasing R shifts the curve down and to the right, but fatigue threshold and fracture toughness keep same values

- While the x-axis can be either ΔK or K_{max} , the shape of the data is the same
- When we look at the effects of load ratio, *R*, the axis causes some differences on the plot
- With ΔK on the x-axis, increasing R will shift the curve up and to the left, shifting the fatigue threshold and fracture toughness on the graph as well
- With K_{max} on the x-axis, increasing R shifts the curve down and to the right, but fatigue threshold and fracture toughness keep same values
- In general, R dependence vanishes for R > 0.8 or R < -0.3. This effect is known as the band width

PARIS EXAMPLE

FACTORS AFFECTING CRACK PROPAGA-TION

FACTORS AFFECTING CRACK PROPAGATION

thickness

FACTORS AFFECTING CRACK PROPAGATION

- thickness
- stress ratio

- thickness
- · stress ratio
- $\cdot \ \text{temperature} \\$

- thickness
- · stress ratio
- · temperature
- environment

- thickness
- · stress ratio
- · temperature
- environment
- frequency

- thickness
- · stress ratio
- · temperature
- environment
- frequency
- · crack orientation

- thickness
- · stress ratio
- · temperature
- environment
- frequency
- · crack orientation
- manufacturer

- thickness
- · stress ratio
- temperature
- environment
- frequency
- · crack orientation
- manufacturer
- · heat treatment

 We already discussed the effects of thickness on fracture toughness

- We already discussed the effects of thickness on fracture toughness
- The same effects are important in crack propagation

- We already discussed the effects of thickness on fracture toughness
- The same effects are important in crack propagation
- In thin (plane stress) plates, cracks can be treated as through cracks

- We already discussed the effects of thickness on fracture toughness
- · The same effects are important in crack propagation
- In thin (plane stress) plates, cracks can be treated as through cracks
- In thick plates (plain strain), we generally need to consider the crack shape

• Cyclic life is primarily a function of K_i/K_c where K_i is the stress intensity factor in the first cycle

- Cyclic life is primarily a function of K_i/K_c where K_i is the stress intensity factor in the first cycle
- Other experiments indicate a relationship between $\frac{d(a/Q)}{dN}$ and K_{max}

- Cyclic life is primarily a function of K_i/K_c where K_i is the stress intensity factor in the first cycle
- Other experiments indicate a relationship between $\frac{d(a/Q)}{dN}$ and K_{max}
- · Q is a shape parameter for elliptical flaws

• In general (for most aluminum alloys) cracks propagate more slowly with a decrease in temperature

- In general (for most aluminum alloys) cracks propagate more slowly with a decrease in temperature
- This trend is exactly opposite the trend for K_c

- In general (for most aluminum alloys) cracks propagate more slowly with a decrease in temperature
- This trend is exactly opposite the trend for K_c
- · The effect varies in different materials

- In general (for most aluminum alloys) cracks propagate more slowly with a decrease in temperature
- This trend is exactly opposite the trend for K_c
- · The effect varies in different materials
- Most materials benefit from slightly lower temperatures, but as temperatures are further decreased the crack growth rate increases again




Fig. 2 Mid-range fatigue crack-growth rates with alternating stress intensity factor for 18%Cr-Nb ferritic stainless steel at

 $\boldsymbol{\cdot}$ In general, temperature effects can not be predicted well


- · In general, temperature effects can not be predicted well
- Instead, materials should be tested at a range of temperatures to establish a range of operating temperatures with corresponding crack growth data


 There are many conditions in the environment that can affect crack growth

- There are many conditions in the environment that can affect crack growth
- · Moisture greatly increases the crack growth rate

- There are many conditions in the environment that can affect crack growth
- · Moisture greatly increases the crack growth rate
- · Salt water increases crack growth rate even further

- There are many conditions in the environment that can affect crack growth
- Moisture greatly increases the crack growth rate
- · Salt water increases crack growth rate even further
- These effects have varying strength depending on the material used





• Further, the shape of the applied load curve has a significant effect when combined with adverse environments

- Further, the shape of the applied load curve has a significant effect when combined with adverse environments
- Crack growth is faster when the load increases slowly and decreases rapidly

- Further, the shape of the applied load curve has a significant effect when combined with adverse environments
- Crack growth is faster when the load increases slowly and decreases rapidly
- Crack growth is slower when the load increases rapidly and decreases slowly

 When the environment is corrosive, the test frequency is of particular importance

- When the environment is corrosive, the test frequency is of particular importance
- At low frequencies, a corrosive environment increases the threshold, \mathcal{K}^{th}

- When the environment is corrosive, the test frequency is of particular importance
- At low frequencies, a corrosive environment increases the threshold, Kth
- · However in Region II, crack growth is faster

- When the environment is corrosive, the test frequency is of particular importance
- At low frequencies, a corrosive environment increases the threshold, Kth
- · However in Region II, crack growth is faster
- This effect can be explained by the corrosive environment blunting the crack tip

FREQUENCY

• There is conflicting information about the effect of frequency in the absence of a corrosive environment

FREQUENCY

- There is conflicting information about the effect of frequency in the absence of a corrosive environment
- Some experiments have found a frequency dependence, while others have not

FREQUENCY

- There is conflicting information about the effect of frequency in the absence of a corrosive environment
- Some experiments have found a frequency dependence, while others have not
- Many claim that the frequency dependence is due to small amounts of water in air during frequency dependence experiment

CRACK ORIENTATION

• For rolled plates, a crack will generally propagate faster parallel to the rolling direction

CRACK ORIENTATION

- For rolled plates, a crack will generally propagate faster parallel to the rolling direction
- In many materials, however, the difference between orientations is not significant when compared to scatter, and it is often neglected

CRACK ORIENTATION

- For rolled plates, a crack will generally propagate faster parallel to the rolling direction
- In many materials, however, the difference between orientations is not significant when compared to scatter, and it is often neglected
- Some materials behave very differently with different crack orientations (i.e. the slope of the paris law curve is different), so care should be taken based on the material used

 Different manufacturers of the same material can produce different crack growth rates

- Different manufacturers of the same material can produce different crack growth rates
- \cdot Some reasons for this may be

- Different manufacturers of the same material can produce different crack growth rates
- · Some reasons for this may be
- Slight variation in composition

- Different manufacturers of the same material can produce different crack growth rates
- \cdot Some reasons for this may be
- Slight variation in composition
- Site cleanliness (inclusions)

- Different manufacturers of the same material can produce different crack growth rates
- · Some reasons for this may be
- · Slight variation in composition
- Site cleanliness (inclusions)
- Heat treatment/cold rolling variations

HEAT AND SURFACE TREATMENTS

· Different heat and surface treatments are often applied

HEAT AND SURFACE TREATMENTS

- · Different heat and surface treatments are often applied
- They provide various benefits (corrosion resistance, residual stress, residual stress relief)

HEAT AND SURFACE TREATMENTS

- · Different heat and surface treatments are often applied
- They provide various benefits (corrosion resistance, residual stress, residual stress relief)
- · But they will also affect the crack growth rate



 While the Paris Law can be integrated directly (for simple load cases), many of the other formulas cannot

- While the Paris Law can be integrated directly (for simple load cases), many of the other formulas cannot
- A simple numerical algorithm for determining incremental crack growth is

- While the Paris Law can be integrated directly (for simple load cases), many of the other formulas cannot
- A simple numerical algorithm for determining incremental crack growth is

$$a_{i+1} = a_i + \left(\frac{da}{dN}\right)_i (\Delta N)_i \tag{20.1}$$

- While the Paris Law can be integrated directly (for simple load cases), many of the other formulas cannot
- A simple numerical algorithm for determining incremental crack growth is

$$a_{i+1} = a_i + \left(\frac{da}{dN}\right)_i (\Delta N)_i \tag{20.1}$$

 This method is quite tedious by hand (need many a_i values for this to be accurate)

- While the Paris Law can be integrated directly (for simple load cases), many of the other formulas cannot
- A simple numerical algorithm for determining incremental crack growth is

$$a_{i+1} = a_i + \left(\frac{da}{dN}\right)_i (\Delta N)_i \tag{20.1}$$

- This method is quite tedious by hand (need many a_i values for this to be accurate)
- But is simple to do in Excel, MATLAB, Python, or many other codes

- While the Paris Law can be integrated directly (for simple load cases), many of the other formulas cannot
- A simple numerical algorithm for determining incremental crack growth is

$$a_{i+1} = a_i + \left(\frac{da}{dN}\right)_i (\Delta N)_i \tag{20.1}$$

- This method is quite tedious by hand (need many a_i values for this to be accurate)
- But is simple to do in Excel, MATLAB, Python, or many other codes
- For most accurate results, use $\Delta N=$ 1, but this is often unnecessary

- While the Paris Law can be integrated directly (for simple load cases), many of the other formulas cannot
- A simple numerical algorithm for determining incremental crack growth is

$$a_{i+1} = a_i + \left(\frac{da}{dN}\right)_i (\Delta N)_i \tag{20.1}$$

- This method is quite tedious by hand (need many a_i values for this to be accurate)
- But is simple to do in Excel, MATLAB, Python, or many other codes
- For most accurate results, use $\Delta N=$ 1, but this is often unnecessary
- When trying to use large ΔN , check convergence by using larger and smaller ΔN values

BOEING-WALKER EXAMPLE

CONVERGENCE EXAMPLE

 \cdot In practice variable loads are often seen

- · In practice variable loads are often seen
- The most basic way to handle these is to simply calculate the crack length after each block of loading

- · In practice variable loads are often seen
- The most basic way to handle these is to simply calculate the crack length after each block of loading
- We will discuss an alternate method, which is more convenient for flight "blocks" next class

- · In practice variable loads are often seen
- The most basic way to handle these is to simply calculate the crack length after each block of loading
- We will discuss an alternate method, which is more convenient for flight "blocks" next class
- · We will also discuss "retardation" models next class

VARIABLE LOAD EXAMPLE