# AE333 Mechanics of Materials

Lecture 18 - Transverse Shear
Dr. Nicholas Smith
Wichita State University, Department of Aerospace Engineering
30 March, 2020

1/34(#/)

#### schedule

- 30 Mar Transverse Shear
- 1 Apr Transverse Shear
- 3 Apr Combined Loading, HW6 Due
- 6 Apr Combined Loading
- 8 Apr Stress Transformation

#### outline


- shear in straight members
- the shear formula
- group problems
- shear flow in built-up members

# shear in straight members

#### shear

- ullet We have discussed the internal stresses caused by the internal moment M
- ullet There are also internal shear stresses caused by the internal shear force V
- We can illustrate the effect of internal shear stress by considering three boards, either resting on top of on another or bonded

#### shear





Boards bonded together

# the shear formula

#### shear formula

- Internal shear causes a more complicated deformation state, so we will use an indirect method to find the shear stress-strain distribution
- We will consider equilibrium along a section of a beam, then we will consider another section





- There must be a shear force along the bottom to equilibrate the different stresses on either side of the section
- If we assume that this shear is constant through the thickness, we obtain the following from equilibrium

$$\sum F_x = 0 = \int_{A'} \sigma' dA' - \int_{A'} \sigma dA' - au(t dx)$$

$$0 = \int_{A'} \left(rac{M+dM}{I}
ight) y dA' - \int_{A'} \left(rac{M}{I}
ight) y dA' - au(t dx) \ \left(rac{dM}{I}
ight) \int_{A'} y dA' = au(t dx) \ au = rac{1}{It} \left(rac{dM}{dx}
ight) \int_{A'} y dA'$$

#### shear formula

- ullet In this formula, recall that  $V=rac{dM}{dx}$
- We also call Q the moment of the area A' which is equal to  $\int_{a'} y dA'$
- We can also write Q in terms of the centroid

$$Q=ar{y}'A'$$

#### shear formula

• Simplified, the shear formula is

$$au = rac{VQ}{It}$$


ullet Q poses the greatest difficulty in calculations, so we will consider a few examples




- ullet Q represents the moment of the cross-sectional area above (or below) the point at which the shear stress is being calculated
- We apply the formula to that area










#### shear formula limitations


- A major assumption made is that the shear stress was constant through the thickness, essentially we have found the average shear
- This is more accurate the more slender a beam is (small *b* and large *h*)
- The formula is also not accurate for cross sections that change or have boundaries that are not right angles

#### procedure

- First we find the internal shear, *V*
- Find *I*, the moment of inertia (of the entire section) about the neutral axis
- Find *t* from an imaginary cross-section at the point of interest
- Calculate *Q* from either the area above or below the point of interest
- $\tau$  acts in the same direction as V (and must be equilibrated on other faces)




Determine the maximum stress needed by a glue to hold the boards together.



Plot the shear stress distribution through the beam.


# group problems

#### group one




Find Q and t that would be used to find the shear stress at A.

#### group two



Find Q and t that would be used to find the shear stress at A.

# group three




Find Q and t that would be used to find the shear stress at A.

# shear flow in built-up members

# built-up members

- Often in practice, structural members are "built-up"
- This refers to parts that are comprised of several other parts to have greater strength in certain areas
- We need to analyze the shear between these members to choose appropriate adhesives or fasteners



• From equilibrium we see that

$$dF = rac{dM}{I} \int_{A'} y dA'$$


• We recall that this integral represents Q, we can also define the shear flow as q=dF/dx and recall that dM/dx=V to find

$$q = rac{VQ}{I}$$

## fastener spacing


- We can use shear flow to determine fastener spacing
- $\bullet\,$  Say a fastener can support a shear force of  $F_{\rm O}$  before failure
- The shear flow (force/distance) times the spacing (distance) will give the shear force per fastener F=qs

# multiple fasteners




#### multiple fasteners


- When multiple arms are connecting the same area (as shown in the previous slide)
- The shear flow "seen" by each fastener is q/n where n is the number of fasteners per area




Determine the shear flow at B and B' that must be resisted by glue to bond the boards together.



If each nail can support a maximum shear force of 30 lb, determine the maximum spacing of the nails at B and at C so that the beam can support the force of 80 lb.





Nails with a shear strength of 40 lb are used in a beam that can be constructed as shown in Case I or Case II. If the nails are spaced at 9 in determine the largest vertical shear that can be supported.