### Mechanics of Materials

Lecture 13 - Transverse Shear

Dr. Nicholas Smith

Wichita State University, Department of Aerospace Engineering

22 March, 2021

1

#### schedule

- 22 Mar Transverse Shear
- 22 Mar Homework 5 Due, Homework 4 Self-grade due
- 24 Mar Transverse Shear
- 29 Mar Exam 2 Review
- 29 Mar Homework 6 Due, Homework 5 Self-grade due
- 31 Mar Exam 2


### outline

- shear in straight members
- the shear formula
- group problems

# shear in straight members

- We have discussed the internal stresses caused by the internal moment M
- There are also internal shear stresses caused by the internal shear force V
- We can illustrate the effect of internal shear stress by considering three boards, either resting on top of on another or bonded

### shear



### the shear formula

# shear formula

- Internal shear causes a more complicated deformation state, so we will use an indirect method to find the shear stress-strain distribution
- We will consider equilibrium along a section of a beam, then we will consider another section





Figure 1: A free body diagram of an arbitrary beam.

7

# equilibrium



### equilibrium

- There must be a shear force along the bottom to equilibrate the different stresses on either side of the section
- If we assume that this shear is constant through the thickness, we obtain the following from equilibrium

$$\sum F_{x} = 0 = \int_{A'} \sigma' dA' - \int_{A'} \sigma dA' - \tau(t dx)$$

9

### equilibrium

$$0 = \int_{A'} \left( \frac{M + dM}{I} \right) y dA' - \int_{A'} \left( \frac{M}{I} \right) y dA' - \tau(t dx)$$

$$\left( \frac{dM}{I} \right) \int_{A'} y dA' = \tau(t dx)$$

$$\tau = \frac{1}{It} \left( \frac{dM}{dx} \right) \int_{A'} y dA'$$

### shear formula

- In this formula, recall that  $V = \frac{dM}{dx}$
- We also call Q the moment of the area A' which is equal to ∫<sub>a'</sub> ydA'
- We can also write Q in terms of the centroid

$$Q = \bar{y}'A'$$

- -

#### shear formula

· Simplified, the shear formula is


$$\tau = \frac{VQ}{It}$$

 Q poses the greatest difficulty in calculations, so we will consider a few examples

- Q represents the moment of the cross-sectional area above (or below) the point at which the shear stress is being calculated
- We apply the formula to that area

13

#### Q



#### shear formula limitations


- A major assumption made is that the shear stress was constant through the thickness, essentially we have found the average shear
- This is more accurate the more slender a beam is (small b and large h)
- The formula is also not accurate for cross sections that change or have boundaries that are not right angles

15

## procedure

- First we find the internal shear, V
- Find I, the moment of inertia (of the entire section) about the neutral axis
- Find t from an imaginary cross-section at the point of interest
- Calculate Q from either the area above or below the point of interest
- τ acts in the same direction as V (and must be equilibrated on other faces)


# example 7.1



Determine the maximum stress needed by a glue to hold the boards together.

17


# example 7.3



Plot the shear stress distribution through the beam.


# group problems

# group one



Find Q and t that would be used to find the shear stress at A.


### group two



Find Q and t that would be used to find the shear stress at A.

20

# group three



Find Q and t that would be used to find the shear stress at A.