Mechanics of Materials

Lecture 10 - Torsion

Dr. Nicholas Smith

Wichita State University, Department of Aerospace Engineering

20 September, 2021

schedule

- 20 Sep Torsion
- 22 Sep Bending
- 24 Sep Homework 3 Due
- 27 Sep Bending
- 29 Sep Transverse Shear
- 1 Oct Homework 4 Due, Homework 3 Self-grade due

2

outline

- angle of twist
- statically indeterminate torsion
- solid non-circular shafts
- thin-walled tubes

angle of twist

angle of twist

- While in axial problems we examined the total deformation for the general case, in torsion we will examine the total angle of twist in general
- Using the method of sections, we can consider a differential disk which has some internal torque as a function of x, T(x).
- On this section, the shear strain will be related to the angle of twist by the thickness of the section (dx) and the radial distance (ρ).

4

angle of twist




Figure 1: A section of an arbitrary cone is shown to depict how we can find the incremental change in angle from one end of the section to the next.

angle of twist

• γ and $d\phi$ are related by

$$d\phi = \gamma \frac{dx}{\rho}$$

• We also know that $\gamma = \tau/G$ and $\tau = T(x)\rho/J(x)$ substituting both this gives

$$d\phi = \frac{T(x)}{J(x)G(x)}dx$$

6

multiple torques

 If a shaft is subjected to multiple torques, or if there is a discontinuous change in shape or material we can sum the change in angle over various segments

$$\phi = \sum \frac{TL}{JG}$$

- Both torque and angle of twist should follow the same convention
- The convention is to use the right hand rule with the thumb pointing normal to the cut, and the fingers curling in the positive direction

8

example 5.8




Figure 2: A wrench is attached to a post. 24 inches of the post are embedded in soil, while the

Find the maximum shear stress in the post and the angle of twist of the wrench. The torque is about to turn the bottom of the post, the soil exerts uniform torsional resistance of *t* lb.in/in and G=5.5 Msi

statically indeterminate torsion

statically indeterminate torsion

- Just as in axial problems, we can now solve statically indeterminate torsion problems
- We will generally need one compatibility condition in addition to the equations of static equilibrium
- At any given section cut the angle of twist needs to be equal, or often the supports restrict the angle of twist and we can use that knowledge

example 5.10




Figure 3: The brass core has a radius of 0.5 inches, while the steel tube has an outer radius of 1 inch. The shaft is 4 ft long and fixed at one end with a torque of 250 ft.lb applied at the other end.

The shaft shown is made from a steel tube bonded to a brass core. Plot the shear stress distribution along a radial line on its cross-section where $G_{ST}=11.4\,$ Msi and $G_{BR}=5.20\,$ Msi.


solid non-circular shafts

non-circular shafts

- When a shaft is non-circular it is no longer axisymmetric, which causes cross-sections to bulge or warp
- Because of this deformation, in-depth analysis of non-circular shafts in torsion is beyond the scope of this class
- Using the theory of elasticity some standard shapes can be analyzed

12

theory of elasticity



thin-walled tubes

shear flow

- Thin-walled tubes of non-circular cross-sections are commonly found in aerospace and other applications
- We can analyze these using a technique called shear flow
- Because the walls of the tube are thin, we assume that the shear stress is uniformly distributed through the wall thickness

 If we consider an arbitrary segment of a tube with varying thickness, we find from equilibrium that the product of the average shear stress and the thickness must be the same at every location on the cross-section

$$q = \tau_{avg} t$$

a is called the shear flow

15

average shear stress

 We can relate the average shear stress to the torque by considering the torque produced about some point within the tubes boundary

$$T = \oint h au_{avg} t ds$$

 Where h is the distance from the reference point, ds is the differential arc length and t is the tube thickness.

average shear stress

- We notice that \(\tau_{avg} t\) is equal to the shear flow, \(q\), which
 must be constant
- We can also simplify the integral by relating a similar area integral to the arc length integral

$$dA_m = 1/2hds$$

Thus

$$T=\oint h au_{avg}tds=2q\int dA_{m}=2qA_{m}$$


17

angle of twist

• The angle of twist for a thin-walled tube is given by

$$\phi = \frac{TL}{4A_m^2G} \oint \frac{ds}{t}$$

example 5.13



Determine the average shear stress at A and B.