Mechanics of Materials

Lecture 16 - Stress Transformation

Dr. Nicholas Smith

Wichita State University, Department of Aerospace Engineering

15 October, 2020

1

schedule

- 15 Oct Stress Transformation
- 20 Oct Stress Transformation, HW 7 Due
- 22 Oct Strain Transformation
- 27 Oct Beam Deflection, HW 8 Due

outline


- plane stress transformation
- general equations
- principal stresses
- mohr's circle

3

plane stress

- In general, the state of stress at a point is characterized by six stress components
- In practice, this is rare, as most stresses and forces act in the same plane
- This case is referred to as plane stress

transformation




Б

procedure


- If the state of stress (σ_x, σ_y, τ_{xy} is known for a known axis system x and y, we can find the stress relative to some rotated coordinate system
- We do this by considering a section of the element perpendicular to the x'
- Sum of forces in x and y will give σ'_x and τ_{xy}
- A second section is needed to find σ_y' perpendicular to the y' axis

procedure



7

example 9.1



Represent the state of stress shown on the fuselage section on an element rotated 30° clockwise from the position shown.

general equations

- We can follow the methodology from the previous section to develop equations for some arbitrary rotation and a completely general state of stress
- We use some trig identities to simplify the formulae

$$\begin{split} \sigma_{x'} &= \frac{\sigma_x + \sigma_y}{2} + \frac{\sigma_x - \sigma_y}{2} \cos 2\theta + \tau_{xy} \sin 2\theta \\ \tau_{x'y'} &= -\frac{\sigma_x - \sigma_y}{2} \sin 2\theta + \tau_{xy} \cos 2\theta \end{split}$$


 \bullet To find σ_{v}' we can simply add 90° to θ

9

procedure

- The procedure in general is mostly "plug and chug"
- The only thing we need to be cautious about is sign convention: stresses are positive in tension, shear is positive with arrows pointing to the 1st and 3rd quadrants, θ is measured counter-clockwise from the x-axis

example 9.2



Determine the stress at this point on an element rotated 30° clockwise from the position shown.

principal stresses

- Since the local stresses only change with the rotation angle, we might like to find the angle with gives the maximum stress
- This is known as the principal direction, and the stresses are known as principal stresses
- We can find this direction by differentiating the equation for $\sigma_{\rm v}'$

principal stress

• We find the angle as

$$\tan 2\theta_p = \frac{2\tau_{\rm xy}}{\sigma_{\rm x}-\sigma_{\rm y}}$$

The principal stresses are then

$$\sigma_{1,2} = \frac{\sigma_{x} + \sigma_{y}}{2} \pm \sqrt{\left(\frac{\sigma_{x} - \sigma_{y}}{2}\right)^{2} + \tau_{xy}^{2}}$$

13

maximum shear stress


Similarly, we might want to find the direction of maximum shear stress

$$an 2 heta_s = rac{\sigma_y - \sigma_x}{2 au_{xy}}$$

• And the maximum shear stress is

$$au_{ extit{max}} = \sqrt{\left(rac{\sigma_{ extit{x}} - \sigma_{ extit{y}}}{2}
ight)^2 + au_{ extit{xy}}^2}$$

example 9.3



Find the principal stress for the stress state shown.

15

example 9.5

- When torsional loading T is applied to a circular bar it produces a state of pure shear stress.
- Find the maximum in-plane shear stress and the associated average normal stress
- Find the principal stresses

mohr's circle

- We can visualize plane stress transformation using a technique known as Mohr's circle
- If we re-write the stress transformation equations we find

$$\begin{split} \sigma_{x'} - \left(\frac{\sigma_x + \sigma_y}{2}\right) &= \left(\frac{\sigma_x - \sigma_y}{2}\right) \cos 2\theta + \tau_{xy} \sin 2\theta \\ \tau_{x'y'} &= -\left(\frac{\sigma_x - \sigma_y}{2}\right) \sin 2\theta + \tau_{xy} \cos 2\theta \end{split}$$

17

mohr's circle

• If we square each equation and add them together, we find

$$\left[\sigma_{x'} - \left(\frac{\sigma_x + \sigma_y}{2}\right)\right]^2 + \tau_{x'y'}^2 = \left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2$$

mohr's circle

 Since σ_x, σ_y and τ_{xy} are known constants, we can write a more compact form by letting


$$\begin{split} (\sigma_{x'} - \sigma_{\text{avg}})^2 + \tau_{x'y'}^2 &= R^2 \\ \sigma_{\text{avg}} &= \frac{\sigma_x + \sigma_y}{2} \\ R &= \sqrt{\left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2} \end{split}$$

19

mohr's circle

- Re-written in this way, we can see that the previous equation is the equation of a circle on the σ, τ axis
- \bullet The center of the circle is at $\tau=$ 0 and $\sigma=\sigma_{\rm avg}$
- \blacksquare The radius of the circle is $\sqrt{\left(\frac{\sigma_{x}-\sigma_{y}}{2}\right)^{2}+\tau_{xy}^{2}}$
- Each point on the circle represents (σ_x', τ_{xy}')

mohr's circle



21

visual construction of Mohr's circle

- By convention, positive τ points down, use this convention to plot the center of the circle and a reference point at (σ'_x, τ'_{xy}) where the x' axis is coincident with the x axis
- Use these two points to sketch the circle

principal stress

- The principal stresses, σ₁and σ₂ are the coordinates where Mohr's circle intersects the σ axis
- The angles θ_{p1} and θ_{p2} can be found by calculating the angle between the reference line and the σ axis (note that this angle is equal to $2\theta_p$)
- Note that the direction from the reference point to the σ axis will be the same as the direction from the x axis to the principal axis

23

maximum shear stress


- The top and bottom of the circle represent the maximum shear stress
- The angles θ_{s1} and θ_{s2} can be found in a similar method to that described for the principal stress

stress on arbitrary plane

- To find the stress at some arbitrary plane some known angle θ away from our reference plane, we find the angle 2θ away from the reference line on Mohr's circle
- We can use trigonometry to find the value of the coordinates at that point
- We must draw our angle in the same direction as the desired rotation

25

example 9.9



Represent the state of stress shown on an element rotated 30° counterclockwise from the position shown.