Lecture 7 - Physical measurements

Dr. Nicholas Smith

Wichita State University, Department of Aerospace Engineering February 23, 2021

1

schedule

- Feb 23 Physical measurements
- Feb 25 Variational Calculus
- Mar 2 Variational Calculus
- Mar 4 Boundary Conditions (HW3 Due)

outline

- review
- measuring orientation

review

checking transformations

- Follow the procedure here¹
- This gives a way to systematically check whether your rotations are correct
- You can check any coordinate transformation as long as you know the unit vectors of your primed coordinate system in the global coordinates

$$x = [Q^T]x'$$

1 http://nbviewer.jupyter.org/github/ndaman/multiscale/blob/master/examples/Orientation%20Playground.jpynb

4

common homework errors

- Some people had rotations about an axis with zeros along the diagonal
- This is possible with successive rotations, but for a rotation about one of the three axes, you should always have one term along the diagonal equal to 1
- When calculating stiffness in Problem 2, most students had some un-expected behavior
- All four walls had same x₁ component of fibers, you should have gotten C₁₁ the same for all 4 walls
- C₂₂ or C₃₃ should have also been equal to C₁₁, depending on the wall

measuring orientation

measuring orientation

- In micromechanics (and most places where multi-scale modeling would be used), measuring local orientations can be difficult
- For composites, these are some common techniques
 - Microscopy (some ambiguity in orientation tensor)
 - Serial sectioned microscopy (eliminates ambiguity, very expensive)
 - CT-scanning (only gives approximate measure)
 - Micro CT-scanning (only for very small parts)

microscopy

- Cylindrical fiber intersects cutting plane at some angle
- After cutting and polishing, this leaves an ellipse
- By measuring the ellipse, we can calculate the angle between it and the cutting plane
- Microscopy can also be used to measure volume fraction, void content, and fiber spacing

7

microscopy




Figure 1: An image showing the ellipse that results from cutting a cylinder at an angle that isn't perpendicular to the axis.

fiber in spherical coordinates




Figure 2: Relating the spherical coordinate system to direction vectors to describe fiber orientation

fiber direction components

Definition
$\sin\theta\cos\phi$
$\sin\theta\sin\phi$
$\cos \theta$




Figure 3: Defining some terms for analyzing the cross-section of an elliptical fiber cut. Phi is the angle between the major axis of the ellipse and the 1 axis, x1, y1 mark the bottom left point of the ellipse x2 y2 mark the upper right point of the ellipse (the major

calculations

• We find the major (M) and minor (m) axes using

$$m = \sqrt{(x_3 - x_4)^2 + (y_3 - y_4)^2}$$

$$X = x_1 - x_2$$

$$Y = y_1 - y_2$$

$$M = \sqrt{X^2 - Y^2}$$

orientation tensor

• We can now calculate angles using

$$\sin\phi = \frac{Y}{M}\cos\phi = \frac{X}{M}\cos\theta = \frac{m}{M}\sin\theta = \sqrt{1 - \frac{m^2}{M^2}}$$

13

microscopy




Figure 4: A microscopic image of a composite laminate, showing plies at different angles

microscopy




Figure 5: An image from some analysis to find the volume fraction of fibers in an image.

microscopy



Figure 6: A demonstration that choosing the correct threshold value to convert greyscale images to only black and white is essential to correctly determining the volume fraction.

microscopy




Figure 7: Ply thickness can be measured from a microscopic image

microscopy




Figure 8: It can also be useful sometimes to measure the distance between a fiber and its nearest neighbors.

software

- If you have to do a lot of microscopy measurements, contact Dr. Sharma, he wrote an automated measurement tool
- Otherwise you can use imageJ²

19

microscopy

- Need to account for bias in measurement (more likely to see fibers coming out of plane)
- There is some ambiguity in fiber angle
- Fiber at (ϕ, θ) is not distinguishable from $(\phi + \pi, \theta)$
- In the second-order orientation tensor, this affects a_{23} and a_{13}

²https://imagej.nih.gov/ij/download.html

serial sectioning

- Serial sectioning is a method where you continually polish a specimen after photographing it
- After photograph you grind and polish, then photograph and repeat
- Gives the full 3D state of orientation, but is difficult

21

CT Scanning

- Even if a CT Scan cannot resolve down to fiber resolution, the gradient information can give an idea of fiber orientation
- This method is not very precise
- But it can view the full-field and detect many forms of damage without destroying a part
- At the micro-scale full orientation can be obtained, but this is not practical for large parts