

# Logosol USB to LDCN NODE Opto-isolated Adapter LS-832RL

Doc. # 711830008/ Rev. B, 12/14/2022

### **DIMENSIONAL DRAWING**



## **PINOUT**



### **INTERFACING**

- a. The USB cable length between LS-832RL and the host should not exceed 16 ft. or 5m.
- b. The cable length between LS-832RL and the first LDCN node should not exceed 100 ft or 30m.
- c. For software drivers and installation refer to FT232R / FT232RN on FTDI Web page: <a href="https://ftdichip.com/document/usb-ic-data-sheets/">https://ftdichip.com/document/usb-ic-data-sheets/</a>

https://ftdichip.com/document/installation-guides/

## **ORDERING GUIDE**

PART NUMBER	MODEL	DESCRIPTION
9218300141	LS-832RL	USB to LDCN NODE Opto-isolated Adapter
9218300151	LS-832RL-C06	USB to LDCN NODE Opto-isolated Adapter with 6ft USB cable and 3ft LDCN 1250 cable