

School of Basic and Applied Sciences

Course Code: BBS01T1002 Course Name: Semiconductor Physics

Energy level diagram, conductivity, mobility and drift velocity

Out lines

- Energy level diagram
- Conductivity in semiconductor
- Concept of drift velocity

GALGOTIAS UNIVERSITY

Faculty Name: Dr Sanjeev Kumar

Program Name: B. Tech.



Prerequisite/Recapitulations

• Knowledge of Classical and quantum Theory of electrons

GALGOTIAS UNIVERSITY



Objectives

After completion of this lecture students/ learners will be able to

- Define the energy level in semiconductor
- Derive the conductivity and mobility semiconductors
- Obtain the drift velocity of electron

GALGOTLAS UNIVERSITY



Visualization






Introduction


Figure shows the energy band description of *n*-type semi-conductor. The addition of pentavalent impurity has produced a number of conduction band electrons *i.e.*, free electrons. The four valence electrons of pentavalent atom form covalent bonds with four neighbouring germanium atoms. The fifth left over valence electron of the pentavalent atom cannot be accommodated in the valence band and travels to the conduction band. The following points may be noted carefully:

- (i) Many new free electrons are produced by the addition of pentavalent impurity.
- (ii) Thermal energy of room temperature still generates a few hole-electron pairs. However, the number of free electrons provided by the pentavalent impurity far exceeds the number of holes. It is due to this predominance of electrons over holes that it is called *n*-type semiconductor (*n* stands for negative).






Energy level diagram



Energy band diagrams for (a) n-type, and (b) p-type semiconductors



Energy level diagram



Energy band diagrams for (a) intrinsic, (b) n-type, and (c) p-type semiconductors. In all cases, $np = n_i^2$.

Conductivity

Conductivity in metal

We can have the equation

$$J = nqv = nq\mu E = \sigma E$$


Where
$$\sigma = nq\mu$$

is the conductivity of the metal.



Conductivity and Mobility


Conductivity and Mobility



At thermal equilibrium, net current due to randomly moving electrons is zero



Drift Motion and Drift Current



under the influence of electric field (E), each electron experiences a force F = -eE

- This results in a net motion of group of electrons in the direction opposite to the direction of electric field.
- The net motion of electrons in a particular direction under the influence of electric field is called drift motion.
- Current due to this motion is called as drift current.



Conductivity and Electric Field

Drift current density, (J) is defined as the drift current per unit area of cross section of the conductor

$$J = \frac{I}{A}$$

Electric field (E) is the potential drop per unit length of the conductor

$$E = -\frac{dV}{dx} = \frac{V}{L}$$

Resistivity (ρ) is the resistance offered by a conductor of unit length and unit cross sectional area

$$\rho = R \frac{A}{L}$$

Conductivity (σ) is the reciprocal of resistivity.

$$\sigma = \frac{1}{\rho} = \frac{L}{R A}$$

2 X 4 gives

$$\sigma E = \frac{L}{R A} \frac{V}{L} = \frac{V}{R} \frac{1}{A} = \frac{I}{A} = J$$

$$J = \sigma E$$
 5



Drift Velocity and Mobility

Drift velocity (v) is defined as net displacement in electron position per unit time under the influence of electric field.

Mobility (μ) of electrons is defined as average drift velocity acquired by the electrons per unit electric field.

$$\mu = \frac{v}{E}$$



Unit of mobility

Mobility (μ) of electrons is defined as average drift velocity acquired by the electrons per unit electric field.

$$\mu = \frac{v}{E}$$


Unit of mobility =
$$\frac{m/s}{V/m} = \frac{m^2}{V-s}$$



Conductivity

Conductivity and Mobility

Drift Current Density is given by -



Let v is drift velocity of electrons

 \therefore length traversed by the electrons in unit time = v

∴ Volume swept by electrons in unit time = v A

If 'n' is number of electrons per unit volume, number of electrons in volume vA = nvA

If e is charge on electron, charge flowing per unit time is -

current I = n e v A

∴ Current Density,

$$J = \frac{I}{A} = \frac{n e v A}{A} = n e v$$

From (

1

and 2

Coductivity,
$$\sigma = \frac{J}{E} = \frac{n e v}{E} = n e \mu$$



Conductivity of Semiconductors

Conductivity of semiconductor is given by -

$$\sigma = \sigma_{\rm e} + \sigma_{\rm h}$$

$$\sigma = n e \mu_e + p e \mu_h$$

Where, n is electron concentration in conduction band

p is hole concentration in valence band

e is charge on electron

 μ_e is mobility of electrons

 μ_h is mobility of holes



Conductivity of Intrinsic Semiconductors

Conductivity of semiconductor is given by - $\sigma = n e \mu_e + p e \mu_h$

$$\sigma = n e \mu_e + p e \mu_h$$

For intrinsic semiconductor, $n = p = n_i$

.: Conductivity of intrinsic semiconductors is given by -

$$: \sigma_i = n_i e \mu_e + n_i e \mu_h$$

$$: \sigma_i = n_i e (\mu_e + \mu_h)$$



Module 3: Semiconductor Physics

Conductivity of Extrinsic Semiconductors

Conductivity of semiconductor is given by -

$$: \sigma = n e \mu_e + p e \mu_h$$

For n-type semiconductor, $\mathbf{n} \gg \mathbf{p}$

∴ Conductivity of n-type semiconductors is given by -

$$\sigma = n e \mu_e = N_d e \mu_e$$

N_d is donor concentration

For p-type semiconductor, $p \gg n$

∴ Conductivity of p-type semiconductors is given by -

$$\sigma = p e \mu_h = N_a e \mu_h$$

N_a is acceptor concentration



Conductivity of semiconductors

Two types of carrier

- Free electrons of mobility μ_n
- Holes of mobility μ_p

These particles move in opposite direction in an electric field *E*, but since they are of opposite sign, the current of each is in the same direction.

$$J = (n\mu_n + p\mu_p)qE = \sigma E$$

n = Free electron concentration

p = Hole concentration

 σ = Conductivity

Hence,

$$\sigma = (n\mu_n + p\mu_p)q$$

Conductivity

For pure semiconductors, $n=p=n_i=$ intrinsic concentration.

Mobility in Semiconductors

If an electric field *E* is applied to a semi-conductor, the rate at which the current carrier gains momentum from the field is *qE*, by Newton's second law of motion, where *q* is the charge of the carrier.

The rate at which the carrier losses the momentum through scattering is usually is given by

$$\frac{m^*v}{\tau_{\tau}}$$

where m^* is the effective mass of the carrier and v is its drift velocity. The quantity τ has the dimension of time and is referred to as the Momentum Relaxation Time.

It has the significance that when the field is removed, the momentum reduces to 1/e of its initial value in time .



Mobility in Semiconductors

• In the steady state, the rate of gain of momentum from the electric field equals to the loss of momentum through scattering. m*v

$$qE = \frac{m^*v}{\tau}$$

The mobility is thus expressed by,

$$\mu = \frac{v}{E} = \frac{q\tau}{m*}$$

• Usually au is a function of the carrier energy and mobility is correctly in the form $\mu = \frac{q\langle \tau \rangle}{m^*}$

- Where < τ > represents the average value of τ involving all the carriers.
- In SI units, q is in Coulomb, \mathcal{T} is in second, m^* is in kg, hence μ comes out in $m^2/(V.s)$.



Numericals

Find resistivity of Ge at 300 °K. Given density of carriers is 2.5 x 10¹⁹ / m³. Mobility of electrons is 0.39 m²/V-sec, mobility of holes = 0.19 m²/V-sec.

The resistivity of intrinsic InSb at room temperature is 2 x 10⁻⁴ ohm-cm. If the mobility of electron is 6 m²/V-s and mobility of hole is 0.2 m²/V-s, calculate its intrinsic carrier density.

Calculate the number of donor atoms which must be added to an intrinsic semiconductor to obtain the resistivity as 10-6 ohm-cm. Use mobility of electron = 1000 cm²/V-sec.

Find resistivity of Copper assuming that each atom contributes one free electron for conduction. Given density of Cu = 8.96 gm / cm³, atomic weight = 63.5,

Avogadro's Number = 6.023×10^{23} / gm-mol, Mobility of electron = $43.3 \text{ cm}^2/\text{V-sec}$.