



- Power
  Ground
  Input / Output pin
  Analog capable pin
- LCD display pins

  PWM capable pin

  Pin is not used in MobiFlight
- Analog pins A5 and A7 do not work for digital I/O like button input or led output on Nano due to hardware limitation.